



C57W40N3GB  
C57W40S3GB  
Microwave



<b>Important safety information</b> .....	<b>2</b>	<b>Electronic clock</b> .....	<b>8</b>
Causes of damage .....	4	Clock display .....	8
<b>Energy and environment tips</b> .....	<b>4</b>	Timer .....	9
Saving energy .....	4	Cooking time .....	9
Environmentally-friendly disposal .....	5	Setting the clock .....	9
<b>Your new appliance</b> .....	<b>5</b>	<b>Changing the basic settings</b> .....	<b>10</b>
Control panel .....	5	Basic settings .....	10
Operating controls .....	5	<b>Care and cleaning</b> .....	<b>10</b>
Shelf heights .....	5	Cleaning agents .....	10
Accessories .....	5	<b>Malfunction table</b> .....	<b>11</b>
Cooking compartment .....	6	Malfunction table .....	11
<b>Switching the appliance on and off</b> .....	<b>6</b>	Replacing the cooking compartment bulb .....	12
Switching on .....	6	<b>After-sales service</b> .....	<b>12</b>
Switching off .....	6	E number and FD number .....	12
<b>Before using the appliance for the first time</b> .....	<b>6</b>	Technical data .....	12
Setting the clock .....	6	<b>Automatic programmes</b> .....	<b>13</b>
Cleaning the accessories .....	6	Setting a programme .....	13
<b>The microwave</b> .....	<b>6</b>	Defrosting and cooking with the automatic programmes .....	13
Notes regarding ovenware .....	6	<b>Tested for you in our cooking studio</b> .....	<b>14</b>
Microwave power settings .....	7	Defrosting, heating up and cooking with the microwave .....	15
Setting the microwave .....	7	Microwave tips .....	17
<b>1, 2, 3 series of operations</b> .....	<b>7</b>	<b>Test dishes in accordance with EN 60705</b> .....	<b>18</b>
Ovenware .....	7	Solo microwave cooking .....	18
Setting a series of operations .....	7	Solo microwave defrosting .....	18
<b>Memory</b> .....	<b>8</b>		
Saving settings in the memory .....	8		
Starting the memory function .....	8		

Additional information on products, accessories, replacement parts and services can be found at [www.neff-international.com](http://www.neff-international.com) and in the online shop [www.neff-eshop.com](http://www.neff-eshop.com)

## **Important safety information**

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The

appliance must be supervised during operation. Only use this appliance indoors.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 8 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment correctly. See "*Description of accessories*" in the instruction manual.

### **Risk of fire!**

- Combustible items stored in the cooking compartment may catch fire. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug it from the mains or switch off the circuit breaker in the fuse box.
- Using the appliance for anything other than its intended purpose is dangerous and may cause damage. The following is not permitted: drying out food or clothing, heating slippers, grain or cereal pillows, sponges, damp cleaning cloths or similar. For example, heated slippers and grain or cereal pillows may catch fire, even several hours after they have been heated. The appliance must only be used for the preparation of food and drinks.
- Food may catch fire. Never heat food in heat-retaining packages. Do not leave food heating unattended in containers made of plastic, paper or other combustible materials. Do not select a microwave power or time setting that is higher than necessary. Follow the information provided in this instruction manual. Never use the microwave to dry food. Never defrost or heat food with a low water content, e.g. bread, at too high a microwave power or for too long.
- Cooking oil may catch fire. Never use the microwave to heat cooking oil on its own.

### **Risk of explosion!**

Liquids and other food may explode when in containers that have been tightly sealed. Never heat liquids or other food in containers that have been tightly sealed.

### **Risk of serious damage to health!**

- The surface of the appliance may become damaged if it is not cleaned properly. Microwave energy may escape. Clean the appliance on a regular basis, and remove any food residue immediately. Always keep the cooking compartment, door seal, door and door stop clean; see also section *Care and cleaning*.
- Microwave energy may escape if the cooking compartment door or the door

seal is damaged. Never use the appliance if the cooking compartment door or the door seal is damaged. Contact the after-sales service.

- Microwave energy will escape from appliances that do not have any casing. Never remove the casing. For any maintenance or repair work, contact the after-sales service.

### **Risk of electric shock!**

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Penetrating moisture may cause an electric shock. Do not use any high-pressure cleaners or steam cleaners.
- When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- The appliance is a high-voltage appliance. Never remove the casing.

### **Risk of burns!**

- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.
- Foods with peel or skin may burst or explode during, or even after, heating. Never cook eggs in their shells or reheat

hard-boiled eggs. Never cook shellfish or crustaceans. Always prick the yolk when baking or poaching eggs. The skin of foods that have a peel or skin, such as apples, tomatoes, potatoes and sausages, may burst. Before heating, prick the peel or skin.

- Heat is not distributed evenly through baby food. Never heat baby food in closed containers. Always remove the lid or teat. Stir or shake well after the food has been heated. Check the temperature of the food before it is given to the child.
- Heated food gives off heat. The ovenware may become hot. Always use oven gloves to remove ovenware or accessories from the cooking compartment.
- Airtight packaging may burst when food is heated. Always observe the instructions on the packaging. Always use oven gloves to remove dishes from the cooking compartment.

### **Risk of scalding!**

- When you open the appliance door, hot steam may escape. Open the appliance

### **Causes of damage**

#### **Caution!**

- Creation of sparks: Metal - e.g. a spoon in a glass - must be kept at least 2 cm from the oven walls and the inside of the door. Sparks could irreparably damage the glass on the inside of the door.
- Water in the cooking compartment when the cooking compartment is hot: Never pour water into the cooking compartment when the cooking compartment is hot. Steam will be created. The temperature change can cause damage to the ceramic floor panel.
- Foil containers: Do not use foil containers in the appliance. They damage the appliance by producing sparks.
- Moist food: Do not store moist food in the closed cooking compartment for long periods. This will damage the enamel. Do not use the appliance to store food. This can lead to corrosion.
- Cooling with the appliance door open: Only leave the cooking compartment to cool with the door closed. Do not trap anything in the appliance door. Even if the door is only slightly ajar, the fronts of adjacent units may be damaged over time.

door with care. Keep children at a safe distance.

- Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.
- There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches boiling temperature without the usual steam bubbles rising to the surface. Even if the container only vibrates a little, the hot liquid may suddenly boil over and spatter. When heating, always place a spoon in the container. This will prevent delayed boiling.

### **Risk of injury!**

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- Unsuitable ovenware may crack. Porcelain or ceramic ovenware can have small perforations in the handles or lids. These perforations conceal a cavity below. Any moisture that penetrates this cavity could cause the ovenware to crack. Only use microwave-safe ovenware.

- Heavily soiled seal: If the seal is very dirty, the appliance door will no longer close properly during operation. The fronts of adjacent units could be damaged. Always keep the seal clean.
- Using the appliance door for standing on or placing objects on: Do not stand or place anything on the open appliance door. Do not place ovenware or accessories on the appliance door.
- Transporting the appliance: Do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.
- Operating the microwave without food: Operating the appliance without food in the cooking compartment may lead to overloading. Never switch on the appliance unless there is food in the cooking compartment. An exception to this rule is a short crockery test (see the section "Microwave, suitable crockery").
- Microwave popcorn: Never set the microwave power too high. Use a power setting no higher than 600 watts. Always place the popcorn bag on a glass plate. The disc may jump if overloaded.

---

## **Energy and environment tips**

Here you can find tips on how to save energy when baking and roasting and how to dispose of your appliance properly.

### **Saving energy**

Only preheat the oven if this is specified in the recipe or in the operating instruction tables.

Use dark, black lacquered or enamelled baking tins. They absorb the heat particularly well.

Open the appliance door as little as possible during cooking, baking or roasting.

It is best to bake several cakes one after the other. The cooking compartment is still warm. This may reduce the baking time for the second cake.

For longer cooking times, you can switch the oven off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

## Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.


## Your new appliance

This section provides information regarding

- the control panel
- the operating controls

- the shelf heights
- the accessories

### Control panel



### Operating controls

Operating controls	Use
90	Selects 90 watt microwave power
180	Selects 180 watt microwave power
360	Selects 360 watt microwave power
600	Selects 600 watt microwave power
1000	Selects 1000 watt microwave power
1 2 3	Selects a series of operations
◀ ▶	Clock function buttons Selects the desired clock function
Rotary selector	Makes settings within a clock function.
Main switch	Switches your appliance on and off.
P/kg	Selects automatic programmes
Programme selector	Sets the programme or weight.
M	Selects memory
Start	Starts operation
Stop	Pausing operation

### Microwave power settings and operating controls

When you press a button, the relevant item lights up on the display.

### Pop-out selectors

Rotary and programme selectors can be pushed in and popped out. Press the selector to push it in or pop it out.

### Shelf heights


The accessories can be inserted into the cooking compartment at 4 different levels.

**Note:** Ovenware can also be placed on the oven floor (level 0).



### Accessories

The following accessories are supplied with your appliance:



### Wire rack

For ovenware, cake tins, grilled food and frozen meals. You can pull the wire rack two thirds of the way out without it tipping. This allows meals to be removed more easily.

## Cooking compartment

Your appliance has a cooling fan.

## Cooling fan

The appliance is equipped with a cooling fan. The fan may run on even if the oven has been switched off.


### Notes




- The cooking compartment remains cold during microwave operation. The cooling fan will still switch on. The fan may run on even when microwave operation has ended.
- Condensation may appear on the door window, interior walls and floor. This is normal and does not adversely affect microwave operation. Wipe away the condensation after cooking.

# Switching the appliance on and off

Switch your microwave oven on and off using the main switch.


## Switching on

1. Press the main switch.  
The appliance switches on. The  symbol lights up.
2. Select a function:
  - 90, 180, 360, 600 or 1000 W button for a microwave power output

-  button = series of operations
-  button = automatic programmes
-  button = memory programme

Please refer to the individual sections for information on how to make the settings.

## Switching off



Press the main switch. The  symbol goes out. The appliance switches off, and the clock appears again.


# Before using the appliance for the first time

In this section, you can read about

- How to set the clock after connecting up your appliance
- How to clean your appliance before using it for the first time

## Setting the clock




 and the  symbols light up in the clock display.

1. Turn the rotary selector to set the time of day.
2. Press the  clock function button.



Your setting is applied.

## Changing the clock

To subsequently change the clock time, press the  clock function button repeatedly until the  and  symbols light up. Use the rotary selector to change the time of day.

**Note:** In order to reduce the energy consumption of your appliance in standby, you can switch off the clock display. Refer to the section entitled *Electronic clock*.

## Cleaning the accessories

Before you use the accessories for the first time, clean them thoroughly with hot soapy water and a soft dish cloth.

# The microwave

Microwaves are converted to heat in foodstuffs. You will find information about ovenware and how to set the microwave.

**Note:** In the *Tested for you in our cooking studio* section, you will find examples for defrosting, heating and cooking with the microwave oven.

## Notes regarding ovenware

### Suitable ovenware

Suitable dishes are heat-resistant ovenware made of glass, glass ceramic, porcelain, ceramic or heat-resistant plastic. These materials allow microwaves to pass through.

You can also use serving dishes. This saves you having to transfer food from one dish to another. You should only use

ovenware with decorative gold or silver trim if the manufacturer guarantees that they are suitable for use in microwaves.

### Unsuitable ovenware

Metal ovenware is unsuitable. Metal does not allow microwaves to pass through. Food in covered metal containers will remain cold.

### Caution!

Creation of sparks: metal – e.g. a spoon in a glass – must be kept at least 2 cm from the oven walls and the inside of the door. Sparks could destroy the glass on the inside of the door.

### Ovenware test

Do not switch on the microwave unless there is food inside. The following ovenware test is the only exception to this rule.

Perform the following test if you are unsure whether your ovenware is suitable for use in the microwave:

1. Heat the empty ovenware at maximum power for ½ to 1 minute.

2. Check the temperature occasionally during that time.

The ovenware should still be cold or warm to the touch.

The ovenware is unsuitable if it becomes hot or sparks are generated.

## Microwave power settings

Use the button to set the desired microwave power.

90 W	for defrosting delicate foods
180 W	for defrosting and continued cooking
360 W	for cooking meat and heating delicate foods
600 W	for heating and cooking food
1000 W	for heating liquids

### Notes

- When you press a button, the selected power lights up.
- The microwave power can be set to 1000 watts for a maximum of 30 minutes. With all other power settings a maximum cooking time of 1 hour 30 minutes is possible.

## 1, 2, 3 series of operations


You can use the series of operations function to set up to three different consecutive settings and then start.

In this section, you can find out how to set a series of operations.


### Ovenware

Always use microwave-safe, heat-resistant ovenware.

### Setting a series of operations

Requirement: switch on the main switch. Your appliance is ready for operation and the  button lights up

1. Press the  button.

The  for the first operation in the series lights up.


2. Set the first microwave power setting and cooking time.

3. Press the  button again.

The  for the second operation in the series lights up.

4. Set the second microwave power setting and cooking time.

5. Press the  button again.

The  lights up for the third operation in the series.

6. Set the third microwave power setting and cooking time.

## Setting the microwave

Example: microwave power 600 W, cooking time 10 minutes.


1. Press the main switch.

The appliance is ready for operation and the  symbol lights up.

2. Press the button for the microwave power setting you require.


The selected power setting lights up and a suggested cooking time is displayed.

3. Set the cooking time using the rotary selector.


4. Press the  button.

The operation starts. The cooking time starts counting down.

### The cooking time has elapsed.

A signal sounds. The microwave operation has finished. You can stop the audible signal by pressing the  button. Switch off with the main switch or make new settings.

### Opening the appliance door during operation

Operation is suspended. The cooling fan may continue to run. After closing the door, press the  button. Operation will then continue.


### Changing the cooking time

Change the cooking time using the rotary selector.

### Changing the microwave power setting

Press the button for the new microwave power setting. Use the rotary selector to set the cooking time and restart.

### Cancelling operation

Press and hold the  button for a few seconds and switch off the main switch


### Notes

- When you make settings, the highest microwave power setting always appears as the default.
- If you open the appliance door during cooking, the fan may continue running.


7. Press the  button.

The operation starts. In the clock display, the total cooking time is displayed and the currently activated operation is lit.


### The cooking time has elapsed

A signal sounds. The series of operations is finished. To stop the signal, press the  button. Switch off or reset the appliance.

### Opening the appliance door during operation

Operation is suspended. The cooling fan may continue to run. After closing the door, press the  button. Operation will then continue.



### Changing the setting

Changes can only be made before operation begins. Press the  button to go to the desired setting, and make the changes.



### Cancelling operation

Press the illuminated button for the set microwave power setting. Make new settings or switch off the appliance.

## Pausing operation

Press the  button to pause operation. Press the  button to continue the operation.

## Cancelling the setting

Press and hold the  button for a few seconds and switch off the main switch. Or press the  button twice and switch off the main switch. The setting is cancelled.

# Memory

The memory gives you the option of saving your own settings and calling them up again. You have two memory locations available, namely "M1" and "M2". The memory is useful if you prepare one meal particularly frequently.


In this section, you can read about

- how to save the memory
- how to start the memory

## Saving settings in the memory

Example: use the "M1" memory location.

### 1. Press the main switch.

The  symbol lights up. Your appliance is ready for operation.

### 2. Press the button for the microwave power setting you require.

The power setting lights up and a suggested cooking time is displayed.

### 3. Set the cooking time using the rotary selector.

### 4. Press and hold the button for a few seconds.

An audible signal sounds and "M1" appears on the clock display for the first memory location.

You can select "M1" or "M2" using the programme selector.

### 5. Press and hold the button for a few seconds.

A signal sounds. The setting is saved and can be started at any time.

## Saving another setting

Enter and save the new setting. The old settings are overwritten.


**Note:** The programmes which have been set remain stored even if there is a power cut.

**Note:** You can also store the series of operations option.

## Starting the memory function

You can start cooking at any time using the settings saved for your meal.


### 1. Press the main switch.

The  symbol lights up. Your appliance is ready for operation.

### 2. Press and hold the button for a few seconds.

### 3. Select "M1" or "M2" with the programme selector.



### 4. Press the button.

The memory function starts. The cooking time  starts counting down.



**Note:** Once operation has started, you can no longer change the memory location.

**Note:** Saved settings are retained even after a power cut.



## The cooking time has elapsed.

A signal sounds. The memory function has finished. You can stop the audible signal by pressing the  button. Press the  button and switch off the appliance at the main switch or make new settings.

## Pausing

Press the  button or open the appliance door. Operation is suspended. After closing the door, press the  button again. Operation will then continue.

## Cancelling the setting

Press the  button twice or open the appliance door and press the  button once.


# Electronic clock

Your appliance has various clock functions.

In this section, the following are explained:

- The clock display
- how to set the timer
- how your appliance is automatically switched off (cooking time)
- how to set or change the clock.

## Clock display



### Clock function

### Use

 Timer

You can use the timer as an egg timer or a kitchen timer. The appliance does not switch on or off automatically



Clock function	Use
I→I Cooking time	The appliance switches off automatically after a set cooking time I→I (e.g. 1:30 hours)
☺ Clock	Setting the clock

### Notes

- Between the times 22:00 and 5:59 the clock display is dimmed if you do not make any settings in that period or no clock function is activated.
- When the Timer ⏰ and Cooking time I→I clock functions are in use, a signal sounds after the settings have elapsed and the corresponding symbol flashes. To stop the audible signal before it finishes, press the clock function ◀▶ button
- If you wish to cancel a setting, turn the set time back to 0:00 and switch the appliance off.
- The setting can be corrected using the rotary selector if necessary.

### Switching the clock display on and off

1. Press and hold the clock function button ◀▶ for a few seconds.

The clock display is switched off. If a clock function is active, the associated symbol remains illuminated.

2. Press and hold the clock function button ◀▶ for a few seconds.

The clock display switches on.

### Timer

1. Press the ◀▶ clock function button repeatedly until the ◀▶ and ⏰ symbols light up.
2. Set the duration using the rotary selector (e.g. 5:00 minutes). The setting is applied automatically. Then the clock is displayed again and the minute minder starts counting down.




### Cooking time

Automatic switch-off after a cooking time setting has elapsed.

1. Set a microwave power setting.
2. Press the clock function button repeatedly until the ◀▶ and I→I symbols light up.

3. Set the cooking time using the rotary selector (e.g. 1:30 hours). The setting is applied automatically.



4. Press the Start button.

The set cooking time counts down.

### The cooking time has elapsed

A signal sounds. The appliance stops heating. The display shows 0:00. You can cancel the audible signal before it has finished by pressing the ◀▶ button.

### Changing the cooking time

Change the cooking time using the rotary selector.

### Cancelling the cooking time

Using the rotary selector, turn the cooking time back to 0:00. The change is applied after a few seconds. The cooking time has been cancelled.

### Checking time settings


If several time-setting options have been set, the corresponding symbols appear in the display. The ◀▶ symbol is in the foreground in front of the time function symbol.

To check the kitchen timer ⏰, cooking time I→I or clock time ☺, press the ◀▶ button repeatedly until the ◀▶ symbol is in front of the appropriate time function. The relevant value will appear for a few seconds in the clock display.

### Setting the clock

You can only change the clock when no other clock function is active.

1. Press the clock function ◀▶ button repeatedly until the ◀▶ and ☺ symbols light up.
2. Turn the rotary selector to set the time of day.




3. Press the ◀▶ clock function button.

Your setting is applied.

### Changing the clock

e.g. from British Summer Time to Greenwich Mean Time. Make the settings as described in steps 1 and 2.

## Checking, correcting or deleting settings

1. To check your settings, press the  clock function button repeatedly until the corresponding symbol lights up.

2. If necessary, you can correct your setting using the rotary selector.



3. If you wish to cancel your setting, turn the rotary selector anti-clockwise to the original value.


## Changing the basic settings



Your appliance has various basic settings which you can change at any time.

### Basic settings

In the table, you will find all the basic settings and options for changing them.

Basic setting	Options	Explanation
 Audible signal duration: 1 = short = 10 seconds	Audible signal duration: 2 = medium = 2 minutes 3 = long = 5 minutes	Signal after the cooking time has elapsed
 Button tone: 1 = on	Button tone: 2 = off	Confirmation tone when a button is pressed

Press the main switch. The appliance is ready for operation and the  symbol lights up.

- Press and hold the  button for a few seconds.  
The first basic setting appears on the clock display.
- Press the  button repeatedly until the required basic setting is shown.

3. Make the desired setting using the programme selector.

4. Finally, press and hold the  button for a few seconds.

All settings are applied.

You can change the settings at any time.

## Care and cleaning

With careful care and cleaning your microwave oven will retain its looks and remain good order. We will explain here how you should care for and clean your appliance correctly.

### Risk of short circuit!

Never use high-pressure cleaners or steam cleaners to clean the oven.

### Risk of burns!

Never clean the appliance immediately after switching off. Let the appliance cool down.

### Notes

- Slight differences in colour on the front of the appliance are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panel which look like streaks, are caused by reflections made by the oven light.
- Enamel is baked on at very high temperatures. This can cause some slight colour variations. This is normal and does not affect their function. The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough. This will not impair the anti-corrosion protection.
- Unpleasant odours, e.g. after fish has been prepared, can be removed very easily. Add a few drops of lemon juice to a cup of water. Place a spoon into the container as well, to prevent delayed boiling. Heat the water for 1 to 2 minutes at maximum microwave power.

### Cleaning agents

To ensure that the different surfaces are not damaged by using the wrong cleaning agent, observe the information in the table. Do not use:

- any caustic or abrasive cleaning agents,
- metal or glass scrapers to clean the glass in the appliance door,

- metal or glass scrapers to clean the door seal,
- hard scouring pads and sponges,
- cleaning agents with high concentrations of alcohol.

Rinse out new sponge cloths thoroughly before use.

For easier cleaning, you can switch on the oven light. Open the appliance door to do so.

Area	Cleaning agents
Appliance front	Hot soapy water: Clean using a dish cloth and then dry with a soft cloth. Do not use glass cleaners or metal or glass scrapers for cleaning.
Stainless steel	Hot soapy water: Clean using a dish cloth and then dry with a soft cloth. Remove traces of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such residues. Special stainless steel cleaning agents can be obtained from the after-sales service or from specialist retailers.
Cooking compartment made of stainless steel	Hot soapy water or a vinegar solution: Clean using a dish cloth and then dry with a soft cloth. If the oven is very dirty: use oven cleaner, but only when cooking compartment is cold. It is best to use a stainless-steel sponge. Do not use oven spray or other aggressive oven cleaners or abrasive materials. Scouring pads, rough sponges and pan cleaners are also unsuitable. These agents scratch the surface. Allow the interior surfaces to dry thoroughly.

Area	Cleaning agents
Door panels	Glass cleaner: Clean with a dish cloth. Do not use a glass scraper.
Glass cover for the cooking compartment light	Hot soapy water: Clean with a dish cloth.

Area	Cleaning agents
Door seal Do not remove.	Hot soapy water: Clean with a dish cloth; do not scrub. Do not use a metal or glass scraper for cleaning.
Accessories	Hot soapy water: Soak and clean with a dish cloth or a brush.

## Malfunction table







Malfunctions often have simple explanations. Please refer to the malfunction table before calling the after-sales service.

If a meal does not turn out exactly as you wanted, refer to the *Tested for you in our cooking studio* section, where you will find plenty of cooking tips and tricks.

### Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers.

## Malfunction table

Problem	Possible cause	Remedy/information
The appliance does not work	Faulty circuit breaker	Look in the fuse box to make sure that the circuit breaker for the appliance is OK.
	Plug not plugged in	Plug the plug in
	Power cut	Check whether the kitchen light is working.
	Incorrect operation	Switch off the circuit breaker in the fuse box. Reconnect it after approx. 10 seconds.
Three zeros are flashing in the display.	Power cut	Reset the clock.
The appliance is not in operation. A cooking time appears in the display.	The  button was not pressed after the setting had been made.	Press the  button or switch the appliance off.
The microwave does not switch on.	The door was not fully closed.	Check whether food remains or foreign material is trapped in the door. Make sure that the sealing surfaces are clean. Check whether the door seal is twisted.
	The  button has not been pressed.	Press the  button.
It takes longer than before for the food to heat up.	The microwave power setting is too low.	Select a higher power setting.
	A larger amount than usual has been placed in the appliance.	Double the amount = almost double the time
	The food was colder than usual.	Stir or turn the food during cooking
A signal sounds. The two dots in the display are flashing.	The appliance is in demo mode.	<ol style="list-style-type: none"> <li>1. Press the  button.</li> <li>2. Press and hold the  button for three seconds.</li> </ol> Demo mode is deactivated.

## Error messages

You can take remedial action yourself for some error messages.

Error message	Possible cause	Remedy/Note
Error message "Er1", "Er4", "Er18" or "E305" appears in the display.	Technical malfunction.	Call the after-sales service.
Error message "Er11" appears in the display. "Button jammed"	The buttons are dirty or the mechanism has jammed.	Press all the buttons several times. Clean the buttons with a dry cloth. Open and close the appliance door. If this does not help, consult the after-sales service.

## Replacing the cooking compartment bulb

You can replace the cooking compartment bulb. Heat-resistant 25 watt, 240 V halogen bulbs can be obtained from the after-sales service or from a specialist retailer.

### **⚠ Risk of electric shock!**




Never replace the oven light when the appliance is switched on. Pull out the mains plug or switch off the appliance at the circuit breaker in the fuse box.

**Note:** Always remove the new halogen bulb from the packaging using a dry cloth. This increases the service life of the bulb.


### Method

**Note:** You must remove the whole appliance in order to replace the cooking compartment light. Follow the installation instructions.

1. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
2. Open the appliance door.  
Undo the securing screws on the right and left-hand side of the oven. Follow the installation instructions.
3. Carefully lift out the appliance.
4. Undo the screw from the light cover on the outer left-hand side wall and remove the cover. (Fig. A) Pull out the halogen light. (Fig. B).



5. Insert the new halogen bulb (Fig. C)



6. Screw the lamp cover in place.  
Reassemble the appliance in the reverse order.
7. Switch the circuit breaker in the fuse box back on or plug in the mains plug.

### Replacing the glass cover

If the glass cover in the oven is damaged, it must be replaced. You can obtain covers from the after-sales service. Please supply your appliance's E number and FD number.

## After-sales service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find the right solution in order to avoid unnecessary visits from a service technician.

### E number and FD number

When calling us, please give the product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate bearing these numbers can be found in the oven. You can make a note of the number of your appliance and the telephone number of the after-sales service in the space below to save time should it be required.

E no. \_\_\_\_\_ FD no. \_\_\_\_\_

After-sales service ☎

Please note that there will be a fee for a visit by a service technician in the event of a malfunction, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

### To book an engineer visit and product advice

- GB** 0844 8928989  
Calls from a BT landline will be charged at up to 3 pence per minute. A call set-up fee of up to 6 pence may apply.
- IE** 01450 2655  
0.03 € per minute at peak. Off peak 0.0088 € per minute.

Trust the expertise of the manufacturer, and rest assured that the repair will be carried out by trained service technicians using original spare parts for your domestic appliance.

This appliance corresponds to the standards EN 55011 and CISPR 11. It is a Group 2, Class B product.

Group 2 means that microwaves are produced for the purpose of heating food. Class B states that the appliance is suitable for private households.

### Technical data

Power supply	220-240 V, 50 Hz
Maximum total connected load	1180 W
Microwave power setting	1000 W (IEC 60705)
Microwave frequency	2450 MHz
Fuse	min. 10 A


Dimensions (HxWxD)	
- appliance	45.4 x 59.5 x 56.3 cm
- cooking compartment	224.2 x 43 x 34.5 cm

VDE approved	yes
CE mark	yes

## Automatic programmes

The automatic programmes enable you to prepare food very easily. You select the programme and enter the weight of your food. The automatic programme makes the optimum setting. You can choose from 9 programmes.

### Setting a programme


Once you have selected a programme, make settings as follows. Switch on the main switch. The  symbol lights up.

Example in diagram:


Programme 2 with a weight of 1 kilogramme.


1. Press the  button.

The first programme number appears on the clock display.




2. Select the desired programme using the programme selector.




3. Press the  button again.


A default weight is shown in the clock display.




4. Set the weight using the programme selector.



5. Press the  button.

The programme starts. The cooking time starts counting down and the  symbol appears.

### The programme has finished

A signal sounds. The appliance stops heating. 0:00 appears in the display. Press the  button and switch off the main switch.


### Changing the programme

Once you have started the programme, the programme number and weight cannot be changed.

### Changing the cooking time

With automatic programmes, you cannot change the cooking time.

### Cancelling the programme

Press and hold the  button for a few seconds and switch off the main switch. The appliance is switched off.

## Defrosting and cooking with the automatic programmes

### Notes

- Take the food out of its packaging and weigh it. If it is not possible to enter the exact weight, you should round it up or down.
- Always use microwaveable ovenware, e.g. made of glass, ceramic or the universal pan. Observe the accessories tips in the programme table.
- Place the food in the cold cooking compartment.
- A table of suitable types of food with appropriate weight ranges and the accessories required can be found in the section after the tips.
- It is not possible to set a weight outside the weight range.
- With many dishes, a signal sounds after a certain time. Turn or stir the food.

### Defrosting

#### Notes

- If possible, freeze and store food flat and in portions at -18 °C.

- Put the frozen food on shallow tableware, e.g. a glass or porcelain plate.
- Cover thin and protruding parts with small pieces of aluminium foil. This prevents these parts from cooking prematurely. Ensure that the aluminium foil does not touch the walls of the cooking compartment.
- After defrosting, allow the food to defrost for a further 10 to 90 minutes so that it acquires an even temperature.
- Liquid will be produced when defrosting meat, poultry or fish. Drain off this liquid when you turn the food. Under no circumstances should it be used for other purposes or be allowed to come into contact with other foods.
- Bread should only be defrosted in the required amounts, as it quickly becomes stale.
- After turning, remove any minced meat that has already defrosted.
- Whole poultry should be placed in the dish breast-side down and poultry portions skin-side down. Cover legs and wings with small pieces of aluminium foil.

### Boiled potatoes

**Note:** Cut into equal sized pieces. Add a little salt and a tablespoon of water for every 100 g of potatoes.

### Vegetables

#### Notes

- Fresh vegetables: cut into pieces of equal size. Add one tablespoon of water for every 100 g vegetables.
- Frozen vegetables: this programme is only suitable for blanched, not pre-cooked vegetables. It is not suitable for frozen vegetables in cream sauce. Add 1 to 3 tablespoons of water. Do not add water to spinach or red cabbage.

#### Rice

#### Notes

- Do not use boil-in-the-bag rice.
- Add two to two and a half times the amount of water to the rice.

#### Fish

**Note:** Fish fillet, fresh: add 1 to 3 tablespoons of water or lemon juice.

#### Resting times

Some dishes need to rest in the oven after the programme has ended.

Dish	Resting time
Vegetables	approx. 5 minutes
Boiled potatoes	approx. 5 minutes. First pour off the remaining water.
Rice	5 to 10 minutes
Meat loaf	10 minutes

Programme no.	Suitable food	Weight range in kg	Cookware/accessories	
<b>Defrost</b>				
1	Loaf of bread*	Wheat bread, mixed wheat bread, wholemeal bread	0.20 - 1.50	Shallow ovenware without a lid
2	Minced meat*	Minced beef, lamb, or pork	0.20 - 1.00	Shallow ovenware without a lid
3	Poultry portions*	Chicken thigh, half chicken	0.20 - 1.20	Shallow ovenware without a lid
4	Fish fillet*	Fillet of pike, cod, ocean perch, pollock, pike-perch	0.20 - 1.00	Shallow ovenware without a lid
* Observe the signals given when it is time to turn the food.				
<b>Cooking</b>				
5	Vegetables, fresh*	Cauliflower, broccoli, carrots, kohlrabi, leeks, peppers, courgettes	0.20 - 1.00	Ovenware with lid
6	Frozen vegetables*	Cauliflower, broccoli, carrots, kohlrabi, red cabbage, spinach	0.20 - 1.00	Ovenware with lid
7	Boiled potatoes*	Waxy potatoes, predominantly waxy potatoes or floury potatoes	0.20 - 1.00	Ovenware with lid
8	Rice, long grain rice*		0.10 - 0.50	Deep ovenware with lid
9	Steam fresh fish fillet*	Fillet of pike, cod, ocean perch, pollock, pike-perch	0.20 - 1.00	Ovenware with lid

\* Observe the turning and stirring signals.

## Tested for you in our cooking studio.

Here you will find a selection of recipes and the ideal settings for them. We show you which microwave power setting is best for your dish and there are tips about cookware and preparation.

#### Notes

- The values in the table always apply to food placed into the cooking compartment when it is cold and empty. Only

preheat the appliance if the table specifies that you should do so. Before using the appliance, remove all accessories from the cooking compartment that you will not be using.

- The times specified in the tables are only guidelines. They depend on the quality and consistency of the food.

- Use the accessories supplied. Additional accessories may be obtained from specialist retailers or from the after-sales service.
- Always use an oven cloth or oven gloves when taking accessories or cookware out of the cooking compartment.

## Defrosting, heating up and cooking with the microwave

The following tables provide you with numerous options and settings for the microwave.

The times specified in the tables are only guidelines. They may vary according to the ovenware used, the quality, temperature and consistency of the food.

Time ranges are often specified in the tables. Set the shortest time first and then extend the time if necessary.

It may be that you have different quantities from those specified in the tables. A rule of thumb can be applied:

Double the amount - almost twice the cooking time,  
Half the amount - half the cooking time.

Stir or turn the food several times during the heating time.  
Check the temperature.

### Defrosting

#### Notes

- Place the frozen food in an open container on the wire rack.
- Delicate parts such as the legs and wings of chicken or fatty outer layers of roasts can be covered with small pieces of aluminium foil. The foil must not touch the cooking compartment walls. You can remove the foil half way through the defrosting time.
- Turn or stir the food once or twice during the defrosting time. Large pieces of food should be turned several times. When turning, remove any liquid that has resulted from defrosting.
- Leave defrosted items to stand at room temperature for a further 10 to 60 minutes so that the temperature can stabilise. The giblets can be removed from poultry at this point.

Defrosting	Weight	Microwave power setting in watts, cooking time in minutes	Notes
Meat, whole pieces of beef, veal or pork (on the bone or boned)	800 g	180 W, 15 mins + 90 W, 15-25 mins	Turn several times
	1 kg	180 W, 20 mins + 90 W, 20-30 mins	
	1.5 kg	180 W, 25 mins + 90 W, 25-30 mins	
Meat in pieces or slices of beef, veal or pork	200 g	180 W, 5-8 mins + 90 W, 5-10 mins	Separate the defrosted parts when turning
	500 g	180 W, 8-11 mins + 90 W, 10-15 mins	
	800 g	180 W, 12-15 mins + 90 W, 15-20 mins	
Minced meat, mixed	200 g	90 W, 10-15 mins	Turn several times, remove meat which has already defrosted
	500 g	180 W, 5 mins + 90 W, 10-15 mins	
	800 g	180 W, 10 mins + 90 W, 15-20 mins	
Poultry or poultry portions	600 g	180 W, 8 mins + 90 W, 10-15 mins	Turn several times
	1.2 kg	180 W, 15 mins + 90 W, 20-25 mins	
Fish fillet, fish steak or slices	400 g	180 W, 5 mins + 90 W, 10-15 mins	Separate defrosted parts.
Whole fish	300 g	180 W, 3 mins + 90 W, 10-15 mins	Turn during defrosting.
	600 g	180 W, 8 mins + 90 W, 15-20 mins	
Vegetables, e.g. peas	300 g	180 W, 10-15 mins	
Fruit, e.g. raspberries	300 g	180 W, 6-9 mins	Stir carefully during defrosting and separate any defrosted parts.
	500 g	180 W, 8 mins + 90 W, 5-10 mins	
Butter, defrosting	125 g	180 W, 1 min + 90 W, 1-2 mins	Remove all packaging.
	250 g	180 W, 1 min + 90 W, 2-4 mins	
Loaf of bread	500 g	180 W, 8 mins + 90 W, 5-10 mins	Turn during defrosting.
	1 kg	180 W, 12 mins + 90 W, 10-20 mins	
Cakes, dry, e.g. sponge cake	500 g	90 W, 10-15 mins	Only for cakes without icing, cream or crème pâtissière, separate the pieces of cake.
	750 g	180 W, 5 mins + 90 W, 10-15 mins	
Cakes, moist, e.g. fruit flan, cheese-cake	500 g	180 W, 5 mins + 90 W, 15-20 mins	Only for cakes without icing, cream or gelatine
	750 g	180 W, 7 mins + 90 W, 15-20 mins	

### Defrosting, heating up or cooking frozen food

#### Notes

- Take ready meals out of the packaging. They will heat up more quickly and evenly in microwaveable ovenware. The different components of the meal may not require the same amount of time to heat up.
- Food which lies flat will cook more quickly than food which is piled high. You should therefore distribute the food so that it is as flat as possible in the ovenware. Different foodstuffs should not be placed in layers on top of one another.
- Always cover the food. If you do not have a suitable cover for your ovenware, use a plate or special microwave foil.

- Stir or turn the food 2 or 3 times during cooking.
- After heating, allow the food to stand for a further 2 to 5 minutes so that it can achieve an even temperature.
- Always use an oven cloth or oven gloves when removing plates from the oven.
- This will help the food retain its own distinct taste, so it will require less seasoning.


**Note:** Place the ovenware on the cooking compartment floor.

Defrosting, heating up or cooking frozen food	Weight	Microwave power setting in watts, cooking time in minutes	Notes
Menu, plated meal, ready meal (2-3 items)	300-400 g	600 W, 8-13 mins	
Soup	400 g	600 W, 8-12 mins	
Stew	500 g	600 W, 10-15 mins	
Slices or pieces of meat in sauce, e.g. goulash	500 g	600 W, 10-15 mins	Separate the pieces of meat when stirring
Fish, e.g. fillets	400 g	600 W, 10-15 mins	possibly add water, lemon juice or wine
Bakes, e.g. lasagne, cannelloni	450 g	600 W, 10-15 mins	Use the wire rack to place the cookware on.
Side dishes, e.g. rice, pasta	250 g	600 W, 3-7 mins	Add a little liquid
	500 g	600 W, 8-12 mins	
Vegetables, e.g. peas, broccoli, carrots	300 g	600 W, 7-11 mins	Add sufficient water to cover base of ovenware
	600 g	600 W, 14-17 mins	
Creamed spinach	450 g	600 W, 10-15 mins	Cook without additional water

### Heating food

#### Risk of scalding!

There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches boiling temperature without the usual steam bubbles rising to the surface. Even if the container only moves a little, the hot liquid can suddenly boil over and spatter. When heating liquids, always place a spoon in the container. This will prevent delayed boiling.



### Caution!

Metal - e.g. a spoon in a glass - must be kept at least 2 cm from the oven walls and the inside of the door. Sparks could irreparably damage the glass on the inside of the door.

### Notes

- Take ready meals out of the packaging. They will heat up more quickly and evenly in microwaveable ovenware. The different components of the meal may not require the same amount of time to heat up .
- Always cover the food. If you do not have a suitable cover for your container, use a plate or special microwave foil.
- Stir or turn the food several times during the heating time. Check the temperature.
- After heating, allow the food to stand for a further 2 to 5 minutes so that it can achieve an even temperature.
- Always use an oven cloth or oven gloves when removing plates from the oven.

**Note:** Place the ovenware on the cooking compartment floor.

Heating food	Weight	Microwave power setting in watts, cooking time in minutes	Notes
Menu, plated meal, ready meal (2-3 items)		600 W, 5-8 mins	-
Drinks	125 ml	1000 W, ½-1 min	Place a spoon in the glass; do not overheat alcoholic drinks; check occasionally while heating
	200 ml	1000 W, 1-2 mins	
	500 ml	1000 W, 3-4 mins	
Baby food, e.g. baby bottle	50 ml	360 W, approx. ½ min	Place baby bottle on the cooking compartment floor without the teat or lid; shake or stir well after heating; always be sure to check the temperature
	100 ml	360 W, ½-1 min	
	200 ml	360 W, 1-2 mins	
Soup 1 cup	175 g each	600 W, 2-3 mins	-
Soup, 2 cups	175 g each	600 W, 3-4 mins	-
Soup, 4 cups	175 g each	600 W, 6-8 mins	-
Meat in sauce	500 g	600 W, 7-10 mins	Separate the slices of meat
Stew	400 g	600 W, 5-7 mins	-
	800 g	600 W, 7-8 mins	-
Vegetables, 1 portion	150 g	600 W, 2-3 mins	-
Vegetables, 2 portions	300 g	600 W, 3-5 mins	-



## Cooking food

### Notes

- Food which lies flat will cook more quickly than food which is piled high. You should therefore distribute the food so that it is as flat as possible in the ovenware. Different foodstuffs should not be placed in layers on top of one another.
- Cook the food in ovenware with a lid. If you do not have a suitable lid for your ovenware, use a plate or special microwave foil.

- This will help the food retain its own distinct taste, so it will require less seasoning.
- After cooking, allow the food to stand for a further 2 to 5 minutes so that it can achieve an even temperature.
- Always use an oven cloth or oven gloves when removing plates from the oven.

Cooking food	Weight	Microwave power setting in watts, cooking time in minutes	Notes
Fresh whole chicken, without giblets	1.2 kg	600 W, 22-25 mins	Turn halfway through the cooking time
Fish fillet, fresh	400 g	600 W, 7-12 mins	-
Vegetables, fresh	250 g	600 W, 5-10 mins	Cut vegetables into pieces of equal size; Add 1-2 tbsp water per 100 g of vegetables; Stir during cooking
	500 g	600 W, 10-15 mins	
Potatoes	250 g	600 W, 8-10 mins	Cut potatoes into pieces of equal size; Add 1-2 tbsp water for every 100 g. Stir during cooking
	500 g	600 W, 12-15 mins	
	750 g	600 W, 15-22 mins	
Rice	125 g	600 W, 4-6 mins + 180 W, 14-16 mins	Add double the quantity of liquid
	250 g	600 W, 6-8 mins + 180 W, 14-16 mins	
Sweet foods, e.g. blancmange (instant)	500 ml	600 W, 5-7 mins	Stir the pudding thoroughly 2 to 3 times during cooking using an egg whisk
Fruit, stewed fruit	500 g	600 W, 9-12 mins	-

## Microwave tips

You cannot find any information about the settings for the quantity of food you have prepared.

Increase or reduce the cooking times using the following rule of thumb:

Double the amount = almost double the cooking time

Half the amount = half the cooking time

The food has become too dry.

Next time, set a shorter cooking time or select a lower microwave power setting. Cover the food and add more liquid.

When the time has elapsed, the food is not defrosted, hot or cooked.

Set a longer time. Large quantities and food which is piled high require longer times.

When the time has elapsed, the food is overheated at the edge but not done in the middle.

Stir it during the cooking time and next time, select a lower microwave power setting and a longer cooking time.

After defrosting, the poultry or meat is defrosted on the outside but not defrosted in the middle.

Next time, select a lower microwave power setting. If you are defrosting a large quantity, turn it several times.

# Test dishes in accordance with EN 60705

The quality and correct operation of microwave appliances are tested by testing institutes using these dishes.

In accordance with EN 60705, IEC 60705, DIN 44547 and EN 60350 (2009)

## Solo microwave cooking

Dish	Microwave power setting in watts, cooking time in minutes	Note
Custard, 1000 g	600 W, 11-12 mins + 180 W, 10-15 mins	Place the Pyrex dish on the cooking compartment floor
Sponge, 475 g	600 W, 8-10 mins	Pyrex dish, dia. 22 cm.
Meat loaf, 900 g	600 W, 25-30 mins	Pyrex cake dish, 28 cm long

## Solo microwave defrosting

Dish	Microwave power setting in watts, cooking time in minutes	Note
Meat, 500 g	Programme 2, 500 g	Place the ovenware on the cooking compartment floor.
	or 180 W, 7 mins + 90 W, 8-12 mins	Place the ovenware on the wire rack.





Constructa Neff  
Vertriebs-GmbH  
Carl-Wery-Straße 34  
D-81739 München

