

Your new dryer

Congratulations! - You have chosen a modern, high-quality domestic appliance from Neff. A distinctive feature of the condensation dryer is its low energy consumption. Every dryer which leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition. Should you have any questions, our after-sales service will be pleased to help.

Environmentally-responsible disposal

This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

For further information about our products, accessories, spare parts and services, please visit: www.neff.de

Observe the safety instructions on page 13.

Caution - risk of scalding.

Read these instructions and the separate **Energy-saving mode** instructions before operating the dryer.

Contents

Preparation	Page 2
Setting the programmes	2
Drying	3/4
Notes on laundry	5
Cleaning and care	6
Overview of programmes	7
Short spin / Refresh	8/9
Installation	10
Frost protection / Transport	10
Technical data	11
Optional accessories	11
What to do if... / After-sales service	12
Safety instructions	13

Reduced temperature for delicate fabrics ☐, for a longer drying time; e.g. acrylic, polyamide, elastane or acetate silk.

Reduces creasing and prolongs the anti-creasing phase after the programme has finished; can be selected in one of two levels.

Indicators which show the programme sequences. Drying, Iron Dry, Cupboard Dry, End / Easy Iron.

Clean the fluff filter and/or air cooler under running water → Page 4/6. Empty the condensate container.

Fill the water tank with distilled water → Page 9.

Intended use

- For domestic use only.
- Only to be used for drying, refreshing or unwrinkling fabrics that have been washed with water.

! This appliance is intended for use up to a maximum height of 4000 metres above sea level. Keep children younger than 3 years old away from the dryer.

Do not let children make the cleaning and maintenance work on the dryer without supervision. Do not leave children unsupervised near the dryer. Keep pets away from the dryer.

The dryer can be operated by children 8 years old and older, by persons with reduced physical, sensory or mental abilities and by persons with insufficient experience or knowledge if they are supervised or have been instructed in its use by a responsible adult.

Preparing for installation, see page 8

! Never operate the dryer if it is damaged. Inform your after-sales service.

! Only if your hands are dry. Only hold the plug by the plug casing.

Sorting and loading laundry

Remove all objects from pockets. Pay particular attention to cigarette lighters. The drum must be empty before filling. If necessary, fill the water tank for **Steam Dry / Steam Refresh** programmes → Page 8. See programme overview on page 7. See also separate instructions for "basket for woollens" (depending on the model).

Selecting and adjusting the programme

Select the drying programme ...

... and adapt to individual requirements

Additional functions	Display panel	Programme selector
<ul style="list-style-type: none"> Low Heat Less Ironing 		
<ul style="list-style-type: none"> Menu Electronic start timer Signal Appliance lock Fine adjustment of the drying result Spin speed 	<ul style="list-style-type: none"> For selecting the settings. For changing all the settings in the display panel. End of the programme after ... (depending on the programme selected, e.g. 1:54h → 2h); you can always select up to the next full hour. There are four buzzer volume settings: 0 (off), 1 (quiet), 2 (normal), 3 (loud), 4 (very loud). Provides protection against unintentional changes to the functions set (press and hold the Menu button for 5 seconds). The drying result (e.g. Cupboard Dry) can be adjusted over three levels (1 - max. 3) for the Cottons, Easy-Care, Mixed Load and Rapid 40' programmes → presetting = 0. After one of these programmes has been finely adjusted, the setting is retained for the others. The spin speed that was used in the washing machine; for more precise indication of the projected drying duration only. 	<ul style="list-style-type: none"> 1-24 hrs 0, 1, 2, 3, 4 On-Off 0, 1, 2, 3 600-1800

1

All buttons are sensitive, a light touch is enough!

Press the Start/Stop button

3

Inspecting the dryer

Connecting the mains plug

Sorting and loading laundry


Selecting and adjusting the programme

Select the drying programme ...

... and adapt to individual requirements

2

Drying



Drying / Short spin / Refresh

3

Emptying condensation

- Empty the container **after** each drying cycle, not during drying!
- Remove the container, holding it level.
 - Pour out condensation.
 - Push the **container** back in until it clicks into place.

Cleaning the fluff filter

- Open the door, remove the filter and fold open.
- Remove the fluff (by wiping the filter with your hand).
- Close the filter, insert it again and close the door.
- Remove fluff from the door and the area around it. Very dirty or blocked filters should be rinsed under warm water, and then dried thoroughly.

Clean the filter in the water tank if it is dirty

- Remove the condensation tank.
- Remove the filter.
- Clean the filter under running water.
- Re-insert the filter and push in the condensation tank until it clicks into place.

Switching off the dryer

Turn the programme selector to **Off**. Do not leave damp laundry in the dryer.

Removing the laundry

The automatic Easy Iron function moves the drum at certain intervals. The load remains loose and soft for an hour (or two hours if you manually select the **Less Ironing** function, depending on the model.)

Programme end

once → lights up in the display.

Interrupt programme

removing or adding laundry.

The drying cycle can be interrupted for a brief period so that laundry may be added or removed. The selected programme must then be continued until it is finished.

! Hot steam may escape during the Steam Drying / Steam Refresh programmes.

- Open the door. The drying cycle is paused.
- Remove or add laundry and close the door.
- If required, select a new programme and additional functions.
- Press the **Start/Stop** button. The remaining time is updated after a few minutes.

4

Information on laundry ...

Labelling of fabrics

Follow the manufacturer's care information.

- ☑ Drying at normal temperature.
- ☑ Dry at a low temperature → select **Low Heat** as well.
- ☑ Do not machine dry.

Do not tumble-dry the following fabrics:

- Airtight fabrics (e.g. rubber-coated fabrics).
- Delicate materials (silk, curtains made from synthetic material) → they may crease.
- Oil-stained laundry.

Drying tips

- To ensure a consistent result, sort the laundry by fabric type and drying programme.
- Close zips, hooks and eyes, and do up any buttons. Tie belts, apron strings etc. together.
- Do not overdry easy-care laundry → risk of creasing. Allow laundry to finish drying in the air.
- Do not iron laundry immediately after drying, fold items up and leave for a while → the remaining moisture will then be distributed evenly.
- The drying result depends on the type of water used during washing. → *Fine adjustment of the drying result* → Page 1/2.
- Knitted fabrics (e.g. T-shirts, jerseys) often shrink slightly the first time they are tumble-dried. → Do not select the **Extra Dry** programme.
- Starched laundry is not always suitable for dryers → starch leaves behind a coating that adversely affects the drying operation.
- When washing laundry that is to be tumble-dried afterwards, dose the fabric softener according to the manufacturer's instructions.
- With a small load, use the Timed Program.

Tips for Steam Dry / Steam Refresh

- Use your dryer for unwrinkling and refreshing fabrics.
 - Short spin cycle for reducing creasing.
 - Refresh cycle for reducing odours from fabrics.
- Do not use Steam Dry / Steam Refresh for the following fabrics:
- Wool, leather, fabrics with metal, wooden or plastic parts.
 - Wax and oil jackets.

- Sort the laundry by colour and put on separate short Steam Dry / Steam Refresh cycles to prevent the colours from bleeding.
- These programmes do not remove stains → stains must be treated and removed beforehand.
- For best results, so that the laundry will have as few creases as possible, remove each item immediately after the programme has finished and hang on a hanger to finish drying. Pull clothes into shape if required.

Environmental protection / Energy-saving tips

- Before drying, spin the laundry thoroughly in the washing machine → the higher the spin speed, the shorter the drying time will be (consumes less energy), also spin easy-care laundry.
- Use the maximum recommended capacity, but do not exceed it → Page 7, "Programme overview".
- Make sure the room is well ventilated during drying.
- Clean the fluff filter after each drying cycle → Page 4.
- Keep the air cooler clean → Page 6 "Cleaning and care".
- Keep the supply of cool air unobstructed → Do not cover or block the cooling grill.

5

Cleaning and care

Dryer housing, control panel, air cooler, moisture sensors

- Wipe with a soft, damp cloth.
- Do not use harsh cleaning agents and solvents.
- Remove detergent and cleaning agent residue immediately.
- During drying, water may collect between the door and seal. This does not affect your dryer's functions in any way.

Clean the protective filter 5 - 6 times a year or if **!** flashes after the fluff filter has been cleaned.

Air cooler / Protective filter

When cleaning, only remove the protective filter. Clean the air cooler behind the protective filter once a year.

- Allow the dryer to cool.
- Residual water may leak out, so place an absorbent towel underneath the maintenance door.

- Unlock the maintenance door.
- Open the maintenance door fully.

- Turn both locking levers towards each another.
- Pull out the protective filter/air cooler.

Do not damage the protective filter or air cooler. Clean with warm water only. Do not use any hard or sharp-edged objects.

- Clean the air cooler thoroughly. Allow to drip dry.
- Clean the seals.

- Re-insert the protective filter/air cooler, with the handle facing down.
- Turn back both locking levers.
- Close the maintenance door until the lock clicks into place.

Moisture sensors

The dryer is fitted with stainless steel moisture sensors. The sensors measure the level of moisture in the laundry. After a long period of operation, a fine layer of limescale may form on the sensors.

- Open the door and clean the moisture sensors with a damp sponge which has a rough surface.

Do not use steel wool or abrasive materials.

Cover for steam nozzle

in the drum. After lengthy operation, limescale and fluff may accumulate on the cover of the steam nozzle. Clean regularly.

- Open the door and remove the cover with a screw driver. Clean the cover under running water.
- Push and click the protective cap back in place.

6

Programme overview

Sort the laundry according to type of textile and fabric. Fabrics must be suitable for tumble drying.

After drying...
 ☐ iron laundry ☐ lightly iron laundry ☐ do not iron laundry ☐ mangle laundry

PROGRAMMES	max. 7 kg	max. 3.5 kg	max. 3 kg	max. 1.5 kg	max. 1 kg	max. 1.5 kg	max. 1.5 kg	max. 3 kg	max. 2 kg	max. 3 kg	max. 3 kg	
Cottons	Hard-wearing fabrics; both-resistant fabrics made of cotton or linen.	Non-iron laundry made of synthetic fibres and blended fabric; easy-care cotton.	Mixed items of laundry made of cotton and synthetics (Mix).	Fabrics suitable for ironing (iron fabrics in order to avoid creasing).	Single-layer fabrics.	Fabrics made of thick, multilayered items of clothing.	For smoothing hard-wearing and easy-care fabrics. Steam smooths the fabrics.	Further information → Page 8.	For freshening hard-wearing and easy-care fabrics. Steam freshens up the fabrics.	Fabrics with membrane coating, water-repellent fabrics; functional clothing, fleece fabrics (dry jackets/trousers with removable internal lining separately).	Woolen fabrics suitable for washing machines. Fabrics become fluffier but not dry.	Laundry made of synthetic fibres, cotton or blended fabrics (for example that needs to be dried quickly. The values may differ from those specified depending on the type of fabric, mixture of laundry to be dried, residual moisture in the fabric and loading capacity).
Easy-Care												
Mixed Load												
Iron Dry												
Cupboard Dry												
Steam Drying												
Minimum Iron												
Minimum Iron Shirt												
Steam Refresh												
Business												
Freshen up												
Sports												
Woolens Finish												
Rapid 40'												
Timed Programme/warm												

Pre-dried, multi-layered, sensitive fabrics made of acrylic fibres, or separate small items of laundry. Also for subsequent drying.

for Cottons and Easy-Care programmes only
 *Dress levels can be selected individually → Extra Dry, Cupboard Dry and Iron Dry (depending on the model).
 Degree of dryness can be finely adjusted; multi-layered textiles require a longer drying time than single-layered items of clothing. Recommendation: Dry separately.

7

Steam Drying - Steam Refresh

Steam programmes for unwrinkling or refreshing

- Your dryer has unwrinkling and refreshing programmes that can be used for reducing odours and minimising creasing in dry fabrics. Steam smooths and freshens up items of clothing.
- Sorting the laundry according to size, weight, fabric and colour is necessary.
- Only use Short spin/Refresh for fabrics with the same properties.
- During steam generation (required), additional noises may occur.
- The result of refreshing and unwrinkling may vary depending on the type of fabric, size of the load and programme selected.
- After unwrinkling or refreshing, all fabrics must be removed immediately and hung crease-free on a hanger or a washing line for 15 minutes.

Programmes

Please observe the treatment symbols and manufacturer's instructions on the fabrics. Do not use Short spin/Refresh for fabrics made of wool, leather, containing metal or wooden parts as well as wax and oil jackets! Do not use any dryer cleaning sets!

Steam Drying

Minimum Iron Shirt
Suitable for easy-care fabrics, e.g. formal shirts. Fabrics are smoothed. You can expect optimum results if "non-iron" appears on the care label. After the programme has finished, the items must be removed immediately and hung crease-free on a hanger or washing line for 15 minutes. The programme is for up to 5 formal shirts.

Minimum Iron Daily Load
Suitable for hard-wearing cotton fabrics, e.g. bed linen, tablecloths or formal shirts. Fabrics are smoothed. You can expect optimum results if "non-iron" appears on the care label. After the programme has finished, the items must be removed immediately and hung crease-free on a hanger or washing line for 15 minutes. The programme is for up to 5 formal shirts or 1 to 2 larger items.

Steam Refresh

Business
Suitable for refreshing suits, jackets and trousers, or dry-clean items that cannot be washed in the washing machine → see the care label. The programme only refreshes fabrics and does not clean them. After the end of the programme, the items must be removed immediately. Programme for 1 suit or 1 to 2 smaller items.

Freshen up
Suitable for refreshing casual wear made of cotton or artificial fibres. Fabrics must be suitable for dryers → see the care label. The programme refreshes fabrics only, and does not clean them. After the programme has finished, the fabrics must be removed immediately. Programme for 1 pullover, 2 pairs of trousers or formal shirts.

Steam Drying - Steam Refresh

Your water tank empties automatically after the programme has finished. Cleaning is therefore not required.

Filling the water tank:
Fill the dryer's water tank with distilled water before every **Steam Drying - Steam Refresh** cycle.

1. Move the programme selector to **Steam Drying** or **Steam Refresh**. The symbol appears in the display.

2. Remove the condensate tank completely.

Before every **Steam Drying - Steam Refresh** cycle, fill the water tank with distilled water only. Do not use tap water, condensation or additives.

3. Fill the water tank. Use the jug supplied.

If the water tank filter is dirty → clean the filter in the water tank. See page 4.

4. Pour the distilled water into the filling hole on the water tank, until the symbol goes out on the display panel.

If drying the recommended load, approximately 250 to 300 ml of distilled water is used in the **Steam Drying - Steam Refresh** programmes.

5. Insert the condensate container all the way.

6. Start the **Steam Drying** or **Steam Refresh** programme.

Installation

– Scope of delivery: dryer, installation and instruction manual, jug, basket for woollens (depending on the model).
– Check dryer for transport damage.
– The dryer is heavy. Do not attempt to lift it on your own.
– Be careful to avoid sharp edges.
– Do not install in a room where there is a risk of freezing. Freezing water may cause damage.
– If in doubt, have the appliance connected by a specialist.
– Do not lift the dryer by protruding parts (e.g. the door) - risk of breakage.

1. **Setting up the dryer**
– The appliance plug must always be accessible.
– Ensure that the appliance is installed on a clean, level and firm surface.
– Keep the cooling grille on the front of the dryer clear.
– Keep the area around the dryer clean.
– Level the dryer using the threaded feet. Use a spirit level.
– Do not remove the threaded feet under any circumstances.

Do not install the dryer behind a door or sliding door, which could prevent or restrict opening of the dryer door. This will prevent children from locking themselves in and putting their lives in danger.

2. **Mains connection** see safety information → page 13.
– Connect to an AC earthed socket. If in doubt, have the socket checked by a specialist.
– The mains voltage and the voltage shown on the rating plate (→ Page 11) must be the same.
– The connected load and necessary fuse protection are specified on the rating plate.

Frost protection / Transport
Do not operate the dryer if there is a danger of frost.

Preparation
1. Empty the condensate container → page 4.
2. Select any programme using the programme selector.
3. Press the **Start/Stop** button → condensation is pumped into the container.
4. Wait 5 min., and then empty the condensate container again.
5. Turn the programme selector to **Off**.

The water tank must not contain any distilled water. If necessary, run the Steam/Refresh programme.

Technical data

Dimensions (DxWxH)	60 x 60 x 85 cm (adjustable height)
Weight	approximately 43.5 kg
Max. capacity	7 kg
Condensate container	4.0 l
Water tank	approx. 0.4 l
Connection voltage	220-240 V
Connected load	max. 2600 W
Fuse protection	13 A
Product number/ Production number	Inside of door
You can find the rating plate on the back of the dryer.	
Power consumption when switched off	0.10 W
Power consumption when ready for use (left-on mode)	1.00 W
Drum interior light (depending on model) (bulb E14, 25 W)	The drum lights up after the door is opened or closed, and after the programme starts, and switches off automatically. Changing the bulb → page 10.

Consumption values table

Programme	Spin speed which is used for spinning the laundry	Duration**		Energy consumption**	
		7 kg	3.5 kg	7 kg	3.5 kg
Cottons	1400 rpm	106 min	65 min	3.60 kWh	1.97 kWh
	1000 rpm	124 min	76 min	4.20 kWh	2.30 kWh
	800 rpm	143 min	88 min	4.80 kWh	2.63 kWh
Iron Dry*	1400 rpm	82 min	50 min	2.59 kWh	1.42 kWh
	1000 rpm	98 min	60 min	3.28 kWh	1.80 kWh
	800 rpm	112 min	69 min	3.96 kWh	2.17 kWh
Easy-Care	3.5 kg			3.5 kg	
	Cupboard Dry*	800 rpm	42 min		1.35 kWh
		600 rpm	51 min		1.65 kWh

* Programme setting for testing in accordance with the applicable EN61121 standard.
** The values may differ from those specified, depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric and the amount of laundry being loaded.

Most efficient programme for cotton fabrics

The following "standard cottons programme" (identified with ☐) is suitable for drying normal, wet cotton laundry and is most efficient in terms of its combined energy consumption for drying wet cotton laundry.

Standard programme for cottons in accordance with current EU regulation 932/2012

Programme	Load	Energy consumption	Programme duration
☐ Cottons Cupboard Dry	7 kg/3.5 kg	4.20 kWh/2.30 kWh	124 min/76min

Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU.

Optional accessories (from after-sales service using order number, depending on model)

CZ 11390	Washer-dryer slack connection set The dryer can be placed on top of a suitable washing machine with the same width and depth to save space. The dryer must be fastened to the washing machine using this connection set.
WZ 20160	Connection fittings for condensation outlet The condensation is conveyed directly via a hose.
WZ 20290	Installation underneath the worktop Instead of the appliance covering plate, you must have a metal cover fitted by a specialist.


What to do if...

- The Start/Stop indicator light does not come on.** Mains plug plugged in? Programme selected? Check the socket fuse.
- The display panel light and indicator lights (depending on model) go out and the Start/Stop indicator light flashes.** Energy-saving mode is activated → see the separate Energy-saving mode instructions.
- The symbol and Start/Stop indicator light are flashing.** Empty the condensate container → Page 4. Check the condensation outlet hose, if applicable (kink).
- The symbol and Start/Stop indicator light are flashing.** Clean the air cooler → Page 6 "Cleaning and care". Clean the fluff filter → Page 4.
- The symbol flashes.** Is the water tank empty? Filling with distilled water → Page 9. The filter in the water tank may have become dirty. If so, clean the filter in the water tank → Page 4.
- The Steam Drying - Steam Refresh does not start.** Has the Start/Stop button been pressed? Is the door closed? Programme set? Ambient temperature greater than 5°C?
- Dryer does not start.** Make sure the dryer is level. Clean the air cooler seal.
- The door opens by itself.** Push the door closed until you hear it click into place.
- Items crease even though the Steam Drying - Steam Refresh programme has been selected.** Laundry load exceeded? Remove articles of clothing immediately after the end of the programme, hang up and pull into shape. Unsuitable programme selected → Page 7.
- Laundry is not dried correctly or is still too damp.** After the end of the programme, warm laundry feels damper than it actually is. Spread the laundry out and allow the heat to disperse. Finely adjust the dryness level. This extends the drying time but does not increase the temperature. Your laundry will become drier. Select a programme with a longer drying time or increase the drying level. This does not increase the temperature. Select a time programme for extended drying of laundry that is still damp. If you have exceeded the maximum load for the programme, the laundry may not be dried correctly. Clean the moisture sensor in the drum. A fine layer of limescale may adversely affect the performance of the sensors and your washing will not dry properly. Drying has been interrupted as a result of a power cut, because the condensate container is full or because the maximum drying time has been exceeded.
- Drying time too long.** Rinse the fluff filters under running water → Page 4. Insufficient supply of air → ensure that air can circulate. Air inlet possibly blocked → Clear inlet → Page 10. Ambient temperature higher than 35°C → ventilate the room.
- The humidity in the room increases significantly.** Make sure the room is sufficiently ventilated.
- Power failure.** Remove laundry from the dryer immediately and spread out. This allows the heat to dissipate. Be careful as the door, the drum and the laundry may be hot.
- One or more programme status indicator lamps are flashing.** Clean the filter and air cooler under running water → Page 4/6. Check the installation conditions → Page 10. Switch off, allow to cool, switch on again and restart the programme.
- The interior light (depending on the model) does not work.** Unplug the appliance plug, fold back the cover cap on the inside above the door (using a Torx 20 screwdriver) and replace the bulb. Close the cover cap.

Safety instructions

- Emergency ONLY use the dryer...** Pull the appliance plug out of the socket immediately or disconnect the fuse. – in rooms inside the house. – for drying or unwrinkling/refreshing fabrics.
- The dryer must NEVER...** – be used for purposes other than those described above. – be modified in terms of its technology or properties.
- Hazards** – The dryer must not be used by children or persons who have not been instructed in its use. – Do not leave children unsupervised near the dryer. – Keep pets away from the dryer. – Remove all objects from pockets, and lighters in particular → **risk of explosion**. – Do not lean or sit on the door → **risk of tipping**. – Open the door carefully. Hot steam may escape. The clothes and drum may be hot → **risk of burns**.
- Installation** – Secure loose leads or hoses, otherwise there is a **risk of tripping**. – Below 0°C there is a possibility of frost damage.
- Mains connection** – Connect the dryer according to specifications to an AC earthed socket, otherwise it cannot be guaranteed that the appliance is completely safe. – The cable cross-section must be sufficient. – Only use earth-leakage circuit breakers with the following symbol: ☒. – The appliance plug and socket must be compatible. – Do not use multiple plugs/connectors and/or extension cables. – Do not touch or hold the appliance plug with wet hands → **risk of electric shock**. – Never pull the appliance plug out of the socket by its cable. – Do not damage the mains lead → **risk of electric shock**.
- Operation** – Only load the drum with laundry. Check the contents before you switch the dryer on. – Do not use the dryer if the laundry has been in contact with solvents, oil, wax, grease or paint (e.g. hair setting spray, nail polish remover, stain remover, cleaning solvent, etc.) → **fire/explosion hazard**. – The tumble dryer is not to be used if industrial chemicals have been used for cleaning. – Dust (e.g. coal dust, flour) poses a danger: do not use the dryer → **explosion hazard**. – Do not turn off the dryer until the drying process ends, unless the laundry will be removed quickly and spread out, so that the heat can dissipate. – Do not put laundry containing foamed material/rubber in the dryer → elastic material may be destroyed and the dryer may be damaged due to possible deformation of the foamed material. – Light things, such as long hair, may be sucked into the air inlet of the dryer → **Risk of injury**. – Final part of a tumble dryer cycle occurs without heat (cool down cycle), to ensure that the items are left at a temperature that ensures that the items will not be damaged. – Switch off the dryer once the programme has ended. – The exterior of the appliance's rear panel becomes very hot during operation. Never touch the hot surface of the appliance's rear panel. Keep children away from the appliance → **Risk of burns!** – For unwrinkling/refreshing fabrics, use distilled water only. Do not use condensation, tap water or additives.
- Defect** – Do not use the dryer if it is defective or if you suspect that it is. Repairs must only be carried out by the after-sales service. – Do not use a dryer with a faulty mains lead. To prevent risks, a faulty mains lead must only be replaced by the after-sales service. – Before changing the bulb of the interior light make absolutely sure you have pulled the appliance plug from the socket → **risk of electric shock**.
- Spare parts** – Only use genuine spare parts and accessories for safety reasons.
- Disposal** – Dryer: unplug the appliance plug, **then** cut the mains lead from the appliance. Dispose of the dryer at an approved public disposal facility. – Packaging: keep all packaging out of reach of babies and children. → **danger of suffocation**. – All materials are environmentally safe and recyclable. Dispose of in an environmentally-responsible manner.

INSTRUCTIONS FOR INSTALLATION AND USE



TUMBLE DRYER

Your new dryer

Congratulations! - You have chosen a modern, high-quality domestic appliance from Neff.

A distinctive feature of the condensation dryer is its low energy consumption.

Every dryer which leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

Should you have any questions, our after-sales service will be pleased to help.

Environmentally-responsible disposal

This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

For further information about our products, accessories, spare parts and services, please visit: www.neff.de



Observe the safety instructions on page 13.



Caution - risk of scalding.



Read these instructions and the separate **Energy-saving mode** instructions before operating the dryer.

Contents

Page

	Preparation	2
	Setting the programmes	2
	Drying	3/4
	Notes on laundry	5
	Cleaning and care	6
	Overview of programmes	7
	Short spin / Refresh	8/9
	Installation	10
	Frost protection / Transport	10
	Technical data	11
	Optional accessories	11
	What to do if... / After-sales service	12
	Safety instructions	13

Reduced temperature for delicate fabrics , for a longer drying time; e.g. acrylic, polyamide, elastane or acetate silk.

Reduces creasing and prolongs the anti-creasing phase after the programme has finished; can be selected in one of two levels.

Indicators which show the programme sequences.
Drying, Iron Dry, Cupboard Dry, End / Easy Iron.

Clean the fluff filter and/or air cooler under running water → Page 4/6.
Empty the condensate container.

Fill the water tank with distilled water → Page 9.

Intended use

-  For domestic use only.
-  Only to be used for drying, refreshing or unwrinkling fabrics that have been washed with water.



This appliance is intended for use up to a maximum height of 4000 metres above sea level.

Keep children younger than 3 years old away from the dryer.

Do not let children make the cleaning and maintenance work on the dryer without supervision.

Do not leave children unsupervised near the dryer. Keep pets away from the dryer.

The dryer can be operated by children 8 years old and older, by persons with reduced physical, sensory or mental abilities and by persons with insufficient experience or knowledge if they are supervised or have been instructed in its use by a responsible adult.

Preparing for installation, see page 8



Never operate the dryer if it is damaged. Inform your after-sales service.



Only if your hands are dry. Only hold the plug by the plug casing.





Sorting and loading

Remove all objects from pockets. Pay particular attention to cigarette lighters. The drum must be empty before filling. If necessary, fill the water tank for **Steam Dry / Steam Refresh** programmes → Page 7. See programme overview on page 7. See also separate instructions for "basket for v..." (depending on the model)

Selecting and adjusting the programmes

Select the d...

... and adapt to individ...

Additional functions	Display panel	Programme selector
 Low Heat  Less Ironing		

All buttons... a light touch

Press th...

	Menu	For selecting the settings.
	-/+	For changing all the settings in the display panel.
	Electronic start timer	End of the programme after ... (depending on the programme selected, e.g. 1:54h – you can always select up to the next full hour).
	Signal	There are four buzzer volume settings: 0 (off), 1 (quiet), 2 (normal), 3 (loud), 4 (very loud).
	Appliance lock (depending on the model)	Provides protection against unintentional changes to the functions set (press and hold the Menu button for 5 seconds).
	Fine adjustment of the drying result	The drying result (e.g. Cupboard Dry) can be adjusted over three levels (1 - max. 3) Cottons, Easy-Care, Mixed Load and Rapid 40' programmes → presetting = 0. After one of these programmes has been finely adjusted, the setting is retained for the next programme.
	Spin speed	The spin speed that was used in the washing machine; for more precise indication of the projected drying duration only.

Drying

Inspecting the dryer

Connecting the mains plug

Loading laundry

Page 8.

woollens"

the programme

Drying programme ...

Individual requirements

are sensitive,
is enough!

the Start/Stop button

→ 2h; 1 -24 hrs

loud). 0, 1, 2, 3, 4
On-Off

for the 0, 1, 2, 3


the others.

600-1800 ©



1
2

3




Drying / Short spin / Refresh



Emptying condensation


Empty the container **after** each drying cycle, not during drying!

1. Remove the container, holding it level.
2. Pour out condensation.
3. Push the **container** back in until it clicks into place.





Cleaning the fluff filter

1. Open the door, remove the filter and fold open.
2. Remove the fluff (by wiping the filter with your hand).
3. Close the filter, insert it again and close the door.
4. Remove fluff from the door and the area around it. Very dirty or blocked filters should be rinsed under warm water, and then dried thoroughly.




Clean the filter in the water tank if it is dirty

1. Remove the condensation tank.
2. Remove the filter.
3. Clean the filter under running water.
4. Re-insert the filter and push in the condensation tank until it clicks into place.



Switching off the dryer

Turn the programme selector to **Off**.
Do not leave damp laundry in the dryer.



Removing the laundry

The automatic Easy Iron function moves the drum at certain intervals. The load remains loose and soft for an hour (or two hours if you manually select the **Less Ironing** function, depending on the model.)


Programme end once → lights up in the display.

Interrupt programme removing or adding laundry.

i The drying cycle can be interrupted for a brief period so that laundry may be added or removed. The selected programme must then be continued until it is finished.

! Hot steam may escape during the Steam Drying / Steam Refresh programmes.

1. Open the door. The drying cycle is paused.
2. Remove or add laundry and close the door.
3. If required, select a new programme and additional functions.
4. Press the **Start/Stop** button. The remaining time is updated after a few minutes.



Information on laundry ...



Labelling of fabrics

Follow the manufacturer's care information.

- ☑ Drying at normal temperature.
- ☑ Dry at a low temperature → select **Low Heat** as well.
- ☒ Do not machine dry.

Do not tumble-dry the following fabrics:

- Airtight fabrics (e.g. rubber-coated fabrics).
- Delicate materials (silk, curtains made from synthetic material) → they may crease.
- Oil-stained laundry.



Drying tips

- To ensure a consistent result, sort the laundry by fabric type and drying programme.
- Close zips, hooks and eyes, and do up any buttons. Tie belts, apron strings etc. together.
- Do not overdry easy-care laundry → risk of creasing. Allow laundry to finish drying in the air.
- Do not iron laundry immediately after drying, fold items up and leave for a while → the remaining moisture will then be distributed evenly.
- The drying result depends on the type of water used during washing. → *Fine adjustment of the drying result* → Page 1/2.
- Knitted fabrics (e.g. T-shirts, jerseys) often shrink slightly the first time they are tumble-dried. → Do not select the **Extra Dry** programme.
- Starched laundry is not always suitable for dryers → starch leaves behind a coating that adversely affects the drying operation.
- When washing laundry that is to be tumble-dried afterwards, dose the fabric softener according to the manufacturer's instructions.
- With a small load, use the Timed Program.



Tips for Steam Dry / Steam Refresh

- Use your dryer for unwrinkling and refreshing fabrics.
- Short spin cycle for reducing creasing.
- Refresh cycle for reducing odours from fabrics.

Do not use Steam Dry / Steam Refresh for the following fabrics:

- Wool, leather, fabrics with metal, wooden or plastic parts.
- Wax and oil jackets.



- Sort the laundry by colour and put on separate short Steam Dry / Steam Refresh cycles to prevent the colours from bleeding.
- These programmes do not remove stains → stains must be treated and removed beforehand.
- For best results, so that the laundry will have as few creases as possible, remove each item immediately after the programme has finished and hang on a hanger to finish drying. Pull clothes into shape if required.

Environmental protection / Energy-saving tips

- Before drying, spin the laundry thoroughly in the washing machine → the higher the spin speed, the shorter the drying time will be (consumes less energy), also spin easy-care laundry.
- Use the maximum recommended capacity, but do not exceed it → Page 7, "Programme overview".
- Make sure the room is well ventilated during drying.
- Clean the fluff filter after each drying cycle → Page 4.
- Keep the air cooler clean → Page 6 "Cleaning and care".
- Keep the supply of cool air unobstructed → Do not cover or block the cooling grill.

Cleaning and care



Only when switched off!

Dryer housing, control panel, air cooler, moisture sensors

- Wipe with a soft, damp cloth.
- Do not use harsh cleaning agents and solvents.
- Remove detergent and cleaning agent residue immediately.
- During drying, water may collect between the door and seal. This does not affect your dryer's functions in any way.


Clean the protective filter 5 - 6 times a year or if flashes after the fluff filter has been cleaned.

Air cooler / Protective filter

When cleaning, only remove the protective filter. Clean the air cooler behind the protective filter once a year.

- Allow the dryer to cool.
- Residual water may leak out, so place an absorbent towel underneath the maintenance door.

1. Unlock the maintenance door.
2. Open the maintenance door fully.



3. Turn both locking levers towards each other.
4. Pull out the protective filter/air cooler.



Do not damage the protective filter or air cooler. Clean with warm water only. Do not use any hard or sharp-edged objects.


5. Clean the air cooler thoroughly. Allow to drip dry.
6. Clean the seals.
7. Re-insert the protective filter/air cooler, with the handle facing down.
8. Turn back both locking levers.
9. Close the maintenance door until the lock clicks into place.



Moisture sensors

The dryer is fitted with stainless steel moisture sensors. The sensors measure the level of moisture in the laundry. After a long period of operation, a fine layer of limescale may form on the sensors.

1. Open the door and clean the moisture sensors with a damp sponge which has a rough surface.




Do not use steel wool or abrasive materials.

Cover for steam nozzle in the drum

After lengthy operation, limescale and fluff may accumulate on the cover of the steam nozzle. Clean regularly:

1. Open the door and remove the cover with a screw driver. Clean the cover under running water.
2. Push and click the protective cap back in place.



Programme overview

see also pages 5 and 8

Sort the laundry according to type of textile and fabric. Fabrics must be suitable for tumble drying.

After drying...	iron laundry	lightly iron laundry	do not iron laundry	mangle laundry
PROGRAMMES				
TEXTILE TYPE AND INFORMATION				
**Cottons	max. 7 kg	Hard-wearing fabrics, boil-resistant fabrics made of cotton or linen.		
**Easy-Care	max. 3.5 kg	Non-iron laundry made of synthetic fibres and blended fabric, easy-care cotton.		
**Mixed Load	max. 3 kg	Mixed items of laundry made of cotton and synthetics (Mix).		
*Iron Dry		Fabrics suitable for ironing (iron fabrics in order to avoid creasing).		
Cupboard Dry		Single-layer fabrics.		
*Extra Dry		Fabrics made of thick, multilayered items of clothing.		
Steam Drying		For smoothing hard-wearing and easy-care fabrics. Steam smooths the fabrics.		
Minimum Iron Daily Load	max. 2.5 kg	Further information → Page 8.		
Minimum Iron Shirt	max. 1.5 kg	For freshening hard-wearing and easy-care fabrics. Steam freshens up the fabrics.		
Steam Refresh		Further information → Page 8.		
Business Freshen up	max. 1.5 kg	Fabrics with membrane coating, water-repellent fabrics, functional clothing, fleece fabrics (dry jackets/trousers with removable internal lining separately).		
Sports	max. 1.5 kg	Woolen fabrics suitable for washing machines. Fabrics become fluffier but not dry. Remove fabrics once the programme has ended and allow to dry.		
Woollens Finish	max. 3 kg	Laundry made of synthetic fibres, cotton or blended fabrics (for example) that needs to be dried quickly. The values may differ from the those specified depending on the type of fabric, mixture of laundry to be dried, residual moisture in the fabric and loading capacity.		
Rapid 40'	max. 2 kg	Pre-dried, multi-layered, sensitive fabrics made of acrylic fibres, or separate small items of laundry.		
Timed Programme/warm	max. 3 kg	Also for subsequent drying.		

*for Cottons and Easy-Care programmes only

**Dryness levels can be selected individually → Extra Dry, Cupboard Dry and Iron Dry (depending on the model).

Degree of dryness can be finely adjusted; multi-layered textiles require a longer drying time than single-layered items of clothing. Recommendation: Dry separately.

9503 / 9000964533



R8580X1GB

Steam Drying - Steam Refresh

i Steam programmes for unwrinkling or refreshing

- Your dryer has unwrinkling and refreshing programmes that can be used for reducing odours and minimising creasing in dry fabrics. Steam smooths and freshens up items of clothing.
- Sorting the laundry according to size, weight, fabric and colour is necessary.
- Only use Short spin/Refresh for fabrics with the same properties.
- During steam generation (required), additional noises may occur.
- The result of refreshing and unwrinkling may vary depending on the type of fabric, size of the load and programme selected.
- After unwrinkling or refreshing, all fabrics must be removed immediately and hung crease-free on a hanger or a washing line for 15 minutes.

Programmes

 Please observe the treatment symbols and manufacturer's instructions on the fabrics. Do not use Short spin/Refresh for fabrics made of wool, leather, containing metal or wooden parts as well as wax and oil jackets! Do not use any dryer cleaning sets!

Steam Drying

Minimum Iron Shirt

Suitable for easy-care fabrics, e.g. formal shirts. Fabrics are smoothed. You can expect optimum results if "non-iron" appears on the care label. After the programme has finished, the items must be removed immediately and hung crease-free on a hanger or washing line for 15 minutes. The programme is for up to 5 formal shirts.

Minimum Iron Daily Load

Suitable for hard-wearing cotton fabrics, e.g. bed linen, tablecloths or formal shirts. Fabrics are smoothed. You can expect optimum results if "non-iron" appears on the care label. After the programme has finished, the items must be removed immediately and hung crease-free on a hanger or washing line for 15 minutes. The programme is for up to 5 formal shirts or 1 to 2 larger items.

Steam Refresh

Business

Suitable for refreshing suits, jackets and trousers, or dry-clean items that cannot be washed in the washing machine → see the care label. The programme only refreshes fabrics and does not clean them. After the end of the programme, the items must be removed immediately. Programme for 1 suit or 1 to 2 smaller items.

Freshen up

Suitable for refreshing casual wear made of cotton or artificial fibres. Fabrics must be suitable for dryers → see the care label. The programme refreshes fabrics only, and does not clean them. After the programme has finished, the fabrics must be removed immediately. Programme for 1 pullover, 2 pairs of trousers or formal shirts.



Steam Drying - Steam Refresh

i Your water tank empties automatically after the programme has finished. Cleaning is therefore not required.


Filling the water tank:

Fill the dryer's water tank with distilled water before every **Steam Drying - Steam Refresh** cycle.

1. Move the programme selector to **Steam Drying** or **Steam Refresh**. The  symbol appears in the display.




2. Remove the condensate tank completely.




 Before every **Steam Drying - Steam Refresh** cycle, fill the water tank with distilled water only. Do not use tap water, condensation or additives.

3. Fill the water tank. Use the jug supplied.



i If the water tank filter is dirty → clean the filter in the water tank. See page 4.

4. Pour the distilled water into the filling hole on the water tank, until the  symbol goes out on the display panel.




i If drying the recommended load, approximately 250 to 300 ml of distilled water is used in the **Steam Drying - Steam Refresh** programmes.

5. Insert the condensate container all the way.



6. Start the **Steam Drying** or **Steam Refresh** programme.




Installation

- ! Scope of delivery: dryer, installation and instruction manual, jug, basket for woollens (depending on the model).
- Check dryer for transport damage.
- The dryer is heavy. Do not attempt to lift it on your own.
- Be careful to avoid sharp edges.
- Do not install in a room where there is a risk of freezing. Freezing water may cause damage.
- If in doubt, have the appliance connected by a specialist.
- Do not lift the dryer by protruding parts (e.g. the door) - risk of breakage.

1. Setting up the dryer

- The appliance plug must always be accessible.
- Ensure that the appliance is installed on a clean, level and firm surface.  Remove all accessories from the drum. The drum must be empty.
- Keep the cooling grille on the front of the dryer clear.
- Keep the area around the dryer clean.
- Level the dryer using the threaded feet. Use a spirit level.
- Do not remove the threaded feet under any circumstances.



! Do not install the dryer behind a door or sliding door, which could prevent or restrict opening of the dryer door. This will prevent children from locking themselves in and putting their lives in danger.

2. Mains connection see safety information → page 13.

- Connect to an AC earthed socket. If in doubt, have the socket checked by a specialist.
- The mains voltage and the voltage shown on the rating plate (→ Page 11) must be the same.
- The connected load and necessary fuse protection are specified on the rating plate.

Frost protection / Transport

! Do not operate the dryer if there is a danger of frost.

Preparation

- Empty the condensate container → page 4.
- Select any programme using the programme selector.
- Press the **Start/Stop** button → condensation is pumped into the container.
- Wait 5 min., and then empty the condensate container again.
- Turn the programme selector to **Off**.

The water tank must not contain any distilled water. If necessary, run the Steam/Refresh programme.

Technical data

● Dimensions (DxWxH)	60 x 60 x 85 cm (adjustable height)		
Weight	approximately 43.5 kg		
Max. capacity	7 kg		
Condensate container	4.0 l		
Water tank	approx. 0.4 l		
Connection voltage	220-240 V		
Connected load	max. 2600 W		
Fuse protection	13 A		
Product number/ Production number	Inside of door		
You can find the rating plate on the back of the dryer.			
Power consumption when switched off	0.10 W		
Power consumption when ready for use (left-on mode)	1.00 W		
● Drum interior light (depending on model) (bulb E14, 25 W)	The drum lights up after the door is opened or closed, and after the programme starts, and switches off automatically. Changing the bulb → page 10.		

Consumption values table

Programme	Spin speed which is used for spinning the laundry	Duration**		Energy consumption**		
		7 kg	3.5 kg	7 kg	3.5 kg	
Cottons						
	Cupboard Dry*	1400 rpm	106 min	65 min	3.60 kWh	1.97 kWh
		1000 rpm	124 min	76 min	4.20 kWh	2.30 kWh
	800 rpm	143 min	88 min	4.80 kWh	2.63 kWh	
Iron Dry*						
		1400 rpm	82 min	50 min	2.59 kWh	1.42 kWh
		1000 rpm	98 min	60 min	3.28 kWh	1.80 kWh
	800 rpm	112 min	69 min	3.96 kWh	2.17 kWh	
Easy-Care						
			3.5 kg		3.5 kg	
Cupboard Dry*						
		800 rpm	42 min		1.35 kWh	
		600 rpm	51 min		1.65 kWh	

* Programme setting for testing in accordance with the applicable EN61121 standard.

** The values may differ from those specified, depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric and the amount of laundry being loaded.

Most efficient programme for cotton fabrics

The following "standard cottons programme" (identified with ) is suitable for drying normal, wet cotton laundry and is most efficient in terms of its combined energy consumption for drying wet cotton laundry.

Standard programme for cottons in accordance with current EU regulation 932/2012

Programme	Load	Energy consumption	Programme duration
 Cottons Cupboard Dry	7 kg/3.5 kg	4.20 kWh/2.30 kWh	124 min/76min

Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU.

Optional accessories (from after-sales service using order number, depending on model)

CZ 11390 Washer-dryer stack connection set
The dryer can be placed on top of a suitable washing machine with the same width and depth to save space. The dryer **must be** fastened to the washing machine using this connection set.

WZ 20160 Connection fittings for condensation outlet
The condensation is conveyed directly via a hose.

WZ 20290 Installation underneath the worktop
Instead of the appliance covering plate, you **must** have a metal cover fitted by a specialist.

What to do if...



If you cannot rectify a fault yourself (e.g. switching off/on), please contact our after-sales service. We will always find an appropriate solution and will avoid unnecessary visits by engineers. Trust the expertise of the manufacturer and rest assured that the repair will be carried out by trained service technicians using original spare parts. The contact details of your local after-sales service can be found in the enclosed **after-sales service** directory, or by calling one of these numbers:

- GB 0344 892 8989 (Calls charged at local or mobile rate.)
- IE 01450 2655 (0.03 € per minute at peak. Off peak 0.0088 € per minute.)

When contacting the after-sales service, please quote the appliance's product number (E no.) and production number (FD) (see the inside of the door).

Set the programme selector to **Off** and remove the appliance plug from the socket.

● The Start/Stop indicator light does not come on.	Mains plug plugged in? Programme selected? Check the socket fuse.
● The display panel light and indicator lights (<i>depending on model</i>) go out and the Start/Stop indicator light flashes.	Energy-saving mode is activated → see the separate <i>Energy-saving mode</i> instructions.
● The  symbol and Start/Stop indicator light are flashing.	Empty the condensate container → <i>Page 4</i> . Check the condensation outlet hose, if applicable (kink).
● The  symbol and Start/Stop indicator light are flashing.	Clean the air cooler → <i>Page 6 "Cleaning and care"</i> . Clean the fluff filter → <i>Page 4</i> .
● The  symbol flashes.	Is the water tank empty? Filling with distilled water → <i>Page 9</i> . The filter in the water tank may have become dirty. If so, clean the filter in the water tank → <i>Page 4</i> .
● The Steam Drying - Steam Refresh does not start.	Is the water tank empty? Filling with distilled water → <i>Page 9</i> . The filter in the water tank may have become dirty. If so, clean the filter in the water tank → <i>Page 4</i> .
● Dryer does not start.	Has the Start/Stop button been pressed? Is the door closed? Programme set? Ambient temperature greater than 5°C?
● Water is leaking out.	Make sure the dryer is level. Clean the air cooler seal.
● The door opens by itself.	Push the door closed until you hear it click into place.
● Items crease even though the Steam Drying - Steam Refresh programme has been selected.	Laundry load exceeded? Remove articles of clothing immediately after the end of the programme, hang up and pull into shape. Unsuitable programme selected → <i>Page 7</i> .
● Laundry is not dried correctly or is still too damp.	After the end of the programme, warm laundry feels damper than it actually is. Spread the laundry out and allow the heat to disperse. Finely adjust the dryness level – this extends the drying time but does not increase the temperature. Your laundry will become drier. Select a programme with a longer drying time or increase the drying level. This does not increase the temperature. Select a time programme for extended drying of laundry that is still damp. If you have exceeded the maximum load for the programme, the laundry may not be dried correctly. Clean the moisture sensor in the drum. A fine layer of limescale may adversely affect the performance of the sensors and your washing will not dry properly. Drying has been interrupted as a result of a power cut, because the condensate container is full or because the maximum drying time has been exceeded.
● Drying time too long.	Rinse the fluff filters under running water → <i>Page 4</i> . Insufficient supply of air → ensure that air can circulate. Air inlet possibly blocked → Clear inlet → <i>Page 10</i> . Ambient temperature higher than 35°C → ventilate the room.
● The humidity in the room increases significantly.	Make sure the room is sufficiently ventilated.
● Power failure.	Remove laundry from the dryer immediately and spread out. This allows the heat to dissipate. Be careful as the door, the drum and the laundry may be hot.
● One or more programme status indicator lamps are flashing.	Clean the filter and air cooler under running water → <i>Page 4/6</i> . Check the installation conditions → <i>Page 10</i> . Switch off, allow to cool, switch on again and restart the programme.
● The interior light (depending on the model) does not work.	Unplug the appliance plug, fold back the cover cap on the inside above the door (using a Torx 20 screwdriver) and replace the bulb. Close the cover cap.

Safety instructions




Emergency	– Pull the appliance plug out of the socket immediately or disconnect the fuse.
ONLY use the dryer...	– in rooms inside the house. – for drying or unwrinkling/refreshing fabrics.
The dryer must NEVER...	– be used for purposes other than those described above. – be modified in terms of its technology or properties.
Hazards	– The dryer must not be used by children or persons who have not been instructed in its use. – Do not leave children unsupervised near the dryer. – Keep pets away from the dryer. – Remove all objects from pockets, and lighters in particular → risk of explosion . – Do not lean or sit on the door → risk of tipping . – Open the door carefully. Hot steam may escape. The clothes and drum may be hot → risk of burns .
Installation	– Secure loose leads or hoses, otherwise there is a risk of tripping . – Below 0°C there is a possibility of frost damage.
Mains connection	– Connect the dryer according to specifications to an AC earthed socket, otherwise it cannot be guaranteed that the appliance is completely safe. – The cable cross-section must be sufficient. – Only use earth-leakage circuit breakers with the following symbol:  – The appliance plug and socket must be compatible. – Do not use multiple plugs/connectors and/or extension cables. – Do not touch or hold the appliance plug with wet hands → risk of electric shock . – Never pull the appliance plug out of the socket by its cable. – Do not damage the mains lead → risk of electric shock .
Operation	– Only load the drum with laundry. Check the contents before you switch the dryer on. – Do not use the dryer if the laundry has been in contact with solvents, oil, wax, grease or paint (e.g. hair setting spray, nail polish remover, stain remover, cleaning solvent, etc.) → fire/explosion hazard . – The tumble dryer is not to be used if industrial chemicals have been used for cleaning. – Dust (e.g. coal dust, flour) poses a danger: do not use the dryer → explosion hazard . – Do not turn off the dryer until the drying process ends, unless the laundry will be removed quickly and spread out, so that the heat can dissipate. – Do not put laundry containing foamed material/rubber in the dryer → elastic material may be destroyed and the dryer may be damaged due to possible deformation of the foamed material. – Light things, such as long hair, may be sucked into the air inlet of the dryer → Risk of injury . – Final part of a tumble dryer cycle occurs without heat (cool down cycle), to ensure that the items are left at a temperature that ensures that the items will not be damaged. – Switch off the dryer once the programme has ended. – The exterior of the appliance's rear panel becomes very hot during operation. Never touch the hot surface of the appliance's rear panel. Keep children away from the appliance → Risk of burns! – For unwrinkling/refreshing fabrics, use distilled water only. Do not use condensation, tap water or additives. – Distilled/condensation water is not for drinking.
Defect	– Do not use the dryer if it is defective or if you suspect that it is. Repairs must only be carried out by the after-sales service. – Do not use a dryer with a faulty mains lead. To prevent risks, a faulty mains lead must only be replaced by the after-sales service. – Before changing the bulb of the interior light make absolutely sure you have pulled the appliance plug from the socket → risk of electric shock .
Spare parts	– Only use genuine spare parts and accessories for safety reasons.
Disposal	– Dryer: unplug the appliance plug, then cut the mains lead from the appliance. Dispose of the dryer at an approved public disposal facility. – Packaging: keep all packaging out of reach of babies and children. → danger of suffocation . – All materials are environmentally safe and recyclable. Dispose of in an environmentally-responsible manner.



INSTRUCTIONS FOR INSTALLATION AND USE

en



TUMBLE DRYER

