

Built-in oven

[en] INSTRUCTION MANUAL

B58VT68.0B



Table of contents

S _∭ Intended use
Important safety information5General information5Steam5Meat thermometer6Cleaning function6
Causes of damage 6 General information 6 Steam. 7
Environmental protection
Centrol panel9Control panel9Controls9Main menu10Menu for the types of heating10Cooking compartment functions11Water tank11
Accessories
Before using for the first time. 14 Before using for the first time. 14 Initial use 14 Cleaning the cooking compartment. 14 Cleaning the accessories. 14 Image: Note: State of the state
Switching the appliance on and off
Steam16Noise16VarioSteam – Steam-assisted cooking.16Dough proving setting17Reheating.17Filling the water tank17After every steam operation18

Time-setting options
Setting the timer .19 Setting the cooking time .20 Start delay – "Ready at" .20 Checking, changing or deleting settings .20
Childproof lock. 20 Automatic childproof lock. 20 One-time childproof lock. 21
Basic settings21Changing MyProfile.21List of basic settings.21Setting favourites.22
A Baking and roasting assistant22Information on the settings.22Selecting a meal.22Selecting and setting food.23
Programmes23Information on the settings.23Selecting a dish.23Setting a programme.24
Meat thermometer24Suitable types of heating
Sabbath mode26Starting the Sabbath mode.26Cancelling Sabbath mode.26
Cleaning agent 26 Suitable cleaning agents .26 Keeping the appliance clean .27
Cleaning function.28Self-cleaning28EasyClean.29Descaling30
Rails. 31 Changing the shelf position for the telescopic rail31 Detaching and refitting the rails31
Appliance door32Removing and fitting the appliance door

Trouble shooting	6
Fault table	3
Maximum operating time exceeded	7
Cooking compartment bulbs	7
Customer service	8
E number and FD number	
Tested for you in our cooking studio	3
Silicone moulds	3
Baking	
Roasting and braising4	
Grilling	5
Convenience products	
Yogurt	
Eco types of heating50	
Acrylamide in foodstuffs5	
Slow cook	
Drying	
Preserving	1
Allowing the dough to prove at dough proving	_
setting	
Defrosting	
Reheating	
Keeping warm	
Test dishes	1

Additional information on products, accessories, replacement parts and services can be found at **www.neff-international.com** and in the online shop **www.neff-eshop.com**

See Intended use

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 2000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 15 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment the right way round.

 \rightarrow "Accessories" on page 12

Important safety information

General information

▲ Warning – Risk of fire!

- Combustible items stored in the cooking compartment may catch fire. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug it from the mains or switch off the circuit breaker in the fuse box.
- Loose food remnants, fat and meat juices may catch fire. Before using the appliance, remove the worst of the food remnants from the cooking compartment, heating elements and accessories.
- A draught is created when the appliance door is opened. Greaseproof paper may come into contact with the heating element and catch fire. Do not place greaseproof paper loosely over accessories during preheating. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. Greaseproof paper must not protrude over the accessories.

\Lambda Warning – Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.

Marning – Risk of scalding!

- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

 Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

Marning – Risk of injury!

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.

Marning – Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the aftersales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

Marning – Hazard due to magnetism!

Permanent magnets are used in the control panel or in the control elements. They may affect electronic implants, e.g. heart pacemakers or insulin pumps. Wearers of electronic implants must stay at least 10 cm away from the control panel.

Steam

▲ Warning – Risk of scalding!

- The water in the water tank may become very hot if you continue to operate the appliance. Empty the water tank after every operation with steam.
- Hot steam is generated in the cooking compartment. Do not reach into the cooking compartment during any operation with steam.

 Hot liquid may spill over the sides of the accessory when it is removed from the cooking compartment. Remove hot accessories with care and always wear oven gloves.

Marning – Risk of injury and risk of fire!

Flammable liquids can catch fire in the cooking compartment when it is hot (explosion). Do not fill the water tank with any flammable fluids (e.g. alcoholic drinks). Only fill the water tank with water or with the descaling solution that is recommended by us.

Meat thermometer

Marning – Risk of electric shock!

The insulation of an incompatible meat thermometer may be damaged. Only use the meat thermometer which is recommended for this appliance.

Cleaning function

Marning – Risk of fire!

- Loose food residues, grease and meat juices may catch fire during the cleaning function. Before starting the cleaning function, remove coarse dirt from the cooking compartment and from the accessories.
- The appliance will become very hot on the outside during the cleaning function. Never hang combustible objects, e.g. tea towels, on the door handle. Do not place anything against the front of the appliance. Keep children away from the appliance.

Warning – Risk of serious damage to health!

The appliance will become very hot during the cleaning function. The non-stick coating on baking trays and tins is destroyed and noxious gases are released. Never clean non-stick baking trays and baking tins using the cleaning function. Only clean enamelled accessories using the cleaning function.

Marning – Risk of burns!

- The cooking compartment becomes extremely hot during the cleaning function. Never open the appliance door. Allow the appliance to cool down. Keep children away from the appliance.
- The appliance will become very hot on the outside during the cleaning function. Never touch the appliance door. Allow the appliance to cool down. Keep children away from the appliance.

Causes of damage

General information

Caution!

- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor if a temperature of over 50 °C has been set. This will cause heat to accumulate. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Aluminium foil: Aluminium foil in the cooking compartment must not come into contact with the door glass. This could cause permanent discolouration of the door glass.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the enamel.
- Moisture in the cooking compartment: Over an extended period of time, moisture in the cooking compartment may lead to corrosion. Allow the cooking compartment to dry after use. Do not keep moist food in the closed cooking compartment for extended periods of time. Do not store food in the cooking compartment.
- Cooling with the appliance door open: Following operation at high temperatures, only allow the cooking compartment to cool down with the door closed. Do not trap anything in the appliance door. Even if the door is only left open a crack, the front of nearby furniture may become damaged over time. Only leave the cooking compartment to dry with the door open if a lot of moisture was produced whilst the oven was operating.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Extremely dirty seal: If the seal is very dirty, the appliance door will no longer close properly during operation. The fronts of adjacent units could be damaged. Always keep the seal clean.
- Appliance door as a seat, shelf or worktop: Do not sit on the appliance door, or place or hang anything on it. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.

Steam

Caution!


- Baking tins: Ovenware must be heat and steam resistant. Silicone baking tins are not suitable for combined operation with steam.
- Ovenware with areas of rust: Do not use any ovenware which displays areas of rust. Even the smallest spots of rust can lead to corrosion in the cooking compartment.
- Dripping liquids: When steaming with a perforated cooking container, always insert the baking tray, the universal pan or the solid cooking container underneath. Dripping liquid is caught.
- Hot water in the water tank: Hot water can damage the pump. Only fill the water tank with cold water.
- Enamel damage: Do not start any operations when there is water on the cooking compartment floor.
 Before operation, wipe away the water from the cooking compartment floor.
- Descaling solution: Do not allow any descaling solution to come into contact with the control panel or other surfaces on the appliance. This damages the surfaces. If this does happen, remove the descaling solution immediately with water.
- Cleaning the water tank: Do not clean the water tank in the dishwasher. Otherwise, the water tank will be damaged. Clean the water tank with a soft cloth and standard washing-up liquid.

Environmental protection


Your new appliance is particularly energy-efficient. Here you can find tips on how to save even more energy when using the appliance, and how to dispose of your appliance properly.


Saving energy

- Only preheat the appliance if this is specified in the recipe or in the tables in the operating instructions.
- Leave frozen food to defrost before placing it in the cooking compartment.




 Use baking tins that are dark-coloured, painted black or have an enamel coating. These absorb the heat particularly well.






 Remove any unnecessary accessories from the cooking compartment.






 Open the appliance door as infrequently as possible when the appliance is in use.



It is best to bake several cakes one after the other. The cooking compartment stays warm. This reduces the baking time for the second cake. You can place two cake tins next to each other in the cooking compartment.



 For longer cooking times, you can switch the appliance off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment -WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Getting to know your appliance

In this chapter, we will explain the indicators and controls. You will also find out about the various functions of your appliance.

Note: Depending on the appliance model, individual details and colours may differ.

Control panel

In the control panel, set your appliance's different functions using the FullTouch TFT display. The current settings are shown on the FullTouch TFT display.



 $\left[1 \right]$

Controls

Use the controls to set your appliance simply and directly.

Touch buttons

There are sensors under the touch buttons. Touch on the corresponding touch button to select a function.

Touch	button	Use
0	on/off	Switching the appliance on or off \rightarrow "Switching the appliance on and off" on page 15
}}	Steam-assisted cook- ing	Switching on steam-assisted cooking → "VarioSteam – Steam-assisted cooking" on page 16
Θ	Time-setting options	Setting the timer, cooking time, or "Ready at" start delay \rightarrow "Time- setting options" on page 19
	Childproof lock	Activating or deactivating the child- proof lock \longrightarrow "Childproof lock" on page 20
	Main menu	Selecting operating modes and settings \rightarrow "Setting and starting the appliance operation" on page 15

8≋	8 Rapid heating €	Activating or deactivating rapid heat- ing \rightarrow "Heating up the appliance quickly" on page 16
		Activating or deactivating Power- Boost \rightarrow "Heating up the appliance quickly" on page 16
ĩ	Information	Displaying further information Displaying the current temperature \rightarrow "Setting and starting the appliance operation" on page 15
1	Open cover	Filling or emptying the water tank → "Filling the water tank" on page 17
⊳II	Start/Stop	Starting or stopping the operation \rightarrow "Setting and starting the appliance operation" on page 15

FullTouch TFT display

With the FullTouch TFT display, you can navigate through the lines and select settings.

To adjust a setting, touch the appropriate point on the display using your finger. The area is displayed more brightly. With your finger touching this area of the display, swipe to the left or right until the required setting is displayed larger.

Direction	Use
Navigate to the left	On the display, use your finger to swipe to the right
Navigate to the right	On the display, use your finger to swipe to the left

Direction	Use
Navigate upwards	Touch the top line of the display
Navigate downwards	Touch the bottom line of the display

Main menu

Touch the $\widehat{\mbox{ }}$ touch button to access the main menu.

Menu	Use
Ū	Types of heating Selecting the required type of heating and tempera- ture for your dish \rightarrow "Switching the appliance on and off" on page 15
Î	Baking and roasting assistant Recommended settings for baking and roasting → "Baking and roasting assistant" on page 22

P.	Steam programmes Preparing dishes with steam → "Programmes" on page 23
0 69	MyProfile Individually adjusting the appliance settings → "Basic settings" on page 21
~~~	Descale
<u> </u>	Drying Drying the cooking compartment after a steam opera- tion $\rightarrow$ "After every steam operation" on page 18
0	EasyClean Cleaning light soiling from the cooking compartment — "Cleaning function" on page 28
***	Pyrolytic self-cleaning Clean the cooking compartment. $\rightarrow$ "Cleaning function" on page 28

# Menu for the types of heating

Your appliance has different types of heating. After switching on the appliance, you are taken directly to the menu for the types of heating.

CircoTherm * 40 - 200 °C For baking and cooking on one or more levels. The fan distributes the heat from the ring heating eler evenly around the cooking compartment.	ment in the back panel
Top/bottom heating * 50 - 275 °C For traditional baking and roasting on one level. Especimiest toppings. Heat is emitted evenly from the top and bottom.	cially suitable for cakes with
Circo-roasting * 50 - 250 °C For roasting poultry, whole fish and larger pieces of m The grill element and the fan switch on and off alterna hot air around the food.	
Circotherm intensive 50 - 275 °C For preparing pizza and dishes which require a lot of I The bottom heating element and the ring heating element up.	
Bread-baking * 180 - 240 °C For baking bread, bread rolls and baked items that re	quire high temperatures.
Full-surface grill50 - 290 °CFor grilling flat items, such as steaks or sausages, for tin dishes. The whole area below the grill element becomes hot.	
Centre-area grill       50 - 290 °C       For grilling small amounts of steaks or sausages, for r tin dishes.         The centre area under the grill heating element become       The centre area under the grill heating element become	
Bottom heat 50 - 250 °C For cooking in a bain marie and for the final baking st The heat is emitted from below.	age.
Low temperature cooking 70 - 120 °C For gentle and slow cooking of seared, tender pieces of a lid. The heat is emitted evenly from the top and bottom at	
Dough proving ** 2 levels For leaving yeast dough and sourdough to prove and Dough will prove more quickly than at room temperat dough does not dry out.	0, 0
<b>★</b> Defrost setting30 - 60 °CFor gently defrosting frozen food.	
Plate warming 30-70 °C For preheating ovenware.	

$\bigcirc$	Keep warm *	60 - 100 °C	For keeping cooked food warm.
eco	Top/bottom heating eco	50-275 °C	For gentle cooking of selected dishes. The heat is emitted from above and below.
eco	CircoTherm eco	40 - 200 °C	For gentle cooking of selected dishes on one level without preheating. The fan distributes the heat from the ring heating element in the back panel around the cooking compartment.
	Reheat **	80 - 180 °C	For gently reheating food or for crisping up pastries.
* Possible to use steam for this type of heating (operation only possible when the water tank is full)			

** Type of steam heating (operation only possible when the water tank is full)

#### **Cooking compartment functions**

The functions in the cooking compartment make your appliance easier to use. This, for example, enables the cooking compartment to be well lit and a cooling fan to prevent the appliance from overheating.

#### Opening the appliance door

If you open the appliance door during an operation, the operation is paused. The operation continues to run when you close the door.

**Note:** For some types of heating, the operation continues to run even when the appliance door is open.

#### **Interior lighting**

If you open the appliance door, the interior lighting switches on. If the door remains open for longer than around 15 minutes, the lighting switches off again.

For most operating modes, the interior lighting switches on as soon as the operation is started. When the operation has finished, the lighting switches off.

**Note:** You can set the interior lighting not to come on during the operation in the basic settings.  $\rightarrow$  "Basic settings" on page 21

#### Cooling fan

The cooling fan switches on and off as required. The hot air escapes above the door.

#### Caution!


Do not cover the ventilation slots. Otherwise, the appliance may overheat.


So that the cooking compartment cools down more quickly after the operation, the cooling fan continues to run for a certain period afterwards.

**Note:** You can change how long the cooling fan continues to run for in the basic settings.  $\rightarrow$  "Basic settings" on page 21

#### Water tank

The appliance is fitted with a water tank. The water tank is behind the panel. For operations with steam, fill the water tank with water.  $\rightarrow$  "Steam" on page 16





1 Tank cover

2 Filling opening

3 Handle for removing and inserting the water tank

# Accessories

Your appliance is accompanied by a range of accessories. Here, you can find an overview of the accessories included and information on how to use them correctly.

# Accessories included

Your appliance is equipped with the following accessories:

#### Wire rack

Universal pan

For ovenware, cake tins and ovenproof dishes.

For roasts, grilled items and frozen meals.

For moist cakes, pastries, frozen meals and large roasts.

It can be used to catch dripping fat when you are grilling directly on the wire rack.

Meat thermometer

Enables precision roasting to your exact requirements.

Its use is described in the relevant section.  $\rightarrow$  "Meat thermometer" on page 24



#### Accessory supports

You can use these if you wish to leave an accessory (e.g. the universal pan) in the cooking compartment for cleaning by the self-cleaning function.

Only use genuine accessories. They are specially adapted for your appliance.

You can buy accessories from the after-sales service, from specialist retailers or online.

**Note:** The accessories may become deformed when they become hot. This does not affect their function. Once they cool down again, they regain their original shape.


# **Inserting accessories**

The cooking compartment has four shelf positions. The shelf positions are counted from the bottom up.

In some appliances, the top shelf position in the cooking compartment features a grill symbol.

# Marning – Risk of burns!


The telescopic shelves become hot when the appliance is in use. Take special care not to get burnt when they are pulled out.




The accessories can be pulled out approximately halfway without tipping. You can use the pull-out rails to pull the accessories out further.

Ensure that the accessory is placed under the lug **a** on the pull-out rail.

Example in the picture: Universal pan



Accessories on the telescopic shelf can be pulled out as far as the notch **b** (fig. **1**). Hold the accessory on both sides in the area marked **c** and remove it (fig. **2**).




#### Notes

- Ensure that you always insert the accessories into the cooking compartment the right way round.
- Always insert the accessories fully into the cooking compartment so that they do not touch the appliance door.


#### Locking function

The accessories can be pulled out approximately halfway until they lock in place. The locking function prevents the accessories from tilting when they are pulled out. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

When inserting the wire rack, ensure that the lug **a** is facing downwards.




When inserting baking trays, ensure that the lug  ${\bf b}$  is at the rear and is facing downwards. The sloping edge of the accessory  ${\bf c}$  must be facing towards the appliance door.



## **Combining accessories**

You can insert the wire rack and the universal pan at the same time to catch drops of liquid.

When inserting the wire rack, ensure that both spacers **a** are at the rear edge. When the universal pan is inserted, the wire rack is on top of the upper guide rod of the shelf position.



# **Optional accessories**

You can purchase optional accessories from the aftersales service and specialist retailers, or on the Internet. You will find a comprehensive range of products for your appliance in our brochures and on the Internet.

Both availability and whether it is possible to order online differ between countries. Please see your sales documents for more details.

Note: Not all optional accessories are suitable for every appliance. When purchasing, please always quote the exact designation (E no.) of your appliance. → "Customer service" on page 38

#### Accessories

Accessones
Baking and roasting shelf
Baking tray, suitable for pyrolytic cleaning
Universal pan, suitable for pyrolytic cleaning
Extra-deep pan, suitable for pyrolytic cleaning
Steaming set for ovens
Profi pan, suitable for pyrolytic cleaning
Lid for the Profi pan
Pizza tray
Grill tray, suitable for pyrolytic cleaning
Bread-baking stone, suitable for pyrolytic cleaning
Glass roasting dish, 5.1 litres
Glass pan
ComfortFlex shelf (1 level) + frame*
ComfortFlex rail (1 level)*
3 x fully extendable pull-out rack*
*Accessory does not fit in every appliance, quote the E no. when order- ing

# Before using for the first time

Before you can use your new appliance, you must make some settings. You must also clean the cooking compartment and accessories.

# Before using for the first time

Before using the appliance for the first time, enquire about the water hardness of your tap water from your water supplier.

So that the appliance can reliably remind you to decalcify it when required, you must correctly set your water hardness range.

#### Caution!

The appliance may be damaged if unsuitable liquids are used.

Do not use distilled water, highly chlorinated tap water (>40 mg/l) or other liquids.

Only use cold, fresh tap water, softened water or uncarbonated mineral water.

#### Notes

- If your water is very hard, we recommend that you use softened water.
- If you only use softened water, you can set the water hardness range to "softened" in this case.
- If you use mineral water, set the water hardness range to "4 very hard".
- If you use mineral water, only use uncarbonated mineral water.

Water hardness range	Setting
0	0 softened
1 (up to 1.3 mmol/l)	1 soft
2 (1.3 - 2.5 mmol/l)	2 medium
3 (2.5 - 3.8 mmol/l)	3 hard
4 (above 3.8 mmol/l)	4 very hard

# Initial use

As soon as the appliance is connected to the power supply, the first setting "Language" appears on the display.

#### Setting the language

- 1. Touch the bottom line.
- 2. Swipe to the left or right to select the required language.
- 3. Touch the top line.

#### Setting the time

- 1. Touch "Clock".
- 2. Touch the bottom line.
- **3.** Swipe to the left or right to select the current hour.
- 4. Touch "Minutes".
- 5. Swipe to the left or right to select the current minute.
- **6.** Touch the  $\square$  symbol to apply the setting.

#### Setting the date

- 1. Touch "Date".
- 2. Touch the bottom line.
- 3. Swipe to the left or right to select the current day.
- 4. Touch "Month".
- 5. Swipe to the left or right to select the current month.
- 6. Touch "Year".
- 7. Swipe to the left or right to select the current year.
- **8.** Touch the  $\Box$  symbol to apply the setting.

#### Setting the water hardness

- 1. Touch "Water hardness".
- 2. Touch the bottom line.
- **3.** Swipe to the left or right to select the appropriate water hardness.
- Touch the symbol to complete the initial use. The initial use is complete.

#### Notes

- You can change these settings at any time in the basic settings. → "Basic settings" on page 21
- After connecting the appliance to the power or following a power cut, the settings for initial use are shown in the display.

### Cleaning the cooking compartment

To remove the new-appliance smell, heat up the cooking compartment when it is empty and with the oven door closed.

- **1.** Remove the accessories from the cooking compartment.
- 2. Remove leftover packaging, such as polystyrene pellets, from the cooking compartment.
- **3.** Before heating the appliance, wipe the smooth surfaces in the cooking compartment with a soft, wet cloth.
- **4.** Use the ① touch button to switch on the appliance.
- 5. Fill the water tank.  $\rightarrow$  "Filling the water tank" on page 17
- 6. Set the heating type, temperature and steamassisted cooking, then start the appliance operation.
   → "VarioSteam - Steam-assisted cooking" on page 16

#### Settings

Heating type	Top/bottom heating $\equiv$ with steam-assisted cooking $\gtrless$ ("low" intensity)
Temperature	240 °C
Cooking time	1 hour

- 7. Keep the kitchen ventilated while the appliance is heating up.
- Use the ① touch button to switch off the appliance after the indicated cooking time.
- **9.** Wait until the cooking compartment has cooled down.
- **10.** Clean the smooth surfaces with soapy water and a dish cloth.
- 11. Empty the water tank and dry the cooking compartment. → "After every steam operation" on page 18

### **Cleaning the accessories**

Clean the accessories thoroughly using soapy water and a dish cloth or soft brush.

# Operating the appliance

You have already learnt about the controls and how they work. Now we will explain how to set your appliance. You will learn about what happens when you switch the appliance on and off, and how to select the operating mode.

# Switching the appliance on and off

To switch the appliance on or off, touch the touch button.

After the appliance has switched off, the display shows whether the residual heat in the cooking compartment is high or low.

Display	Temperature
Residual heat high	above 120 °C
Residual heat low	between 60 °C und 120 °C

#### Notes

- Certain indicators and instructions (e.g. about residual heat in the cooking compartment) remain visible on the display even when the appliance is switched off.
- After the appliance has completed an operation, you will hear the cooling fan continuing to run until the cooking compartment is cooled as much as possible.
- Switch off your appliance when you do not need to use it. If no settings are made for a long time, the appliance switches off automatically.

# Setting and starting the appliance operation

Example: & CircoTherm hot air at 170 °C

1. Touch the ① touch button to switch on the appliance.

You go directly to the  $\square$  Types of heating menu.



- 2. Swipe to the left or right to select the type of heating.
- 3. Touch the bottom line.
- 4. Swipe to the left or right to select the temperature.



 Touch the ▷|| touch button to start the appliance operation. The heat-up indicator bar and the run time appear in the display.

**Note:** If you want to go directly to the  $\bigcirc$  main menu when you switch on the appliance, you can find instructions on how to do this in the Basic settings chapter under "Operation after switching on".

#### **Default values**

The appliance suggests a temperature or setting for each type of heating. You can accept this value or change it in the appropriate area.

#### Heating bar

As soon as a type of heating has started, the heating bar appears on the display. The heating bar shows the temperature increase in the cooking compartment.

#### Run time

When a type of heating has been started, the run time is displayed. The run time counts upwards during the operation. You can therefore check how long the operation has already been running.

#### Displaying the current temperature

To show the current temperature on the display, press the  $\underline{\$}$  touch button.

The current temperature is shown briefly only when heating up.

#### **Further information**

If the  $\frac{3}{2}$  touch button lights up, information can be displayed. Touch the  $\frac{3}{2}$  touch button to do this. The information is displayed for a few seconds.

# Changing or cancelling the appliance operation

#### Changing the appliance operation

- **1.** Use the || button to stop the operation.
- 2. Tap the line for the setting that should be changed.
- **3.** Swipe to the left or right to change the setting.
- **4.** Use the ▷|| touch button to start the changed operation.

#### Notes

- The cooling fan may continue to run while an operation is interrupted.
- After a temperature change, the paused running time continues to count. After a change in the type of heating, the running time starts again from zero.

#### Cancelling the appliance operation

Press and hold the || touch button until the appliance operation is cancelled.

**Note:** Operating modes such as the cleaning function cannot be cancelled.

# Heating up the appliance quickly

You can use the "Rapid heat-up" and "PowerBoost" functions to reduce the preheat time. Whether the appliance is preheated with the "Rapid heat-up" function or the "PowerBoost" function depends on the type of heating that has been set. With the "PowerBoost" function, unlike with the "Rapid heat-up" function, you can place your food into the cold cooking compartment even before preheating has begun. Only cook on one level when using the "PowerBoost" function.

Function	Type of heating	Place the food in the cooking compartment
Rapid heat-up	Top/bottom heating $\overline{\equiv}$	after preheating
PowerBoost*	CircoTherm hot air 😞	before preheating
	Bread-baking setting 🕮	
* Do not use more thar	n one level for cooking	

#### Notes

- If the light touch button is lit, the "Rapid heat-up" or "PowerBoost" function can be activated.
- To deactivate the "Rapid heat-up" or "PowerBoost" function before it has finished, touch the 🗟 touch button.

#### Activating the "Rapid heat-up" function

- Set top/bottom heating = and the temperature. Note: Set a temperature above 100 °C to allow the appliance to preheat guickly.
- 2. Touch the ▷|| touch button to start the appliance operation.
- 3. Touch the li touch button to activate the "Rapid heat-up" function.
- The & symbol appears on the display.
- 4. Once the set temperature has been reached, the "Rapid heat-up" function switches itself off automatically. The li symbol disappears from the display. Place the food in the cooking compartment

#### Activating the "PowerBoost" function

- Set CircoTherm hot air & or the bread baking setting and the temperature.
   Note: Set a temperature above 100 °C to allow the appliance to preheat quickly.
- 2. Place the food on a single level in the cooking compartment.
- Touch the ▷|| touch button to start the appliance operation.
- 4. Touch the å touch button to activate the "PowerBoost" function.

The & symbol appears on the display. Once the set temperature has been reached, the "PowerBoost" function switches itself off automatically. The & symbol disappears from the display.

# 🙈 Steam

With some heating modes, you can prepare food with steam assistance. In addition, the Dough proving and Reheat heating modes are available.

#### Marning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

#### Noise

#### Pump

You will hear a humming noise while the pump is in operation and after switching it off. This noise is caused by the pump function test. It is a normal operating noise.

#### **Control panel**

You will hear a humming or clicking noise when opening the control panel. These noises are caused by the control panel being pushed out. They are normal operating noises.

## VarioSteam – Steam-assisted cooking

When you cook with steam assistance, steam is introduced into the cooking compartment at various intervals and with varying degrees of intensity. This gives you a better cooking result.

Your food

- Becomes crispy on the outside
- Develops a shiny surface
- Is succulent and tender on the inside
- Only undergoes a minimum reduction in volume

You set the combination of heating mode and steam intensity that you want. Use the information in the tables to select a suitable heating mode and steam intensity. Alternatively, select a program from the steam programs.  $\rightarrow$  "Tested for you in our cooking studio" on page 38 $\rightarrow$  "Programmes" on page 23

#### Steam intensity

Different intensity levels are available when adding steam:

- Low
- Medium
- High

#### Suitable heating modes

You can switch on steam assistance for these heating modes:

- CircoTherm hot air &
- Top/bottom heating
- Circo-roasting L
- Bread-baking
- Keeping warm ⊕

#### Starting

- **1.** Touch the  $\bigcirc$  touch button.
- 2. Fill the water tank.
- **3.** Set the type of heating and temperature.
- 4. Touch the 送 touch button to switch on steam assistance.
- **5.** On the display, swipe to the left or right to select the steam intensity.
- **6.** Touch the  $\square$  symbol to apply the setting.
- **7.** Touch the || touch button.
  - The appliance starts the operation.

**Note:** If the water tank runs dry during an operation with steam assistance, a message appears on the display prompting you to fill up the water tank.

#### Cancelling steam addition

- 1. Touch the  $\gtrless$  touch button to cancel the addition of steam early.
- 2. Touch the set added steam in the bottom line.
- **3.** On the display, swipe to the left or right to select "Off".
- **4.** Touch the  $\square$  symbol to apply the setting.

Note: The operation continues without adding steam.

#### **Cancelling appliance operation**

Press and hold the || touch button until the appliance operation is cancelled.

#### Finishing

Touch the ① touch button to switch the appliance off.

# **Dough proving setting**

Dough will prove considerably more quickly using the "Dough proving ⊖" heating mode than at room temperature and does not dry out.

There are two levels available for the Dough proving setting. Use the information in the tables to select the appropriate level.  $\rightarrow$  "Tested for you in our cooking studio" on page 38

**Note:** If the water tank runs dry during operation with the Dough proving setting, operation is interrupted. Fill the water tank.

#### Starting

- 1. Touch the ① touch button.
- Fill the water tank.
   Note: Only switch on the Dough proving setting once the cooking compartment has completely cooled down (to room temperature).
- 3. Swipe to the left or right to select "Dough proving".
- **4.** Touch "1" in the bottom line.
- 5. Swipe to the left or right to select the required level.
- **6.** Touch the  $\square$  symbol to apply the setting.
- **7.** Touch " $\rightarrow$ " in the bottom line.
- **8.** Swipe to the left or right to select the required duration.
- **9.** Touch the  $\Box$  symbol to apply the setting.
- **10.** Touch the ▷|| touch button. The appliance starts the operation.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the () touch button to end the audible signal.

#### Cancelling

Press and hold the  $|{\boldsymbol{\varphi}}||$  touch button until the appliance operation is cancelled.

#### Finishing

Touch the ① touch button to switch the appliance off.

### Reheating

With the "Reheat "" heating mode, you can gently reheat food that has already been cooked or crisp up day-old baked goods. Steam is switched on automatically.

**Note:** If the water tank runs dry during operation with the Reheat setting, operation is interrupted. Fill the water tank.

#### Starting

- **1.** Touch the ① touch button.
- 2. Fill the water tank.
- **3.** Swipe to the left or right to select "Reheat  $\underline{\textcircled{B}}$ ".
- Touch the temperature in the bottom line.
   Swipe to the left or right to select the required
- temperature.
- **6.** Touch the  $\begin{subarray}{c} \end{subarray}$  symbol to apply the setting.
- 7. Touch " $\rightarrow$ " in the bottom line.
- **8.** Swipe to the left or right to select the required duration.
- **9.** Touch the  $\boxtimes$  symbol to apply the setting.
- **10.** Touch the *b*|| touch button. The appliance starts the operation.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the () touch button to end the audible signal.

#### Cancelling

Press and hold the || touch button until the appliance operation is cancelled.

#### Finishing

Touch the touch button to switch the appliance off.

#### Filling the water tank

The water tank is located behind the control panel. Before starting an operation with steam, open the control panel and fill the water tank with water.

Make sure that you have set the water hardness range correctly.  $\rightarrow$  "Basic settings" on page 21

#### Marning – Risk of injury and risk of fire!

Only fill the water tank with water or with the descaling solution that is recommended by us. Do not pour any flammable liquids (e.g. alcoholic drinks) into the water tank. Due to hot surfaces, vapours from flammable liquids may catch fire in the cooking compartment (explosion). The appliance door may spring open. Hot steam and jets of flame may escape.

#### Marning – Risk of burns!

The water tank may heat up while the appliance is in operation. Wait until the water tank has cooled down after the previous appliance operation. Remove the water tank from the water tank recess.

#### Caution!


The appliance may become damaged due to the use of unsuitable liquids.

Do not use distilled water, highly chlorinated tap water (> 40 mg/l) or other liquids.


Only use cold, fresh tap water, softened water or uncarbonated mineral water.

#### Notes


- If your water is very hard, we recommend that you use softened water.
- If you use only softened water, you can set your appliance to the "softened" water hardness range.
- If you use mineral water, set the water hardness range to "4 very hard".
- If you use mineral water, you must only use noncarbonated mineral water.
- **1.** Touch the  $\square$  touch button.
- The control panel is automatically pushed forwards. **2.** Pull the control panel forwards with both hands and
- then push it upwards until it locks into place (fig. **1**). **3.** Lift the water tank and remove it from the water tank



- **4.** Press down on the lid along the seal to prevent water from leaking out of the water tank.
- 5. Remove the cover **a** (fig. 3).
- Fill the water tank with cold water up to the "max." mark (fig. 4).



- 7. Reinsert the cover **a** into the opening in the water tank.
- Insert the filled water tank (fig. 5). Ensure that the water tank locks into place behind both holders b (fig. 6).



 Slowly push the control panel downwards and then towards the rear until it is closed completely. The water tank has been filled. You can start operations with steam.

#### Refilling the water tank

#### Notes

- Steam-assisted operations continue without adding steam.
- If the water tank runs dry during operation with the Dough proving or Reheat settings, operation is interrupted. Fill the water tank.
- 1. Open the control panel.
- 2. Remove and refill the water tank.
- **3.** Insert the filled water tank and close the control panel.

# After every steam operation

### Marning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

### Marning – Risk of burns!

The appliance becomes hot during operation. Allow the appliance to cool down before cleaning.

#### Caution!

Enamel damage: Do not start any operations when there is water on the cooking compartment floor. Before operation, wipe away the water from the cooking compartment floor.

The remaining water is pumped back into the water tank after every operation with steam. Then empty and dry the water tank. Moisture remains in the cooking compartment. To dry the cooking compartment, you can either use the "Drying \\\" operating mode or dry the cooking compartment by hand.

#### Notes

- Once the appliance has been switched off, the touch button remains lit for a little longer to remind you to empty the water tank.
- Remove limescale marks with a cloth soaked in vinegar, then wipe with clean water and dry with a soft cloth.

#### Emptying the water tank

#### Caution!

- Do not dry the water tank in the hot cooking compartment. This will damage the water tank.
- Do not clean the water tank in the dishwasher. This will damage the water tank.
- 1. Open the control panel.
- 2. Remove water tank.
- **3.** Carefully remove the lid of the water tank.
- 4. Empty the water tank, clean it with detergent and then rinse it thoroughly with clean water.
- 5. Dry all parts with a soft cloth.
- 6. Rub the seal on the lid until dry.
- 7. Leave to dry with the lid open.
- 8. Place the lid on the water tank and push it down.
- 9. Insert the water tank and close the control panel.

#### Starting drying

To dry the cooking compartment, it is heated up so that the moisture in the cooking compartment evaporates. You will then need to open the appliance door to allow the steam to escape from the cooking compartment.

#### Caution!

Enamel damage: Do not start any operations when there is water on the cooking compartment floor. Before operation, wipe away the water from the cooking compartment floor.

- **1.** Allow the appliance to cool down.
- 2. Remove the worst of the food remnants from the cooking compartment immediately and use a sponge to wipe away moisture from the cooking compartment floor.
- **3.** If necessary, touch the ① touch button to switch the appliance on.
- **4.** Touch the  $\bigcirc$  field to display the operating modes.
- On the touch display, swipe to the left or right to select "Dry \\\".
- 6. Touch the line at the bottom.
- The duration will be displayed. It cannot be changed. **7.** Touch the line at the bottom.
- Touch the ▷|| field. This starts the drying function; it will end automatically after 10 minutes.
- **9.** Open the appliance door and leave it open for 1 to 2 minutes so that the moisture in the cooking compartment can escape.

#### Drying the cooking compartment by hand

- 1. Allow the appliance to cool down.
- 2. Remove any food remnants from the walls of the cooking compartment.
- **3.** Dry the cooking compartment with a sponge.
- 4. Leave the appliance door open for 1 hour so that the cooking compartment dries completely.

# Time-setting options

Your appliance has different time-setting options.

Time-setting option		Use
Ĉ	Timer	The timer functions like an egg timer. The appliance does not switch on and off auto- matically.
→	Cooking time	Once the set cooking time has elapsed, the appliance switches off automatically.
$\rightarrow$	Ready at	The appliance switches on automatically, and once the set cooking time has elapsed and the end time has passed, it switches off automatically.

**Note:** If you have set a time-setting option, the time interval increases if you set a higher value. Example: You can set a cooking time of up to one hour in one-minute increments; for cooking times over one hour, you can set a cooking time in five-minute increments.

# Showing and hiding the time-setting options

To show or hide the time-setting options, touch the touch button.

**Note:** After a particular length of time, the time-setting options that are shown are automatically hidden. If you have already set a cooking time, it will be applied.

$ \rightarrow $	Ĉ	Timer			
$\rightarrow$					

# Setting the timer

The timer can be set when the appliance is switched on or off.

- 1. Touch the 🕒 touch button.
- The time-setting options are shown on the display.
- Swipe to the left or right to select the duration.
   Note: With the appliance switched on, first touch "Q Timer" and then swipe to the left or right to select the duration.
- Touch the ⊕ touch button. The ♀ symbol appears on the display.

Note: As soon as the set time has elapsed, a signal sounds. Touch the touch button to end the audible signal.

# Setting the cooking time

Once the set cooking time has elapsed, the appliance switches off automatically. The function can only be used in combination with a type of heating.

- 1. Touch the ① touch button.
- 2. Set the type of heating and temperature.
- **3.** Touch the () touch button. The time-setting options are shown on the display.
- **4.** Swipe to the left or right to select the cooking time.
- Touch the ▷|| touch button to start the set cooking time.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the () touch button to end the audible signal.

# Start delay - "Ready at"

The appliance switches on automatically and switches off at the preset end time. To do this, set the cooking time and determine the end time for the operation.

The start delay can only be used in combination with a type of heating.

#### Notes

- Ensure that food is not left in the cooking compartment for too long as it may spoil.
- The option to delay the start of operation is not available for every type of heating.
- 1. Place the food onto the appropriate accessory in the cooking compartment and close the appliance door.
- 2. Touch the ① touch button.
- 3. Set the type of heating and temperature.
- Touch the touch button. The time-setting options are shown in the display.
- 5. Swipe to the left or right to select the cooking time.
- **6.** Touch " $\rightarrow$ | Ready at".
- 7. Swipe to the left to select the end time.
- 8. Touch the ▷|| touch button.
- The appliance waits until the appropriate time to start the operation.

As soon as the end time has been reached, an audible signal sounds and the appliance ends the operation automatically. Touch the 🕑 touch button to end the audible signal.

# Checking, changing or deleting settings

- 1. Touch the 🕒 field.
- The time-setting options are shown on the display. **2.** Touch the time-setting option.
- If required, swipe to the left or right in the touch display to change the settings. To delete a timesetting option, set "- - : - -".

The setting is applied automatically.

# Childproof lock

Your appliance is equipped with a childproof lock so that children cannot switch it on accidentally or change any settings.

Your appliance has two different locks.

Lock	Activate/deactivate
Automatic childproof lock	Via the MyProfile menu $\longrightarrow$ "Basic settings" on page 21
One-time childproof lock	Via the 🕒 touch button

**Note:** As soon as you activate the childproof lock, the control panel is locked. The () and () touch buttons are not included. You can deactivate the childproof lock at any time.

# Automatic childproof lock

The control panel is locked so that the appliance cannot be switched on. To switch it on, the automatic childproof lock must be interrupted. After the appliance operation, the control panel is locked automatically.

#### Activation

- **1.** Touch the ① touch button.
- **2.** Touch the  $\bigcirc$  touch button.
- 3. Swipe to the left or right to select "MyProfile".
- 4. Touch the bottom line.
- 5. Swipe to the left or right to select the "Automatic childproof lock".
- **6.** Touch the bottom line.
- 7. Swipe to the left or right to select "Activated".
- **8.** Touch the  $\bigcirc$  touch button.
- Touch "Save". The settings are saved. The automatic childproof lock is active. After the appliance is switched off, the ⇐ symbol appears in the display.

#### Cancelling

- 1. Press and hold the () touch button until "Childproof lock deactivated" appears on the display.
- 2. Touch the ① touch button.
- 3. Switch on the required appliance operation.

#### Deactivation

- 1. Press and hold the () touch button until "Childproof lock deactivated" appears on the display.
- **2.** Touch the  $\bigcirc$  touch button.
- **3.** Touch the  $\bigcirc$  touch button.
- 4. Swipe to the left or right to select "MyProfile".
- 5. Touch the bottom line.
- 6. Touch the top line.
- **7.** Swipe to the left or right to select the "Automatic childproof lock".
- 8. Touch the bottom line.
- 9. Swipe to the left or right to select "Deactivated".
- **10.** Touch the 🗋 touch button.
- 11. Touch "Save".
- The "Automatic childproof lock" is deactivated. **12.** Touch the ① touch button.

### **One-time childproof lock**

The control panel is locked so that the appliance cannot be switched on. To switch it on, the one-time childproof lock must be deactivated. After the appliance is switched off, the control panel is no longer locked.

#### Activating and deactivating

- Press and hold the () touch button until "Childproof lock activated" appears on the display. The childproof lock is activated.
- Press and hold the () touch button until "Childproof lock deactivated" appears on the display. The childproof lock is deactivated.

# Basic settings

There are various settings available to you in order to help use your appliance effectively and simply. If necessary, you can change these settings in MyProfile  $\bigcirc$ .

## **Changing MyProfile**

- **1.** Touch the ① touch button.
- **2.** Touch the  $\bigcirc$  touch button.
- **3.** Swipe to the left or right to select "MyProfile  $c_{\alpha}^{\circ}$ ".
- 4. Touch the bottom line.
- **5.** Swipe to the left or right to select the required setting.
- 6. Touch the bottom line.
- **7.** Swipe to the left or right to select the required setting.
- **8.** Touch the  $\bigcirc$  touch button.
- 9. Touch "Save".

### List of basic settings

anguage	
unguugo	Select language
ime of day	Sets the current time
late	Sets the current date
Vater hardness	0 (softened)
	1 (soft)
:	2 (medium)
:	3 (hard)
	4 (very hard)
	Set the heating types that should be shown in the heating types menu
udible signal	Short duration
Ī	Medium duration
	Long duration
	Can be adjusted to one of five different levels
t	Switched off (Exception: The button tone for the $\oplus$ touch button remains switched on)
:	Switched on
lisplay brightness	Adjustable across 5 levels
lock display	Off
I	Digital
1	Analogue
ighting	On during operation
	Off during operation
hildproof lock*	Only key lock
	Door lock and key lock
utomatic childproof lock	Deactivated
	Activated

Action after switching on	Main menu
Action arter switching on	
	Heating types
	Baking and roasting assistant
	Steam programmes
Night-time dimming	Switched off
	Switched on (display dimmed between 10 p.m. and 5.59 a.m.)
Brand name logo	Display
	Do not display
Fan run-on time	Recommended
	Minimum
Pull-out system*	Not retrofitted (rack or single pull-out system)
	Retrofitted (double or triple pull-out sys- tem)
Factory settings	Restore
*) Depending on the applia lected	ance model, this basic setting cannot be se-

# Setting favourites

You can set which types of heating are shown in the Types of heating menu.

**Note:** The "CircoTherm hot air", "Circo-roasting" and "Grill, large area" types of heating are always shown in the Types of heating menu. They cannot be deactivated.

- **1.** Touch the  $\bigcirc$  touch button.
- **2.** Touch the  $\bigcirc$  touch button.
- 3. Swipe to the left or right to select "MyProfile 🖧".
- 4. Touch the bottom line.
- 5. Swipe to the left or right to select "Favourites".
- 6. Touch the bottom line.
- 7. Swipe to the left or right to select the required type of heating.
- 8. Touch "Activated" or "Deactivated".
- **9.** Touch the  $\bigcirc$  touch button.
- 10. Touch "Save".

# Baking and roasting assistant

The baking and roasting assistant helps you to prepare meals with ease. The appliance applies the most suitable settings.

To achieve good results, the cooking compartment must not be too hot for the type of food you have selected. If it is, a message will appear on the display. Allow the cooking compartment to cool down and start again.

## Information on the settings

- The cooking result depends on the quality of the food and the type of cookware. For an optimal cooking result, use food that is in good condition and chilled meat only.
- The baking and roasting assistant helps you to prepare classic cakes, bread and roasts. The appliance selects the optimal type of heating for you. It suggests a suitable temperature and cooking time, which you can change if you wish.
- Information is provided, e.g. on cookware, shelf position or the addition of liquid when cooking meat. Some food requires turning or stirring, etc. during cooking. This is shown in the display shortly after operation starts. An audible signal will remind you at the right time.
- Information on the right kind of cookware to use and tips and tricks for preparation can be found at the end of the instruction manual.

### Selecting a meal

The following table shows the corresponding setting values for the listed meals.

Dishes
Rich fruit cake
Victoria sponge cake
Victoria sponge cake, on two levels
Swiss roll
Jam tarts
Jam tarts, on two levels
Fruit crumble
Pavlova
Vol au vents
Small cakes
Small cakes, on two levels
White bread
Scones
Scones, on two levels
Pizza, frozen
Oven chips
Baked potatoes
Baked potatoes, on two levels

Dishes
Lasagne, chilled
Roast pork
Top rump
Slow roasting joint
Leg of lamb
Whole chicken
Chicken drumsticks
Duck

# Selecting and setting food

You will be guided through the entire setting process for your chosen food.

- 1. Touch the ① touch button to switch on the appliance.
- **2.** Touch the  $\bigcirc$  touch button.
- **3.** Swipe to the left or right to select "Baking and roasting assistant".
- 4. Touch the bottom line.
- 5. Touch the required category.
- 6. Swipe to the left or right to select the required dish.
- Touch the required dish. The recommended settings appear on the display. Note: For some meals, you can also display notes, e.g. on the shelf height and cookware. To do this, swipe to the left until all of the notes are displayed.
- If required, you can change the recommended settings. To do this, touch "Adjust" in the bottom line. Touch the appropriate setting and adjust it.
- 9. Touch the ▷ || touch button to start the appliance operation.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the () touch button to end the audible signal.

Some recommended settings offer you the opportunity to continue cooking your dish.

If you are satisfied with the cooking result, touch "End".

If you are not happy with the cooking result, you can continue cooking your dish.

#### **Continue cooking**

- 1. Touch "Continue cooking".
- 2. If necessary, adjust the recommended setting.
- **3.** Touch the ▷|| touch button to start "Continue cooking".

#### Cancelling

Press and hold the ||| touch button until the appliance operation is cancelled.

#### Switching off the appliance

Touch the  ${\rm \textcircled{O}}$  touch button to switch off the appliance.

# Programmes

You can prepare food very easily using the various programmes. You select a programme and enter the weight of your food. The program then applies the most suitable settings.

To achieve good results, the cooking compartment must not be too hot for the type of food you have selected. If it is, a message will appear on the display. Allow the cooking compartment to cool down and start again.

# Information on the settings

- The cooking result depends on the quality of the food and the type of cookware used. For best results, only use high-quality food and refrigerated meat.For frozen products, only use food directly from the freezer.
- For some dishes, you will be required to enter the weight. The appliance will then apply the time and temperature settings for you.
   It is not possible to set weights outside the intended weight range.
- For roasting programmes, for which the appliance applies the temperature selection, temperatures can be as high as 300 °C. Therefore ensure that you are using heat-resistant cookware.
- Information about cookware, shelf position or adding liquid for meat is provided for you. For some dishes, the food needs to be turned or stirred during cooking. This is shown briefly on the display after the start. A signal reminds you to do this at the right time.
- Information about suitable cookware and preparation tips and tricks can be found at the end of the instruction manual.

#### Steam

For the steam programme, the appliance provides you with programmes you can use to prepare your meals easily and professionally.

Information about the steam functions can be found in the relevant sections.  $\rightarrow$  "Steam" on page 16

# Marning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

# Selecting a dish

The following table shows the corresponding setting values for the listed dishes.

Dishes White bread, without a tin Wheat bread, multi-grain wheat bread in loaf tin Flatbread Plaited loaf, unfilled/savarin

Dishes
Fatless sponge cake
Pork neck joint, boned
Top side, top rump
Leg of lamb
Chicken, whole, fresh
Chicken portions, fresh
Goose, duck, unstuffed, fresh
Fish fillet
Whole fish
Reheat cooked side dishes

# Setting a programme

You will be guided through the entire setting process for your chosen food.

- 1. Touch the ① touch button to switch on the appliance.
- **2.** Touch the  $\bigcirc$  touch button.
- **3.** Swipe to the left or right to select "Steam programmes".
- 4. Touch the bottom line.
- 5. Touch the required category.
- **6.** Swipe to the left or right to select the required steam programme.
- Touch the required steam programme. The settings for this dish appear on the display.
   Note: For some meals, you can also display notes, e.g. on the shelf height and cookware. To do this, swipe to the left until all of the notes are displayed.
- If required, you adjust can set the weight for some meals. To do this, touch "Adjust" in the bottom line. Touch the appropriate setting and adjust it.
- 9. Touch the ▷ || touch button to start the appliance operation.

The estimated cooking time is shown.

**Note:** For some programmes, the displayed cooking time may change during the first few minutes, as the heating-up time depends on the temperature of the food and the water, amongst other things.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the () touch button to end the audible signal.

Some programmes offer you the opportunity to continue cooking your dish.

If you are satisfied with the cooking result, touch "End".

If you are not happy with the cooking result, you can continue cooking your dish.

#### **Continue cooking**

- 1. Touch "Continue cooking".
- 2. If necessary, adjust the recommended setting.
- **3.** Touch the ▷|| touch button to start "Continue cooking".

#### Cancelling

Press and hold the || touch button until the appliance operation is cancelled.

#### Switching off the appliance

Touch the ① touch button to switch off the appliance.

# Meat thermometer

The MultiPoint meat thermometer makes precise cooking possible. It measures the temperature inside the food. Once the set temperature has been reached, the appliance automatically switches itself off.

# Suitable types of heating

- & CircoTherm hot air
- Top/bottom heating
- Circo-roasting
- 🚣 Pizza setting
- Bread-baking
- Top/bottom heating eco
- 🕱 CircoTherm eco
- 塗 Reheating

#### Notes

- The meat thermometer measures the temperature on the inside of the food between 30 °C and 99 °C.
- Use only the meat thermometer supplied. You can purchase it as a spare part from the after-sales service.
- After use, always remove the meat thermometer from the cooking compartment. Never store it inside the cooking compartment.

# Inserting the meat probe into the food


Before placing your food into the cooking compartment, insert the meat probe into the food.

The meat probe has three measuring points. Ensure that the middle measuring point is inserted in the food.

**Meat:** For large pieces of meat, insert the meat probe at an angle from above as far as it will go into the meat. For relatively thin pieces of meat, insert the meat probe from the side at the thickest point.



**Poultry:** Insert the meat probe as far as it will go into the thickest point in the breast. Insert the meat probe into the poultry crossways or lengthways depending on its structure. Then turn the poultry and place it on the wire rack breast-side down.



**Turning the food:** If you wish to turn the food, do not remove the meat probe. Once you have turned the food, check that the meat probe is correctly positioned in the food.

If you remove the meat probe while the food is cooking, all settings will be reset and you will have to apply them again.

#### Caution!

Ensure that the meat probe's cable does not become trapped.

To prevent the meat probe from being damaged by excessive heat, there must be a gap of a few centimetres between the grill element and the meat probe. The meat may expand during the cooking process.

### Setting and starting the appliance operation

#### Marning – Risk of burns!

The cooking interior and the core temperature probe become very hot. Use oven mitts to plug and unplug the core temperature probe.

#### Marning – Risk of electric shock!

The insulation of an incompatible meat probe may be damaged. Only use the meat probe which is recommended for this appliance.

#### Notes

- The set cooking compartment temperature must be at least 10 °C higher than the core temperature.
- To prevent the meat thermometer from being damaged, the cooking compartment temperature must not be set higher than 250 °C.
- 1. Insert the meat thermometer in the socket on the lefthand side of the cooking compartment.
- 2. Close the appliance door.

#### Caution!

When doing so, ensure that the meat thermometer's cable is not trapped in the appliance door. It may be damaged.

- 3. Touch the ① touch button.
- **4.** Set the type of heating.

**Note:** When the meat thermometer is plugged into the socket, you can only select a type of heating with which the meat thermometer can be used.

- **5.** Touch the cooking compartment temperature on the left in the bottom line.
- **6.** Swipe to the left or right to select the required cooking compartment temperature.
- **7.** Touch the  $\square$  symbol to apply the setting.
- Touch the 
   ✓ core temperature on the right in the bottom line.
- **9.** Swipe to the left or right to select the required core temperature.
- **10.** Touch the ▷|| touch button. The appliance starts the operation.

# Changing or cancelling the appliance operation

#### Changing the appliance operation

During appliance operation, you can change the cooking compartment temperature and core temperature.

- 1. Touch the cooking compartment temperature or core temperature twice.
- 2. Swipe to the left or right to change the temperature.
- **3.** Touch the  $\square$  symbol to apply the setting.

#### Stopping the appliance operation

Once the set core temperature has been reached, a signal sounds and the appliance stops the operation automatically.

- **1.** Touch the  $\ensuremath{\mathfrak{O}}$  touch button to end the signal.
- **2.** Use the touch button to switch off the appliance.
- **3.** Using an oven glove, unplug the meat thermometer from the socket.

### Core temperatures of different foods

Do not use frozen food. The figures in the table are given as a guide. They depend on the quality and composition of the food.

You can find comprehensive information on the heating mode and temperature at the end of the instruction manual.  $\rightarrow$  "Tested for you in our cooking studio" on page 38

Food	Core temperature in °C
Poultry	75
Pork	75
Beef, rare	50
Beef, medium	60
Beef, well done	70
Lamb	70
Other: Heating/reheating food	65-75

# 👖 Sabbath mode

You can set a time of up to 74 hours using Sabbath mode. The food in the cooking compartment remains warm, without you having to switch the appliance on or off.

# Starting the Sabbath mode

Before you can use Sabbath mode, you must activate it under "Favourites" in the basic settings.

Once the Sabbath mode has been activated, you can select it under the menu for the types of heating.

The appliance heats up with top/bottom heating. The temperature can be set between 85  $^\circ C$  and 140  $^\circ C.$ 

- 1. Touch the ① touch button.
- 2. Swipe to the left or right to select the "Sabbath mode".
- **3.** Touch the temperature in the bottom line.
- **4.** Swipe to the left or right to select the required temperature.
- **5.** Touch the  $\square$  symbol to apply the setting.
- 6. Touch the  $|\rightarrow|$  duration in the bottom line.
- 7. Swipe to the left or right to select the required duration.
- **8.** Touch the  $\begin{subarray}{c} \end{subarray}$  symbol to apply the setting.
- **9.** Touch the ▷|| touch button.

The appliance starts the operation.

#### Notes

- Once Sabbath mode has started, you can no longer change any settings or cancel the operation using the ▷|| touch button.
- The operation is not interrupted if you open the appliance door.

Once the Sabbath mode duration has elapsed, a signal sounds. The appliance stops heating. Use the  $\oplus$  touch button to switch off the appliance.

# **Cancelling Sabbath mode**

Touch the touch button to cancel Sabbath mode.

# Cleaning agent

With good care and cleaning, your appliance will retain its appearance and remain fully functioning for a long time to come. We will explain here how you should correctly care for and clean your appliance.

### Suitable cleaning agents

To ensure that the different surfaces are not damaged by using the wrong cleaning agent, observe the information in the table. Depending on the appliance model, not all of the areas listed may be on/in your appliance.

#### Caution!

# Risk of surface damage

- Do not use:
- Harsh or abrasive cleaning agents,
- Cleaning agents with a high alcohol content,
- Hard scouring pads or cleaning sponges,
- High-pressure cleaners or steam cleaners,
- Special cleaners for cleaning the appliance while it is hot.

Wash new sponge cloths thoroughly before use.

**Tip:** Highly recommended cleaning and care products can be purchased through the after-sales service. Observe the respective manufacturer's instructions.

#### Marning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

Area	Cleaning	
Appliance exterior		
Stainless steel front	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such flecks. Special stainless steel cleaning products suitable for hot surfaces are available from our after-sales	
	service or from specialist retailers. Apply a very thin layer of the cleaning product with a soft cloth.	
Plastic	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Do not use glass cleaner or a glass scraper.	
Painted surfaces	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth.	
Control panel	Hot soapy water: Clean with a dish cloth and dry with a soft cloth. Do not use glass cleaner or a glass scraper. If descaler comes into contact with the control panel, wipe it off immediately. If you leave it, it may stain the control panel.	

Door panels	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Do not use a glass scraper or a stainless steel scouring pad.
Door handle	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. If descaler comes into contact with the door han- dle, wipe it off immediately. Otherwise, any stains will not be able to be removed.

#### **Appliance interior**

•••		
Enamelled sur- faces	Hot soapy water or a vinegar solution: Clean with a dish cloth and then dry with a soft cloth.	
	Soften baked-on food residues with a damp cloth and soapy water. Use stainless steel wire wool or oven cleaner to remove stubborn dirt.	
	Leave the cooking compartment open to dry after cleaning.	
	Using the cleaning function gives the best results. $\rightarrow$ "Cleaning function" on page 28	
	<b>Note:</b> Food residues can cause white deposits to form. These are harmless and do not affect how the appliance works. Remove using lemon juice if required.	
Glass cover for the interior light- ing	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth.	
ing ing	If the cooking compartment is heavily soiled, use oven cleaner.	
Door cover	made from stainless steel: Use stainless steel cleaner. Follow the manufac- turers' instructions. Do not use stainless steel care products.	
	made from plastic: Clean using hot soapy water and a dish cloth. Dry with a soft cloth. Do not use glass cleaner or a glass scraper. Remove the door cover for cleaning.	
Rails	Hot soapy water: Soak and clean with a dish cloth or brush.	
Pull-out system	Hot soapy water: Clean with a dish cloth or a brush. Do not remove the lubricant while the pull-out rails are pulled out – it is best to clean them when they are pushed in. Do not clean in the dishwasher.	

Accessories	Hot soapy water: Soak and clean with a dish cloth or brush. If there are heavy deposits of dirt, use a stainless steel scouring pad.
Water tank	Hot soapy water: Clean with a dish cloth and rinse thoroughly to remove residual detergent. Then dry with a soft cloth. Leave the water tank to dry with the lid open. Rub the seal on the lid until dry. Do not clean in the dishwasher.
Meat thermome- ter	Hot soapy water: Clean with a dish cloth or a brush. Do not clean in the dishwasher.

#### Notes

- Slight differences in colour on the front of the appliance are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panels, which look like streaks, are caused by reflections made by the interior lighting.
- Enamel is baked on at very high temperatures. This can cause some slight colour variation. This is normal and does not affect operation.
   The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough.
   This does not impair the anti-corrosion protection.

## Keeping the appliance clean

Always keep the appliance clean and remove dirt immediately so that stubborn deposits of dirt do not build up.

#### Tips

- Clean the cooking compartment after each use. This will ensure that dirt cannot be baked on.
- Always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately.
- Use the universal pan for baking very moist cakes.
- Use suitable ovenware for roasting, e.g. a roasting dish.
- Where possible, use Circotherm hot air. This type of heating creates less dirt.

# Cleaning function

Your appliance is equipped with a self-cleaning function, EasyClean and a descaling function You can use the self-cleaning function to clean the cooking compartment. Use the EasyClean cleaning aid for intermediate cleaning of the cooking compartment. Dirt is softened beforehand using EasyClean. It can then be removed more easily. You can use the descaling function to remove limescale from the evaporator.

# Self-cleaning

You can use the "Self-cleaning" operating mode to clean the cooking compartment effortlessly. The cooking compartment is heated up to a very high temperature. Residues from roasting, grilling and baking will burn.

You can choose from three cleaning settings.

Setting	Cleaning level	Duration
1	Light	Approx. 1 hour, 15 minutes
2	Medium	Approx. 1 hour, 30 minutes
3	Intensive	Approx. 2 hours

The dirtier the cooking compartment and the longer the dirt has been there, the higher the cleaning setting should be. A cleaning cycle requires only approx. 2.5 – 4.7 kilowatt hours.

# \Lambda Warning

#### **Risk of burns!**

- The cooking compartment becomes extremely hot during the cleaning function. Never open the appliance door. Allow the appliance to cool down. Keep children away from the appliance.
- A The appliance will become very hot on the outside during the cleaning function. Never touch the appliance door. Allow the appliance to cool down. Keep children away from the appliance.

#### Preparation

# Warning Risk of fire!

- Loose food residues, grease and meat juices may catch fire during the cleaning function. Before starting the cleaning function, remove coarse dirt from the cooking compartment and from the accessories.
- The appliance will become very hot on the outside during the cleaning function. Never hang combustible objects, e.g. tea towels, on the door handle. Do not place anything against the front of the appliance. Keep children away from the appliance.

# ▲ Warning – Risk of serious damage to health!

The appliance will become very hot during the cleaning function. The non-stick coating on baking trays and tins is destroyed and noxious gases are released. Never clean non-stick baking trays and baking tins using the cleaning function. Only clean enamelled accessories using the cleaning function.


#### Caution!

Shelf supports and pull-out rails tend to discolour if they are left in the cooking compartment when it is cleaned. Before you start the cleaning function, remove the shelf supports and pull-out rails from the cooking compartment.


- 1. Remove the shelf supports and pull-out rails from the cooking compartment.  $\rightarrow$  "Rails" on page 31
- Remove the water reservoir. → "Steam" on page 16
   Caution!
   Before you start the cleaning function, remove the

Before you start the cleaning function, remove the water reservoir from the appliance.

- **3.** Remove the worst of the food residues from the cooking compartment and accessories.
- Clean the inside of the appliance door and along the edges of the cooking compartment in the area around the seal. Do not scrub the seal. → "Cleaning agent" on page 26
- Insert the accessory supports if you wish to clean accessories when the cooking compartment is being cleaned. Make sure that the vertical bar a on the accessory support is facing the front (figure 1).




- Insert the rear end of the accessory support as far as it will go into the rear socket b, and push the accessory support back c (figure 2).
- Then insert the front end of the accessory support as far as it will go into the front socket d, and push the accessory support down e (figure 3).



8. Whenever you wish to use the cleaning function, make sure that you never leave anything other than an enamelled accessory without anti-stick coating (e.g. the universal pan) on the accessory supports (figure 4).

#### Caution!

The wire rack tends to discolour if it is left in the cooking compartment when it is cleaned.Do not attempt to clean the rack using the cleaning function.



**Note:** Further accessories that can be cleaned using the cleaning function are listed in the table for special accessories.  $\rightarrow$  "Accessories" on page 12

#### Starting

- **1.** Touch the  $\bigcirc$  touch button.
- **2.** Touch the  $\widehat{\Box}$  touch button.
- Swipe to the left or right to select "Pyrolytic selfcleaning
- 4. Touch the bottom line.
- Swipe to the left or right to select the cleaning level.
   Note: Once cleaning starts, the cleaning level can no longer be changed.
- 6. Touch the bottom line.
- 7. Touch the ▷|| touch button.

The appliance starts the self-cleaning programme.

Ventilate the kitchen when the cleaning function is running.

During self-cleaning, the appliance door is automatically locked. The  $\bigcirc$  symbol appears on the display.

**Note:** If you would like to start self-cleaning later, set an end time.

#### Cancelling

Touch the 0 touch button to cancel. The appliance door cannot be opened until the 1 symbol goes out.

#### Finishing

As soon as self-cleaning has run through, a signal sounds. The appliance door cannot be opened until the  $\hat{\Box}$  symbol goes out.

#### Once the cleaning function has ended

- 1. Allow the cooking compartment to cool down.
- 2. Wipe off any ash that has been left behind in the cooking compartment and around the appliance door with a damp cloth.
- **3.** If you have left an accessory inside the cooking compartment to be cleaned, remove it and wipe it down with a damp cloth.
- 4. Lift the accessory support up at the front and remove it. → "Rails" on page 31
- 5. Refit the shelf supports or pull-out rails.  $\rightarrow$  "Rails" on page 31

## EasyClean

The EasyClean cleaning aid makes it easier to clean the cooking compartment. Dirt is softened beforehand by vaporizing soapy water. It can then be removed more easily.

#### Marning – Risk of scalding!

Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

#### Starting

#### Notes

- The "EasyClean []] cleaning aid can only be started once the cooking compartment is cold (room temperature) and the appliance door is closed.
- Do not open the appliance door during operation. Doing this will interrupt the "EasyClean []" cleaning aid.
- 1. Remove the accessories from the cooking compartment.
- 2. Mix a drop of washing-up liquid into 0.4 litres of water (do not use distilled water) and pour it onto the centre of the cooking compartment floor.
- **3.** Touch the ① touch button.
- **4.** Touch the  $\bigcirc$  touch button.
- **5.** Swipe to the left or right to select "EasyClean  $\boxed{[\Delta]}$ ".
- 6. Touch the bottom line.
- Touch the ▷|| touch button. The appliance starts EasyClean. The remaining time appears on the display.

#### Finishing

As soon as the cleaning aid has finished, an audible signal sounds and the appliance ends the operation automatically.

As soon as you open the appliance door, the interior lighting is switched on so that you can finish cleaning the cooking compartment more easily. The remaining water in the cooking compartment must be removed promptly. Do not leave the remaining water in the cooking compartment for a long time (e.g. overnight). The appliance must not be operated when the cooking compartment is still wet or damp.

#### **Final cleaning**

- 1. Open the appliance door and remove the remaining water with an absorbent sponge cloth.
- Clean the smooth surfaces in the cooking compartment with a dish cloth or a soft brush. Stubborn residues can be removed using a stainless steel scouring pad.
- **3.** Remove limescale with a cloth soaked in vinegar. Then wipe with clean water and rub dry with a soft cloth (including under the door seal).
- **4.** Use the ① touch button to switch off the appliance.
- Leave the appliance door ajar in the locking position (approx. 30°) for approx. 1 hour to allow the enamel surfaces in the cooking compartment to dry. Alternatively, you can also run the rapid drying function for the cooking compartment.

# Running the rapid drying function for the cooking compartment

- After the cleaning aid process has finished, leave the appliance door ajar in the locking position (approx. 30°).
- 2. Touch the ① touch button.
- 3. Start CircoTherm hot air at 50 °C.
- **4.** After 5 minutes, switch off the appliance and close the appliance door.

#### Removing heavy deposits of dirt

You have several options for removing particularly stubborn deposits of dirt.

- Leave the soapy water to work for some time before starting the cleaning aid.
- Rub soapy water onto the dirt on the smooth surfaces before starting the cleaning aid.
- Repeat the cleaning aid once the cooking compartment has cooled down.

# Descaling

The appliance must be descaled regularly in order for it to continue operating correctly.

There are several steps in the descaling programme. For hygiene reasons, the descaling programme must be run through completely so that the appliance can be ready for operation again. In total, the descaling programme runs for approx. 70-90 minutes.

- Descale (approx. 55-70 minutes), then empty and refill the water tank
- First rinsing cycle (approx. 6-9 minutes), then empty and refill the water tank
- Second rinsing cycle (approx. 6-9 minutes), then empty and dry the water tank

If the descaling process is interrupted (for example, due to a power failure or because the appliance has been switched off), you are prompted to rinse the appliance twice after it is switched back on. The appliance cannot be used until the second rinsing cycle has come to an end.

The frequency with which the appliance must be descaled depends on the hardness of the water used. When only five more steam-assisted operations are possible, or fewer, the appliance reminds you to descale it with a message on the display. The number of remaining operations is displayed after the appliance is switched on. You can therefore prepare for the descaling in good time.

#### Starting

#### Caution!

- Risk of damage to the appliance: Only use liquid descalers recommended by us for the descaling programme. The time the product needs to work during descaling depends on the type of descaler used. Other descalers may damage the appliance. Descaler order no. 311 680
- Descaling solution: Do not allow any descaling solution or descaler to come into contact with the control panel or other surfaces on the appliance. This damages the surfaces. If this does happen, remove the descaling solution immediately with water.

If you have used a steam-assisted operation immediately before descaling, you must first switch the appliance off so that the residual water is pumped out of the evaporator system.

- **1.** Mix 400 ml water with 200 ml liquid descaler to make a descaling solution.
- 2. Touch the ① touch button.
- **3.** Remove the water tank and fill it with descaling solution.
- **4.** Once the water tank has been filled with descaling solution, push it back in again fully.
- **5.** Close the control panel.
- **6.** Touch the  $\bigcirc$  touch button.
- Touch the bottom line. The duration of the descaling programme is displayed. It cannot be changed.
- 9. Touch the bottom line.
- 10. Touch the ▷|| touch button. The appliance is now descaled. The remaining time counts down on the display. As soon as the descaling programme has finished, an audible signal sounds.

#### First wash cycle

- **1.** Open the control panel.
- 2. Remove the water tank, rinse thoroughly, fill with water and reinsert.
- 3. Close the control panel.
- Touch the ▷|| touch button. The appliance is rinsed. As soon as the wash cycle has finished, an audible signal sounds.

#### Second wash cycle

- **1.** Open the control panel.
- 2. Remove the water tank, rinse thoroughly, fill with water and reinsert.
- 3. Close the control panel.
- Touch the ▷|| touch button. The appliance is rinsed. As soon as the wash cycle has finished, an audible signal sounds.

#### **Final cleaning**


- 1. Open the control panel.
- 2. Empty and dry the water tank.
- Switch off the appliance. Descaling is complete and the appliance is ready for use again.


# 🔰 Rails

With good care and cleaning, your appliance will retain its appearance and remain fully functional for a long time to come. This will tell you how to remove the shelves and clean them.

# Changing the shelf position for the telescopic rail

Bars and telescopic rails can be positioned in any order. For example, you can fit the telescopic rail to the shelf position which you use the most frequently.






#### Removing the bar


Telescopic rails are removed and fitted like bars.

- **1.** Push the bar towards the back **a** until it can be pulled out upwords **b** (Fig. **7**)
- pulled out upwards **b** (Fig. **1**). **2.** Unhook the bar at the back and remove it (Fig. **2**).




### Fitting the bar

1. Fit the bar at the back (Fig. 1).



- Push the bar towards the back a and down b onto the pin c (Fig. 2).
- Ensure that the hook is hooked onto the pin C (Fig.
   ).




# Detaching and refitting the rails

#### \Lambda Warning – Risk of burns!

The rails become very hot. Never touch the hot rails. Always allow the appliance to cool down. Keep children away from the appliance.

#### Detaching the rails

- Lift the rail slightly at the front **a** and detach it **b** (do not hold by the accessory holders or the telescopic shelf) (figure 1).
- Then pull the whole rail towards you and take it out (figure 2).




Clean the rails with cleaning agent and a sponge. For stubborn deposits of dirt, use a brush.

#### Attaching the rails

The rails only fit on the right or the left side. The pull-out rails must pull out towards you.

- First, insert the rail in the middle of the rear socket a, until the rail rests against the cooking compartment wall, and push it back b (figure 1).
- Then insert the rail into the front socket C, until the rail also rests against the cooking compartment wall here, and press it downwards d (figure 2).



# Appliance door

With good care and cleaning, your appliance will retain its appearance and remain fully functional for a long time to come. This will tell you how to remove the appliance door and clean it.

# Removing and fitting the appliance door

To clean the door panels, you can detach the appliance door.

## Marning – Risk of injury!

The hinges of the appliance door may snap shut with great force. Always fully turn the two locks for fitting and removing the appliance door.

## Marning – Risk of injury!

If the appliance door has been removed without turning both locking levers to their limit stops, the hinge may snap shut. Do not reach into the hinge. Call the aftersales service.

#### Detaching the appliance door

 Open the left- and right-hand door locks (fig. 1). To do this, hold the screwdriver horizontally and use it to push the door lock (black component) on each side of the door all the way up (fig. 2).


**Tip:** Use a torch to light up the gap so that you can see the door locks.


2



Door lock closed (fig. 3)







**2.** Open the appliance door approx. 45° (fig. **5**).




**3.** Using a coin, turn both the left- and right-hand locks on the inside of the appliance at the bottom as far as they will go.


Left-hand lock: Clockwise

Right-hand lock: Anti-clockwise

The arrows will now be pointing to one another and the lock will click into place (fig. 6).



Left-hand lock secured (fig. 7) Right-hand lock released (fig. 8)



4. Move the appliance


door back and forth until you hear a quiet click (fig. 9).

The appliance door is now in the lock position.You will only be able to move it slightly.

#### Caution!

Risk of damaging the door hinges. Do not force the appliance door open or closed when it is in the lock position.

If you have forced the appliance door open or closed when it was in the lock position, please contact our after-sales service.




# Marning Risk of injury!

The door handle may break off. Do not carry the appliance door by the door handle. To carry or remove the appliance door, take hold of it with both hands, one on the left and one on the right.

 Take hold of the appliance door with both hands, one on the left and one on the right, and rotate the door handle upwards slightly a until you are able to pull up the appliance door and remove it b(fig.°10).

#### Warning Risk of injury!


Do not drop the appliance door. The appliance door weighs 7 - 10 kg – handle it with care.




6. Set the appliance door down on a flat, soft, clean surface.


## Refitting the appliance door


 Slide the appliance door over the left- and right-hand guide rollers simultaneously (fig. 1 and 2). Ensure that the appliance door is not wedged at an angle and that it is properly fitted in place.





- Rotate the door handle upwards slightly a (fig. 3). The appliance door will slide the short distance remaining to the bottom b (fig. 3).
- Use a coin to release the locks on both sides of the appliance door (fig. 4).






Left-hand lock: Anti-clockwise Right-hand lock: Clockwise

**4.** Open the appliance door slightly until you hear a quiet click. Close the appliance door.

# **M** Warning

**Risk of injury if the door locks are not closed!** The appliance door may become detached. You may be injured and the appliance door damaged. After refitting the door, always close the left- and right-hand door locks.

5. Close the left- and right-hand door locks (fig. 5). To do this, hold the screwdriver horizontally and use it to push the door lock on each side of the door all the way down (fig. 6).



# Removing and installing the door panels

For cleaning, you can remove the glass panels from the appliance door.

To do this, the appliance door must be removed beforehand (see section "Removing and fitting the appliance door").

# Marning – Risk of injury!

The appliance must not be used again until the door panels and appliance door have been correctly fitted.


# Marning – Risk of injury!

Components inside the appliance door may have sharp edges. Wear protective gloves.

### Removing the glass panels


**Note:** Lay the glass panels you have removed on a flat surface that is soft and clean.

- 1. Detach the appliance door.
- 2. Lay the appliance door with the front side facing down on a flat surface that is soft and clean.
- Push on the left- and right-hand side on the outside of the appliance door until the inner glass panel is released on both sides (fig. 1).
- Carefully lift the inner glass panel and remove it in the direction of the arrow (fig. 2).





#### en Appliance door

- Slide the tip of the screwdriver in between the metal tab a and the plastic underneath it (fig. 3).
- 6. Use the tip of the screwdriver to carefully lift the reflector **b** until it is detached (fig. 4).





- 7. Lift the reflector **b** up and out (fig. **5**).
- 8. Remove the second reflector in the same way as the first.
- Push down on the intermediate panel around c, and carefully lift the holder d until you are able to pull it out (fig. 6).






10. Lift the first and second intermediate panels from below (fig. 2) and remove them in the direction of the arrow (fig. 3).





11. Remove the spacers (fig. 9) and seals (fig. 10) for cleaning if needed.




**12.** Clean the glass door panels and reflectors on both sides with glass cleaner and a soft cloth.

#### ▲ Warning Risk of injury!

Scratched glass in the appliance door may develop into a crack. Do not use glass scrapers, sharp or abrasive cleaning aids or aggressive or abrasive cleaning products.

#### Caution!

Make sure you do not damage the lighting. Do not clean or touch either of the LEDs **a**. The two LEDs are on the right and left in the appliance door.




**13.** Dry the door panels and refit them.


#### Fitting

**Note:** When fitting the door panels, make sure that they are in the original order.


1. Insert the intermediate panel so that the **a** arrow on the right-hand side is pointing upwards (Fig. **1**).




- 2. Check the fit of the four spacers and two seals on the intermediate panel:
  - Position the spacers so that each of the lines runs through the centre (Fig. 2).
  - Attach the seals at the corners (Fig. 3).





- Insert the intermediate panel with the seals and spacers. The arrow on the intermediate panel must line up with the arrow on the frame (Fig. 4).
- Insert the second intermediate panel without the seals and spacers and push it in the direction of the arrow until it is fitted in the frame. The arrow on the intermediate panel must line up with the arrow on the frame (Fig. 5).





5. Push down on the intermediate panel around b, slide the holder c in at an angle and push down until it clicks into place (Fig. 6). The holder has been inserted (Fig. 7).







#### Caution!

Do not touch the glass rod with your bare hands. Greasy residues reduce light transmission. Clean the glass rod with glass cleaner once it has been inserted.


- 6. Select the left-hand reflector (Fig. 8).
- 7. Insert the left-hand reflector d at the top (Fig. 9).




- 8. Insert reflector d (Fig. 10).
- 9. Fit reflector **d** into slot **e** (Fig. **1**).



- **10.** Insert the second reflector on the right-hand side in the same way as the left-hand reflector.
- **11.** Use glass cleaner to remove any finger marks from the reflectors if necessary.
- 12. Insert the inner glass into the mounting rail f at an angle towards the back (Fig. 2).
- 13. Push the inner glass downwards until it clicks into place (Fig. 13).





# Trouble shooting

If a fault occurs, there is often a simple explanation. Before calling the after-sales service, please refer to the fault table and attempt to correct the fault yourself.

**Tip: .** If a meal does not turn out exactly as you wanted, refer to the "Tested for you in our cooking studio" section.Here, you will find plenty of cooking tips and notes.

# Fault table

#### Marning – Risk of electric shock!

- Work on the appliance electronics may only be performed by a specialist.
- Always disconnect the appliance from the power supply when work is carried out on the electronics. Switch off the circuit breaker or remove the fuse from your household fuse box.

#### Marning – Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

Fault	Possible cause	Notes/remedy
The appliance does not work	The plug is not plugged into the mains	Connect the appliance to the power supply
	Power cut	Check whether other kitchen appliances are working
	The circuit breaker is faulty	Check in the fuse box to make sure that the fuse for the appliance is OK
Operations with steam or descaling	Water tank empty	Refill water tank
do not start or do not continue	The panel is open	Close the panel
	Descaling locks operations with steam	Carry out descaling
	Faulty sensor	Call the after-sales service
The Neff Light reflector in the appli- ance door is discoloured	This is a normal occurrence as a result of high tem- peratures	Not possible
After switching on an operating mode, a message is shown on the display which indicates that the temperature is too high	The appliance has not cooled down sufficiently	Allow the appliance to cool down and switch the oper- ating mode on again
The appliance prompts you to rinse	The power supply was interrupted or the appliance was switched off during the descaling process	Once the appliance is switched on again, rinse it twice
The appliance prompts you to descale without the counter appearing beforehand	The set water hardness range is too low	Carry out descaling Check the set water hardness range and adjust it, if necessary
Buttons flash	Normal occurrence caused by condensation behind the control panel	As soon as the condensation has evaporated, the buttons no longer flash
Cooked dishes turn out too moist or too dry when cooking with steam- assisted applications	The wrong steam intensity was selected	Select a higher or lower steam intensity
The "Fill water tank" message	The panel is open	Close the panel
appears even though the water tank is full	The water tank is not clicked into place	Click the water tank into place $\rightarrow$ "Steam" on page 16
	Faulty sensor	Call the after-sales service
	The water tank has fallen off. Due to the impact, components inside the water tank have come loose, and the tank is leaking.	Order a new water tank
Steam escapes from the ventilation slots during cooking	Normal procedure	Not possible

The panel for removing the tank does	The plug is not plugged into the mains	Connect the appliance to the power supply
not open	Power cut	Check whether other kitchen appliances are working
	The circuit breaker is faulty	Check in the fuse box to make sure that the fuse for the appliance is OK
	Faulty sensor for the 🗇 touch button	Call the after-sales service If required, empty the water tank: Open the appliance door, take hold of the lower part of the panel on the left and right with your fingers and pull out the panel
The appliance cannot be switched on; the ⇔ symbol is shown on the dis- play	The automatic childproof lock is activated	Press and hold the ${}^{igodold t}$ touch button until the ${}^{\scriptsize\leftarrow\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!\!$
The appliance cannot be operated when it is switched on; the constrained symbol is shown on the display	The childproof lock is activated	Press and hold the $\odot$ touch button until the $\lhd$ symbol goes out
The appliance does not heat up; □ is shown on the display	Demo mode is activated in the basic settings	Disconnect the appliance from the mains for approx. 10 seconds (switch off the circuit breaker in the fuse box) and then deactivate demo mode in the basic set- tings within 3 minutes $\rightarrow$ "Basic settings" on page 21
The appliance door cannot be opened; the ⊕ symbol is shown on	The appliance door is locked until the cooking com- partment has cooled down	Wait until the 🗄 symbol goes out
the display	The childproof lock locks the appliance door	Press and hold the 🕒 touch button until the 🗄 symbol goes out; adjust the childproof lock setting
There is a "pop" noise during cooking	Cold/warm effect with frozen food, caused by the steam	Not possible
"EXXXX" appears on the display, e.g. "E0111"	Technical problem	Switch the appliance off and back on again If the message appears again, call the after-sales ser- vice

# Maximum operating time exceeded

Your appliance ends the operation automatically when no cooking time is set and the setting has not been changed for a long time.

The actual cooking time until the operation is stopped automatically varies according to the selected settings.

The appliance display indicates that the operation will end automatically. Afterwards, the operation is stopped.

To use the appliance again, switch it off beforehand. Then switch the appliance on again and set the required operation.

# Cooking compartment bulbs

To light the interior of your cooking compartment, your appliance has one or more long-life LED bulbs.

However, if ever an LED bulb or the bulb's glass cover is defective, call the after-sales service. The lamp cover must not be removed.

# Customer service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find an appropriate solution, also in order to avoid after-sales personnel having to make unnecessary visits.

# E number and FD number

When calling us, please give the full product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate bearing these numbers can be found on the right-hand side when you open the fascia panel. Touch the  $\Box$  touch button to do this.  $\rightarrow$  "Steam" on page 16

	E-Nr:	FD: Z-Nr:	
Type:			

To save time, you can make a note of the number of your appliance and the telephone number of the aftersales service in the space below, should it be required.

E no.

FD no.

### After-sales service 🕾

Please note that there will be a fee for a visit by a service technician in the event of a malfunction, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

# To book an engineer visit and product advice GB 0344 892 8989

Calls charged at local or mobile rate.

IE 01450 2655

0.03 € per minute at peak. Off peak 0.0088 € per minute.

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

# Tested for you in our cooking studio

Here, you can find a selection of dishes and the ideal settings for them. We will show you which type of heating and temperature are best suited to your dish. You will get information on suitable cooking accessories and the height at which they should be placed in the oven. You will also get tips about cookware and preparation methods.

**Note:** A lot of steam can build up in the cooking compartment when cooking food.

Your appliance is very energy-efficient and radiates very little heat to its surroundings during operation. Due to the high difference in temperature between the appliance interior and the external parts of the appliance, condensation may build up on the door, control panel or adjacent kitchen cabinet panels. This is a normal physical phenomenon. Condensation can be reduced by preheating the oven or opening the door carefully.

During operation with steam assistance, it is desirable that there is a significant build-up of steam in the cooking compartment. Wipe the cooking compartment clean after cooking, once it has cooled off.

# Silicone moulds

We recommend dark-coloured metal baking tins for ideal cooking results.

Nevertheless, if you wish to use silicone moulds, follow the manufacturer's instructions and recipes. Silicone moulds are often smaller than normal baking tins. Quantity and recipe specifications may vary.

Silicone moulds are unsuitable for steam-assisted cooking.

# Baking

Here, you can find recommended settings for many dishes.

Also refer to the notes in the section on allowing dough to rise.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

# Steam- assisted baking

Certain types of baked item (e.g. yeast-risen pastries) get a more crispy crust and a more glossy surface if baked with the steam assist mode. The baked item does not dry out as much.

Steam-assisted baking is only possible on one level.

Some food turns out better if it is baked in several stages. These dishes are indicated in the table.

# Shelf positions

Use the indicated shelf positions.

#### Baking on one level

When baking on one level, use the following shelf positions:

- Tall baked items: Level 2
- Flat baked items: Level 3

If you are using CircoTherm Hot air as the type of heating, you can choose between levels 1, 2, 3 and 4.

You can also prepare soufflés in a water bath in the universal pan. To do so, slide the universal pan in at level 2.

#### Baking on two levels

Use CircoTherm. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

- Universal pan: Level 3 Baking tray: Level 1
- Baking tins/dishes on the wire rack First wire rack: Level 3 Second wire rack: Level 1

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another or offset and vertically stacked in the cooking compartment.

#### Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

#### Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

#### Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

When baking moist cakes or pastries with many toppings, use the universal pan so that any excess liquid does not overflow and make the cooking compartment dirty.

#### **Baking tins**

Dark- coloured metal baking tins are most suitable.

Tinplate baking tins, ceramic dishes and glass dishes extend baking time and mean that the baked item will not brown evenly. If you wish to bake using these baking tins/dishes and using top/bottom heating, slide in the tin/dish at level 1.

The baking tins must be resistant to heat and steam for use in steam-assisted baking.

#### Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

#### **Recommended setting values**

The table lists the optimal heating type for various baked items. The temperature and baking time depend on the amount and consistency of the dough/mixture. For this reason, the table specifies setting ranges. Try using the lower values to start with. A lower temperature will result in more even browning. You can use a higher setting next time if necessary.

Note: Baking times cannot be reduced by using higher temperatures. Cakes or small baked items would only be cooked on the outside, and would not be fully baked in the middle.

The setting values apply to food that is placed into a cold cooking compartment; by doing this, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated baking times by several minutes.

Preheating is necessary for selected food, and this is indicated in the table. Do not place your food or accessories into the cooking compartment until it has finished preheating.

If you wish to follow one of your own recipes when baking, you should use the setting values listed for similar baked items in the table as reference.Additional information can be found in the baking tips listed after the settings table.

Remove unused accessories from the cooking compartment. This will ensure that you achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- & CircoTherm
- $\equiv$  Top/bottom heating  $\stackrel{\frown}{\underline{\,\,}}$  Circotherm intensive
- Bread baking

The levels of steam intensity are indicated as numbers in the table:

- 1 = 1 ow
- 2 = Medium
- 3 = High

Dish	Accessories/cookware	Shelf po- sition	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
One level baking						
Victoria sponge cake	2x Ø20 cm tins	2	S	160-170*	-	25-30
Victoria sponge cake	2x Ø20 cm tins	2	S	150-160	1	25-35
Light fruit cake	high Ø20 cm tin	2	S	140-160	-	70-90
Light fruit cake	high Ø20 cm tin	2	S	140-150	1	90-100
Rich fruit cake	high Ø23 cm tin	2	S	130-150	-	150-180
* Preheat						

Dish	Accessories/cookware	Shelf po- sition	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Fruit crumble	flat glass dish	3	S	150-170*	-	35-45
Sponge Cake (fatless), 3 eggs	springform cake tin Ø26 cm	2	S	160-170*	-	25-35
Sponge Cake (fatless), 3 eggs	springform cake tin Ø26 cm	2	S	150-160	1	10
					-	20-25
Sponge flan, 6 eggs	springform cake tin Ø28 cm	2	S	150-170*	-	30-50
Sponge flan, 6 eggs	springform cake tin Ø28 cm	2	S	150-160	1	10
					-	30-35
Swiss roll	swiss roll tin	3	S	180-190*	-	10-15
Swiss roll	swiss roll tin	3	S	180-190*	1	10-15
Fruit Pie	plate Ø20 cm or pie tin	2	<u>&amp;</u>	160-170	-	55-65
Fruit Pie	plate Ø20 cm or pie tin	2	S	170-190	-	55-70
Quiche	quiche tin (dark coated)	3	<u>&amp;</u>	190-210	-	30-40
(White) Bread	loaf tin (1x 900 g or 2x 450 g)	2		180-200*	-	20-30
(White) Bread	loaf tin (1x 900 g or 2x 450 g)	2	S	190-200	2	30-40
Scones	baking tray	3	S	180-200*	-	10-14
Scones	baking tray	3	=	190-200	-	10-14
Biscuits	baking tray	3	S	140-160*	-	10-25
Biscuits	baking tray	3	=	150-170	-	10-20
Small Cakes	12-cup-tin	3	S	140-160*	-	20-30
Small Cakes	12-cup-tin	3	=	150-170	-	20-30
Puff pastry slices	baking tray	3	S	170-190*	-	20-35
Puff pastry slices	baking tray	3		200-220*	1	15-25
Jam tarts	12-cup-tin	3	L	170-190*	-	15-30
Jam tarts	12-cup-tin	3	=	180-200	-	15-25
Meringue	baking tray	3	L	80-90*	-	120-150
Pavlova	baking tray	3	L	90-100*	-	120-180
Soufflé	1,2L-soufflé dish	2	L	160-170*	-	35-45
Soufflé	1,2L-soufflé dish	2	L	160-180	2	35-45
Soufflé	individual moulds	2	=	170-190	-	65-75
Choux pastry	baking tray	3		190-210*	-	30-40
Choux pastry	baking tray	3	≞	200-220*	1	25-35
Meat Pie	rectangular pie tin	2	L	180-190	-	40-50
Meat Pie	rectangular pie tin	2	L	170-180	2	40-50
Yorkshire pudding	12-cup-tin	3	≞	200-220*	-	15-25
Jacket potatoes	baking tray	3	L	150-170	-	75-90
Jacket potatoes	universal pan	3	L	180-190	2	40-50
Pizza, homemade	baking tray	3	=	200-220	-	25-35
Pizza, homemade	baking tray	3	<u>&amp;</u>	200-220	-	25-35
Pizza, homemade, thin base	pizza tray	2	=	250-270	-	20-25
Pizza, homemade, thin base	pizza tray	2	<u>&amp;</u>	210-220	-	25-30
Multishelf baking						
Victoria Sponge Cake, 2 levels	4x Ø20 cm tins	3+1	S	160-170*	-	25-35
Scones, 2 levels	2 baking trays	3+1	L	170-190*	-	12-16
Biscuits, 2 levels	2 baking trays	3+1	L	140-160*	-	10-25
Biscuits, 3 levels	3 baking trays	4+3+1	L	140-160*	-	15-30
Small cakes, 2 levels	2x 12-cup-tins	3+1	S	140-160*	-	22-32
* Preheat						

Dish	Accessories/cookware	Shelf po- sition	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Puff pastry slices, 2 levels	2 baking trays	3+1	S	170-190*	-	25-45
Puff pastry slices, 3 levels	3 baking trays	4+3+1	S	170-190*	-	25-45
Jam tarts, 2 levels	2x 12-cup-tins	3+1	S	170-190*	-	20-35
Meringues, 2 levels	2 baking trays	3+1	S	80-90*	-	120-150
Jacket potatoes, 2 levels	universal pan + baking tray	3+1	L	150-170*	-	75-90
(White) Bread, 2 levels	4x loaf tins	3+1	S	170-190*	-	30-40
Pizza, homemade, 2 levels	universal pan + baking tray	3+1	L	180-200	-	35-45
* Preheat						

### Tips on baking

You want to find out whether the cake is completely cooked in the middle.	Push a cocktail stick into the highest point on the cake. If the cocktail stick comes out clean with no dough residue, the cake is ready.
The cake collapses.	Next time, use less liquid. Alternatively, set the temperature to be 10 °C lower and extend the baking time. Adhere to the specified ingredients and preparation instructions in the recipe.
The cake has risen in the middle but is lower around the edge.	Only grease the base of the springform cake tin. After baking, loosen the cake carefully with a knife.
The fruit juice overflows.	Next time, use the universal pan.
Small baked items stick to one another during baking.	There should be a gap of approx. 2 cm around each item. This gives enough space for the baked items to expand well and brown on all sides.
The cake is too dry.	Set the temperature 10 °C higher and shorten the baking time.
The cake is generally too light in col- our.	If the shelf position and the cookware are correct, then you should increase the temperature if necessary or extend the baking time.
The cake is too light on top, and too dark underneath.	Bake the cake one level higher in the oven the next time.
The cake is too dark on top, and too light underneath.	Bake the cake one level lower in the oven the next time. Select a lower temperature and extend the baking time.
Cakes baked in a tray or tin are too brown at the back.	Place the baking tray in the middle of the accessories, not directly against the back wall.
The whole cake is too dark.	Select a lower temperature next time and extend the baking time if necessary.
The cake is unevenly browned.	Select a slightly lower temperature.
	Protruding greaseproof paper can affect the air circulation. Always cut greaseproof paper to size. Ensure that the baking tin does not stand directly in front of the openings in the cooking compartment back wall.
	When baking small items, you should use similar sizes and thicknesses wherever possible.
You were baking on several levels. The items on the top baking tray are darker than those on the lower baking tray.	Always use CircoTherm when baking on several levels. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.
The cake looks good, but is not cooked properly in the middle.	Use a lower temperature and bake slightly longer; if necessary, add slightly less liquid. For cakes with a moist topping, bake the base first. Sprinkle it with almonds or breadcrumbs and then place the topping on top.
The cake cannot be turned out of the dish when it is turned upside down.	Allow the cake to cool down for 5 to 10 minutes after baking. If it still sticks, carefully loosen the cake around the edges again using a knife. Turn the cake tin upside down again and cover it several times with a cold, wet cloth. Next time, grease the baking tin/dish and sprinkle with breadcrumbs.

# **Roasting and braising**

Here, you can find information on roasting and braising poultry and meat. You can find the ideal settings for many dishes in the settings tables.

### Poultry

For duck or goose, pierce the skin on the underside of the wings. This allows the fat to run out.

If using duck breast, score the skin. Do not turn duck breasts.

When you turn poultry, ensure that the breast side or the skin side is underneath at first.

Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water or orange juice.

#### Meat

Baste lean meat with fat as required or cover it with strips of bacon.

Score the rind crosswise. If you turn the joint when cooking, ensure that the rind is underneath at first.

When the joint is ready, turn off the oven and allow it to rest for another 10 minutes in the cooking compartment. This allows the meat juices to be better distributed. Wrap the joint in aluminium foil if necessary. The recommended resting time is not included in the cooking time indicated.

### Roasting on the wire rack

On the wire rack, poultry and meat will become very crispy on all sides. Roasting on the wire rack is well suited for larger poultry or for multiple pieces at the same time.

Depending on the size and type of the meat, add up to 1/2 litres of water to the universal pan. Any dripping fat and meat juices will be caught. You can prepare a sauce using these meat juices. In addition, less smoke is generated, and the cooking compartment stays cleaner.

Slide the universal pan into the oven at the indicated shelf position with the wire rack attached. Ensure that the wire rack is correctly positioned on the universal pan.  $\rightarrow$  "Accessories" on page 12

### Roasting and braising in cookware

It is more convenient to roast and braise meat in cookware. You can take the joint out of the cooking compartment more easily in the cookware, and prepare the sauce in the cookware itself.

Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Add in a little liquid for roasting if the meat is lean. A covering of approx. ¹/₂ cm depth should be applied to the base of any glass cookware.

The amount of liquid is dependent on the type of meat, the cookware material and also on whether or not a lid is used. If preparing meat in an enamelled or dark metal roasting dish, it will need a little more liquid than if cooked in glass cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The meat cooks more slowly and will not brown so much. Use a higher temperature and/or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

#### Roasting in uncovered cookware

It is best to use a deep roasting tin/dish for roasting poultry and meat. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

#### Braising in covered cookware

When preparing food with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

The distance between the meat and the lid must be at least 3 cm. The meat may rise.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

If necessary, braise the meat first by searing it. Add water, wine, vinegar or a similar liquid to the braising liquid. A covering at least 2 cm deep should be applied to the base of the cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

### Steam- assisted roasting and braising

Certain dishes become crispier if cooked using steam, and do not dry out as much.

Use uncovered cookware. Cookware must be heat- and steam-resistant.

The joints do not have to be turned.

Use steam-assisted cooking if it is indicated in the settings table. Some dishes turn out best if they are cooked in several stages. These are indicated in the table.

#### Meat thermometer

You can cook accurately using a meat thermometer. Read important notes on using the meat thermometer in the corresponding chapter. There, you can find notes on inserting the meat thermometer, the possible heating types and additional information.  $\rightarrow$  "Meat thermometer" on page 24

### **Recommended setting values**

In the table, you can find the ideal heating type for poultry and meat. Temperature and cooking time depend on the quantity, composition and temperature of the food. Different settings ranges are indicated for this reason. Try using the lower values at first. You can increase the temperature next time if necessary.

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry and meat are placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, the indicated cooking times will be reduced by several minutes.

In the table, you can find specifications for poultry and meat with default values for the weight. If you wish to prepare heavier poultry or meat, use the lower temperature in every case. If roasting several joints, use the weight of the heaviest piece as a basis for determining the cooking time. The individual pieces should be approximately equal in size.

A general rule: the larger the poultry or piece of meat is, the lower the cooking temperature and the longer the cooking time.

Turn the poultry and meat after approx.  $1\!\!/_2$  to  $2\!\!/_3$  of the indicated time.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

Cooking time calculation (e. g. 20+35): Please calculate the cooking time with 20 minutes per 500 g meat + 35 minutes additional time. For 1,5 kg the calculated cooking time would be 95 minutes.

#### Cooking time range (e. g. 10-15): The food is done within the stated minutes.

Type of heating used:

CircoTherm

The levels of steam intensity are indicated as numbers in the table:

- 1 = Low
- 2 = Medium
- 3 = High

Dish	Accessories/cookware	Shelf po- sition	Type of heating	Tempera- ture in °C	Steam in- tensity	Time in min.
Beef						
Slow roasting joint	wire rack	2	S	140-150	-	35+40
Slow roasting joint, 1.5 kg	wire rack	2	S	130-140	1	70-80
					-	40-50
Top side / Top rump	wire rack	2	S	160-170	-	30+25
Top side / Top rump, 1.5 kg	wire rack	2	L	170-180	1	100-120
Lamb						
Leg (bone-in)	wire rack	2	S	160-170	-	25+25
Leg (bone-in), 1.5 kg	wire rack	2	S	180-190	1	80-90
Shoulder (bone-in)	wire rack	2	S	160-170	-	25+20
Shoulder (boned and rolled)	wire rack	2	S	170-180	-	25+25
Rack of lamb**	wire rack	2	S	180-190*	-	15+25
Rack of lamb (each 700 g)	wire rack	2	S	200	-	20
				170-180	1	25-30
Pork						
Roasting joint	wire rack	2	S	180-190	-	30+35
Roasting joint, 1.5 kg	wire rack	2	S	120	3	30
				190-200	-	30
				160-170	1	80-100
Loin joint	wire rack	2	S	180-190	-	35+35
Loin joint, 1 kg	wire rack	2	S	180-190	-	25-30
				170-180	1	70-80
Belly	wire rack	2	S	170-180	-	30+25
Gammon joint	wire rack	2	S	160-170	-	30+30
Gammon joint, 1.5 kg	wire rack	2	L	170-180	2	100-120
Poultry						
Chicken, whole	wire rack	2	L	170-180	-	25+15
Chicken, whole, 1.5 kg	wire rack	2	S	180-190	2	65-75
Chicken, portion (each 200-250 g)***	wire rack	2	L	190-200	-	35-45
Chicken, portion (each 200-250 g)***	wire rack	2	₫	200-210	2	35-45
Duck	wire rack	2	L	180-190	-	25+20
* Preheat						

* Preheat

** Without fat layer (best and neck), do not turn

*** Skin side down

**** Bone side dowr

***** Turn after app. 1 hour

Dish	Accessories/cookware	Shelf po- sition	Type of heating	Tempera- ture in °C	Steam in- tensity	Time in min.
Duck, 2-3 kg	wire rack	2	L	160-170	2	70-90
				170-180	-	30-40
Turkey, crown****	wire rack	2	L	150-160	-	20+15
Turkey, crown, 3 kg	wire rack	2	L	140-150	2	100-140
Turkey, thighs	wire rack	2	L	170-180	-	25+30
Turkey, whole, 4-8 kg*****	wire rack	2	S	150-160	-	12+12
Turkey, whole, 7 kg	wire rack	1	L	140-150	2	120-150
				170-180	-	30-40
Meat dishes						
Meat loaf	cookware, uncovered	2	S	170-180	-	20+35
Meat loaf, 1 kg	cookware, uncovered	2	S	190-200	1	70-80
Casserole						
Diced meat (beef, pork, lamb), 500 g meat	cookware, covered	2	S	140*	-	100-120
Diced chicken (boned), 500 g meat	cookware, covered	2	S	140*	-	90-100
Braising steak	cookware, covered	2	S	140	-	65+60
Complete meal						
With beef	wire rack + wire rack	4+1	L	160, then 200 (York- shire Pud- ding)	-	calculation for meat (see table above) + 15-25 for Yorkshire Pudding
With chicken	wire rack + wire rack	4+1	L	180	-	calculation for chicken (see table above)
With chicken, 1.5 kg	wire rack + wire rack	4+1	L	180	low (steam 0 when Yorkshire Pudding is inserted)	65-75
* Preheat ** Without fat layer (best and neck), do *** Skin side down **** Bone side down ***** Turn after app. 1 hour	o not turn					

# Tips on roasting and braising

The cooking compartment becomes very dirty.	Prepare your food in an enclosed roasting dish with higher temperature or use the grill tray. You will achieve the best roasting results if you use the grill tray. The grill tray can be bought later as a special accessory.
The roast is too dark and the crack- ling is burned in places, and/or the roast is too dry.	Check the shelf position and temperature. Select a lower temperature the next time and reduce the roasting time if necessary.
The crackling is too thin.	Increase the temperature or switch on the grill briefly at the end of the roasting time.
The roast looks good but the juices are burnt.	Next time, use a smaller roasting dish and add more liquid if necessary.
The roast looks good but the juices are too clear and watery.	Next time, use a larger roasting dish and add less liquid if necessary.
The meat gets burned during brais- ing.	The roasting dish and lid must fit together well and close properly. Reduce the temperature and add more liquid when braising if necessary.

# Grilling

Here, you can find information on grilling poultry, meat and fish, as well as toast. You can find the ideal settings for certain dishes in the settings tables.

# Grilling with circo-roasting

Circo-roasting is very well suited to the preparation of whole poultry and fish, in addition to meat, e.g. roast pork with crackling.

### Poultry

For duck or goose, pierce the skin on the underside of the wings. This allows the fat to run out.

If using duck breast, score the skin. Do not turn duck breasts.

When you turn poultry, ensure that the breast side or the skin side is underneath at first.

Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water or orange juice.

### Meat

Baste lean meat with fat as required or cover it with strips of bacon.

Score the rind crosswise. If you turn the joint when cooking, ensure that the rind is underneath at first.

When the joint is ready, turn off the oven and allow it to rest for another 10 minutes in the cooking compartment. This allows the meat juices to be better distributed. Wrap the joint in aluminium foil if necessary. The recommended resting time is not included in the cooking time indicated.

#### Fish

Fish cooked whole does not have to be turned. Place the whole fish into the cooking compartment in swimming position with the dorsal fin facing upwards. Placing half a potato or a small oven-proof container in the stomach cavity of the fish will provide stability.

You can tell when the fish is cooked because the dorsal fin can be removed easily.

### Roasting on the wire rack

On the wire rack, poultry and meat will become very crispy on all sides. Roasting on the wire rack is well suited for larger poultry or for multiple pieces at the same time.

Depending on the size and type of the meat, add up to 1/2 litres of water to the universal pan. Any dripping fat and meat juices will be caught. You can prepare a sauce using these meat juices. In addition, less smoke is generated, and the cooking compartment stays cleaner.

Slide the universal pan into the oven at the indicated shelf position with the wire rack attached. Ensure that the wire rack is correctly positioned on the universal pan.  $\rightarrow$  "Accessories" on page 12

### Roasting in cookware

It is more convenient to roast and braise meat in cookware. You can take the joint out of the cooking compartment more easily in the cookware, and prepare the sauce in the cookware itself. Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Add in a little liquid if the meat is lean. A covering of approx.  $\frac{1}{2}$  cm depth should be applied to the base of any glass cookware.

The quantity of liquid is dependent on the type of meat, the cookware material and also on whether or not a lid is used. If preparing poultry, meat or fish in an enamelled or dark metal roasting dish, it will need a little more liquid than if cooked in glass cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The meat cooks more slowly and will not brown so much. Use a higher temperature and/or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

#### **Uncovered cookware**

Use a deep roasting tin/dish for roasting meat. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

### **Covered cookware**

When cooking with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

The distance between the meat and the lid must be at least 3 cm. The meat may rise.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

If necessary, braise the meat first by searing it. Add water, wine, vinegar or a similar liquid to the braising liquid. A covering approx. 1-2 cm deep should be applied to the base of the cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Meat can also become crispy in a covered roasting dish. To do so, use a roasting dish with a glass lid and set a higher temperature.

### Steam- assisted roasting

Certain foodstuffs will become crispier during steamassisted cooking. Their surface becomes glossier and they dry out less.

Use uncovered cookware. Cookware must be heat- and steam-resistant.

Use steam-assisted cooking if it is indicated in the settings table. Some dishes turn out best if they are cooked in several stages. These are indicated in the table.

# **Grilling flat pieces**

Flat pieces of poultry, meat and fish, such as steaks, drumsticks and burgers, can be prepared well using the "Grill" heating type. Excellent results are also achieved when grilling toast.

# Grilling

Keep the appliance door closed when using the grill. Never grill with the appliance door open.

Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. Any dripping fat will be caught.

When grilling, try wherever possible to use pieces of food which are of a similar thickness and weight. This will allow them to brown evenly and remain succulent and juicy. Place the food to be grilled directly onto the wire rack.

Use tongs to turn the pieces of food you are grilling. If you pierce the meat with a fork, the juices will run out and it will become dry.

Do not add salt until after the meat has been grilled. Salt draws water from the meat.

### Notes

- The grill element switches itself continuously on and off; this is normal. The set temperature determines how frequently this occurs.
- Smoke may be produced when grilling.

# Meat thermometer

You can cook accurately using a meat thermometer. Read important notes on using the meat thermometer in the corresponding chapter. There, you can find notes on inserting the meat thermometer, the possible heating types and additional information.  $\rightarrow$  "Meat thermometer" on page 24

#### **Recommended setting values**

In the table, you can find the ideal heating type for your poultry, meat and fish, in addition to toast. Temperature and cooking time depend on the quantity, composition and temperature of the food. Settings ranges are indicated for this reason. Try using the lower values at first. You can use a higher setting next time if necessary.

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry, meat and fish are placed into a cold cooking compartment.

In the table, you can find specifications for poultry, meat and fish with default values for the weight. If you wish to prepare heavier poultry, meat or fish, use the lower temperature in every case. If roasting several joints, use the weight of the heaviest piece as a basis for determining the cooking time. The individual pieces should be approximately equal in size.

A general rule: the larger the poultry, meat or fish is, the lower the cooking temperature and the longer the cooking time.

Turn the poultry, meat and fish after approx.¹/₂ to ²/₃ of the indicated time.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

Cooking time calculation (e. g. 20+35): Please calculate the cooking time with 20 minutes per 500 g meat + 35 minutes additional time. For 1,5 kg the calculated cooking time would be 95 minutes.

Cooking time range (e. g. 10-15): The food is done within the stated minutes.

Types of heating used:

- Circo-roasting Full-surface grill

The levels of steam intensity are indicated as numbers in the table:

- 1 = Low
- 2 = Medium
- 3 = High

Dish	Accessories	Shelf po- sition	Type of heating	Tempera- ture in °C	Steam in- tensity	Time in min.
Beef						
Steaks, height 2-3 cm**	wire rack	3	****	290	-	1st side 10-12
, 0						2nd side 3-5
Burger, height 1-2 cm	wire rack	3	****	290*	-	1st side 6-8
						2nd side 4-6
Top side / Top rump	wire rack	2	ž	150-160	-	30+30
Lamb						
Steaks, height 2-3 cm	wire rack	3	****	290*	-	1st side 8-10
						2nd side 4-6
Chops, height 2-3 cm	wire rack	3	****	290	-	1st side 7-9
						2nd side 7-9
Leg (bone-in)	wire rack	2	ž	170-180	-	25+30
Leg (bone-in), 1.5 kg	wire rack	2	ž	170-180	1	80-90
Shoulder (bone-in)	wire rack	2	ž	170-190	-	25+15
Shoulder (boned and rolled)	wire rack	2	ž	170-180	-	20+15
Rack of lamb	wire rack	2	ž	190-200	-	15+25
Pork						
Steaks, height 2 cm	wire rack	4	****	290	-	1st side 10-12
						2nd side 5-7
Chops, height 2-3 cm	wire rack	3	****	275*	-	1st side 10-12
						2nd side 9-10
Burger, height 1-2 cm	wire rack	3	****	290***	-	1st side 7-9
						2nd side 5-7
Bacon rashers	wire rack	3	****	290****	-	1st side 4-5
						2nd side 3-4
Sausages, thickness 2 -4 cm	wire rack	3	****	290****	-	10-15
Roasting joint	wire rack	2	ž	180-200	-	30+40
Loin joint	wire rack	2	ž	180-200	-	35+35
Belly	wire rack	2	ž	200-220	-	30+25
Belly, 1 kg	wire rack	2	ž	170-180	1	50-60
				190-200	-	25-35
Gammon joint	wire rack	2	ž	180-200	-	30+25
Poultry						
Chicken drumstick, 150 g each	wire rack	3	ž	210-230	-	20-30
Chicken drumstick, 150 g each	wire rack	3	Ĩ	210-220	2	30-40
Chicken breast, boned, 150 g each	wire rack	3	****	275***	-	1st side 10-15 2nd side 10-15
Chicken breast, boned, 150 g each	wire rack	3	ž	200-210	2	20-30
Chicken, whole	wire rack	2	ж Ж	200-220	-	20+15
* Preheat						

^{**} Do not prehe

**** Preheat 3 minutes, turn over several times

***** Preheat 5 minutes

****** Skin side dowr

^{***} Preheat 3 minute

			- (	-	01	
Dish	Accessories	Shelf po- sition	Type of heating	Tempera- ture in °C	Steam in- tensity	Time in min.
Chicken, whole, 1.5 kg	wire rack	2	Ĩ	180-190	2	65-75
Chicken, portion, bone-in, 200- 250 g each*****	wire rack	3	ž	200-220	-	30-45
Chicken, portion, bone-in, 200- 250 g each*****	wire rack	3	ž	200-210	2	35-45
Duck, 2-3 kg	wire rack	2	ž	190-200	-	20+20
Duck, 2-3 kg	wire rack	2	ž	150-160	2	100-120
Turkey, thighs	wire rack	2	ž	180-190	-	25+30
Turkey, whole, 4-8 kg	wire rack	2	ž	140-160	-	12+12
Turkey, whole, 7 kg	wire rack	1	ž	140-150	2	120-150
				170-180	-	30-40
Fish						
Trout, whole, 300 g each	wire rack	2	Ĩ	170-190	-	20-30
Fillets, each 150 g	wire rack	4	****	220***	-	1st side 5-10
						2nd side 5-10
Toast						
Grilling white bread**	wire rack	4	****	290	-	4-6
* Preheat						
** Do not preheat						
*** Preheat 3 minutes						
**** Preheat 3 minutes, turn over seve	eral times					
***** Preheat 5 minutes						
****** Skin side down						

# **Convenience products**

Here, you can find the ideal settings for preparing chilled and frozen food.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

# Tips

- The cooking result greatly depends on the quality of the food. Pre-browning and unevenness may already be present on the packaged product.
- Do not use frozen products that are heavily frosted. Remove any ice on the food.
- Distribute foods which are in pieces, such as bread rolls and potato products, so that they are spread flat and evenly on the accessories. Leave a little space between the individual pieces.
- Observe the instructions on the packaging.

# Steam- assisted baking

Certain types of baked item (e.g. yeast-risen pastries) get a more crispy crust and a more glossy surface if baked with the steam assist mode. The baked item does not dry out as much.

Steam-assisted baking is only possible on one level.

# Shelf positions

Use the indicated shelf positions.

# Baking on one level

When baking on one level, use the following shelf positions:

- Tall baked items: Level 2
- Flat baked items: Level 3

If you are using CircoTherm Hot air as the type of heating, you can choose between levels 1, 2, 3 and 4.

# Baking on two levels

Use CircoTherm. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

 Universal pan: Level 3 Baking tray: Level 1

# Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

### Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

# Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

### Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

#### **Recommended setting values**

In the table, you can find the ideal heating type for various dishes. Temperature and cooking time depend on the quantity and composition of the product. Setting ranges are indicated for this reason. Try using the lower values at first. A lower temperature results in more even browning. You can use a higher setting next time if necessary.

**Note:** Cooking times cannot be reduced by using higher temperatures. The dish would only be cooked on the outside, but would not be fully cooked in the middle.

The setting values apply to dishes placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, the indicated cooking times will be reduced by several minutes. Preheating is necessary for selected dishes, and this is indicated in the table.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- & CircoTherm
- <u>A</u> Circotherm intensive
- Bread baking

The levels of steam intensity are indicated as numbers in the table:

- 1 = Low
- 2 = Medium
- 3 = High

Dish	Accessories/cookware	Shelf po- sition	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Pizza, chilled						
Pizza, chilled	wire rack	3	<u>&amp;</u>	190-210	-	10-15
Pizza, frozen						
Pizza, thin base	wire rack	3	<u>&amp;</u>	190-210	-	15-20
Pizza, thin base, 2 levels	universal pan + wire rack	3+1	₫	190-210	-	20-25
Pizza, thick base	wire rack	3	<u>&amp;</u>	180-200	-	20-25
Pizza, thick base, 2 levels	universal pan + wire rack	3+1	₫	190-210	-	20-30
Pizza baguette	wire rack	3	\$	200-220	-	15-20
Potatoe products, frozen						
Oven chips	universal pan	3	<u>&amp;</u>	190-210	-	25-35
Oven chips, 2 levels	universal pan + baking tray	3+1	₫	190-210	-	30-40
Croquettes	universal pan	3	\$	200-220	-	25-35
Hash browns	universal pan	3	\$	200-220	-	25-35
Potatoe wedges	universal pan	3	<u>&amp;</u>	190-210	-	25-35
Baked goods, frozen, prebaked						
Rolls, baguettes	universal pan	3	<u>&amp;</u>	180-200	-	10-15
Rolls, baguettes	universal pan	3		180-200	1	15-25
Fried food, frozen						
Fish fingers*	universal pan	3	=	200-220	-	20-30
Chicken nuggets	universal pan	3	<u>&amp;</u>	190-210	-	20-25
Food, chilled						
Lasagna, 500 g	ovenproof dish on wire rack	2	<u>&amp;</u>	190-210	-	25-35
Lasagna, 500 g	ovenproof dish on wire rack	2	S	180-190	2	30-40
Lasagna, 1,5 kg	ovenproof dish on wire rack	2	\$	180-200	-	30-40
Lasagna, 1,5 kg	ovenproof dish on wire rack	2	L	160-170	2	35-45
* Turn during cooking						

Dish	Accessories/cookware	Shelf po- sition	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Food, frozen						
Lasagna, 500 g	ovenproof dish on wire rack	2	<u>&amp;</u>	190-210	-	30-40
Lasagna, 500 g	ovenproof dish on wire rack	2	S	180-190	2	40-50
Lasagna, 1,5 kg	ovenproof dish on wire rack	2	<u>&amp;</u>	180-200	-	50-70
Lasagna, 1,5 kg	ovenproof dish on wire rack	2	S	160-170	2	45-55
* Turn during cooking						

# Yogurt

You can make your own yogurt using your appliance.

# **Preparing yogurt**

Remove accessories and shelves from the cooking compartment. The cooking compartment must be empty.

1. Heat 1 litre of milk (3.5 % fat) to 90 °C on the hob and then cool down to 40 °C.

It is sufficient to heat UHT milk to 40 °C.

- **2.** Stir in 150 g (chilled) yogurt.
- 3. Pour into cups or small jars and cover with cling film.
- Place the cups or jars onto the cooking compartment floor and use the settings indicated in the table.
- **5.** After preparation, leave the yogurt to cool in the refrigerator.

Type of heating used:

Dough proving

Dish	Cookware	Shelf position	Type of heating	Dough proving setting	Cooking time in hours
Yoghurt	individual moulds	cooking compartment floor	$\square$	1	5-6

# Eco types of heating

CircoTherm eco and Top/bottom heating eco are intelligent heating types for the gentle preparation of meat, fish and pastries. The appliance optimally controls the supply of energy to the cooking compartment. The food is prepared in phases using residual heat. This means that it remains more succulent and browns less. Energy can be saved, depending on the preparation and food.

Place the food into the empty cooking compartment before it has heated up. Always keep the appliance door closed when cooking.

Remove unused accessories from the cooking compartment. This will allow you to achieve optimum cooking results and save energy.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

# Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

# Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

# Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

# Baking tins and cookware

Dark- coloured metal baking tins are most suitable. These allow you to make energy savings of up to 35 per cent.

Cookware made from stainless steel or aluminium reflects heat like a mirror. Non-reflective cookware made from enamel, heat-resistant glass or coated, diecast aluminium is more suitable.

Tinplate baking tins, ceramic dishes or glass dishes prolong baking time, and the cake will not brown so evenly.

### Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

# **Recommended setting values**

Here, you can find specifications for the various dishes with CircoTherm Eco and Top/bottom heating Eco. The temperature and baking time depend on the consistency and amount of the dough. Settings ranges are indicated for this reason. Try with the lower values first. A lower temperature results in more even browning. You can increase the temperature next time if necessary.

**Note:** Baking times can not be reduced by using higher temperatures. Cakes or baked items would only be cooked on the outside, but would not be fully cooked in the middle.

Types of heating used:

- <u>L</u> CircoTherm eco
- Ē Top/bottom heating Eco

Dish	Accessories/cookware	Shelf po- sition	Type of heating	Tempera- ture in °C	Cooking time in mins.
Baking					
Victoria Sponge Cake	2x Ø20 cm tins	2	eco	170-180	25-35
Light Fruit Cake	high Ø20 cm tin	2	eco	150-170	70-90
Rich Fruit Cake	high Ø23 cm tin	2	eco	140-160	120-180
Fruit crumble	flat glass dish	3	eco	160-180	40-70
Sponge Cake (fatless), 3 eggs	springform cake tin Ø26 cm	2	eco	160-170	25-40
Swiss Roll	swiss roll tin	3	eco	180-190	15-25
Fruit Pie	plate Ø20 cm or pie tin	2	eco	170-190	60-75
Quiche	quiche tin (dark coated)	3	eco	190-210	35-45
(White) Bread	loaf tin (1x 900 g or 2x 450 g)	2	eco	190-200	40-50
Scones	baking tray	3	eco	190-210	15-20
Jam tarts	12-cup-tin	3	eco	180-200	20-30
Soufflé	1,2L-soufflé dish	2	eco	160-170	40-50
Meat Pie	rectangular pie tin	2	eco	190-200	40-55
Jacket Potatoes	baking tray	3	eco	150-170	60-90
Meat					
Beef, slow roast joint	wire rack	2	eco	140-150	35+40
Casserole					
Diced meat (beef, pork, lamb), 500 g meat	cookware, covered	2	eco	140	100-120
Braising steak	cookware, covered	2	eco	140	65+60
Fish					
Fish, braised, whole 300 g, e. g. trout	cookware, covered	2	eco	190-210	25-35
Fish, braised, whole 1,5kg, e. g. salmon	cookware, covered	2	eco	190-210	45-55
Fish fillet, plain, braised, 100 g	cookware, covered	2	eco	190-210	15-25

# Acrylamide in foodstuffs

Acrylamide is mainly produced in grain and potato products prepared at high temperatures, such as potato crisps, chips, sliced bread, bread rolls, bread or fine baked goods (biscuits, gingerbread, spiced biscuit).

Tips for keeping acrylamide to a minin	num
General	<ul> <li>Keep cooking times as short as possible.</li> <li>Cook food until it is golden brown, but not too dark.</li> <li>Large, thick pieces of food contain less acrylamide.</li> </ul>
Baking	With top/bottom heating at max. 200 °C. With hot air at max. 180 °C.
Biscuits	With top/bottom heating at max. 190 °C. With hot air at max. 170 °C. Egg or egg yolk reduces the production of acrylamide.
Oven chips	Spread out a single layer evenly on the baking tray. Cook at least 400 g at once on a baking tray so that the chips do not dry out.

# Slow cook

Slow cooking is a technique for cooking food over a long period at low temperatures. For this reason, it is also called "low-temperature cooking".

Slow cooking is ideal for all prime cuts (e.g. tender portions of beef, veal, pork, lamb or poultry) which are to be cooked "à point". The meat will remain succulent and tender.

The benefit of this cooking method is that it allows lots of scope for menu planning because slow-cooked meat is easy to keep warm. You do not have to turn the meat when cooking. Keep the appliance door closed in order to maintain an even cooking climate.

Only use fresh, clean and hygienic meat without bones. Carefully remove sinews and fat from around the edge. Fat develops a strong, distinct flavour during slow cooking. You can also use seasoned or marinated meat. Do not use defrosted meat.

Meat can be carved immediately following slow cooking. No standing time is required. Due to the special cooking method, the meat looks pink, but is not raw or undercooked.

**Note:** Delayed-start operation with an end time is not possible for the slow cooking heating type.

# Cookware

Use shallow cookware, e.g. a glass/porcelain serving dish. Place the cookware into the cooking compartment to preheat it.

Always place the uncovered cookware onto the wire rack at level 2.

You can find additional information in the tips on slow cooking attached to the settings table.

Your appliance features the heating type "Slow cook". Only start operation when the cooking compartment has fully cooled down. Allow the cooking compartment to warm up for approx. 15 minutes with the cookware inside.

Sear the meat on the hotplate at a very high heat and for a sufficiently long time on all sides, even on the ends. Place into the preheated cookware right away. Place the cookware containing the meat into the cooking compartment once again and cook slowly.

#### **Recommended setting values**

The slow cooking temperature and cooking time are dependent on the size, thickness and quality of the meat. Different settings ranges are indicated for this reason.

#### Type of heating used:

■ See Low temperature cooking

Dish	Cookware	Shelf posi- tion	Heating function	Searing time in mins	Tempera- ture in °C	Cooking time in mins
Poultry						
Duck breast, medium rare, 300 g each	Cookware, uncovered	2	8	6-8	90*	45-60
Chicken breast fillet, 200 g each, well done	Cookware, uncovered	2	Ø	4	120*	45-60
Turkey breast, boned, 1 kg, well done	Cookware, uncovered	2	Ø	6-8	120*	110-130
Pork						
Pork tenderloin steak, 5-6 cm thick, 1.5 kg	Cookware, uncovered	2	Ø	6-8	80*	130-180
Fillet of pork, whole	Cookware, uncovered	2	8	4-6	80*	45-70
Beef						
Joint of beef (rump), 6-7 cm thick, 1.5 kg	Cookware, uncovered	2	Ø	6-8	100*	150-180
Fillet of beef, 1 kg	Cookware, uncovered	2	8	4-6	80*	90-120
Sirloin, 5-6 cm thick	Cookware, uncovered	2	Ø	6-8	80*	120-180
Beef medallions/rump steak, 4 cm thick	Cookware, uncovered	2	ß	4	80*	30-60
Veal						
Joint of veal, 4-5 cm thick, 1.5 kg	Cookware, uncovered	2	8	6-8	80*	80-140
Joint of veal, 7-10 cm thick, 1.5 kg	Cookware, uncovered	2	8	6-8	80*	140-200
Fillet of veal, whole, 800 g	Cookware, uncovered	2	Ø	4-6	80*	70-120
Veal medallions, 4 cm thick	Cookware, uncovered	2	8	4	80*	30-50
* Preheat						

Dish	Cookware	Shelf posi- tion	Heating function	Searing time in mins	Tempera- ture in °C	Cooking time in mins
Lamb						
Saddle of lamb, boneless, 200 g each	Cookware, uncovered	2	Ø	4	80*	30-45
Leg of lamb, boned, medium, 1 kg, tied	Cookware, uncovered	2	Ø	6-8	95*	120-180
* Preheat						

# Tips for slow cooking

Slow-cooking duck breast.	Place the cold duck breast into a pan and fry the skin side first. After slow cooking, grill for 3 to 5 minutes until crispy.
The slow-cooked meat is not as hot as conventionally roasted meat.	So that the roasted meat does not cool so quickly, warm the plates and serve the sauces very hot.

# Drying

You can achieve outstanding drying results with CircoTherm. With this type of preserving, flavourings are concentrated by the dehydration.

Only use unblemished fruit, vegetables and herbs and wash them thoroughly. Line the wire rack with greaseproof paper or parchment paper. Drain the excess water from the fruit and dry it.

If necessary, cut it into equal chunks or thin slices. Place unpeeled fruit onto the dish with the sliced surfaces facing upwards. Ensure that neither fruit nor mushrooms overlap on the wire rack.

Grate vegetables and then blanch them. Allow the blanched vegetables to drain off and distribute them evenly on the wire rack.

Dry herbs on the stem. Position the herbs evenly and slightly heaped on the wire rack.

Use the following shelf positions for drying:

- 1 wire rack: Level 3
- 2 wire racks: Level 3+1

Turn very juicy fruit and vegetables several times. After drying, remove the dried products from the paper immediately.

### **Recommended setting values**

In the table, you can find settings for drying various foodstuffs. The temperature and cooking time are dependent on the type, moisture, ripeness and thickness of the food to be dried. The longer you leave the food to be dried, the better it will be preserved. The thinner the slices are, the quicker the drying process will be and the more aromatic the dried food will remain. Setting ranges are indicated for this reason.

If you wish to dry additional foodstuffs, you should use similar foodstuffs in the table as a reference.

Type of heating used:

& CircoTherm

Fruit, vegetables and herbs	Accessories	Type of heating	Tempera- ture in °C	Cooking time in hours
Pomes (apple rings, 3 mm thick, 200 g per wire rack)	1-2 wire racks	L	80	5-9
Stone fruit (plums)	1-2 wire racks	L	80	8-10
Root vegetables (carrots), grated, blanched	1-2 wire racks	L	80	5-8
Sliced mushrooms	1-2 wire racks	L	60	6-9
Herbs, washed	1-2 wire racks	S	60	2-6

# Preserving

You can preserve fruit and vegetables using your appliance.

# Marning – Risk of injury!

If the food is preserved incorrectly, the preserving jars may burst. Follow the instructions for preserving.

# Jars

Use only clean and undamaged preserving jars. Only use heat-resistant, clean and undamaged rubber rings. Check clips and clamps in advance.

For each preserving process, only use preserving jars that are the same size and contain the same food. In the cooking compartment, you can preserve the contents of a maximum of six  $\frac{1}{2}$ , 1 or  $\frac{1}{2}$ -litre preserving jars at the same time. Do not use jars that are larger or taller than this. The lids could rupture.

Preserving jars must not touch one another in the cooking compartment during the preserving process.

# Preparing fruit and vegetables

Only use fruit and vegetables that are in good condition. Wash them thoroughly.

Peel, core and chop fruit and vegetables appropriate to their type and fill the preserving jars with them up to approx. 2 cm below the rim.

# Fruit

Fill the preserving jars with the fruit along with a hot, skimmed sugar solution (approx. 400 ml for a 1-litre jar). For one litre of water:

- Approx. 250 g sugar for sweet fruit
- Approx. 500 g sugar for sour fruit

# Vegetables

Fill the jars with the vegetables along with hot, boiled water.

Wipe the rims of the jars, as they must be clean. Place a damp rubber ring and a lid on each jar. Seal the jars with clamps. Place the jars into the universal pan so that they do not touch each other. Pour 500 ml hot water (approx. 80 °C) into the universal pan. Use the settings indicated in the table.

# Ending the preserving process

# Fruit

After a short while, small bubbles will form at short intervals. Switch off the appliance once all preserving jars are bubbling. Remove the jars from the cooking compartment after the indicated cooling time.

### Vegetables

After a short while, small bubbles will form at short intervals. As soon as all preserving jars are bubbling, reduce the temperature to 120 °C and allow the jars to continue to bubble in the closed cooking compartment as indicated in the table. After this time has elapsed, switch off the appliance and make use of the residual heat for several minutes as indicated in the table.

After preserving, remove the jars from the cooking compartment and place them onto a clean cloth. Do not place these hot jars onto a cold or damp surface, as they may crack. Cover the preserving jars to protect them from draughts. Only remove the clamps once the jars are cold.

# **Recommended setting values**

The indicated times in the settings table are average values for preserving fruit and vegetables. They may be influenced by room temperature, the number of jars, quantity, heat and quality of the jar contents. The specifications are based on 1-litre round jars. Before you switch off the appliance or change the cooking mode, check whether the contents of the jars are bubbling as they should. The bubbling process starts after approx. 30-60 minutes.

Type of heating used:

& CircoTherm

Cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.		
1-litre preserving jars	1	S	160-170	Before it starts bubbling:30-40		
					120	When it starts to bubble: 30-40
			-	Residual heat: 30		
1-litre preserving jars	1	L	160-170	Before it starts bubbling: 30-40		
			-	Residual heat: 30		
1-litre preserving jars	1	L	160-170	Before it starts bubbling:30-40		
			-	Residual heat:35		
1-litre preserving jars	1	S	160-170	Before it starts bubbling:30-40		
			-	Residual heat: 25		
	<ul><li>1-litre preserving jars</li><li>1-litre preserving jars</li><li>1-litre preserving jars</li></ul>	tion1-litre preserving jars1-litre preserving jars1-litre preserving jars1	tionheating1-litre preserving jars11-litre preserving jars11-litre preserving jars122	tion         heating         ture in °C           1-litre preserving jars         1         & 160-170           -         -         -           1-litre preserving jars         1         & 160-170		

# Allowing the dough to prove at dough proving setting

Yeast dough will prove considerably more quickly using the "Dough proving" heating type than at room temperature and does not dry out. Only start operation when the cooking compartment has fully cooled down.

Always allow yeast dough to prove twice. Observe the specifications in the settings tables for the 1st and 2nd proving processes (dough fermentation and final fermentation).

#### **Dough fermentation**

Position the dough bowl on the wire rack for the dough fermentation. Use the settings indicated in the table.

Do not open the appliance door during the proving process, as moisture will escape. Do not cover the dough.

#### **Final fermentation**

Place your baked item into the oven at the shelf position indicated in the table.

Wipe moisture from the cooking compartment before baking.

#### **Recommended setting values**

The temperature and proving time are dependent on the type and quantity of the ingredients. The values in the table are therefore only meant to be average values.

Type of heating used:

Dough proving

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Step	Dough proving	Cooking time in mins.
Yeast dough, sweet						
E.g. small baked items	Bowl	2		Dough fer- mentation	1	30-45
	Universal pan	2		Final fermen- tation	1	10-20
Rich dough, e.g. panettone	Bowl	2		Dough fer- mentation	2	40-90
	Tin on wire rack	2		Final fermen- tation	2	30-60
Yeast dough, savoury						
E.g. pizza	Bowl	2		Dough fer- mentation	1	20-30
	Universal pan	2		Final fermen- tation	1	10-15
Bread dough						
White bread	Bowl	2		Dough fer- mentation	1	30-40
	Universal pan	2		Final fermen- tation	1	15-25
Multigrain bread	Bowl	2		Dough fer- mentation	1	25-40
	Universal pan	2		Final fermen- tation	1	10-20
Bread rolls	Bowl	2		Dough fer- mentation	1	30-40
	Universal pan	2		Final fermen- tation	1	15-25

# Defrosting

The defrost setting is suitable for defrosting frozen fruit, vegetables and baked items. Poultry, meat and fish should ideally be defrosted in the refrigerator.

Use the following shelf positions when defrosting:

- 1 wire rack: Level 2
- 2 wire racks: Level 3+1

### **Recommended setting values**

The times in the table are average values. They are dependent on the quality, freezing temperature (-18  $^{\circ}$ C) and composition of the food. Time ranges are indicated. Set the shortest time first and then extend the time if necessary.

**Tip:** Items which were frozen flat or portioned defrost faster than those frozen in a block.

Remove frozen food from the packaging and place it in suitable cookware onto the wire rack.

Stir the food or turn it once or twice in between. Large pieces of food should be turned several times.

Occasionally split the food or remove items which have already defrosted from the cooking compartment.

Leave the defrosted food to rest for another 10 to 30 minutes in the appliance whilst it is switched off, so that the temperature balances out.

Type of heating used:

Defrost setting

Dish	Accessories	Shelf posi- tion		Tempera- ture in °C	Cooking time in mins.
Bread, bread rolls					
Bread & bread rolls general	Baking tray	2	ð	50	40-70
Cake					
Cake, moist	Baking tray	2	ð	50	70-90
Cake, dry	Baking tray	2	ð	60	60-75

# Reheating

Using heating type "Reheating", food is reheated gently using steam. It tastes and looks as though it has been freshly prepared. Even baked items from the day before can be re-crisped.

Use containers which are as flat, wide and heatresistant as possible. Cold containers prolong the reheating process.

Where possible, only reheat dishes of the same size and type at the same time. If this is not possible, the time required for the component with the longest reheating time should be used as a basis.

Do not cover food while it is being reheated.

Place the food in the cookware onto the wire rack or place it directly onto the wire rack at level 2.

Do not open the appliance door during operation, as a lot of steam will escape.

# **Recommended setting values**

In the table, you can find the ideal settings for various dishes. The times specified are only average values. They are dependent on the cookware used, the quality, temperature and consistency of the food. Time ranges are indicated. Set the shortest time first and then extend the time if necessary.

The values in the table apply to dishes placed into a cold cooking compartment. Preheating is necessary for selected dishes, and this is indicated in the table.

Remove unused accessories from the cooking compartment. This will allow you to achieve ideal cooking results and save energy.

Type of heating used:

∎ 🖹 🖳 Reheat

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Vegetables, chilled					
1 kg	Cookware, uncovered	2	(=)	120-130	15-25
250 g	Cookware, uncovered	2	(≡)	120-130	5-15
Dishes, chilled					
Plated meal, 1 portion	Cookware, uncovered	2		120-130	15-25
Soup, stew, 400 ml	Cookware, uncovered	2		120-130	10-25
Side dishes, e.g. pasta, dumplings, potatoes, rice	Cookware, uncovered	2	(≡)	120-130	8-25
Bakes, e.g. lasagne, potato gratin	Cookware, uncovered	2		120-140	10-25
Pizza, cooked	Wire rack	2	(≡)	170-180*	5-15
Baked goods					
Bread rolls, baguette, baked	Wire rack	2		150-160*	10-20
Pastries (vol-au-vents)	Wire rack	2		180*	4-10
* Preheat					

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Baked goods, frozen					
Pizza, cooked	Wire rack	2		170-180*	5-15
Bread rolls, baguette, baked	Wire rack	2		160-170*	10-20
* Drohaat					

# **Keeping warm**

You can keep cooked dishes warm using the "Keeping warm" heating type. This will avoid condensation developing, and means you will not have to wipe out the cooking compartment.

Do not keep cooked dishes warm for longer than two hours. Be aware that some dishes may continue cooking whilst being kept warm. Cover the dishes if necessary.

# **Test dishes**

These tables have been produced for test institutes to facilitate the inspection of the appliance.

In accordance with EN 60350-1:2013 and IEC 60350-1:2011.

# Baking

Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

Shelf positions for baking on two levels:

- Universal pan: Level 3 Baking tray: Level 1
- Baking tins/dishes on the wire rack
   First wire rack: Level 3
   Second wire rack: Level 1

Shelf positions for baking on three levels:

- Baking tray: Level 4
- Universal pan: Level 3
- Baking tray: Level 1

# Apple pie

Apple pie on one level: place dark-coloured springform cake tins diagonally next to each other.

Apple pie on two levels: position dark-coloured springform cake tins above each other so that they are offset.

Cakes in tinplate springform cake tins: bake on one level with top/bottom heating. Place the springform cake tin onto the universal pan instead of onto the wire rack.

#### Fatless sponge cake

Fatless sponge cake on two levels: vertically stack springform cake tins in an offset manner on the wire racks.

#### Notes

- The setting values apply to dishes placed into a cold cooking compartment.
- Please note the information in the tables about preheating. The setting values are valid without rapid heating-up.
- For baking, use the lower of the indicated temperatures first.

Types of heating used:

- & CircoTherm
- $\equiv$  Top/bottom heating
- A Circotherm intensive

The levels of steam intensity are indicated as numbers in the table:

- 1 = Low
- 2 = Medium
- 3 = High

Dish	Accessory	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Baking						
Shortbread	Baking tray	3	=	140-150*	-	25-40
Shortbread	Baking tray	3	S	140-150*	-	25-40
Shortbread, 2 levels	Universal pan + baking tray	3+1	S	140-150*	-	30-40
Shortbread, 3 levels	Baking trays + universal pan	4+3+1	S	130-140*	-	35-55
Small cakes	Baking tray	3	=	160*	-	20-30
Small cakes	Baking tray	3	S	150*	-	25-35
Small cakes, 2 levels	Universal pan + baking tray	3+1	S	150*	-	25-35
Small cakes, 3 levels	Baking trays + universal pan	4+3+1	S	140*	-	35-45
* Preheat for 5 mins, do not use guick heat function						

** Preheat, do not use quick heat function

#### Tested for you in our cooking studio en

Dish	Accessory	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Fatless sponge cake	Springform cake tin, diameter 26 cm	2	=	160-170**	-	25-35
Fatless sponge cake	Springform cake tin, diameter 26 cm	2	S	160-170**	-	30-40
Fatless sponge cake	Springform cake tin, diameter 26 cm	2	S	150-160	1	10
					-	20-25
Fatless sponge cake, 2 levels	Springform cake tin, diameter 26 cm	3+1	S	150-170**	-	30-50
Apple pie	2 x black plate tins, diameter 20 cm	2	$\underline{\&}$	170-180	-	60-80
Apple pie	2 x black plate tins, diameter 20 cm	2		180-200	-	60-80
Apple pie, 2 levels	2 x black plate tins, diameter 20 cm	3+1	S	170-190	-	70-90
* Preheat for 5 mins, do not use quick h	eat function					

** Preheat, do not use quick heat function


# Grilling

Also slide in the universal pan. The liquid will be caught and the cooking compartment stays cleaner.

# Type of heating used: Full-surface grill

Dish	Accessories	Shelf posi- tion		Tempera- ture in °C	Cooking time in mins.
Grilling					
Toasting bread*	Wire rack	4	****	290	4-6
Beefburger, 12 pieces**	Wire rack	4	****	290	25-30
* Do not preheat					
** Turn after 2/3 of the total time					

ſ	18
	K//
U	



Constructa Neff Vertriebs-GmbH Carl-Wery-Straße 34 D-81739 München

Register your product online





www.neff-international.com

9001127204 970607 en