






CL4TT11.0, CL9TX11Y0



















































Further information and explanations are available online:



Table of contents

1 Safety	. 9 . 9 . 9
2 Preventing material damage	13
3 Environmental protection and saving energy	13 13 13
4 Installation and connection4.1 Scope of delivery4.2 Installing and connecting the appliance4.3 Connecting the appliance to	13 13 14
the electricity supply 5 Familiarising yourself with your appliance	14 14 15 15
6 Accessories	15
7 Before using for the first time7.1 Preparing and cleaning the appliance7.2 Checking the water hard-	16
ness	16 17 17 18

8 Basic operation	18
8.1 Switching the appliance on	10
or off	18
8.2 Dispensing beverages	18
8.3 Double Shot and Triple Shot	19
8.4 Dispensing a coffee drink with milk	19
8.5 Dispensing two cups at once	20
9 Grinder	20
9.1 Setting the grinding level	20
10 Milk container shelf	20
10.1 Using the milk container	20
shelf	20
10.2 Using your own milk container ¹	20
0011tai1101	20
11 Childproof lock	21
11.1 Activating the child-proof	
11.1 Activating the child-proof lock	21 21
11.1 Activating the child-proof lock11.2 Deactivating the childproof	21
11.1 Activating the child-proof lock	
11.1 Activating the child-proof lock11.2 Deactivating the childproof	21
11.1 Activating the child-proof lock11.2 Deactivating the childproof lock12 Favourites	21 21
11.1 Activating the child-proof lock11.2 Deactivating the childproof lock	21 21
 11.1 Activating the child-proof lock 11.2 Deactivating the childproof lock 12 Favourites 12.1 Creating favourites from Favourites menu 12.2 Create favourites from 	21 21 21
 11.1 Activating the child-proof lock	21 21 21
 11.1 Activating the child-proof lock	21 21 21 21
 11.1 Activating the child-proof lock	21 21 21 21 21 21 21 21
 11.1 Activating the child-proof lock	21 21 21 21 21 21 21 21
 11.1 Activating the child-proof lock	21 21 21 21 21 21 21 21
 11.1 Activating the child-proof lock	21 21 21 21 21 21 21 21

¹ Depending on the appliance specifications

13 TwistPad with twist knob ¹ 13.1 Using the twist knob	22 22
14 Home Connect	23 23 23 24
15 Basic settings	24 24 25
 16 Cleaning and servicing	26 27 27 28 28 28
17 Troubleshooting	30
18 Transportation, storage and disposal	35 35
19 Customer Service	35
20 Technical specifications	35
21 Declaration of Conformity	36

¹ Only possible for the NEFF Collection appliance series



1 Safety

Observe the following safety instructions.

1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for preparing hot drinks.
- in private households and in enclosed spaces in a domestic environment.
- up to an altitude of max. 2000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Children must not perform cleaning or user maintenance unless they are at least 8 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

1.4 Safe installation

⚠ WARNING – Risk of electric shock!

Incorrect installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Always use the supplied power cable for the new appliance.

en Safety

- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed.

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never operate an appliance with a cracked or fractured surface.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 35

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.

1.5 Safe use

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material. Children may breathe in or swallow small parts, causing them to suffocate.
- ► Keep small parts away from children.
- ► Do not let children play with small parts.

⚠ WARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

- ▶ Never immerse the appliance or the power cord in water.
- ► Liquids must not be spilled on the appliance plug connection.
- ► Only use the appliance in enclosed spaces.

- ► Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners to clean the appliance.

The appliance will become hot.

- Ventilate the appliance adequately.
- ► Never operate the appliance with the cupboard door closed. It is dangerous to use an extended power cord and non-approved adapters.
- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.
- ▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

Some parts of the appliance become very hot.

- ► Never touch hot appliance parts.
- ► Allow hot appliance parts to cool down before touching.

⚠ WARNING – Risk of scalding!

Freshly prepared drinks are very hot.

- ► Leave drinks to cool down if necessary.
- ► Do not let escaping liquids or steam come into contact with your skin.

A remote start via the Home Connect app while the appliance is unattended may cause scalding to third parties.

- Do not reach under the coffee outlet during the dispensing of drinks.
- Keep other persons, in particular children, away from the appliance.

⚠ WARNING – Risk of injury!

Improper use of the appliance may endanger the user.

► To avoid injuries, only use the appliance for its intended purpose.

en Safety

Trapped fingers when closing the appliance door.

- ► Be careful of your fingers when closing the appliance door. The grinder rotates.
- ► Never reach into the grinder.

⚠ WARNING – Danger: Magnetism!

Caution: Magnetism!

Warning for wearers of pacemakers

The appliance contains permanent magnets. They may affect electronic implants, e.g. pacemakers or insulin pumps.

- ► People with electronic implants must stand at least 10 cm away from the appliance and appliance door.
- ► Keep a minimum distance of 10 cm from the water tank, milk container, coffee dregs container, beverage outlet cover, beverage dispenser, beverage outlet, milk system holder, brewing chamber cover and brewing unit.

⚠ WARNING – Risk of harm to health!

Soiling on the appliance may be harmful to health.

► To ensure hygiene, follow the cleaning instructions for the appliance.

2 Preventing material damage

ATTENTION!

Risk of damage to the appliance. If the appliance is not started up correctly, it may be damaged.

- ▶ Use the appliance in frost-free rooms only.
- ▶ If the appliance has been transported or stored below 0 °C, wait 3 hours at room temperature before starting it up.
- After plugging in, always wait approx. 5 seconds.

Improper installation may cause material damage.

- Observe the installation instructions for the appliance installed above or below.
- When installing the appliance above a warming drawer, observe a niche height of 590 mm.

Unsecured units may fall over.

Secure units to the wall using a standard bracket.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recvcled.

 Sort the individual components by type and dispose of them separately.

3.2 Tips for saving energy

If you follow these instructions, your appliance will use less power.

Set the interval for automatic switchoff to the smallest value.

- ✓ If the appliance is not being used, it will switch itself off earlier.
 - → "Basic settings", Page 24

Do not interrupt the dispensing process prematurely.

 ✓ The amount of water or milk that is heated is used optimally.

Descale the appliance regularly.

✓ Limescale deposits increase the appliance's energy consumption.

4 Installation and connection

4.1 Scope of delivery

After unpacking all parts, check for any damage in transit and completeness of the delivery.

Note: Different accessories are enclosed depending on the appliance model. This accessory is shown in a frame with a dashed line.

→ Fig. **1**

- Fully automatic coffee machine
- В Milk container
- Installation instructions
- Water filter 1
- Water hardness testing strip
- User manual
- Microfibre cloth

Depending on the appliance specifications

4.2 Installing and connecting the appliance

The installation instructions describe various models that differ with regard to scope of supply and installation.

Note: Observe the information on safety → Page 9 and preventing material damage → Page 13.

 Install and connect the appliance properly in accordance with the installation instructions enclosed in the box.

4.3 Connecting the appliance to the electricity supply

- 1. Insert the non-heating appliance plug of the power cable into the appliance.
- 2. Insert the mains plug of the appliance's power cable in a socket nearby.
- 3. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance

You can find an overview of the parts of your appliance here.

Note: Individual details and colours may differ, depending on the appliance model.

Exterior view

→ Fig. 2

1	Shelf, removable
2	Lights
3	Control panel

4	Beverage outlet, height-ad- justable
5	Cup lighting
6	Appliance door
7	Beverage dispenser
8	Beverage outlet cover

Interior view

→ Fig. 3

9	Collecting tray

10 Rating plate

Water tank with lid 11

Mains switch

13 Accessory drawer

14 Bean container with lid

Interior lighting 1

16 Grinding level adjustment

Brewing chamber cover

18 Brewing unit

19 Milk container

20 Milk system

21 Milk container shelf, removable

Coffee dregs container

23 Drip tray

Drip tray cover

Depending on the appliance specifications

5.2 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

· •	
(1)	Switch the appliance on or off.
Favour- ites	Select saved beverages with personal settings. → Page 21
Classics	Select standard beverages.
Coffee World	Select basic beverages which can be extended in conjunction with Home Connect.
Care & mainten-ance	Call up service programmes.
Settings	Open or exit the settings.
D	Start or stop the process.

Info	rma	tion
11110	mna	uon

E Y	Customer service
िं	Appliance is connected to Home Connect.
蒼	Appliance is not connected to Home Connect.
((x	Appliance is not connected to the server.
Œ	Playlist function is activated in the Home Connect app.

	Check the milk container.
0	Add beans.
۵	Fill with water.

Beverage settings

	_	•
(1)		Strength
Š		Aroma
		Quantity
ŷ		Share of milk
Å		Temperature

Operation

-	
\leftarrow	Go back in the menu.
\bigcirc	Add favourite.
•	Delete favourite.
i	Call up information about the respective mode.
×2	Dispense two cups.

Quick selection

$\overline{\Leftrightarrow}$	Activate or deactivate childproof lock.
<u></u>	Switch WiFi on or off.

5.3 Lighting

In addition to the lighting, your application uses colours to indicate when an action is required. Follow the instructions on the display.

6 Accessories

Use original accessories. These have been made especially for your appliance.

en first time

Accessories	Retail	Customer service
Cleaning tablets	-	00311969
Descaling tablets	-	00311974
Water filter	-	17000705
Water filter pack of 3	-	17000706
Microfibre cloth	-	00312289
Milk container, glass	-	12043068
Limit stop for 92° opening angle	-	10020041
Power cord extension Europe, 5 m	-	12022522

7 Before using for the first time

Prepare the appliance for use.

7.1 Preparing and cleaning the appliance

Clean the appliance and individual parts. Follow the illustrated instructions at the beginning of this manual.

ATTENTION!

Unsuitable beans can block the grinder.

- Only use pure, roasted bean mixes that are suitable for use in fully automatic coffee or espresso machines.
- ▶ Do not use glazed coffee beans.
- ▶ Do not use caramelised coffee beans.
- Do not use coffee beans that have been treated with additives containing sugar.
- Do not add instant coffee.

→ Fig. 4 - 23

Note: Fill the water tank each day with fresh, cold, non-carbonated water.

Tip: To keep the coffee beans at their best, store them in a sealed container in a cool place. You can keep the coffee beans in the bean container for several days without them losing their aroma.

7.2 Checking the water hardness

It is important to set the water hardness correctly so that your appliance indicates in good time that it needs descaling. You can use the enclosed test strip to check the water hardness or ask your local water company.

- 1. Briefly dip the test strip in fresh tap water.
- **2.** Allow the water to drain off the test strip.
- **3.** Read the water hardness off the test strip after 1 minute.

The table shows allocation of the levels to the different degrees of water hardness:

_	Level	German degrees in °dH	Total hard- ness in mmol/ I
	1	1-7	< 1.3
	2	8-14	1.3-2.5
	3	15-21	2.5-3.8

Factory setting

Level	German degrees in °dH	Total hard- ness in mmol/ I
4 ¹	22-30	> 3.8

Factory setting

Note: If a water softening system is installed in your house, you can select "Water softening system".

Tips

- You can change the settings at any time.
 - → "Basic settings", Page 24
- If the water hardness exceeds 21 °dH (3.8 mmol/l), you can fill the water tank with prefiltered water to reduce limescale deposits.

7.3 Water filter1

You can use a water filter to minimise limescale deposits and reduce impurities in the water.

Inserting the water filter

ATTENTION!

Possible damage to the appliance due to limescale build-up.

- Change the water filter in good time
- Change the water filter after 2 months at the latest.
- Observe the display messages.
- 1. Press "Care & maintenance".
- 2. Press "INTENZA filter" and follow the instructions on the display.

Changing or removing the water filter

You can also operate your appliance without a water filter.

- 1. Press "Care & maintenance".
- 2. Press "INTENZA filter".

Press "Replace" or "Remove" and follow the instructions on the display.

Tips

- You should also change your water filter for reasons of hygiene.
- With a water filter you need to descale your appliance less frequently.
- If you use a water filter, your coffee will be more flavoursome.
- If your appliance has not been used for a long time, for example if you were on holiday, you should rinse the water filter before use by dispensing a cup of hot water.
- The water filter can be purchased from retailers or customer service. → "Accessories", Page 15

7.4 Performing initial start-up

After connecting the appliance to the power supply, configure the settings for initial start-up. Initial start-up only appears when switching on for the first time.

- 1. Open the appliance door.
- 2. Set the mains switch to l.
 - → Fig. **24**
- 3. Close the appliance door.
- Press ① to switch the appliance on and wait until the appliance has rinsed.
- Follow the instructions on the display.
- The display will guide you through the programme.

Tip: To call up brief information, press i.

¹ Depending on the appliance specifications

Notes

- If you want to set up Home Connect now, follow the instructions in the Home Connect app.
 - → "Setting up Home Connect", Page 23
- If "Demo mode" is selected, only the displays will work. You cannot dispense a beverage or run a programme.

7.5 General information

Please bear this information in mind so that you can get the best out of your appliance.

Notes

- The appliance has been programmed at the factory with standard settings for optimum operation.
- The integrated fan switches on each time a beverage is dispensed and switches off again after around 5-7 minutes.
- The grinder has been factory-set for optimum operation. If coffee is only dispensed drop by drop or is too thin and with too little crema, you can adjust the grinding level. → "Setting the grinding level", Page 20
- If you do not perform any actions on the appliance for a certain period, it will switch off automatically. You can change the duration in the basic settings.
- The first beverage will not yet have its full aroma if:
 - You are using the appliance for the first time.
 - You have run a service programme.
 - You have not used the appliance for a long time.

Do not drink the beverage.

8 Basic operation

8.1 Switching the appliance on or off

Notes

- Do not press the power switch while the appliance is operating.
- Before switching off the power switch, switch the appliance off with ①. This is the only way for the appliance to rinse automatically.
- ► Press ①.

When the appliance switches on, the display shows the logo. When the appliance is switched on or off, it will rinse itself automatically. When switched off, the appliance will emit steam into the drip tray for cleaning. The appliance will not rinse itself if the appliance is still warm when switched on or if no beverage was dispensed before it was switched off.

8.2 Dispensing beverages

Find out how to prepare a drink of your choice.

⚠ WARNING Risk of scalding!

Freshly prepared drinks are very hot.

- Leave drinks to cool down if necessary.
- Do not let escaping liquids or steam come into contact with your skin.

Notes

With a number of settings your coffee is prepared in several steps.
 Wait until the process is fully completed.

- If you are dispensing a beverage with milk, always connect a container filled with milk to the milk hose and suction pipe.
- The milk container is specially designed for this appliance. Only use the milk container for storing milk in the refrigerator and in the house.
- If the milk system has not been cleaned, small amounts of milk may escape when hot water is dispensed.

8.3 Double Shot and Triple Shot

Your appliance grinds the coffee two or three times.

To ensure that only pleasant-tasting and easily digestible aromatic substances are released, coffee beans are freshly ground and brewed again by the appliance.

The longer coffee brews, the more bitter substances and undesirable aromas are released. These bitter substances and undesirable aromas affect the taste and digestibility of coffee.

Note: The functions "Double Shot" and "Triple Shot" depend on the beverage strength and beverage size selected.

8.4 Dispensing a coffee drink with milk

An example explains how to make a latte macchiato.

⚠ WARNING Risk of burns!

The milk system can become extremely hot.

 Never touch the milk system when it is hot.

 Allow the hot milk system to cool down before touching it.

Requirements

- The milk container is inserted.
- The milk system is connected to the beverage dispenser.
- The milk container has been filled with sufficient milk.
- 1. Place a glass underneath the beverage outlet.
- Press "Classics".
- 3. Select and press the beverage symbol for latte macchiato.
- **4.** Set the beverage parameters.
 - To change the strength, press 0 and slide your finger up or down.
 - To change the milk ratio, press and slide your finger up or
 - To change the per-cup quantity, press and slide your finger up or down.
- 5. Press □ and wait until the process is complete.
 - To completely stop dispensing the beverage, press D.
 - To stop only the current dispensing step, press >>.

Notes

- If you do not change any settings for approx. 30 seconds, the appliance will exit settings mode.
- The appliance saves the settings automatically.

Tips

- You can also pre-heat cups before dispensing using hot water.
- You can also use plant-based alternatives to milk, e.g. soya milk.
- The quality of the milk froth depends on the type of milk or plantbased alternative used.

8.5 Dispensing two cups at once

Depending on your beverage, you can make 2 cups at the same time.

Note: If the "Double Shot" or "Triple Shot" function is active, the function for dispensing two cups at once is not possible.

- **1.** Press the symbol for your desired drink.
- 2. Press × 2.
- → The display shows the setting ×2.
- Place two cups on the left and right underneath the beverage outlet.
- 4. Press №.

The beverage is prepared in 2 steps. The beans are ground in 2 grinding operations.

- ▼ The beverage is brewed and then runs into the cups.
- 5. Wait until the process is complete.

9 Grinder

Your appliance has an adjustable grinder, which you can use to customise the grinding level of your coffee beans.

9.1 Setting the grinding level

- - → Fig. **25**

Only change grinding level setting slightly.

The grinding level setting only takes effect after the second cup.

Tip: If the coffee is only dispensed drop by drop, set a coarser grinding level

If the coffee is too thin with too little crema, set a finer grinding level.

10 Milk container shelf

Your appliance detects when there is a milk container on the shelf.

10.1 Using the milk container shelf

- 1. Connect the milk container or milk carton and place it on the shelf.
- 2. Start dispensing.

Note: If the message "Please insert milk container." appears, dispensing is not possible.

10.2 Using your own milk container¹

With certain appliance series, you can use your own milk container.

- 1. Put out your own milk container.
- 2 Tare your own milk container. → "Overview of settings", Page 25 The appliance uses the weight to detect the quantity of milk in the milk container or the milk carton. If there is not enough milk in the milk container, a message will appear.

Note: If you use the standard milk container or a milk carton, the appliance detects this automatically.

¹ Depending on the appliance specifications

11 Childproof lock

You can lock the appliance, to protect children against scalding and hurns

11.1 Activating the childproof lock

Requirement: The appliance is switched on.

- 1. Press .
- ✓ □ lights up red: childproof lock is activated.

11.2 Deactivating the childproof lock

- 1. Press :
- proof lock is deactivated.

12 Favourites

Save individual beverages as favourites so that you can dispense them more quickly.

A favourite is a beverage with personal settings. You can change the settings at any time.

12.1 Creating favourites from **Favourites menu**

- 1. Press "Favourites".
- 2. Press "Adding favourite".
- 3. Select a beverage.
- 4. Set the beverage parameters.
- 5. Press "Apply".
- 6. Enter the name.
- 7. Press "Save".

12.2 Create favourites from Classics or Coffee World

- 1. Select a beverage from "Classics" or "Coffee World".
- 2. Set the beverage parameters.
- **3.** Press ♥.
- 4. Fnter the name.
- 5. Press "Save".

12.3 Changing a favourite

- 1. Press "Favourites".
- 2. Select favourite.
- **3.** Press _∅.
- 4. Make the changes.
- 5. Press ✓.

12.4 Deleting a favourite

- Press "Favourites".
- 2. Select favourite.
- Press ♥.
- 4. Press "Delete".

12.5 Sorting favourites

You can change the sequence of vour favourites.

- 1. Press "Favourites".
- 2. Press 1.
- 3. To sort favourites, move the tiles to the required position with your fin-
- ▼ The appliance saves the new sequence automatically.

Tips

You can also use the Home Connect app to create, change, delete. or sort favourites.

If the appliance goes into standby, you can access the Favourites menu directly by pressing \heartsuit . If you have moved a favourite into the red tile in edit mode, you can access the favourite directly. Press the relevant icon to the right on the standby display.

13 TwistPad with twist knob1

If you have a twist knob, you can also use it on a fully automatic coffee machine, e.g. from a Neff oven.

Note: The twist knob is magnetic.

Observe all safety information and the cleaning instructions for the Twist-Pad and the twist knob in the instruction manual for the relevant appliance.

13.1 Using the twist knob

- 1. Fit the twist knob on the control panel to the left or right next to the display.
- 2. To operate the appliance, turn the twist knob and press the symbols.
- The display will adjust accordingly.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com. To be able to use Home Connect. you must first set up the connection to the WLAN home network (Wi-Fi²) and to the Home Connect app.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

Tip: Please also follow the instructions in the Home Connect app.

Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app. → "Safety", Page 9
- Operating the appliance on the appliance itself always takes priority. During this time it is not possible to operate the appliance using the Home Connect app.

14 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

Only possible for the NEFF Collection appliance series

² Wi-Fi is a registered trademark of the Wi-Fi Alliance.

14.1 Setting up the **Home Connect app**

1. Install the Home Connect app on your mobile device.



2. Start the Home Connect app and set up access for Home Connect. The Home Connect app guides you through the entire login process.

14.2 Setting up Home Connect

Requirements

- The Home Connect app has been installed on your mobile device.
- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- 1. Open the Home Connect app and scan the following QR code.



2. Follow the instructions in the Home Connect app.

14.3 Home Connect settings

Apple App Store und the Apple App Store logo are trademarks of Apple Inc.

Google Play and the Google Play logo are trademarks of Google LLC.

Adapt Home Connect to your needs.

You can find the Home Connect settings in the basic settings for your appliance. Which settings the display shows will depend on whether Home Connect has been set up and whether the appliance is connected to your home network.

Overview of the Home Connect settings

You can find an overview of the Home Connect settings and network settings here.

Basic setting	Selection	Description
Home Connect assistant	Start Disconnect	Add mobile device. Disconnect appliance from network.
WiFi	On Off	Switch off the wireless module during long absences or to save energy. Note: In networked standby mode your appliance requires max. 2 W.
Remote start	On Off	Switch remote start on the appliance on and off. Note: With the Home Connect app only switch-off is possible.
Software update	-	Note: This setting is only available with a software update.

14.4 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

15 Basic settings

You can configure the basic settings for your appliance to meet your needs and call up additional functions.

15.1 Changing settings

- 1. Press "Settings".
- The display shows the list of settings.
- 2. Change the required setting.
- The appliance saves the setting automatically.
- **3.** To go back to the menu, press \leftarrow .

Tip: To call up brief information, press i.

15.2 Overview of settings

You can find an overview of the basic settings here.

Language		Set language.
Home Connect	Home Connect assistant	→ "Setting up Home Connect", Page 23
Time		Set the current time or automatically display via Home Connect.
Date		Set current date or display automatically via Home Connect.
Display settings	Display brightness	Set the brightness in steps.
	Clock display	Switch the time display on and off after the appliance has been switched off.
	Clock	Set the time display.
	Adjustment	 Set the horizontal and vertical alignment of the display. Adjust the optimisation and centring of the display to the viewing angle.
Sounds	Button tone	Switch sound off and on.
	Volume	Adjust volume in steps.
	Welcome tune	Switch sound off and on when the appliance is started.
	Signal tone	Switch sound off and on.
Beverage setting	Brewing temperature	Set the brewing temperature.
	Milk sequence	Select the sequence for milk and coffee.
	Latte macchiato pause	Select the pause between milk and coffee.
Appliance settings	Automatic switch-off	Set the time after which the appliance switches off.
	Water hardness	Set the water hardness.
	Illumination brightness	Adjust brightness of the illumination in steps.
¹ Depending on the a	ppliance specifications	

en Cleaning and servicing

	Milk container ¹	Set milk carton or individual milk container. Note: If you use the standard milk container, the appliance automatically detects it.
Customisation	Start category	Set the menu display after switching on, e.g. "Classics".
Factory settings	Factory settings	Reset appliance to factory settings.
Demo mode	Mode for demo purposes	Switch "Demo mode" on or off.
Appliance information	Beverage counter	Display the number of beverages dispensed.
	Cleaning information	Time until the water filter should next be changed or a service programme started.
	Version information	Display appliance information.
	Network information	Display network information.
¹ Depending on the ap	pliance specifications	

16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

16.1 Dishwasher-safe components

Here you can find an overview of the components you can clean in the dishwasher.

ATTENTION!

Some components are sensitive to heat and may be damaged if they are cleaned in a dishwasher.

 Follow the operating instructions of the dishwasher.

- Only clean dishwasher-safe components in the dishwasher.
- Only use programmes that do not heat the components above 60 °C.

Suitable: 🖾

- Drip tray
- Drip tray cover
- Coffee dregs container
- Collecting tray
- Milk container with lid and base

Not suitable: X

- Water tank
- Water tank lid
- Brewing unit
- Beverage dispenser cover
- Brewing unit cover

- Shelf for milk container
- Beverage dispenser
- Milk system

- Accessory drawer
- Bean container
- Bean container lid

16.2 Cleaning agent

Only use suitable cleaning agents.


ATTENTION!

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive deteraents.
- Do not use cleaning agents containing alcohol or spirits.
- Do not use hard scouring pads or cleaning sponges.

Unsuitable cleaning and descaling agents may damage the appliance.

- Do not use pure citric acid, vinegar or any vinegar-based agents to descale the appliance.
- Do not use descaling agent with phosphoric acid.
- ► Only use cleaning tablets and descaling tablets that have been specially developed for the appliance.
 - → "Accessories", Page 15



Tips

Wash new sponge cloths thoroughly to remove any salt adhering to them. Salt can cause rust film to develop on stainless steel surfaces.

 Always remove any residues of limescale, coffee, milk and cleaning/descaling solutions immediately to prevent corrosion.

16.3 Cleaning the appliance

⚠ WARNING Risk of electric shock!

An ingress of moisture can cause an electric shock.

- ▶ Never immerse the appliance or the power cord in water.
- ► Liquids must not be spilled on the appliance plug connection.
- Do not use steam- or high-pressure cleaners to clean the appliance.

♠ WARNING Risk of burns!

Some parts of the appliance become very hot.

- Never touch hot appliance parts.
- Allow hot appliance parts to cool down before touching.
- 1. Clean the housing, the high-gloss surfaces and the control panel with the enclosed microfibre cloth
- 2. Clean the beverage outlet with a soft, damp cloth after beverages have been dispensed.
- 3. Rinse the water tank with fresh, clean water.
- 4. If the appliance has not been used for a long time, e.g. after a holiday, clean the entire appliance, including moving parts such as the brewing unit or water tank.

Note: The appliance will rinse itself automatically if you switch it on when it is cold or switch it off after it has dispensed coffee. The system is therefore self-cleaning.

16.4 Cleaning the drip tray and coffee dregs container

Clean and empty the drip tray and coffee dregs container every day to prevent deposits. Follow the illustrated instructions at the beginning of this manual.

→ Fig. **26** - **28**

16.5 Cleaning the milk container

Clean the milk container regularly for hygiene reasons. You can clean the milk container in the dishwasher. Follow the illustrated instructions at the beginning of this manual.

→ Fig. 19 - 22

16.6 Service programmes

Use the service programmes if you insert or remove a water filter or in order to clean your appliance thor-

oughly. Your appliance will tell you when you need to perform a service programme, e.g. cleaning.

ATTENTION!

Improper cleaning and descaling or a delay in doing so may damage the appliance.

- Immediately perform the descaling process in accordance with the instructions.
- ► Only put cleaning tablets in the brew chamber of the brewing unit.
- Do not put descaling tablets or other products in the brew chamber of the brewing unit.

Notes

- The display indicates the progress of the descaling or cleaning process.
- If your appliance has been locked, you can only operate it again once the descaling process has been carried out.

Tip: In addition to the automatic rinsing process, regularly also remove and clean the brewing unit.

Using the service programmes

- 1. Press "Care & maintenance".
- **2.** Press the required programme.
- The display will guide you through the programme.

Overview of service programmes

You can find an overview of the service programmes here.

Note: The start image shows the remaining number of beverages that can be dispensed until running the programme and the duration.

Ô	INTENZA filter	Insert, replace or remove the water filter.
<u> </u>	Cleaning milk system	Rinse the milk system automatically.

₩	Calc'n Clean	Combine cleaning and descaling. Remove residues of limescale and coffee from the pipes.
	Cleaning	Remove residues of coffee from the pipes.
*	Descale	Remove residues of limescale from the pipes.
_Å*	Frost protection	Drain the pipes to protect the appliance during transport or storage.
<u></u>	Cleaning brewing unit	The display shows optimum cleaning of the brewing unit step by step.
	Cleaning beverage system	The display shows optimum manual cleaning of the beverage dispenser and milk system step by step.
	Special rinsing	If a service programme is interrupted, e.g. due to a power failure, it will rinse itself automatically. The appliance is then ready for use again.

Tips

- If you are starting the "Descale" or "Calc'n Clean" programme, keep a container with a capacity of min. 0,5 I at the ready.
- If you use a water filter, this will prolong the time until you have to run a service programme.

 You can combine "Descale" and
- "Cleaning" with the "Calc'n Clean" service programme.

17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

⚠ WARNING

Risk of electric shock!

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ► If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.

Fault	Cause and troubleshooting
Home Connect is not working properly.	Different causes are possible. • Go to www.home-connect.com.
Appliance only dispenses water, not coffee.	Empty bean container is not detected by the appliance. Pour in coffee beans.
	Coffee shaft on brewing unit is blocked. Clean the brewing unit.
	Coffee beans are too oily and do not fall into the grinder. • Gently tap the bean container. • Change the coffee variety. • Do not use oily beans. • Clean the empty bean container with a damp cloth.
	Brewing unit is not inserted properly.1. Check whether the brewing unit is inserted correctly and is securely locked.2. Push the red lever up to the left.3. Insert the brewing unit cover.
Appliance is not dispensing milk froth.	Milk system is soiled. • Clean the milk system in the dishwasher.
	Milk tube not immersed in milk. ► Use more milk. ► Check whether the milk tube is immersed in the milk. Heavy build-up of limescale in the appliance.

Fault	Cause and troubleshooting
Appliance is not dispensing milk froth.	➤ Descale the appliance.
No milk intake by the milk system.	The milk system is assembled incorrectly. Assemble the milk system correctly.
	Milk tube not immersed in milk.► Use more milk.► Check whether the milk tube is immersed in the milk.
Milk froth is too cold.	Milk is too cold. ► Use lukewarm milk.
Appliance is not dispensing hot water.	Beverage dispenser is soiled. • Clean the beverage dispenser in the dishwasher.
Appliance is not dispensing drinks.	 Air is in the water filter. 1. Immerse the water filter in water with the opening facing upwards until no more air bubbles escape. 2. Reinsert the filter. Firmly press the water filter straight down into the tank connection.
	Residues of limescale remover are blocking the water tank. 1. Remove the water tank. 2. Clean the water tank thoroughly.
There is dripping water on the inner floor of the appliance.	Drip tray was removed too soon. ➤ Wait a few seconds after the last drink was dispensed before removing the drip tray.
Brewing unit cannot be removed.	Locking device cannot be released, brewing unit is jammed. ➤ Switch the appliance off and back on after 3 minutes.
Grinder won't start.	Appliance is too hot. 1. Disconnect the appliance from the mains. 2. Wait 1 hour so the appliance can cool down.
Grinder is not grinding any coffee beans despite full bean container.	Coffee beans are too oily and do not fall into the grinder. • Gently tap the bean container. • Change the coffee variety. • Do not use oily beans. • Clean the empty bean container with a damp cloth.

en Troubleshooting

Fault	Cause and troubleshooting
Coffee or milk froth quality varies widely.	Build-up of limescale in the appliance. • Descale the appliance.
Milk froth quality varies widely.	Milk froth quality depends on the type of milk or plant- based alternative used. ► Optimise the result through the selection of the milk or vegetable-based drink type.
Coffee is not dispensed or has slowed	Grinding level is set too fine. ► Set a coarser grinding level.
to a trickle. Set quantity is not reached.	Heavy build-up of limescale in the appliance. ▶ Descale the appliance.
reached.	Air is in the water filter.1. Immerse the water filter in water with the opening facing upwards until no more air bubbles escape.2. Reinsert the filter.
	Appliance is soiled. ► Clean the brewing unit. ► Descale and clean the appliance.
Coffee has no crema.	Type of coffee is not optimal.Use a coffee variety with a higher proportion of Robusta beans.
	Coffee beans are no longer freshly roasted. • Use fresh coffee beans.
	Grinding level is not appropriate for coffee beans. Adjust the grinder to a finer setting.
Coffee is too acidic.	Grinding level is set too coarse. Adjust the grinder to a finer setting.
	Type of coffee is not optimal. ► Use a coffee variety with a higher proportion of Robusta beans.
Coffee is too bitter.	Grinding level is set too fine. ► Set a coarser grinding level.
	Type of coffee is not optimal. ► Change the coffee variety.
Coffee tastes burnt.	Grinding level is set too fine. ► Set a coarser grinding level.
	Type of coffee is not optimal. ► Change the coffee variety.
	Coffee temperature setting is too high.

Fault	Cause and troubleshooting				
Coffee tastes burnt.	► Set the coffee temperature lower.				
Coffee grounds are not compact and are	The grinding level is not set optimally. • Adjust the grinder to a coarser or finer setting.				
too wet.	Coffee beans are too oily. • Use a different type of bean.				
Display shows "Please insert brewing unit.".	 Brewing unit is not inserted properly. 1. Check whether the brewing unit is inserted correctly and is securely locked. 2. Push the red lever up to the left. 3. Insert the brewing unit cover. 				
Display shows "Please fill the water tank."	Water tank is wrongly inserted. ► Insert the water tank correctly.				
despite the fact that the water tank is full.	Carbonated water is in the water tank. Fill the water tank with fresh tap water.				
	Float is stuck in the water tank. 1. Remove the water tank. 2. Clean the water tank thoroughly.				
	New water filter was not rinsed as per instructions. 1. Rinse the water filter according to the instructions. 2. Place the water filter into operation.				
	Air is in the water filter.1. Immerse the water filter in water with the opening facing upwards until no more air bubbles escape.2. Reinsert the filter.				
	Water filter is old. ► Insert a new water filter.				
	Limescale deposits in the water tank are blocking the system. 1. Clean the water tank thoroughly. 2. Start the descaling programme.				
Display shows "E61: Please clean brewing	Brewing unit is soiled. • Clean the brewing unit.				
unit.".	Mechanism of brewing unit is stiff. ► Clean the brewing unit.				
Display shows "Incorrect voltage".	There are problems with the power supply. ▶ Only operate the appliance at 220 - 240 V.				

en Troubleshooting

Fault	Cause and troubleshooting			
Display shows "Restart appliance".	Appliance has a fault.1. Set the mains switch to ○ and wait 60 seconds.2. Set the mains switch to I.			
Display shows calc'nClean very frequently.	Decalcified water still contains small amounts of lime. 1. Insert a new water filter. 2. Set the corresponding water hardness.			
	Incorrect or too little descaling agent used. • When descaling, only use suitable tablets.			
	Service programme has not been carried out in its entirety. ► Start the "Special rinsing" service programme. → "Service programmes", Page 28			

18 Transportation, storage and disposal

18.1 Activating frost protection

Protect your appliance from frost during transport and storage.

ATTENTION!

Residues of liquid in the appliance may damage it during transport or storage.

- Empty the pipe system before transport or storage.
- 1. Run the "Frost protection" programme.
 - → "Overview of service programmes", Page 28
- 2. Disconnect the appliance from the power supply.

18.2 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- 1. Unplug the appliance from the mains.
- **2.** Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE).

The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

19 Customer Service

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

19.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) on the appliance's rating plate. Make a note of your appliance's details and the Customer Service telephone number to find them again

20 Technical specifications

quickly.

Voltage	220- 240 V ~
Frequency	50 / 60 Hz

en Declaration of Conformity

Connection rating	1500 W
Maximum static pump pressure	20 bar
Maximum capacity of water tank (without filter)	2,2
Maximum capacity of bean container	400 g
Length of the power cable	170 cm
Appliance height	45,5 cm
Appliance width	59,4 cm
Appliance depth	37,7 cm
Weight, empty	20,6 kg
Type of grinder	Ceramic

This product contains light sources from energy efficiency classes D and F. These light sources are available as spare parts and may only be replaced by trained specialist staff.

20.1 Information regarding Free and Open Source Software

This product includes software components that are licensed by the copyright holders as free or open source software.

The applicable licence information is stored on your home appliance. You can also access the applicable licence information via your Home Connect app: "Profile -> Legal information -> Licence Information". You can download the licence information on the brand product website. (Please search on the product website for your appliance model

and additional documents). Alternatively, you can request the relevant information from oss-

request@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str. 34, 81739 Munich, Germany.

The source code will be made available to you on request.

Please send your request to oss-request@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str.34, 81739 Munich, Germany.

Subject: "OSSREQUEST"

The cost of performing your request will be charged to you. This offer is valid for three years from the date of purchase or at least as long as we offer support and spare parts for the relevant appliance.

21 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/FU.

A detailed RED Declaration of Conformity can be found online at www.neff-international.com among the additional documents on the product page for your appliance.




2.4 GHz band (2400-2483.5 MHz): Max. 100 mW 5 GHz band (5150-5350 MHz + 5470-5725 MHz): max. 200 mW

8	BE	BG	CZ	DK	DE	EE	ΙΕ	EL	ES
	FR	HR	IT	CY	LI	LV	LT	LU	HU

Depending on the appliance specifications

Declaration of Conformity en

	MT	NL	AT	PL	PT	RO	SI	SK	FI	_
	SE	NO	CH	TR	IS	UK (NI)				
5 GHz WLAN (Wi-Fi): For indoor use only.										
AL	ВА	N	ИD	ME	MK	RS	UK		UA	
5 GHz WLAN (Wi-Fi): For indoor use only.										





BSH Hausgeräte GmbH Carl-Wery-Straße 34 81739 München, GERMANY



Register your product online **neff-home.com**



8001292281

en 030607