U15M62.0GB



[en] Instruction manual2



en Table of contents

Safety precautions	3
Before installation	3
Safety notes	3
Causes of damage	3
Energy and environment tips	3
Saving energy	3
Environmentally-friendly disposal	4
Your new appliance	4
Control panel	
Operating modes	4
Shelf positions	5
Accessories	
Before using the appliance for the first time	6
Setting the clock	6
Cleaning the appliance	6
Operating the appliance	6
Switching on the appliance	6
Switching off the appliance	6
Electronic clock	6
Clock display	6
Timer	
Cooking time	
End of operation	
Preset operation	
Setting the clock	
Rapid heat up	
Checking, correcting or deleting settings	
Baking	
Baking on one level	
Baking on two or more levels	
Baking table	
Baking table for ready-made products	
Tips and tricks	
Roasting and braising	
Roasting	
Braising	
Tables for roasting and braising	
Tips and tricks	
Grilling	
Circo-roasting	
Radiant grilling	
Grilling table	
Defrosting	
Defrosting with CircoTherm®	
Defrost	
Yoghurt	17

Cleaning and care	17
Cleaning the appliance exterior	17
Cleaning the cooking compartment	17
Self-cleaning surfaces	18
Removing and fitting the appliance door	18
Cleaning the door panels	19
Cleaning the hook-in racks	19
Faults and repairs	20
Replacing the oven light bulb	20
Changing the door seal	21
After-sales service	21
E number and FD number	21
Test dishes	22

Additional information on products, accessories, replacement parts and services can be found at **www.neff-international.com** and in the online shop **www.neff-eshop.com**

△ Safety precautions

Please read this instruction manual carefully. Please keep the instruction and installation manuals in a safe place. Please pass on these manuals to the new owner if you sell the appliance.

Before installation

Damage during transport

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.

Electrical connection

Only a licensed expert may connect the appliance. You will lose your warranty entitlement in the event of any damage caused by incorrect connection.

Safety notes

This appliance is intended for domestic use only. This appliance must only be used for food preparation.

Adults and children must not operate the appliance without supervision,

- if they are physically or mentally incapable of doing so or
- if they have insufficient knowledge or experience.

Never let children play with the appliance.

Hot cooking compartment

Risk of burns!

- Never touch the interior surfaces of the cooking compartment or the heating elements. Open the appliance door carefully. Hot steam may escape. Small children must be kept at a safe distance from the appliance.
- Never prepare food containing large quantities of drinks with a high alcohol content. Alcoholic vapours can catch fire in the cooking compartment. Only use small quantities of drinks with a high alcohol content and open the appliance door carefully.

Risk of fire!

- Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance. Pull out the mains plug or switch off the circuit breaker in the fuse box.
- Do not place greaseproof paper loosely over accessories during preheating. A draught is created when the appliance door is opened. The greaseproof paper may come into contact with the heating element and catch fire. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. The greaseproof paper must not protrude over the accessories.

Risk of short circuit!

Never trap connecting cables of electrical appliances in the hot appliance door. The cable insulation could melt.

Risk of scalding!

Never pour water into the hot cooking compartment. This will produce hot steam.

Hot accessories and ovenware

Risk of burns!

Never remove ovenware or accessories from the cooking compartment without an oven cloth or oven gloves.

Improper repairs

Risk of electric shock!

Improper repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers. If the appliance is defective, pull out the mains plug or switch off the appliance at the circuit breaker in the fuse box. Call the after-sales service.

Causes of damage

Caution!

- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor if a temperature of over 50 °C has been set. This will cause heat to accumulate. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the
- Moist food: do not store moist food in the cooking compartment when it is closed for prolonged periods This will damage the enamel.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Cooling with the appliance door open: only allow the cooking compartment to cool when it is closed. Even if the appliance door is only open a little, front panels of adjacent units could be damaged over time.
- Heavily soiled oven seal: if the oven seal is heavily soiled, the oven door will no longer close properly when the oven is in operation. The fronts of adjacent units could be damaged. Always keep the oven seal clean.
- Oven door as a bearing surface: do not stand or place objects on the oven door when it is open. Do not place ovenware or accessories on the oven door.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.

Energy and environment tips

Here you can find tips on how to save energy when baking and roasting and how to dispose of your appliance properly.

Saving energy

Only preheat the oven if this is specified in the recipe or in the operating instruction tables.

Use dark, black lacquered or enamelled baking tins. They absorb the heat particularly well.

Open the appliance door as little as possible during cooking, baking or roasting.

It is best to bake several cakes one after the other. The cooking compartment is still warm. This may reduce the baking time for the second cake.

For longer cooking times, you can switch the oven off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance complies with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). The directive gives a framework for the collection and recycling of old appliances, which is valid across the EU.


Your new appliance

In this section, you will find information on

- the control panel
- the operating modes

- the shelf positions
- accessories

Control panel



Control element		Use		
Clock function button		Selects the required clock function or Rapid heat up (see section: Electronic clock)		
	Rotary selector	Makes settings within a clock function or activates Rapid heat up (see section: Electronic clock)		
	Operating mode selector	Selects the desired operating mode		
	Temperature selector	Sets the desired temperature		

Pop-out operating knob

The rotary, temperature and operating mode selectors can all be popped out. Push the required operating knob to pop it in or out.

Operating modes

Here is an overview of the operating modes of your appliance.

Bottom oven

Operating mode		Used for			
&	CircoTherm®	For baking and roasting on one or more levels			
	Top/bottom heat	For baking and roasting on one level. Especially suitable for cakes with moist toppings (e.g. cheesecake)			
<u>&</u>	CircoTherm intensive	For frozen ready-made products and dishes which require a lot of heat from underneath. (see section: Baking)			
Z	Circo-roasting	For poultry and larger pieces of meat			
***	Full-surface grill	For large amounts of flat, small items for grilling (e.g. steaks, sausages)			
""	Centre-area grill	For small amounts of flat, small items for grilling (e.g. steaks, bread)			
	Bottom heat	For food and baked goods which should form a crust or which need more browning on the underside			
		Only activate bottom heat for a short while at the end of the baking time.			

Operating mode		Used for
*	Defrost setting	For gentle defrosting of pieces of meat, bread and delicate pastries (e.g. cream gateau)
	Interior lighting	Provides assistance when maintaining and cleaning the cooking compartment

Top oven

Opera	iting mode	Used for
	Top/bottom heat	Especially suitable for cakes with moist toppings (e.g. cheesecake)
***	Full-surface grill	For large amounts of flat, small items for grilling (e.g. steaks, sausages)
	Centre-area grill	For large amounts of flat, small items for grilling (e.g. steaks, sausages)
	Interior lighting	Provides assistance when maintaining and cleaning the cooking compartment


Shelf positions

The shelf positions in the cooking compartment are counted from the bottom up.

Note: When baking and roasting with CircoTherm® 愚, do not use shelf position 2. This will adversely affect air circulation and your baking and roasting results will not be as good.

Bottom oven 🖃

The cooking compartment in the bottom oven has four shelf positions.



Top oven

The cooking compartment of the top oven has two shelf positions.




Accessories

The following accessories are supplied with your appliance:




Enamelled universal pan

for baking moist cakes, roasting, grilling and collecting dripping liquids



Wire rack, flat, with tilt protection For baking

Slide the flat wire racks in so that the rear upstand, for preventing items sliding off the back of the shelf, is at the rear and facing upwards (see illustration below). Otherwise, the tilt protection feature will not work properly.



You can obtain further accessories from specialist retailers:

Accessories	Order no.
System steamer	N8642X0EU
Grill set	Z1240X2
Glass pan	Z1262X0
Roasting pan, enamelled	Z1272X0
Baking tray, aluminium	Z1332X0
Baking tray, enamelled	Z1342X0
Baking tray, non-stick	Z1343X0
Wire rack with cut-out, stepped	Z1432X0
Roasting tray, enamelled, two-piece	Z1512X0
CLOU 1x telescopic railing retrofit kit	Z1701X1
CLOU 3x telescopic railings retrofit kit	Z1742X1
CLOU 4x telescopic railings retrofit kit	Z1752X1
Tilt protection retrofit kit, pull-out stop	Z9110X0
Universal roasting dish, enamelled	Z9930X0

Note: The baking tray and universal pan may become distorted during use. This is caused by the considerable temperature differences acting on the accessories. This may happen when only a part of the accessory is covered with food or when frozen items such as pizza have been placed on the accessory.

Before using the appliance for the first time

In this section, you can read about

- How to set the clock after connecting up your appliance
- How to clean your appliance before using it for the first time

Setting the clock

Note: When you press the ⟨□⟩ clock function button, you have 3 seconds to set the clock using the rotary selector. Should this have been insufficient for you, you can amend the clock time later.

 $\square:\square\square$ flashes in the clock display.

- Briefly press the ⟨□⟩ clock function button to go to the setting mode.
 - The $\triangleleft \triangleright$ and \bigcirc symbols light up. $i \ge : \square \square$ appears in the clock display.
- **2.** Set the current time using the rotary selector. Your setting is accepted after 3 seconds.

Changing the clock

To subsequently change the time, press the $\triangleleft \triangleright$ clock function button repeatedly until the $\triangleleft \triangleright$ and \bigcirc symbols light up again. Change the time with the rotary selector.



Cleaning the appliance

Clean your appliance before using it for the first time.

- Remove any accessories and residual packaging from both cooking compartments.
- 2. Clean the accessories and cooking compartments with hot soapy water (see section: Cleaning and care).
- **3.** Heat the at 270 °C using Full-surface grill and the bottom oven at 240 °C using CircoTherm for 30 minutes.
- **4.** Once the cooking compartments have cooled, wipe them out with hot soapy water.
- **5.** Clean the outside of the appliance with a soft, damp cloth and soapy water.

Operating the appliance

In this section, you can read about

- how to switch your appliance on and off
- how to select an operating mode and temperature

Switching on the appliance

- Turn the operating mode selector for the bottom oven or for the top oven clockwise until the desired operating mode is selected.
- **2.** Turn the corresponding temperature selector clockwise, until the desired temperature is selected.
 - The corresponding lindicator lamp lights up while the oven is heating up and during any subsequent heating.

Switching off the appliance

- 1. Turn the operating mode selector back to the o position.
- 2. Turn the temperature selector back to the position.

After the appliance is switched off, the cooling fan may continue to run.

Electronic clock

In this section, you can read about

- how to set the timer
- how to switch your appliance off automatically (cooking time and end of operation)
- how to switch your appliance on and off automatically (preset operation)
- how to set the time
- find out how to activate rapid heat up

Clock display



Clock function button F

Rotary selector

Clock function		Use			
△ Timer		You can use the minute minder as an egg timer or a kitchen timer. The appliance does not switch on or off automatically			
 	Cooking time	Bottom oven : The oven switches off automatically after a set cooking time (e.g. 1:30 hours).			
\rightarrow	End of operation	Bottom oven ■: The oven switches off automatically at a set time (e.g.: 12:30).			
	Preset operation	Bottom oven : The oven switches on and off automatically. Cooking time and end of operation have been combined.			
9	Clock	Sets the clock			
\$\$\$	Rapid heat up	Bottom oven 🖃: Decreases the preheat time			

Notes

- When you set a clock function, the time interval increases when you set higher values (e.g. cooking time up to !:☐☐h to the minute, using !:☐☐h to the nearest 5 minutes).
- For the △ minute minder, I→I cooking time, →I end of operation and preselection mode clock functions, a signal sounds when the settings have elapsed and the △ or →I symbol flashes. To cancel the audible signal before it ends, press the ⊲▷ clock function button.
- Briefly press the ⟨▷⟩ clock function button to select a clock function. You then have 3 seconds to set the selected clock function. After this time, the setting mode is exited automatically.

Switching the clock display on and off

- Press and hold the ⟨□⟩ clock function button for 6 seconds.
 The clock display switches off. If a clock function is active, the associated symbol remains lit.
- 2. Press the ⊲ Clock function button briefly. The clock display switches on.

Timer

- Press the ⟨□⟩ clock function button repeatedly until the ⟨□⟩ and △ symbols light up.
- 2. Set the duration using the rotary selector (e.g. 5:00 minutes). The setting is applied automatically. Then the clock is displayed again and the minute minder starts counting down.




Cooking time

Automatic switch-off after a cooking time setting has elapsed.

- **1.**Set the operating mode and temperature for the bottom oven. The bottom oven starts heating.
- 2. Press the ⟨▷ clock function button repeatedly until the ⟨▷ and I→I symbols light up.
- 3. Set the cooking time with the rotary selector (e.g. 1:∃□ hours).

The setting is applied automatically. The time is then displayed again and the set cooking time counts down.



Once the cooking time has elapsed, the appliance switches off automatically.

- Turn the operating mode and temperature selector back to the o position.
- **2.** Press the $\triangleleft \triangleright$ clock function button to exit the clock function.

End of operation

Automatic switch-off at a set time.

- **1.** Set the operating mode and temperature for the bottom oven. The bottom oven starts heating.
- Press the ⟨□⟩ clock function button repeatedly until the ⟨□⟩ and → symbols light up.
- 3. Set the end of operation using the rotary selector (e.g. 12:3₺ o'clock).

The setting is applied automatically. The clock is then displayed again.



The appliance switches off automatically at the time set for the end of operation.

- **1.**Turn the operating mode and temperature selector back to the O position.
- **2.** Press the $\triangleleft \triangleright$ clock function button to exit the clock function.

Preset operation

The bottom oven switches on automatically and switches off at the time preselected for the end of operation. To set this function, combine the cooking time and end of operation clock functions.

Bear in mind that food which spoils easily should not be left in the cooking compartment for too long.

- **1.** Set the operating mode and temperature for the bottom oven. The bottom oven starts heating.
- 2. Press the ⟨▷ clock function button repeatedly until the ⟨▷ and I→I symbols light up.
- 3. Set the cooking time with the rotary selector (e.g. 1:∃□ hours).

The setting is applied automatically.

- Press the
 Clock function button repeatedly until the
 and → symbols light up.
- **5.** Set the end of operation using the rotary selector (e.g. 12:30 o'clock).

The bottom oven switches off and waits until the correct time to switch on (in the example at $l: \square \square$). The bottom oven switches off automatically at the time set for the end of operation $l: \square \square$

- **6.** Turn the operating mode and temperature selector back to the o position.
- 7. Press the ⟨□⟩ clock function button to exit the clock function.

Setting the clock

You can only change the clock when no other clock function is active.

- Press the ⟨▷ clock function button repeatedly until the ⟨▷ and ⊗ symbols light up.
- **2.** Set the clock using the rotary selector. The setting is applied automatically.



Rapid heat up

With A CircoTherm®, you can shorten the heat up time if your selected temperature setting is higher than 100 °C.

Note: During Rapid heat up, do not place any food in the cooking compartment for as long as the \$\mathbb{M}\$ symbol is lit.

- **1.** Set the operating mode and temperature for the bottom oven. The bottom oven starts heating.
- 2. Press the ⟨□⟩ clock function button repeatedly until the ⟨□⟩ and ∭ symbols light up and ☐FF is displayed in the clock display.
- 3. Turn the rotary selector clockwise.

 In the clock display, ⊕n is displayed and the ∰ symbol lights up. Rapid heat up is activated for the bottom oven.



After reaching the set temperature, Rapid heat up switches off. The $\ensuremath{\mathbb{M}}$ symbol goes out.

Checking, correcting or deleting settings

- 1. To check your settings, press the ⟨□⟩ clock function button repeatedly until the corresponding symbol lights up.
- 2. If necessary, you can correct your setting using the rotary selector.
- **3.** If you wish to cancel your setting, turn the rotary selector anticlockwise to the original value.

Baking

In this section, you will find information on

- Baking on one level
- Baking on two or more levels
- The baking table
- The baking table for ready-made products
- Tips and tricks for baking

Note: Do not use shelf height 2 when baking with B. CircoTherm®. The air circulation is impaired and this will have a negative effect on your baking.

We recommend that you use dark baking tins made from metal.

Tinplate and glass dishes increase the baking time required and the cake will not brown evenly.


If you wish to bake using tinplate tins and \square Top/bottom heat, you should use shelf height 1.

Always slide the universal pan in carefully as far as it will go and make sure that the sloping edge is facing the appliance

Slide the flat wire racks in so that the rear upstand is at the rear. The baking tins therefore cannot slide off the back of the shelf.


Baking on one level

If you are baking on one level with & CircoTherm®, always place a round tin in the centre (Figure A) and always place a loaf tin diagonally (Figure B).





If you are baking on one level with &CircoTherm, always place two round baking tins diagonally from each other on the stepped wire rack (Figure C).



Baking on two or more levels


If you are baking on more than one level, only use the 🗟 CircoTherm operating mode.


Bear in mind that your items may brown at different rates on each level. The items on the top level will brown more quickly and can be taken out earlier.

Two baking tins on two levels

When baking with two round baking tins or two baking trays, slide the stepped wire rack in at shelf position 1 and the straight wire rack in at shelf position 3.

Place the lower baking tin to the left (Figure A) and the upper baking tin to the right (Figure B) on their respective wire racks.







Four baking tins on two levels

When baking with four round baking tins, slide the stepped wire rack in at shelf position 1 and the straight wire rack in at shelf position 3.

Place the lower baking tins diagonally from each other as shown in Figure C and the upper baking tins diagonally from each other as shown in Figure D on their respective wire racks.





Baking table

The details given in the table are guidelines and apply to dark baking tins. The values may vary depending on the type and amount of the dough/mixture and on the baking tin.

We recommend that you set the lower of the specified temperatures the first time. Lower temperatures will generally allow more even browning.

If you are baking according to your own recipe, use similar recipes in the table as a guide.

Observe the notes in the table about preheating.

Meal	Oven	Setting	Level	Temperature	Time in minutes
Victoria sponge cake		æ	1	160 - 170*	25 - 30
			2	160 - 170*	20 - 30
			1	160 - 170*	25 - 35
		B	1 + 3	150 - 160*	25 - 35
Scones		&	1	180 - 200*	10 - 15
			3	210 - 220*	8 - 10
			1	200 - 210*	10 - 12
		愚	1 + 3	180 - 200*	10 - 15
Small cakes		愚	1	160 - 170*	20 - 30
			3	150 - 160*	25 - 35
			1	150 - 160*	25 - 30
		B	1 + 3	150 - 160*	25 - 35
Light fruit cake	₽	B	1	140 - 150*	80 - 100
			2	160 - 170*	70 - 90
Rich fruit cake		B	1	140 - 150*	210 - 240
			2	140 - 150*	210 - 240
Jam tarts	₽	&	1	190 - 200*	15 - 20
			3	200 - 210*	15 - 20
			1	190 - 210*	15 - 25
		愚	1 + 3	190 - 200*	20 - 25
Swiss roll		B	1	180 - 190*	10 - 15
			2	190 - 200*	10 - 15
			1	180 - 190*	10 - 15

^{*} Preheat oven

^{**} Preheat the oven to 130 $^{\circ}\text{C}$

Meal	Oven	Setting	Level	Temperature	Time in minutes
Tart		愚	1	160 - 170*	50 - 60
		<u>&</u>	1	180 - 190*	45 - 55
		&	1 + 3	160 - 170*	50 - 60
Pies		æ	1	170 - 180*	65 - 75
		<u>&</u>	1	170 - 180*	65 - 75
		&	1 + 3	170 - 180*	65 - 75
Biscuits		&	1	160 - 170*	15 - 20
			2	170 - 180*	15 - 20
			1	170 - 180*	10 - 15
		&	1 + 3	160 - 170*	20 - 25
		&	1 + 3 + 4	160 - 170*	20 - 25
Meringue		&	1	80*	100 - 130
			3	80*	100 - 130
			1	80*	110 - 140
Pavlova		愚	1	90 - 100**	90 - 120
			3	80 - 90**	90 - 120
Fruit crumble		₽.	1	170 - 180*	45 - 55
			2	190 - 200*	45 - 55
Yorkshire pudding		愚	1	200 - 220*	15 - 20
		<u>&</u>	1	210 - 220*	10 - 15
		愚	1 + 3	200 - 220*	15 - 20
Vol au vents		₽.	1	190 - 200*	20 - 30
		<u>&</u>	1	180 - 190*	20 - 25
Quiche		愚	1	180 - 200*	20 - 25
		<u>&</u>	1	180 - 190*	20 - 25
(White) bread		₽.	1	210 - 220*	20 - 25
		<u>&</u>	1	200 - 220*	20 - 25
Homemade pizza		愚	1	190 - 200*	20 - 30
		<u>&</u>	1	180 - 190*	15 - 20
		愚	1 + 3	180 - 190*	35 - 45
Jacket potatoes		愚	1	160 - 170	60 - 70
		<u>&</u>	1	160 - 170	50 - 55
		&	1 + 3	160 - 170	65 - 75

^{*} Preheat oven

Baking table for ready-made products

Notes

- Use the universal pan
- Only use greaseproof paper that is suitable for the selected temperature
- Spread chips out in a single layer
- Turn frozen potato products half way through the baking time
- Only season frozen potato products after they have finished baking
- Leave a little space between the dough when baking bread rolls. Do not place too many in the universal pan
- Cover the lasagne with plenty of cheese so that the top browns evenly
- Do not use frozen products with freezer burn
- Do not use frozen products that are heavily frosted
- Follow the manufacturer's instructions.

The details given in the table are guidelines and apply to the universal pan.

We recommend that you set the lower of the specified temperatures the first time. Lower temperatures will generally allow more even browning.

If you are baking on more than one level, only use the &CircoTherm operating mode.

Observe the notes in the table about preheating.

^{**} Preheat the oven to 130 $^{\circ}\text{C}$

Meal	Oven	Setting	Level	Temperature in °C	C Time in minutes
Frozen pizza		₽.	1	180 - 200*	15 - 25
		<u>&</u>	1	180 - 200*	10 - 20
			1	180 - 200*	10 - 20
		₽.	1 + 3	170 - 190*	20 - 30
Chilled pizza		&	1	200 - 210*	10 - 15
		<u>&</u>	1	190 - 200	10 - 15
Part-baked white bread		₽	1	180 - 190*	10 - 20
		<u>&</u>	1	180 - 190*	5 - 15
			1	190 - 200*	5 - 15
		&	1 + 3	170 - 180*	15 - 20
Oven chips		&	1	180 - 200*	25 - 30
		<u>&</u>	1	180 - 190*	20 - 25
			1	190 - 200*	25 - 30
Potato wedges		₽.	1	180 - 190*	25 - 30
		<u>&</u>	1	180 - 190*	15 - 20
			1	190 - 200*	15 - 20
Croquettes		₽.	1	180 - 190*	25 - 30
		<u>&</u>	1	180 - 190*	20 - 25
			1	190 - 200*	20 - 25
Fish fingers		₽.	1	180 - 200*	15 - 20
		<u>&</u>	1	180 - 200*	10 - 15
			1	190 - 200*	10 - 15
Lasagne, frozen (400 g)		A.	1	180 - 190*	40 - 45
		<u>&</u>	1	180 - 190*	35 - 40
Lasagne, frozen (1200 g)		₽.	1	180 - 190*	45 - 50
		<u>&</u>	1	180 - 190*	40 - 45
Lasagne, chilled (400 g)		₽	1	170 - 180*	35 - 40
			2	190 - 200*	35 - 40
Lasagne, chilled (1200 g)		₽.	1	170 - 180*	40 - 45
			2	190 - 200*	

^{*} Preheat oven

Tips and tricks

The cake is too light in colour	Check the shelf height.			
	Check whether you have used the bakeware that we have recommended.			
	Place your tin on the wire rack and not on the baking tray.			
	If the shelf height and the bakeware are correct, then you should either extend the baking time or increase the temperature.			
The cake is too dark	Check the shelf height.			
	If the shelf height is correct, you should either shorten the baking time or reduce the temperature.			
The cake is unevenly browned in the	Check the shelf height.			
baking tin	Check the temperature.			
	Make sure that your baking tin is not placed directly in front of the air outlets in the rear panel of the cooking compartment.			
	Check that the baking tin is in the correct position on the wire rack.			
The cake is too dry	Set a slightly higher temperature and a slightly shorter baking time.			

The cake is too moist in the centre	Cat a alightly lower temperature		
The cake is too moist in the centre	Set a slightly lower temperature.		
	Note: Higher temperatures may not mean shorter baking times (cooked on the outside, but not on the inside).		
	Select a longer baking time and allow the cake mixture to prove for longer.		
	Add less liquid to the mixture.		
The cake collapses when you take it out of	Use less liquid for the mixture.		
the oven	Set a longer baking time or a slightly lower temperature.		
The specified baking time is not correct	For small items, check the quantity on the baking tray. Small items must not be touching each other.		
Frozen products are not browned evenly after baking	Check whether the frozen product is unevenly pre-browned before baking. This uneven browning will remain after the baking time.		
Several cakes on one level are unevenly browned	Check the position of the baking tins on the wire rack.		
Frozen products are not browned, not crispy or the specified times are not correct	Remove ice from frozen products before baking. Do not use frozen products that are heavily frosted		
Saving energy	Only preheat the appliance when it is specified in the baking table that you should do so.		
	Use dark baking tins as these absorb the heat better.		
	Make use of the residual heat with longer baking times and switch the oven off 5 - 10 minutes before the end of the baking time.		

Roasting and braising

In this section, you will find information on

- Roasting
- Braising
- Tables for roasting and braising
- Tips and tricks

There is a risk of injury if you use roasting dishes that are not heat-resistant!

Only use roasting dishes that are marked as being suitable for use in the oven.

Do not use shelf height 2 when roasting with & CircoTherm®. The air circulation would be impaired and this will have a negative effect on your roast.

Roasting

Roasting dish without a lid is used for roasting.

When you are roasting with Top/bottom heat, turn the roast approximately half to two thirds of the way through the roasting time.

Roasting in the universal pan

Juices escape from the roasting meat and are collected in the universal pan. You can use these juices as the basis for a tasty gravy.

Deglaze the pan of the juices with hot water, stock, wine or similar. Bring to the boil, thicken with cornflour, season and pass through a sieve if necessary.

You can also cook side dishes (e.g. vegetables) at the same time as roasting meat in the universal pan.

For smaller joints, you can use a smaller roasting dish instead of the universal pan. Place this directly on the wire rack.

Roasting in the universal pan with stepped wire rack

Place the stepped wire rack on the universal pan and slide them in together at the same shelf position.

For fatty meat and poultry, add $\frac{1}{8}$ to $\frac{1}{4}$ litre water to the universal pan, depending on the size and type of the joint.

While the meat is roasting, the liquid in the roasting dish will evaporate. Pour in more hot water if required.

Roasting in the universal pan with roasting sheet

The roasting sheet reduces dirt in the cooking compartment. Place the roasting sheet in the universal pan and slide them in together at the same shelf position.

Dripping fat and meat juices are caught in the universal pan.

Braising

For braising, a roasting dish with a lid is used. Ensure that the roasting dish and lid fit together well and close properly.

First, sear the meat if required.

Add the meat, vegetables and liquid to the roasting dish in equal proportions and place the dish with the lid closed on the wire rack at shelf position 1.

While the meat is braising, the liquid in the roasting dish will evaporate. Pour in more liquid if required.

Tables for roasting and braising

The details given in the table are guidelines and apply to food placed in a cold oven and for meat taken directly from the refrigerator.

Poultry

The information in the tables applies to unstuffed poultry. Turn the poultry after half of the cooking time.

Lean mea

Coat lean meat with fat or oil as required and cover it with strips of bacon.

Cooking time and temperature

The cooking time and temperature depend on the size, height, type and quality of the food and the roasting dish.

As a general rule: the larger the item, the lower the temperature and the longer the roasting time.

You should set the lower of the specified temperatures the first time. Lower temperatures will generally allow more even browning.

The values for cooking time apply to 0.5 - $2~{\rm kg}$ of food. For greater weights, reduce the temperature and increase the cooking time. For multiple pieces, apply the cooking time for the weight of the heaviest piece.

Standing time
At the end of the cooking time, switch the oven off and leave the roast to stand for approximately 10 minutes in the cooking compartment with the door closed. The recommended standing time is not included in the cooking times specified.

Meal	Oven	Setting	Level	Temperature in °	C Time in minutes (per 500 g)
Beef					
Slow roast joint		&	1	140	40 + 40
			2	150	40 + 40
Top side / top rump		愚	1	160	30 + 25
			2	190	30 + 25
Lamb					
Leg		悬	1	170	30 + 25
			2	200	30 + 25
Shoulder (on the bone)		₽	1	170	25 + 20
			2	200	25 + 20
Shoulder (boned and rolled)		&	1	170	30 + 25
			2	200	30 + 25
Rack of lamb		愚	1	180	25 + 25
			2	200	25 + 25
Pork					
Roasting point		&	1	180	35 + 35
			2	180	35 + 35
Loin joint		&	1	180	30 + 30
			2	180	30 + 30
Belly		愚	1	160	30 + 25
			2	190	30 + 25
Gammon					
Joint		恩	1	160	30 + 30
			2	190	30 + 30
Chicken					
Whole chicken		₽	1	170 - 180	20 + 25
			2	190 - 200	20 + 25
Portion (boned)		愚	1	190	20 + 25
			2	200 - 210	20 + 25
Quarter		&	1	190	20 + 25
			2	200 - 210	20 + 25
Duck		&	1	180	20 + 20
			2	190 - 200	20 + 20
Turkey					
Drumstick		₽ A	1	180	20 + 20
Crown		 &	1	160	25 + 20
Whole		<u> </u>	1	150 - 160	25 + 25
Complete Meal					
with beef		₽	1 + 3	160	30 - +25*
with chicken		&	1 + 3	180	20 + 25

^{* +} time for Yorkshire pudding

Casseroles	Oven	Setting	Level	Temperature in C°	Time in minutes (per 500 g)
Diced meat (beef, pork, lamb, chicken)		&	1	140	40 + 80
			1	140*	40 + 80
Braising steak		&	1	140	45 + 80
			1	140*	45 + 80
Chicken pieces (boned)		₽.	1	140	50 + 70
			2	140	50 + 70

^{*} Preheat oven

Tips and tricks

Crust too thick and/or roast too dry	Reduce the temperature or shorten the roasting time.
	Check the shelf height.
Crust too thin	Increase the temperature or switch on the grill briefly at the end of the roasting time.
The meat is not cooked right through	Remove any accessories that are not required from the cooking compartment.
	Increase the roasting time.
	Check the core temperature of the joint using a meat thermometer.
Steam in the cooking compartment is condensing on the appliance door	The steam dries during the course of the cooking. If there is an excessive volume of steam, you can carefully open the door briefly to dissipate the steam more quickly.
The meat is burned slightly during braising	Add the meat, vegetables and liquid to the roasting dish in equal proportions.
	The roasting dish and lid must fit together well and close properly.
	Reduce the temperature.

Grilling

In this section, you will find information on

- Grilling in general
- Circo-roasting
- Radiant grilling (Full-surface 🖾 and Centre-area grill 🖺)
- The grilling table

Caution!

There is a risk of damage to kitchen units if you grill with the appliance door open: The adjacent units may be damaged by the extreme heat. Keep the appliance door closed when using the grill.

Notes

- Always use the stepped wire rack and the universal pan when grilling.
- Place the stepped wire rack in the universal pan and slide them both in at the height specified in the grilling table
- Always place the food to be grilled in the centre of the wire rack
- If you are grilling more than one piece of meat, make sure that they are the same sort of meat and that they are of similar thickness and weight.

Circo-roasting

The Ticro-roasting operating mode is particularly suitable for poultry or meat (e.g. roast pork with crackling) that is to be crispy.

Turn large items of food after approximately half to two-thirds of the grilling time. For items of food with rind, place them on the wire rack rind-side down for the first half of the grilling time.

Pierce duck and goose skin under the wings and legs to allow the fat to escape.

Depending on the type of food you are cooking, the cooking compartment may become very dirty when you cook food on the wire rack using Circo-roasting. You should therefore clean

the cooking compartment after every use so that the dirt does not become burnt on.

At the end of the cooking time, switch the grill off and leave the food to stand for approximately 10 minutes in the cooking compartment with the door closed. The recommended standing time is not included in the grilling times specified.

Radiant grilling

For grilling large quantities of flat items, use the $\ ^{\boxtimes}$ Full-surface grill (Fig. A).

For grilling small quantities of flat items, use the Centre-area grill. Place the food to be grilled in the centre of the wire rack (Fig. B). Using the Centre-area grill operating mode will save energy.





Brush the items to be grilled with a little oil to taste.

Turn the items after half to two-thirds of the grilling time.

You can influence the grilling result by changing the position of the wire rack

Wire rack position	Use
~	Place the stepped wire rack in the universal pan with the step pointing downwards: suitable for grill items that should be well-done
	Place the stepped wire rack in the universal pan with the step pointing upwards: suitable for grill items that should be rare to medium

Note: Always use the universal pan in the standard position (not the other way up).

Grilling table

The details given in the table are guidelines and apply to the enamelled universal pan with stepped wire rack. The values

may vary depending on the type and amount of items to be grilled.

You should set the lower of the specified temperatures the first time. Lower temperatures will generally allow more even browning.

The values refer to food placed in the oven when it is cold and for meat taken directly from the refrigerator.

Meal	Oven	Setting	Level	Temperature in °C	Time in minutes (per 500 g)
Beef					
Steaks, 2 - 3 cm thick		***	4	270*	1st side: 9 - 12
					2 nd side: 5 - 7
		***	2	270*	1st side: 10 - 13
					2 nd side: 6 - 8
Burgers, 1 - 2 cm thick		***	4	270	1st side: 8 - 10
					2 nd side: 6 - 8
		***	2	270	1 st side: 10 - 12
					2 nd side: 6 - 8
Lamb					
Leg		II.	2	170 - 190	120 - 150***
Shoulder (on the bone)		Z	2	170 - 190	100 - 130***
Shoulder (boned and rolled)		X	2	170 - 190	120 - 130***
Steaks, 2 - 3 cm thick		***	4	270	1st side: 5 - 7
					2 nd side: 3 - 5
		***	2	270	1st side: 6 - 8
					2 nd side: 4 - 6
Chops, 2 - 3 cm thick		***	4	270	1 st side: 6 - 8
					2 nd side: 4 - 7
		***	2	270	1st side: 7 - 9
					2 nd side: 5 - 8
Pork					
Roast joint		[X	2	180 - 200	120 - 150***
Steaks, 1 - 2 cm thick		***	4	270*	1st side: 8 - 10
					2 nd side: 5 - 8
		***	2	270*	1st side: 9 - 12
					2 nd side: 6 - 8
Chops, 2 - 3 cm thick		***	4	270	1st side: 10 - 12
					2 nd side: 8 - 10
		***	2	270	1 st side: 10 - 13
					2 nd side: 8 - 12
Burgers, 1 - 2 cm thick		***	4	270	1st side: 8 - 10
					2 nd side: 6 - 8
		***	2	270	1st side: 10 - 12
				070	2 nd side: 6 - 8
Sausages, 2 - 4 cm thick			4	270	12 - 16**
	=	***	2	270	14 - 18**
Gammon					
Steaks, 1 - 2 cm thick		***	4	270	1st side: 9 - 12
					2 nd side: 5 - 7
		***	2	270	1st side: 10 - 12
					2 nd side: 5 - 7

^{*} Preheat for 3 minutes

^{**} Turn frequently

^{***} Turn after half of the time

Meal	Oven	Setting	Level	Temperature in °C	Time in minutes (per 500 g)
Chicken					
Drumsticks		***	3	250	1st side: 15 - 17
					2 nd side: 10 - 13
		***	2	250	1st side: 16 - 20
					2 nd side: 12 - 15
Breast (boneless)		***	4	250	1st side: 12 - 15
					2 nd side: 7 - 10
	=	**	2	250	1st side: 13 - 15
					2 nd side: 8 - 10
Whole chicken		\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	2	200 - 220	70 - 90***
Quarter		I	2	210 - 230	40 - 50***
Fish					
Whole fish, e.g. trout		***	3	220	1st side: 10 - 15
					2 nd side: 10 - 15
		Image: Control of the	2	220	15 - 25
Fillets		***	4	220	1st side: 8 - 12
					2 nd side: 7 - 10
		***	1	220	1st side: 9 - 13
					2 nd side: 8 - 12

^{*} Preheat for 3 minutes

Defrosting

In this section, you can read about

- how to defrost using CircoTherm®
- how to use the [*] Defrost operating mode

Defrosting with CircoTherm®

Use A CircoTherm® to defrost and cook frozen products.

Notes

- Frozen products that have been defrosted (meat in particular) require shorter cooking times than fresh products
- The cooking time for frozen meat increases by the defrosting time
- Always defrost frozen poultry before cooking so that you can remove the giblets
- Cook frozen fish at the same temperatures as fresh fish
- You can place large quantities of ready made frozen vegetables in aluminium dishes in the cooking compartment at the same time
- Use shelf height 1 when defrosting on one level, and shelf heights 1 + 3 when using two levels
- Observe the instructions on the packaging when using frozen foods.

Frozen meals	Temperatur e in °C	Defrosting time in minutes
Raw frozen products/ foods	50	30 - 90
Bread/Bread rolls (750 - 1,500 g)	50	30 - 60
Dry, frozen tray bakes	60	45 - 60
Moist, frozen tray bakes	50	50 - 70

Defrost

Using defrost setting 🚺 you can defrost delicate pastries particularly well (e.g. cream cakes).

- **1.** Switch on the T Defrost operating mode.
- 2. Defrost the frozen food for 25-45 minutes, depending on type and size.
- **3.** Remove the frozen food from the cooking compartment and let it thaw for 30 45 minutes.

With small quantities (pieces), the defrosting time is shortened to 15-20 minutes and the extended defrosting time is shortened to 10-15 minutes.

^{**} Turn frequently

^{***} Turn after half of the time

Yoghurt

You can also use the appliance to make home-made yoghurt: The heat of the 🔝 cooking compartment light is used for this.

- Remove accessories and hook-in racks, telescopic shelves or separate fitting systems.
- 2. Heat 1 litre of long-life milk (3.5 % fat) or fresh pasteurised milk to 40 °C
 - Bring 1 litre of fresh milk to the boil once and allow to cool down to 40 $^{\circ}\text{C}.$
- 3. Add 150 g of set yoghurt to the warm milk, stir in and fill the jars or bowls evenly. Do not pour more than 200 ml into any single container.

- 4. Cover the filled containers with a suitable lid or cling film.
- Preheat the oven at 100 °C for 15 minutes using the fullsurface grill.
- 6. Then set the operating mode selector to the ♠ cooking compartment light.
- **7.** Evenly space the containers over the cooking compartment floor, then close the appliance door.
- **8.** After 8 hours, switch off the 🗟 cooking compartment light and place the containers in the refrigerator for at least 12 hours.

Cleaning and care

In this section, you will find information on

- cleaning and care of your appliance
- Cleaning agents and aids
- Self-cleaning surfaces in the cooking compartment

A Risk of short circuit!

Do not use high-pressure cleaners or steam jet cleaners to clean your appliance.

Caution!

Surface damage due to incorrect cleaning: Do not use any

- harsh or abrasive cleaning agents
- cleaning agents that contain alcohol
- abrasive cleaning aids such as steel wool or scourers.

Observe the specifications in the tables.

Note: Highly recommended cleaning and care products can be purchased through our after-sales service. Observe the manufacturer's instructions.

Cleaning the appliance exterior

Appliance part/surface	Cleaning agent/aid
Stainless steel surfaces	Apply commercially available washing-up liquid with a soft, damp cloth or chamois; dry with a soft cloth.
	Use cleaners for matted stainless steel if very dirty.
Painted surfaces	Apply commercially available washing-up liquid with a soft, damp cloth or chamois; dry with a soft cloth.
Control panel	Apply commercially available washing-up liquid with a soft, damp cloth or chamois; dry with a soft cloth.
	Do not use glass cleaners or glass scrapers.
Door panels	Use a commercially available glass cleaner or washing-up liquid with a soft, damp cloth or chamois; dry with a soft cloth.
	The inner door panel on the appliance door has a coating which reduces the temperature and reflects the heat. The view through the appliance door is not impaired by this. When the appliance door is open, this coating can have the effect of a light-coloured film. This is part of the design and is not due to any quality defect.

Cleaning the cooking compartment

Caution!

Risk of damaging the surface. Do not clean the appliance while still warm, even if using oven cleaners specially intended for this purpose.

Notes

- Enamel is baked on at very high temperatures during manufacture. This can cause some slight colour variation. This is normal and does not affect proper functioning.
- The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough. Anti-corrosion protection is still guaranteed, however.

Appliance part	Cleaning agent/aid
Enamel surfaces (smooth surfaces)	To facilitate cleaning, you can switch on the interior lighting and detach the appliance door if necessary.
	Apply commercially available washing-up liquid or a vinegar solution with a soft, damp cloth or chamois; dry with a soft cloth.
	Loosen baked on food residues with a damp cloth and detergent.
	We recommend using oven cleaning gel if the oven is very dirty. This can be applied neat to the affected area.
	Leave the cooking compartment open to dry after cleaning.
Self-cleaning surfaces (rough surfaces)	Please see the notes in section: Self-cleaning surfaces
Door seal	Hot soapy water
Hook-in rack/telescopic shelf	Hot soapy water
Accessories	Soak in hot soapy water, clean with a brush and sponge or wash in the dishwasher.

Keeping the appliance clean

To avoid getting the cooking compartment dirty,

- clean the cooking compartment after each use, as dirt will bake on the next time it is heated up, and this can only be removed with difficulty
- always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately
- use 基 CircoTherm® whenever possible. This operating mode creates less dirt
- Use the universal pan to bake very moist cakes
- use suitable ovenware when roasting (e.g. roasting dish) or a roasting sheet (see section: Accessories)

Self-cleaning surfaces

The rear wall, ceiling and side walls of the cooking compartment are coated with self-cleaning enamel. This coating absorbs and disintegrates splashes from baking and roasting while the oven is in operation.

Large splashes only disappear after the oven has been used several times.

Discolouration on the self-cleaning surfaces does not affect the self-cleaning function.

Caution!

Damage to surfaces on self-cleaning areas due to applying oven cleaner. Never clean the self-cleaning surfaces with oven cleaner.

If oven cleaner accidentally gets onto self-cleaning surfaces, remove it immediately with a sponge and plenty of water.

Caution!

Damage to surfaces on self-cleaning areas due to the use of abrasive and acidic cleaning agents and aids.

Do not use cleaning agents containing abrasive substances or acids.

Do not use abrasive cleaning aids such as steel wool or scourers.

Removing and fitting the appliance door

You can remove the appliance door to clean it more thoroughly.

A Risk of injury!


The hinges of the appliance door may snap shut with great force. Always open the hinge locking lever fully when removing the appliance door and close it fully after refitting. Do not reach into the hinge.

A Risk of injury!

If the appliance door has only been unhinged on one side, do not reach into the hinge. The hinge can snap back with great force. Call the after-sales service.

Removing the appliance door


- 1. Open the appliance door fully.
- 2. Open the locking levers on the left and right-hand side fully.



The hinges are secured and cannot snap closed.


- **3.** Close the appliance door until resistance becomes noticeable (figure A)
- **4.** With both hands, grip the door on the left and right-hand side, close the door a little more and pull it out (figure B).






Fitting the appliance door

- **1.** Insert the hinges in the left and right-hand holders (figure C). The notch on both hinges must engage.
- 2. Open the appliance door fully.
- **3.** Close the locking levers on the left and right-hand side fully (figure D).





The appliance door is secured and can no longer be removed.

4. Close the appliance door.

Cleaning the door panels

To facilitate cleaning, you can remove the inner door panels from the appliance door.

A Risk of injury!

The components inside the appliance door may have sharp edges. Take care not to cut yourself. Wear protective gloves.


A Risk of injury!

The appliance must not be used again until the door panels and appliance door have been correctly fitted.

Remove the door panels from the ■ main oven and from the ■ top oven

Note: Before removing, make a note of which way round the door panel is fitted, so that it is not refitted the wrong way round


- 1. Unhook the appliance door and lay it on a soft, clean surface with the front side facing downwards (see section: Removing and installing the appliance door).
- 2. Unscrew the cover at the front left and right of the appliance door and detach it (Fig. A).
- 3. Lift the door panel and remove it (Fig. B).





Clean the intermediate panel on the 🗏 main oven

- 1. Unscrew the retainers on the left and right (Fig. C).
- 2. Unfold the retainers on the left and right.




- 3. Gently lift the intermediate panel and pull it out forwards.
- **4.** Clean the door panel and intermediate panel with glass cleaner and a soft cloth.

Caution!

Do not use any sharp or abrasive medium or a glass scraper. The glass could be damaged.

Refitting the intermediate panel:

1. Slide in the intermediate panel as far as it will go (Fig. D).




2. Close the retainers on the left and right and screw them tight.

Refitting the door panel:

- 1. Slide in the door panel all the way.
- 2. Put the cover back in place and screw it in.
- 3. Refit the appliance door.

Clean the intermediate panel on the 🗏 top oven

- **1.** Press the retainer on the intermediate panel on one side and unlatch it, using a spatula for instance (Fig. C).
- 2. Unlatch the other side in the same way and remove the intermediate panel.




3. Clean the door panel and intermediate panel with glass cleaner and a soft cloth.

Caution

Do not use any sharp or abrasive medium or a glass scraper. The glass could be damaged.

Refitting the intermediate panel:

- **1.** Place the intermediate panel in the supports on the left and right (Fig. D).
- 2. Push the intermediate panel downwards in the retainers.



Refitting the door panel:

- 1. Slide in the door panel all the way.
- 2. Put the cover back in place and screw it in.
- 3. Refit the appliance door.


Cleaning the hook-in racks


You can remove the hook-in racks for easier cleaning.

A Risk of burning due to hot components in the cooking compartment!

Wait until the cooking compartment has cooled down.


- Push the hook-in rack upwards at the front and unhook to the side (figure A).
- **2.** Pull the hook-in rack forwards at the rear and unhook to the side (figure B).






- Clean the hook-in rack with washing-up liquid and a sponge or brush.
- 4. Align the hook-in rack with the indentation (a) facing downwards, so that the shelf heights match.

- 5. Insert the hook-in rack at the rear as far as it will go and push to the rear (figure C).
- **6.** Insert the hook-in rack at the front as far as it will go and push downwards (figure D).





Faults and repairs

It is not always necessary to call the after-sales service. Sometimes, you can find a remedy yourself. You will find some tips for troubleshooting in the following table.

A Risk of electric shock!

- Work on the appliance electronics may only be performed by a specialist.
- Always disconnect the appliance from the power supply when work is carried out on the electronics. Switch off the circuit breaker or remove the fuse from your household fuse box.

Problem	Possible cause	Remedial action
Electrical operation is malfunctioning (e.g. indicator lamps do not light up)	Fuse defective	Check fuses in the fuse box and replace if necessary
Liquid or thin dough runs to one side	Appliance not installed level	Check the appliance installation (see the Installation instructions)
☐:☐☐ flashes in the clock display	There was a power cut	Reset the clock (see section: Electronic clock)
Electronically controlled functions are malfunctioning	Energy surges (e.g. lightning strike)	Reset the function concerned
Smoke is generated during roasting or grilling	Fat is burning on the grill element	Continue grilling or roasting until the fat on the grill element is burnt away
	Wire rack or universal pan inserted incorrectly	Place the wire rack in the universal pan and insert them together at a lower shelf height
High levels of condensation are generated in the cooking compartment	Normal occurrence (e.g. when baking with very moist toppings or roasting a large joint)	Open the appliance door briefly from time to time during operation
Enamelled accessories have light, matt marks	Normal occurrence caused by dripping meat or fruit juices	Not possible
Door panels are misted up	Normal occurrence caused by temperature differences	Heat the appliance up to 100 °C and then switch off again after 5 minutes

Replacing the oven light bulb

Replace faulty oven light bulbs.

Spare bulbs can be obtained from the after-sales service or specialist retailers. Only use these oven light bulbs.

- \blacksquare For the main oven: E14, 220 240 V, 40 W, heat-resistant to 300 $^{\circ}\text{C}.$
- For the top oven: E14, 220 240 V, 25 W, heat-resistant to 300 °C.

A Risk of electric shock !

Disconnect the appliance from the power supply. Switch off the circuit breaker or remove the fuse from the household fuse box.

- Place a tea towel in the cold cooking compartment to prevent damage.
- 2. Turn the glass cover anticlockwise and remove it.



- 3. Replace the oven light bulb with a bulb of the same type.
- 4. Screw on the glass cover again.
- 5. Remove the tea towel and switch on the circuit breaker.


Note: Use rubber gloves if the glass cover cannot be unscrewed: Or order a special removal tool from the after-sales service:


- For the main oven: Order no. 613634
- For the top oven: Order no. 621743

Changing the door seal

If the door seal is defective, it must be replaced. Replacement seals for your appliance can be obtained from the after-sales service.

The door seal is attached in four places (figure A). When replacing it, disconnect and attach the hooks at all four points (figure B).





Check again to ensure that the seal is seated correctly in the corners in particular.

After-sales service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find the right solution in order to avoid unnecessary visits from a service technician.

E number and FD number

When calling us, please give the product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate containing these numbers can be found on the right-hand side of the oven door. You can make a note of the numbers of your appliance and the telephone number of the after-sales service in the space below to save time should it be required.

E no.	FD no.
After-sales service ®	

Please note that there will be a fee for a visit by a service technician in the event of a malfunction, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

To book an engineer visit and product advice

GB 0844 8928989 Calls from a BT landline

Calls from a BT landline will be charged at up to 3 pence per minute. A call set-up fee of up to 6 pence may apply.

IE 01450 2655

Trust the expertise of the manufacturer, and rest assured that the repair will be carried out by trained service technicians using original spare parts for your domestic appliance.


Test dishes

Test dishes tested to standard EN 50304/EN 60350 (2009) and IEC 60350. Please note the information in the tables about preheating. The table values do not include Rapid heat up.


Baking	Cookware	Oven	Setting	Level	Temperature	Time in minutes
Shortbread	Baking tray***			3	140 - 150**	20 - 25
	Baking tray***		æ	1	140 - 150**	20 - 30
	2 x baking tray***		B	1 + 3	140 - 150**	20 - 30
	3 x baking tray***		B	1 + 3 + 4	130 - 150**	35 - 45
Small cakes (x 20)	Baking tray***			3	160 - 170*	25 - 35
	Baking tray***		B	1	150 - 160*	25 - 35
	2 x baking tray***		B	1 + 3	150 - 160*	25 - 35
	3 x baking tray***		B	1 + 3 + 4	150 - 160*	25 - 35
Fat-free sponge cake	Springform cake tin dia. 26 cm			2	160 - 170**	20 - 30
	Springform cake tin dia. 26 cm		B	1	150 - 160**	20 - 30
German apple pie	2 x Springform cake tin, dia. 20 cm (see fig. A)		&	1	170 - 180**	70 - 80
	2 x Springform cake tin, dia. 20 cm		<u>&</u>	1	170 - 180**	70 - 80
	2 x Springform cake tin, dia. 20 cm (see fig. B and C)		&	1 + 3	170 - 180**	70 - 80


^{*} Preheat for 10 minutes

When baking apple pie using & CircoTherm@, always place both springform cake tins diagonally on the stepped wire rack (fig. A).



When baking apple pie on two levels, place the lower baking tin to the left on the stepped wire rack (fig. B) and the upper baking tin to the right on the straight wire rack (fig. C).





Grilling	Oven	Wire rack position	Setting	Level	Temperature in °C	Time in minutes	Cookware
White bread		~	***	2	275*	0.5 - 2	universal pan + stepped wire rack
Beef steaks		~	***	2	270	25 - 30**	universal pan + stepped wire rack

^{*} Preheat for 10 minutes

^{**} Preheat oven

^{***} Only use original baking trays, order no. Z1342X0

^{**} Turn after 3/3 of the time

