




T58.S1....
Hob

[en] INSTRUCTION MANUAL































| | | g^* | b^* |
|----------|---|---------|---------|
| A |  | 2.200 W | 3.700 W |
| |  | 3.300 W | 3.700 W |
| B | Ø 28 | 2.600 W | 3.700 W |
| C | Ø 14,5 | 1.400 W | 2.200 W |

*  IEC 60335-2-6

Table of contents

| | | |
|---|---|-----------|
|  | Intended use | 4 |
|  | Important safety information | 5 |
|  | Causes of damage | 6 |
| | Overview | 6 |
|  | Environmental protection | 7 |
| | Energy-saving advice | 7 |
| | Environmentally-friendly disposal | 7 |
|  | Induction cooking | 7 |
| | Advantages of induction cooking | 7 |
| | Cookware | 7 |
|  | Getting to know your appliance | 9 |
| | The control panel | 9 |
| | The hotplates | 10 |
| | Residual heat indicator | 10 |
|  | Twist-Pad with Twist knob | 11 |
| | Remove the twist knob | 11 |
| | Storing the twist knob | 11 |
| | Operating the hob without the twist knob | 11 |
|  | Operating the appliance | 12 |
| | Switching the hob on and off | 12 |
| | Setting a hotplate | 12 |
| | Chef's recommendations | 12 |
|  | Flex Zone | 15 |
| | Advice on using cookware | 15 |
| | As two independent hotplates | 15 |
| | As a single hotplate | 15 |
|  | Move function | 16 |
| | Activation | 16 |
| | Deactivating | 16 |
|  | Time-setting options | 17 |
| | Programming the cooking time | 17 |
| | The kitchen timer | 17 |
| | Stopwatch function | 18 |
|  | PowerBoost function | 18 |
| | Activating | 18 |
| | Deactivating | 18 |
|  | ShortBoost function | 19 |
| | Recommendations for use | 19 |
| | Activating | 19 |
| | Deactivating | 19 |
|  | Keep warm function | 19 |
| | Activation | 19 |
| | Deactivation | 19 |
|  | Frying Sensor | 20 |
| | Advantages when frying | 20 |
| | For frying with the frying sensor | 20 |
| | Temperature settings | 21 |
| | Table | 21 |
| | Setting procedure | 23 |
|  | Childproof lock | 23 |
| | Activating and deactivating the childproof lock | 23 |
| | Childproof lock | 23 |
|  | Wipe protection | 24 |
|  | Automatic safety cut-out | 24 |
|  | Basic settings | 25 |
| | To access the basic settings: | 26 |
|  | Energy consumption indicator | 27 |
|  | Cookware check | 27 |
|  | Cleaning | 28 |
| | Hob | 28 |
| | Hob surround | 28 |
| | Twist knob | 28 |
|  | Frequently Asked Questions (FAQ) | 29 |
|  | Trouble shooting | 30 |
|  | Customer service | 31 |
| | E number and FD number | 31 |
|  | Test dishes | 32 |

Additional information on products, accessories, replacement parts and services can be found at **www.neff-international.com** and in the online shop **www.neff-eshop.com**



Intended use

Read these instructions carefully. Please keep the instruction and installation manual, as well as the appliance certificate, in a safe place for later use or for subsequent owners.

Check the appliance after removing it from the packaging. If it has suffered any damage in transport, do not connect the appliance, contact the Technical Assistance Service and provide written notification of the damage caused, otherwise you will lose your right to any type of compensation.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance must be installed according to the installation instructions included.

This appliance is intended for private domestic use and the household environment only. The appliance must only be used for the preparation of food and beverages. The cooking process must be supervised. A short cooking process must be supervised without interruption. Only use the appliance in enclosed spaces.

This appliance is intended for use up to a maximum height of 4000 metres above sea level.

Do not use covers. These can cause accidents, due to overheating, catching fire or materials shattering, for example.

Do not use inappropriate child safety shields or hob guards. These can cause accidents.

This appliance is not intended for operation with an external clock timer or a remote control.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 8 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

We advise that you exercise caution using or standing near an induction hob while it is in operation, if you wear a pacemaker or a similar medical device. Consult your doctor or the device manufacturer concerning its conformity or any possible incompatibilities,

Important safety information

Warning – Risk of fire!

- Hot oil and fat can ignite very quickly. Never leave hot fat or oil unattended. Never use water to put out burning oil or fat. Switch off the hotplate. Extinguish flames carefully using a lid, fire blanket or something similar.
- The hotplates become very hot. Never place combustible items on the hob. Never place objects on the hob.
- The appliance gets hot. Do not keep combustible objects or aerosol cans in drawers directly underneath the hob.
- The hob switches off automatically and can no longer be operated. It may switch on unintentionally at a later point. Switch off the circuit breaker in the fuse box. Contact the after-sales service.

Warning – Risk of burns!

- The hotplates and surrounding area (particularly the hob surround, if fitted) become very hot. Never touch the hot surfaces. Keep children at a safe distance.
- The hotplate heats up but the display does not work. Switch off the circuit breaker in the fuse box. Contact the after-sales service.
- Metal objects on the hob quickly become very hot. Never place metal objects (such as knives, forks, spoons and lids) on the hob.
- After each use, always turn off the hob at the main switch. Do not wait until the hob turns off automatically after the pan is removed.

Warning – Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- Cracks or fractures in the glass ceramic may cause electric shocks. Switch off the circuit breaker in the fuse box. Contact the after-sales service.

Warning – Hazard due to magnetism!

The removable control element is magnetic. Magnets may affect electronic implants, e.g. heart pacemakers or insulin pumps. Thus, for persons with electronic implants: avoid carrying the control element in clothing pockets; keep a minimum distance of 10 cm to heart pacemaker or device.

Warning – Malfunction risk!

The hob is equipped with a fan in the lower section. If there is a drawer under the hob it should not be used to store small objects or paper, since they could damage the fan or interfere with the cooling if they are sucked into it.

There should be a minimum of 2 cm between the contents of the drawer and fan intake.

Warning – Risk of injury!

- When cooking in a bain marie, the hob and cooking container could shatter due to overheating. The cooking container in the bain marie must not directly touch the bottom of the water-filled pot. Only use heat-resistant cookware.
- Sauce pans may suddenly jump due to liquid between the pan base and the hotplate. Always keep the hotplate and saucepan bases dry.

Causes of damage

Caution!

- Rough pan bases may scratch the hob.
- Avoid leaving empty pots and pans on the hotplate. Doing so may cause damage.
- Do not place hot pans on the control panel, the indicator area, or the hob frame. Doing so may cause damage.
- Hard or pointed objects dropped on the hob may damage it.
- Aluminium foil and plastic containers will melt if placed on the hotplate while it is hot. The use of laminated sheeting is not recommended on the hob.

Overview

You will find the most frequently caused damage in the following table:

| Damage | Cause | Measure |
|----------------|--|--|
| Stains | Boiled over food. | Remove boiled over food immediately with a glass scraper. |
| | Unsuitable cleaning agent. | Only use cleaning agents that are suitable for this type of hob. |
| Scratches | Salt, sugar and sand. | Do not use the hob as a work surface or storage space. |
| | Cookware with rough bases scratch the hob. | Check the cookware. |
| Discolouration | Unsuitable cleaning agent. | Only use cleaning agents that are suitable for this type of hob. |
| | Pan abrasion. | Lift pots and pans when moving them. |
| Chips | Sugar, food with a high sugar content. | Remove boiled over food immediately with a glass scraper. |

Environmental protection

In this section, you can find information about saving energy and disposing of the appliance.

Energy-saving advice

- Always use the correct lid for each pan. Cooking without a lid uses a lot more energy. Use a glass lid to provide visibility and avoid having to lift the lid.
- Use pans with flat bases. Bases that are not flat use a lot more energy.
- The diameter of the pan base must match the size of the hotplate. Please note: pan manufacturers usually provide the diameter for the top of the pan, which is usually larger than the diameter of the pan base.
- Use a small pan for small amounts of food. A large pan which is not full uses a lot of energy.
- Use little water when cooking. This saves energy and preserves all the vitamins and minerals in vegetables.
- Select the lowest power level to maintain cooking. If the power level is too high, energy is wasted.

Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Induction cooking

Advantages of induction cooking

Induction cooking is very different from traditional cooking methods, as heat builds up directly in the item of cookware. This offers numerous advantages:

- Saves time when boiling and frying.
- Saves energy.
- Easier to care for and clean. Spilled food does not burn on as quickly.
- Heat control and safety – the hob increases or decreases the heat supply as soon as the user changes the setting. The induction hotplate stops the heat supply as soon as the cookware is removed from the hotplate, without having to switch it off first.


Cookware

Only use ferromagnetic cookware for induction cooking, such as:

- Cookware made from enamelled steel
- Cookware made from cast iron
- Special induction-compatible cookware made from stainless steel.

To check whether your cookware is suitable for induction cooking, refer to the section on → *"Cookware check"*.

To achieve a good cooking result, the ferromagnetic area on the base of the pan should match the size of the hotplate. If a hotplate does not detect an item of cookware, try placing it on another hotplate with a smaller diameter.




If the only hotplate being used is the flexible cooking zone, larger cookware that is particularly suited to this zone can be used. You can find information on positioning cookware in the section on → *"Flex Zone"*.




Some induction cookware does not have a fully ferromagnetic base:

- If the base of the cookware is only partially ferromagnetic, only the area that is ferromagnetic will heat up. This may mean that heat will not be distributed evenly. The non-ferromagnetic area may not heat up to a sufficient temperature for cooking.



- The ferromagnetic area will also be reduced if the material from which the base of the cookware is made contains aluminium, for example. This may mean that the cookware will not become sufficiently hot or even that it will not be detected.



Unsuitable pans


Never use diffuser hobs or pans made from:

- common thin steel
- glass
- earthenware
- copper
- aluminium

Properties of the base of the cookware

The material(s) from which the base of the cookware is made can affect the cooking result. Using pots and pans made from materials that distribute heat evenly through them, such as stainless-steel pans with a three-layer base, saves time and energy.

Use cookware with a flat base; if the base of the cookware is uneven, this may impair the heat supply.



Absence of pan or unsuitable size

If no pan is placed on the selected hotplate, or if it is made of unsuitable material or is not the correct size, the power level displayed on the hotplate indicator will flash. Place a suitable pan on the hotplate to stop the flashing. If this takes more than 90 seconds, the hotplate will switch off automatically.

Empty pans or those with a thin base

Do not heat empty pans, nor use pans with a thin base. The hob is equipped with an internal safety system. However, an empty pan may heat up so quickly that the "automatic switch off" function may not have time to react and the pan may reach very high temperatures. The base of the pan could melt and damage the glass on the hob. In this case, do not touch the pan and switch the hotplate off. If it fails to work after it has cooled down, please contact the Technical Assistance Service.


Pan detection

Each hotplate has a lower limit for pan detection. This depends on the diameter of the ferromagnetic area of the cookware and the material from which its base is made. For this reason, you should always use the hotplate that best matches the diameter of the base of the pan.

Getting to know your appliance

You can find information on the dimensions and power of the hotplates in → *Page 2*

The control panel



| Controls | |
|----------|------------------------------------|
| ⓘ | Main switch |
| L | Keep warm function |
| P | PowerBoost and ShortBoost function |
| 🔥 | Frying sensor |
| ☐ | Flexible cooking zone |
| ↕ | Move function |
| ⌚ | Stopwatch function |
| ⌚ | Programming the cooking time |
| 🔔 | Kitchen timer and childproof lock |

| Indicators | |
|------------|--|
| 0 | Operating status |
| 1-9 | Heat settings |
| H/h | Residual heat |
| 000 | Timer function |
| 🔒 | Locking the control panel for cleaning |
| P | PowerBoost and ShortBoost functions |
| 🍲 | PowerBoost function |
| 🔥 | ShortBoost function |
| L | Keep-warm function |
| 🔑 | Childproof lock |
| 🔥 | Frying sensor |
| ⌚ | Setting the cooking time |
| ☐ | Flexible cooking zone |
| ↕ | Move function |
| min | Time display |
| kWh | Energy consumption |

Controls



When the hob heats up, the symbols for the controls available at this time light up.

Touching a symbol activates the respective function.

Notes

- The corresponding symbols for the controls light up depending on whether they are available. The displays for the hotplates or the selected functions get brighter.
- Always keep the control panel clean and dry. Moisture can prevent it from working properly.
- Do not place any cookware near the indicators or sensors. The electronics could overheat.

The hotplates

| Hotplates | | |
|--|-----------------------|---------------------------------------|
|  | Simple hotplate | Use cookware that is a suitable size. |
|  | Flexible cooking zone | See section → " <i>Flex Zone</i> " |
| Only use cookware that is suitable for induction cooking; see section → " <i>Induction cooking</i> " | | |

Residual heat indicator

The hob has a residual heat indicator for each hotplate. This indicates that a hotplate is still hot. Do not touch a hotplate while the residual heat indicator is lit up.

The following are shown depending on the amount of residual heat:

- Display **H**: High temperature
- Display **h**: Low temperature


If you remove the cookware from the hotplate during cooking, the residual heat indicator and the selected heat setting will flash alternately.

When the hotplate is switched off, the residual heat indicator will light up. Even after the hob has been switched off, the residual heat indicator will stay lit for as long as the hotplate is still warm.

Twist-Pad with Twist knob

The twistpad is the area in which you can use the twist knob to select the hotplates and heat settings. The twist knob automatically centres itself in the twistpad area.

The twist knob is magnetic and is placed on top of the twistpad. To activate a hotplate, touch the twist knob at the level for the required hotplate. Turning the twist knob selects the heat setting.



Position the twist knob on the twist pad so that it is in the centre of the indicators which delimit the twist pad area.

Notes

- Even if the twist knob is not entirely central, this will not affect how the twist knob works.
- Always keep the twist knob clean. Soiling may impair its function.

Remove the twist knob.

If the twist knob is removed, the "Lock control panel for cleaning" function is activated.

The twist knob can be removed during cooking. The "Lock control panel for cleaning" function is activated for 35 seconds. If the twist knob is not placed back in position before this time elapses, the hob switches off.

Warning – Risk of fire!

If during this 35 seconds a metallic object is placed in the twistpad area, the hob may continue to heat up. Therefore, always switch off the hob using the main switch.

Storing the twist knob






A strong magnet is located inside of the twist knob. Keep the twist knob away from magnetic data carriers such as credit cards and cards with magnetic strips. Otherwise, these data carriers may be damaged beyond repair.

The magnet could also cause faults on televisions and screens.

Note: The twist knob is magnetic. Metal particles stuck to the bottom could scratch the surface of the hob. Always clean the twist knob thoroughly.

Operating the hob without the twist knob

The hob can also be operated without the twist knob:

1. Switch on the hob using the main switch.
2. Within the next 5 seconds, simultaneously touch and hold the  and  symbols for 4 seconds. An audible signal will sound.
3. Touch the  symbol repeatedly until the indicator for the required hotplate lights up.
4. Then set the required heat setting using the  or  symbol.

The hotplate has now been activated.

Notes



- The timer function cannot be activated without the twist knob.
- The twist knob can be placed back on the twistpad at any time.


Operating the appliance

This chapter explains how to set a hotplate. The table shows heat settings and cooking times for various meals.

Switching the hob on and off

Switch the hob on and off using the main switch.

To switch on: Touch the  symbol. The symbols for the hotplates and the functions available at this time light up.  lights up next to the hotplates. Position the twist knob in the area in which it can be used. The hob is ready for use.

To switch off: Touch the  symbol until the indicator goes out. All hotplates are switched off. The residual heat indicator remains lit until the hotplates have cooled down sufficiently.

Notes

- The hob switches off automatically if all hotplates have been switched off for more than 15 seconds.
- The selected settings are stored for four seconds after the hob has been switched off. If the hob is switched on again within this time, the previous settings are applied.

Setting a hotplate

Set the required heat setting using the twist knob.

Heat setting 1 = lowest setting.


Heat setting 9 = highest setting.

Every heat setting has an intermediate setting. This is marked with a dot.

Selecting a hotplate and heat setting

The hob must be switched on.

1. Select the hotplate. To do this, touch the twist knob in the appropriate area for the required hotplate.
2. Turn the twist knob until the required heat setting appears in the heat setting display.




The heat setting is set.

Changing the heat setting

Select the hotplate and change the heat setting using the twist knob.

Switching off the hotplate

Select the hotplate and turn the twist knob until  appears. The hotplate switches itself off and the residual heat indicator lights up.

Notes

- If no pan has been placed on the hotplate, the selected power level flashes. After a certain time has elapsed, the hotplate switches off.
- If a pan has been placed on the hotplate before switching on the hob, it will be detected within 20 seconds of pressing the main switch and the hotplate will be selected automatically. Once detected, select the power level within the next 20 seconds or the hotplate will switch off. If more than one pan is placed on the hob, only one will be detected when switching it on.

Chef's recommendations

Recommendations

- When heating up puree, cream soups and thick sauces, stir occasionally.
- Set heat setting 8 to 9 for preheating.
- When cooking with the lid on, turn the heat setting down as soon as steam escapes between the lid and the cookware. Steam does not need to escape for a good cooking result.
- After cooking, keep the lid on the cookware until you serve the food.
- To cook with the pressure cooker, observe the manufacturer's instructions.
- Do not cook food for too long, otherwise the nutrients will be lost. The kitchen clock can be used to set the optimum cooking time.
- For a more healthy cooking result, smoking oil should be avoided.
- To brown food, fry small portions in succession.
- Cookware may reach high temperatures while the food is cooking. We recommend that you use oven gloves.
- You can find recommendations for energy-efficient cooking in section → "Environmental protection"

Cooking table

The table shows which heat setting is suitable for each type of food. The cooking time may vary depending on the type, weight, thickness and quality of the food.

| | Heat setting | Cooking time (mins) |
|---|--------------|---------------------|
| Melting | | |
| Chocolate coating | 1 - 1. | - |
| Butter, honey, gelatine | 1 - 2 | - |
| Heating and keeping warm | | |
| Stew, e.g. lentil stew | 1. - 2 | - |
| Milk* | 1. - 2. | - |
| Heating sausages in water* | 3 - 4 | - |
| Defrosting and heating | | |
| Spinach, frozen | 3 - 4 | 15 - 25 |
| Goulash, frozen | 3 - 4 | 35 - 55 |
| Poaching, simmering | | |
| Potato dumplings* | 4. - 5. | 20 - 30 |
| Fish* | 4 - 5 | 10 - 15 |
| White sauces, e.g. Béchamel sauce | 1 - 2 | 3 - 6 |
| Whisked sauces, e.g. sauce béarnaise, hollandaise | 3 - 4 | 8 - 12 |
| Boiling, steaming, braising | | |
| Rice (with double the volume of water) | 2. - 3. | 15 - 30 |
| Rice pudding*** | 2 - 3 | 30 - 40 |
| Unpeeled boiled potatoes | 4. - 5. | 25 - 35 |
| Boiled potatoes | 4. - 5. | 15 - 30 |
| Pasta, noodles* | 6 - 7 | 6 - 10 |
| Stew | 3. - 4. | 120 - 180 |
| Soups | 3. - 4. | 15 - 60 |
| Vegetables | 2. - 3. | 10 - 20 |
| Vegetables, frozen | 3. - 4. | 7 - 20 |
| Cooking in a pressure cooker | 4. - 5. | - |
| Braising | | |
| Roulades | 4 - 5 | 50 - 65 |
| Pot roast | 4 - 5 | 60 - 100 |
| Goulash*** | 3 - 4 | 50 - 60 |
| * Without lid | | |
| ** Turn several times | | |
| *** Preheat to heat setting 8 - 8. | | |

| | Heat setting | Cooking time (mins) |
|--|--------------|---------------------|
| Roasting/frying with little oil* | | |
| Escalope, plain or breaded | 6 - 7 | 6 - 10 |
| Escalope, frozen | 6 - 7 | 8 - 12 |
| Chop, plain or breaded** | 6 - 7 | 8 - 12 |
| Steak (3 cm thick) | 7 - 8 | 8 - 12 |
| Poultry breast (2 cm thick)** | 5 - 6 | 10 - 20 |
| Poultry breast, frozen** | 5 - 6 | 10 - 30 |
| Rissoles (3 cm thick)** | 4. - 5. | 20 - 30 |
| Hamburgers (2 cm thick)** | 6 - 7 | 10 - 20 |
| Fish and fish fillet, plain | 5 - 6 | 8 - 20 |
| Fish and fish fillet, breaded | 6 - 7 | 8 - 20 |
| Fish, breaded and frozen, e.g. fish fingers | 6 - 7 | 8 - 15 |
| Scampi, prawns | 7 - 8 | 4 - 10 |
| Sautéing fresh vegetables and mushrooms | 7 - 8 | 10 - 20 |
| Stir-fry, vegetables, meat cut in Asian-style strips | 7 - 8 | 15 - 20 |
| Frozen dishes, e.g. roasted dishes | 6 - 7 | 6 - 10 |
| Pancakes (baked in succession) | 6. - 7. | - |
| Omelette (cooked in succession) | 3. - 4. | 3 - 6 |
| Fried eggs | 5 - 6 | 3 - 6 |
| Deep-fat frying* (150-200 g per portion in 1-2 l oil, deep-fat fried in portions) | | |
| Frozen products, e.g. chips, chicken nuggets | 8 - 9 | - |
| Croquettes, frozen | 7 - 8 | - |
| Meat, e.g. chicken portions | 6 - 7 | - |
| Fish, breaded or in beer batter | 6 - 7 | - |
| Vegetables, mushrooms, breaded or battered, tempura | 6 - 7 | - |
| Small baked items, e.g. doughnuts, fruit in batter | 4 - 5 | - |
| * Without lid | | |
| ** Turn several times | | |
| *** Preheat to heat setting 8 - 8. | | |

Flex Zone


You can use each flex zone as a single hotplate or as two independent hotplates, as required.

It consists of four inductors that work independently of each other. If using the flexible cooking zone, only the area that is covered by cookware is activated.


Advice on using cookware

To ensure that the cookware is detected and heat is distributed evenly, correctly centre the cookware:


As a single hotplate



Diameter smaller than or equal to 13 cm
Place the cookware on one of the four positions that can be seen in the illustration.




Diameter greater than 13 cm
Place the cookware on one of the three positions that can be seen in the illustration.



If the cookware takes up more than one hotplate, place it starting on the upper or lower edge of the flexible cooking zone.

As two independent hotplates



The front and rear hotplates each have two inductors and can be used independently of each other. Select the required heat setting for each of the hotplates. Use only one item of cookware on each hotplate.

As two independent hotplates

The flexible cooking zone is used like two independent hotplates.



Activating

See section → "Operating the appliance"

As a single hotplate

Using the entire cooking zone by connecting both hotplates.

Linking the two hotplates


1. Set down the cookware. Select one of the two hotplates in the flexible cooking zone and set the heat setting.
2. Touch the  symbol. The  indicator lights up. The flexible cooking zone is activated.

Note: The heat setting appears in the two displays for the flexible cooking zone.

Changing the heat setting


Select one of the two hotplates assigned to the flexible cooking zone and set the heat setting using the twist knob.

Adding new cookware

Set the new item of cookware down, select one of the two hotplates in the flexible cooking zone and then touch the  symbol twice. The new cookware is detected and the previously selected heat setting remains the same.

Note: If the cookware is moved to the hotplate being used or lifted up, the hotplate begins an automatic search and the heat setting selected previously is retained.

Disconnecting the two hotplates

Select one of the two hotplates assigned to the flexible cooking zone and touch the  symbol.

This deactivates the flexible cooking zone. The two hotplates will now function independently.


Note: If the hob is switched off, and then switched back on again later, the flexible cooking zone is reset to function as two independent hotplates.




Move function

This function activates the entire flexible cooking zone, which is divided into three cooking areas and which has preset heat settings.

Only use one item of cookware. The size of the cooking area depends on the cookware used and whether it is positioned correctly.



This means that an item of cookware can be moved during the cooking process to another cooking area with another heat setting:



Preset heat settings:

Front area = heat setting **9**

Middle area = heat setting **5**

Rear area = heat setting **L**.

The preset heat settings can be changed independently of one another. You can find out how to change these in the section on → "Basic settings"

Notes

- If more than one item of cookware is detected on the flexible cooking zone, the function is deactivated.
- If the cookware is moved within the flexible cooking zone or lifted up, the hob automatically starts searching and the heat setting of the area in which the vessel was detected is set.
- You can find information on the size and positioning of the cookware in the section on → "Flex Zone"

Activation

1. Select one of the two hotplates in the flexible cooking zone.
2. Touch the **1** symbol. The indicator beside the **1** symbol lights up. The flexible cooking zone is activated as a single hotplate. The heat setting in the area in which the cookware is located lights up in the display for the front hotplate. The function has now been activated.

Changing the heat setting

The heat settings for the individual cooking areas can be changed during the cooking process. Set the cookware down on the cooking area and change the heat setting using the twist knob.

Notes

- Only the heat setting in the area in which the cookware is located is changed.
- If the function is deactivated, the heat settings for the three cooking areas are reset to the preset values.

Deactivating

Touch the **1** symbol. The indicator beside the **1** symbol goes out.

The function was deactivated.

Note: If one of the cooking areas is set to **0**, the function deactivates after a few seconds.

Time-setting options




Your hob has three timer functions:


- Programming the cooking time
- Kitchen timer
- Stopwatch function

Programming the cooking time


The hotplate automatically switches off after the time that is set has elapsed.

Setting procedure:

1. Select the hotplate and the required heat setting.
2. Touch the  symbol. The  display for the hotplate lights up.  lights up on the timer display.



3. Use the twist knob to select the required cooking time.



The cooking time begins to elapse.

Notes


- The same cooking time can be set automatically for all hotplates. The set time for each of the hotplates counts down independently. You can find information on automatically programming the cooking time in section → "Basic settings"
- If the flexible cooking zone is selected as the only hotplate, the set time for the entire cooking zone is the same.
- If the Move function is selected for the combined hotplate, the set time for the three hotplates is the same.

Frying sensor




If a cooking time has been programmed for a hotplate and the frying sensor has been activated, the cooking time will not begin to count down until the selected temperature setting has been reached.

Changing or deleting the time


Select the hotplate and then touch the  symbol.

Change the cooking time using the twist knob or on the control panel or set  to delete the programmed cooking time.

When the time has elapsed

The hotplate switches off. An audible signal sounds,  appears in the hotplate display and  appears in the timer display for one minute. The hotplate indicator  flashes. Touch any symbol; the indicators go out and the audible signal ceases.

Notes





- If a cooking time was programmed for several hotplates, the cooking time which ends first appears in the timer display. The  display for the hotplate lights up.
- Select the relevant hotplate to call up the remaining cooking time for a hotplate. The cooking time is displayed for 10 seconds.
- You can set a cooking time of up to 99 minutes.

The kitchen timer

You can use the kitchen timer to set a time of up to 99 minutes.



This functions independently from the hotplates and from other settings. This function does not automatically switch off a hotplate.

How to activate the function



1. Touch the  symbol:  and the  indicator appear in the timer display.
2. Use the twist knob to select the required time.
3. Touch the  symbol again to confirm the selected time.

The time begins to elapse.

Changing or deleting the time

Touch the  symbol and use the twist knob to change the time or set it to .

When the time has elapsed



An audible signal sounds for one minute and the  symbol flashes in the timer display. Touch the  symbol again: The displays go out and the audible signal ceases.

Stopwatch function

The stopwatch function displays the time that has elapsed since activation.

This functions independently from the hotplates and from other settings. This function does not automatically switch off a hotplate.

Activating

Touch the  symbol. The  symbol and the — indicator light up in the timer display.

The time begins to elapse.

Deactivating


Touch the  symbol.  appear in the timer display and then go out.

The function is deactivated.


Note: This function must be selected in order to deactivate the stopwatch.



PowerBoost function

The PowerBoost function enables you to heat up large quantities of water faster than when using heat setting .

This function can always be activated for a hotplate, provided the other hotplate in the same group is not in use (see illustration).







Note: The PowerBoost function can also be activated in the flexible area if the cooking zone is being used as a single hotplate.

Activating

1. Select a hotplate.
2. Touch the  symbol. The  and  indicators light up.

The function is activated.

Deactivating

1. Select a hotplate.
2. Touch the  symbol. The  and  indicators go out. The heat setting  lights up in the hotplate's display.

The function is deactivated.


Note: In certain circumstances, the PowerBoost function can switch itself off automatically in order to protect the electronic elements inside the hob.

ShortBoost function

The ShortBoost function enables you to heat cookware faster than when using heat setting 9.

After deactivating the function, select the appropriate heat setting for your food.

This function can always be activated for a hotplate, provided the other hotplate in the same group is not in use (see illustration).




Note: With the flexible cooking zone, the ShortBoost function can be activated even if it is used as the only cooking zone.

Recommendations for use


- Always use cookware that has not been pre-heated.
- Use pots and pans with a flat base. Do not use cookware with a thin base.
- Never leave empty cookware, oil, butter or lard to heat up unattended.
- Do not place a lid on the cookware.
- Place the cookware on the centre of the hotplate. Ensure that the diameter of the base of the cookware corresponds to the size of the hotplate.
- You can find information on the type, size and positioning of the cookware in section → "Induction cooking"

Activating

1. Select a hotplate.
2. Touch the **P** symbol twice. The **P** and  indicators light up.

The function is activated.

Deactivating

1. Select a hotplate.
2. Touch the **P** symbol. The **P** and  displays go out. The heat setting 9 lights up in the display for the hotplate.

The function is deactivated.

Note: In certain circumstances, the ShortBoost function can switch itself off automatically in order to protect the electronic elements inside the hob.

Keep warm function

This function is suitable for melting chocolate or butter and for keeping food warm.

Activation

1. Select the required hotplate.
2. Touch the **L** within the next 10 seconds. **L** lights up on the display.

The function is activated.

Deactivation

1. Select the hotplate.
2. Touch the **L** symbol. The **L** indicator goes out. The hotplate switches itself off and the residual heat indicator lights up. The function is deactivated.



Frying Sensor

This function can be used to fry food while maintaining the suitable frying pan temperature.

The cooking zones that have this function are identified by the roasting function symbol.

Advantages when frying

- The hotplate only heats up if this is required to maintain the temperature. This saves energy and prevents the oil or fat from overheating.
- The roasting function reports when the empty frying pan has reached the optimum temperature for adding oil and then for adding the food.

Notes

- Do not place a lid on the pan. Otherwise, the function does not activate correctly. You can use a splash guard to prevent splashes of grease.
- Use suitable oil or fat for frying. If butter, margarine, extra virgin olive oil or lard is used, set heat setting 1 or 2.
- Never leave a frying pan, with or without food, unattended when it is being heated.
- If the hotplate is at a higher temperature than the cookware or vice versa, the frying sensor will not be activated correctly.

For frying with the frying sensor

Frying pans that are perfect for using with the frying sensor can be purchased from specialist retailers or through our technical after-sales service. Quote the relevant reference number:

- Z9451X0 15 cm frying pan.
- Z9452X0 19 cm frying pan.
- Z9453X0 21 cm frying pan.
- Z9455X0 28 cm frying pan. Only recommended for the 28 cm simple hotplate.

These frying pans have a non-stick coating so that you require only a small amount of oil to fry food.

Notes

- The frying sensor has been configured specifically for this type of frying pan.
- Ensure that the diameter of the base of the frying pan corresponds to the size of the hotplate. Put the frying pan in the centre of the hotplate.
- Using a frying pan of a different size or one that is poorly positioned on the flexible cooking zones may result in the frying sensor not being activated. See the section on → "Flex Zone".
- Other frying pans may overheat. They may reach a temperature above or below the selected temperature setting. Try the lowest temperature setting to begin with and change it if necessary.

Temperature settings

| Temperature setting | | Suitable for |
|---------------------|---------------|--|
| 1 | Very low | Preparing and preserving sauces, sweating vegetables and frying food in extra virgin olive oil, butter or margarine. |
| 2 | Low | Frying food using extra virgin olive oil, butter or margarine, e.g. omelettes. |
| 3 | Medium - low | Frying fish and Thick food, e.g. meatballs and sausages. |
| 4 | Medium - high | Frying steaks, medium or well-done, frozen, breaded and fine foods, e.g. escalope, fresh ragout and vegetables. |
| 5 | High | Frying food at high temperatures, e.g. steaks, bloody, potato fritter and Frozen French fries. |

Table

The table shows which heat setting is suitable for each type of food. The roasting time may vary depending on the type, weight, size and quality of the food.

The set heat setting varies depending on the frying pan that is used.



Preheat the empty pan; add oil and food after the acoustic signal has sounded.


| | Temperature setting | Total frying time after the signal sounds (mins.) |
|---|---------------------|---|
| Meat | | |
| Escalope, plain or breaded | 4 | 6 - 10 |
| Fillet | 4 | 6 - 10 |
| Chops* | 3 | 10 - 15 |
| Cordon bleu, Wiener Schnitzel* | 4 | 10 - 15 |
| Steak, rare (3 cm thick) | 5 | 6 - 8 |
| Steak, medium or well-done (3 cm thick) | 4 | 8 - 12 |
| Poultry breast (2 cm thick)* | 3 | 10 - 20 |
| Sausages, pre-boiled or raw* | 3 | 8 - 20 |
| Hamburger, meatballs, rissoles* | 3 | 6 - 30 |
| Meat loaf | 2 | 6 - 9 |
| Ragout, gyros | 4 | 7 - 12 |
| Ground meat | 4 | 6 - 10 |
| Bacon | 2 | 5 - 8 |
| Fish | | |
| Fish, fried, whole, e.g. trout | 3 | 10 - 20 |
| Fish fillet, plain or breaded | 3 - 4 | 10 - 20 |
| Prawns, scampi | 4 | 4 - 8 |
| Egg dishes | | |
| Pancakes** | 5 | - |
| Omelette** | 2 | 3 - 6 |
| Fried eggs | 2 - 4 | 2 - 6 |
| Scrambled eggs | 2 | 4 - 9 |
| Raisin pancake | 3 | 10 - 15 |
| French toast** | 3 | 4 - 8 |
| * Turn several times. | | |
| ** Total cooking time per portion. Fry in succession. | | |

| | Temperature setting | Total frying time after the signal sounds (mins.) |
|--|---------------------|---|
| Potatoes | | |
| Fried potatoes (boiled in their skin) | 5 | 6 - 12 |
| French fries (made from raw potatoes) | 4 | 15 - 25 |
| Potato fritter** | 5 | 2,5 - 3,5 |
| Swiss rösti | 1 | 50 - 55 |
| Glazed potatoes | 3 | 15 - 20 |
| Vegetables | | |
| Garlic, onions | 1 - 2 | 2 - 10 |
| Courgettes, aubergines | 3 | 4 - 12 |
| Peppers, green asparagus | 3 | 4 - 15 |
| Vegetables sautéed in oil, e.g. courgettes, green peppers | 1 | 10 - 20 |
| Mushrooms | 4 | 10 - 15 |
| Glazed vegetables | 3 | 6 - 10 |
| Frozen products | | |
| Escalope | 4 | 15 - 20 |
| Cordon bleu* | 4 | 10 - 30 |
| Poultry breast* | 4 | 10 - 30 |
| Chicken nuggets | 4 | 10 - 15 |
| Gyros, kebab | 3 | 5 - 10 |
| Fish fillet, plain or breaded | 3 | 10 - 20 |
| Fish fingers | 4 | 8 - 12 |
| French fries | 5 | 4 - 6 |
| Stir-fries meals, e.g. fried vegetables with chicken | 3 | 6 - 10 |
| Spring rolls | 4 | 10 - 30 |
| Camembert/cheese | 3 | 10 - 15 |
| Sauces | | |
| Tomato sauce with vegetables | 1 | 25 - 35 |
| Béchamel sauce | 1 | 10 - 20 |
| Cheese sauce, e.g. Gorgonzola sauce | 1 | 10 - 20 |
| Reducing sauces, e.g. tomato sauce, Bolognese sauce | 1 | 25 - 35 |
| Sweet sauces, e.g. orange sauce | 1 | 15 - 25 |
| Miscellaneous | | |
| Camembert/cheese | 3 | 7 - 10 |
| Dry ready meals that require water to be added, e.g. pasta | 1 | 5 - 10 |
| Croutons | 3 | 6 - 10 |
| Almonds/walnuts/pine nuts | 4 | 3 - 15 |
| * Turn several times. | | |
| ** Total cooking time per portion. Fry in succession. | | |


Setting procedure

Select the appropriate temperature setting from the table. Place the empty frying pan on the hotplate.


1. Select the hotplate and touch the  symbol.  lights up in the hotplate display.



2. Within the next 5 seconds, select the required temperature setting using the twist knob.




The function has now been activated.

The  temperature symbol flashes until the frying temperature is reached. A signal sounds and the temperature symbol lights up.

3. Once the frying temperature has been reached, add the fat and then the food to the pan.

Note: Turn the food so that it does not burn.

Switching off the frying sensor



Select the hotplate and touch the  symbol. The function is deactivated.

Childproof lock

You can use the childproof lock to prevent children from switching on the hob.

Activating and deactivating the childproof lock

The hob must be switched off.

To activate: Touch the  symbol for approx. 4 seconds. The  indicator lights up for 10 seconds. The hob is locked.

To deactivate: Touch the  symbol for approx. 4 seconds. The lock is released.

Childproof lock

With this function, the childproof lock automatically activates when a hob is switched off.


Switching on and off


You can find out how to switch the automatic childproof lock on in the → "Basic settings" section



Wipe protection

Wiping over the control panel while the hob is switched on may alter the settings. To avoid doing this, you can use the hob's "Lock control panel for cleaning" function.

To activate this function: Remove the twist knob. The  indicator will be lit. The control panel will remain locked for 35 seconds. You will now be able to clean the surface of the control panel without altering the settings.

To deactivate this function: The control panel will be unlocked once 35 seconds have elapsed. To end the function early, fit the twist knob back on and turn it until the  indicator goes out.

Notes

- The timer displays the time that has elapsed since the lock was activated. An audible signal sounds 30 seconds after activation. This indicates that the function is about to finish.
- The cleaning lock does not lock the main switch. The hob can be switched off at any time.



Automatic safety cut-out

If a hotplate operates for an extended period and no settings are changed, the automatic safety shut-off is activated.

The hotplate stops heating. **F**, **B** and the residual heat indicator **h** or **H** flash alternately in the hotplate display.

When you touch any symbol, the display switches off. The hotplate can now be set again.




The point at which the safety shut-off becomes active depends on which heat setting has been set (after 1 to 10 hours).

Basic settings

The appliance has various basic settings. You can adapt these to suit your cooking habits.

| Display | Function |
|-------------|---|
| c 1 | Automatic childproof lock 0 Manual*. 1 Automatic. 2 Function deactivated. |
| c 2 | Audible signals 0 Confirmation and fault signals are switched off. 1 Only the fault signal is switched on. 2 Only the confirmation signal is switched on. 3 All signal tones are switched on.* |
| c 3 | Display energy consumption 0 Switched off.* 1 Switched on. |
| c 5 | Automatically programming the cooking time 00 Switched off.* 0 1-99 Time until automatic switch-off. |
| c 6 | Duration of the timer-end signal tone 1 10 seconds. 2 30 seconds. 3 1 minute.* |
| c 7 | Power management function. Limiting the total power of the hob 0 Switched off.* 1 1000 W minimum power. 1. 1500 W. 2 2000 W. ... 9 or 9. Maximum power of the hob. |
| c 9 | Time for selecting the hotplate 0 Unlimited: The hotplate which was set last remains selected.* 1 Limited: The hotplate only remains selected for a few seconds. |
| c 11 | Changing the preset heat settings for the Move function -9 Preset heat setting for the front cooking zone. -5 Preset heat setting for the central cooking zone. -1 Preset heat setting for the rear cooking zone. |
| c 12 | Checking cookware and cooking results 0 Not suitable 1 Not perfect 2 Suitable |


* Factory settings





| Display | Function |
|---|---------------------------------------|
|  | Restoring the factory settings |
|  | Individual settings.* |
|  | Restore factory settings. |




* Factory settings

To access the basic settings:


The hob must be off.


- 1. Switch on the hob.
- 2. Within ten seconds, touch and hold the  symbol for approximately three seconds.
The first four displays provide product information.
Turn the twist knob to view the individual displays.


| Product information | Display screen |
|----------------------------------|---|
| After-sales service index (ASSI) |  |
| Production number |  |
| Production number 1 |  |
| Production number 2 |  |

- 3. Touch the  symbol again to access the basic settings.
 and  light up as a presetting in the displays.



- 4. Touch the  symbol repeatedly until the required function is displayed.
- 5. Then use the twist knob to select the required setting.



- 6. Touch the  symbol for at least three seconds.
The settings have been saved.

Leaving the basic settings

Turn off the hob with the main switch.

Energy consumption indicator

This function indicates the total amount of energy consumed by this hob the last time it was used for cooking.

Once switched off, the energy consumption in kWh is displayed for 10 seconds.

The picture shows an example with an energy consumption of **1.08 kWh**.



You can find out how to switch this function on in the section on → "Basic settings"


Cookware check

This function can be used to check the speed and quality of the cooking process depending on the cookware.




The result is a reference value and depends on the properties of the cookware and the hotplate being used.

1. With the cookware still cold, fill it with approx. 200 ml of water and place it on the centre of the hotplate with the diameter that most closely matches that of the base of the cookware.
2. Go to the basic settings and select the **c 12** setting.
3. Turn the twist knob.— flashes on the hotplate displays.
The function is activated.

After 10 seconds, information on the quality and speed of the cooking process appears in the hotplate displays.



Check the result using the following table:

| Result | |
|--|--|
|  | The cookware is not suitable for the hotplate and will therefore not heat up.* |
|  | The cookware is taking longer to heat up than expected and the cooking process is not going as well as it should.* |
|  | The cookware is heating up correctly and the cooking process is going well. |
| * If there is a smaller hotplate available, test the cookware again on the smaller hotplate. | |

To reactivate the function, turn the twist knob.

Notes

- The flexible cooking zone only counts as a single hotplate; place no more than one item of cookware on it.
- If the diameter of the hotplate used is much smaller than the diameter of the cookware, only the middle of the cookware can be expected to heat up. This may result in the cooking results not being as good as expected or being less than satisfactory.
- You can find information on this function in the section on → "Basic settings".
- You can find information on the type, size and positioning of the cookware in the sections on → "Induction cooking" and → "Flex Zone".



Cleaning

Suitable maintenance and cleaning products can be purchased from the after-sales service or in our e-Shop.

Hob

Cleaning

Always clean the hob after cooking. This will prevent food deposits from becoming burned on. Only clean the hob after the residual heat indicator has gone out.

Clean the hob with a damp dish cloth and dry it with a cloth or towel to prevent limescale build-up.

Only use cleaning agents that are suitable for this type of hob. Observe the manufacturer's instructions on the product packaging.

Never use:

- Undiluted washing-up liquid
- Cleaning agents designed for dishwashers
- Abrasive cleaners
- Harsh cleaning agents, such as oven spray and limescale remover
- Scouring pads
- High-pressure cleaners or steam jet cleaners

Stubborn dirt is best removed with a glass scraper, available from retailers. Observe the manufacturer's instructions.

You can obtain a suitable glass scraper from customer services or through our online shop.

Using a special sponge for cleaning glass-ceramic hobs achieves a great cleaning result.

| Potential marks | |
|--|---|
| Limescale and water marks | Clean the hob as soon as it has cooled down. You can use a cleaning agent suitable for glass-ceramic hobs.* |
| Sugar, rice starch or plastic | Clean immediately. Use a glass scraper. Caution: Risk of burns.* |
| * Then clean with a damp dish cloth and dry with a cloth or towel. | |

Note: Do not use any cleaning agents while the hob is still hot. This may mark the surface. Make sure that any residue left by cleaning agents is removed.

Hob surround

To prevent damage to the hob surround, observe the following instructions:

- Only use warm soapy water
- Wash new dish cloths thoroughly before use.
- Do not use harsh or abrasive cleaning agents.
- Do not use a glass scraper or sharp objects.

Twist knob

The twist knob is best cleaned using lukewarm soapy water. Do not use harsh or abrasive cleaning agents. Do not clean the twist knob in the dishwasher or using rinsing water. This may damage it.

Frequently Asked Questions (FAQ)

Using the appliance

Why can't I switch on the hob and why is the childproof lock symbol lit?

The childproof lock is activated.

You can find information on this function in the section on → *"Childproof lock"*

Why are the displays flashing and why can I hear an audible signal?

Remove any liquid or food remains from the control panel. Remove any objects from the control panel.

You can find instructions on how to deactivate the audible signal in the section on → *"Basic settings"*

Noises

Why I can hear noises while I'm cooking?

Noises may be generated while using the hob depending on the base material of the cookware. These noises are a normal part of induction technology. They do not indicate a defect.

Possible noises:

A low humming noise like the one a transformer makes:

Occurs when cooking at a high heat setting. The noise disappears or becomes quieter when the heat setting is reduced.

Low whistling noise:

Occurs when the cookware is empty. This noise disappears when water or food is added to the cookware.

Crackling:

Occurs when using cookware made from different layers of material or when using cookware of different sizes and different materials at the same time. The loudness of the noise can vary depending on the quantity of food being cooked or the cooking method.

High-pitched whistling noises:

Can occur when two hotplates are used at the highest heat setting at the same time. The whistling noises disappear or become quieter when the heat setting is reduced.

Fan noise:

The hob is equipped with a fan that switches on automatically at high temperatures. The fan may continue to run even after you have switched off the hob if the temperature detected is still too high.

Cookware

Which types of cookware can be used with an induction hob?

You can find information on which types of cookware can be used with an induction hob in the section on → *"Induction cooking"*.

Why is the hotplate not heating up and why is the heat setting flashing?

The hotplate on which the cookware is standing is not switched on.

Check that you have switched on the correct hotplate.

The cookware is too small for the hotplate that is switched on or it is not suitable for induction cooking.

Check that the cookware is suitable for induction cooking and that it is placed on the hotplate that best corresponds to its size. You can find information on the type, size and positioning of cookware in the sections on → *"Induction cooking"*, → *"Flex Zone"* and → *"Move function"*.

Why is it taking so long for the cookware to heat up or why is it not heating up sufficiently despite being on a high heat setting?

The cookware is too small for the hotplate that is switched on or it is not suitable for induction cooking.

Check that the cookware is suitable for induction cooking and that it is placed on the hotplate that best corresponds to its size. You can find information on the type, size and positioning of cookware in the sections on → *"Induction cooking"*, → *"Flex Zone"* and → *"Move function"*.

Cleaning

How do I clean the hob?

Using a special glass-ceramic cleaning agent produces the best results. We advise against using harsh or abrasive cleaning agents, dishwasher detergent (concentrated) or scouring pads.

You can find more information on cleaning and caring for your hob in the section on → "Cleaning"

? Trouble shooting

Usually, faults are small matters that are easy to eliminate. Please read the information in the table before calling the after-sales service.

| Display | Possible cause | Solution |
|--|---|--|
| None | The power supply has been disconnected. The device has not been connected in accordance with the circuit diagram. Electronics fault. | Use other electrical devices to check whether a short-circuit has occurred in the power supply. Ensure that the device has been connected in accordance with the circuit diagram. If the fault cannot be eliminated, inform the technical after-sales service. |
| The displays flash | The control panel is damp or an object is covering it. | Dry the control panel or remove the object. |
| The — indicator flashes in the hotplate displays | A fault has occurred in the electronics. | To acknowledge the fault, cover the control panel with your hand. |
| F2 F4 | The electronics have overheated and have switched off the corresponding hotplate. The electronics have overheated and have switched off all hotplates. | Wait until the electronics have cooled down sufficiently. Then touch any symbol on the hob. |
| F5 + heat setting and acoustic signal | There is a hot pan in the area of the control panel. There is a risk that the electronics will overheat. | Remove the pan. The fault display goes out shortly afterwards. You can continue to cook. |
| F5 and acoustic signal | There is a hot pan in the area of the control panel. To protect the electronics, the hotplate has been switched off. | Remove the pan. Wait for a few seconds. Touch any control. If the fault display goes out, you can continue to cook. |
| F1/F6 | The hotplate has overheated and switched itself off to protect the work surface. | Wait until the electronics have cooled down sufficiently and switch the hotplate on again. |
| F8 | The hotplate was operating for an extended period without interruption. | The automatic safety switch-off function has been activated. See section |
| E9000 E9010 | The supply voltage is faulty; outside of the normal operating range. | Contact your electricity provider. |
| U400 | The hob is not connected properly | Disconnect the hob from the power supply. Ensure that it has been connected in accordance with the circuit diagram. |
| dE | The demo mode is activated | Disconnect the hob from the power supply. Wait 30 seconds and reconnect it. Touch any touch control in the next three minutes. The demo mode is deactivated. |

Do not place hot pans on the control panel.

Notes

- If **E** appears on the display, the Twist knob for the burner in question must be held down in order to be able to read off the fault code.
- If the fault code is not listed in the table, disconnect the hob from the power supply and wait 30 seconds before reconnecting it. If the display appears again, contact technical Customer Service and tell them the precise fault code. If the display appears again, contact technical after-sales and tell them the precise fault code.

Customer service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find an appropriate solution, also in order to avoid after-sales personnel having to make unnecessary visits.

E number and FD number

Please quote the E number (product number) and the FD number (production number) of your appliance when contacting the after-sales service.

The rating plate bearing these numbers can be found:

- On the appliance certificate.
- On the lower section of the hob.

The E-number can also be found on the glass surface of the hob. You can check the customer index (KI) and FD number by going to the basic settings. Look up section → *"Basic settings"* for this.

Please note that a visit from an after-sales service engineer is not free of charge in the event of misuse of the appliance, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

To book an engineer visit and product advice

GB 0344 892 8989

Calls charged at local or mobile rate.

IE 01450 2655

0.03 € per minute at peak. Off peak 0.0088 € per minute.

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

Test dishes

This table has been produced for test institutes to facilitate the testing of our appliances.

The data in the table refer to our Schulte-Ufer cookware accessories (4-piece cooking set for induction hob Z9442X0) with the following dimensions:

- Saucepan: 16 cm Ø, 1.2 l for 14.5 cm Ø hotplates
- Pot: 16 cm Ø, 1.7 l for 14.5 cm Ø hotplates
- Pot: 22 cm Ø, 4.2 l, for 18 cm Ø hotplates
- Pan: 24 cm Ø, for 18 cm Ø hotplates

| Test dishes | Cookware | Heat set- ting | Preheating | Lid | Cooking | |
|---|-----------------------------|-------------------|--|-----|--------------|-----|
| | | | Cooking time (min:sec) | | Heat setting | Lid |
| Melting chocolate | | | | | | |
| Chocolate coating (e.g. Dr. Oetker brand, dark chocolate 55% cocoa, 150 g) | Saucepan, 16 cm diameter | - | - | - | 1. | No |
| Heating and keeping lentil stew warm | | | | | | |
| Lentil stew* | | | | | | |
| Initial temperature 20 °C | | | | | | |
| Amount: 450 g | Cooking pot, 16 cm diameter | 9 | 1:30 (without stir- ring) | Yes | 1. | Yes |
| Amount: 800 g | Saucepan, 22 cm diameter | 9 | 2:30 (without stir- ring) | Yes | 1. | Yes |
| Lentil stew from a tin | | | | | | |
| E.g lentils with Erasco sausages. | | | | | | |
| Initial temperature 20 °C | | | | | | |
| Amount: 500 g | Cooking pot, 16 cm diameter | 9 | Approx. 1:30 (stir after approx. 1 minute) | Yes | 1. | Yes |
| Amount: 1 kg | Saucepan, 22 cm diameter | 9 | Approx. 2:30 (stir after approx. 1 minute) | Yes | 1. | Yes |
| Preparing Béchamel sauce | | | | | | |
| Temperature of the milk: 7 °C | | | | | | |
| Ingredients: 40 g butter, 40 g flour, 0.5 l milk (3.5% fat content) and a pinch of salt | | | | | | |
| 1. Melt the butter, stir in the flour and salt, and heat up the mixture. | Saucepan, 16 cm diameter | 2 | Approx. 6:00 | No | - | - |
| 2 Add the milk to the roux and bring to the boil, stirring continuously. | | 7 | Approx. 6:30 | No | - | - |
| 3. Once the Béchamel sauce comes to the boil, leave it on the hot-plate for a further two minutes, stirring continuously. | | - | - | - | 2 | No |
| *Recipe in accordance with DIN 44550 | | | | | | |
| **Recipe in accordance with DIN EN 60350-2 | | | | | | |

| Test dishes | Cookware | Heat setting | Preheating | Lid | Cooking | | |
|--|-----------------------------|--------------|--|-----|---------------------------|-----|--|
| | | | Cooking time (min:sec) | | Heat setting | Lid | |
| Cooking rice pudding | | | | | | | |
| Rice pudding, cooked with the lid on | | | | | | | |
| Temperature of the milk: 7 °C | | | | | | | |
| Heat the milk until it starts to rise up. Set the recommended heat setting and add rice, sugar and salt to the milk. | | | | | | | |
| The cooking time, including preheating, is approx. 45 minutes. | | | | | | | |
| Ingredients: 190 g short-grain rice, 90 g sugar, 750 ml milk (3.5% fat content) and 1 g salt | Cooking pot, 16 cm diameter | 8. | Approx. 5:30 | No | 3 (stir after 10 minutes) | Yes | |
| Ingredients: 250 g short-grain rice, 120 g sugar, 1 l milk (3.5% fat content) and 1.5 g salt | Saucepan, 22 cm diameter | 8. | Approx. 5:30 | No | 3 (stir after 10 minutes) | Yes | |
| Rice pudding, cooked without lid | | | | | | | |
| Temperature of the milk: 7 °C | | | | | | | |
| Add the ingredients to the milk and heat the mixture up while stirring continuously. Once the milk has reached approx. 90 °C, select the recommended heat setting and leave it to simmer on a low heat for approx. 50 minutes. | | | | | | | |
| Ingredients: 190 g short-grain rice, 90 g sugar, 750 ml milk (3.5% fat content) and 1 g salt | Cooking pot, 16 cm diameter | 8. | Approx. 5:30 | No | 3 | No | |
| Ingredients: 250 g short-grain rice, 120 g sugar, 1 l milk (3.5% fat content) and 1.5 g salt | Saucepan, 22 cm diameter | 8. | Approx. 5:30 | No | 2. | No | |
| Cooking rice* | | | | | | | |
| Water temperature: 20 °C | | | | | | | |
| Ingredients: 125 g long grain rice, 300 g water and a pinch of salt | Cooking pot, 16 cm diameter | 9 | Approx. 2:30 | Yes | 2 | Yes | |
| Ingredients: 250 g long grain rice, 600 g water and a pinch of salt | Saucepan, 22 cm diameter | 9 | Approx. 2:30 | Yes | 2. | Yes | |
| Roasting a pork loin | | | | | | | |
| Initial temperature of the loin: 7 °C | | | | | | | |
| Amount: 3 pork loins (total weight approx. 300 g, 1 cm thick) and 15 ml sunflower oil | Frying pan, 24 cm diameter | 9 | Approx. 1:30 | No | 7 | No | |
| Preparing pancakes** | | | | | | | |
| Amount: 55 ml batter for each pancake | Frying pan, 24 cm diameter | 9 | Approx. 1:30 | No | 7 | No | |
| Deep-fat frying chips | | | | | | | |
| Amount: 1.8 l sunflower oil, per portion: 200 g frozen chips (e.g. McCain 123 Original fries) | Saucepan, 22 cm diameter | 9 | Until the oil temperature reaches 180 °C | No | 9 | No | |
| *Recipe in accordance with DIN 44550 | | | | | | | |
| **Recipe in accordance with DIN EN 60350-2 | | | | | | | |

Constructa Neff
Vertriebs-GmbH
Carl-Wery-Straße 34
D-81739 München

Register your product online

www.neff-international.com



9001063770
961201(03)
en