

### **Table of contents**

S Intended use	. 4
Important safety information	. 4
Causes of damage	<b>. 5</b> . 5
Environmental protection	. 6
Getting to know your appliance  Control panel  Controls  Main menu  Menu for the types of heating  Cooking compartment functions	.7 .7 .8
Accessories  Accessories included  Inserting accessories  Combining accessories  Optional accessories	. 9 . 9 10
Before using for the first time.  Initial use	11 11
Operating the appliance  Switching the appliance on and off  Setting and starting the appliance operation  Changing or cancelling the appliance operation  Heating up the appliance quickly	12 12 13
Time-setting options  Showing and hiding the time-setting options  Setting the timer  Setting the cooking time  Start delay – "Ready at"  Checking, changing or deleting settings	14 14 14 14
Childproof lock	15
Basic settings.  Changing the basic settings.  List of basic settings.  Setting favourites.	16 16
Starting Sabbath mode	17

Cleaning agent	.17 .18
Cleaning function. Starting. Finishing. Final cleaning. Removing heavy deposits of dirt	.19 .19 .20
Rails  Detaching and refitting the rails	
Appliance door	.21 .21
Trouble shooting	.23 .23
Customer service	. 24
Customer service	. <b>24</b> . 24 . 25 . 25 . 28 . 30 . 32 . 33 . 34 . 37 . 38 . 39 . 41 . 42

Additional information on products, accessories, replacement parts and services can be found at **www.neff-international.com** and in the online shop **www.neff-eshop.com** 

### Intended use

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 4000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 15 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment the right way round.

→ "Accessories" on page 9

# Important safety information

#### **General information**

#### ▲ Warning – Risk of fire!

- Combustible items stored in the cooking compartment may catch fire. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug it from the mains or switch off the circuit breaker in the fuse box.
- Loose food remnants, fat and meat juices may catch fire. Before using the appliance, remove the worst of the food remnants from the cooking compartment, heating elements and accessories.
- A draught is created when the appliance door is opened. Greaseproof paper may come into contact with the heating element and catch fire. Do not place greaseproof paper loosely over accessories during preheating. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. Greaseproof paper must not protrude over the accessories.

#### Marning – Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.

### Marning – Risk of scalding!

- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.
- Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

#### Marning – Risk of injury!

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.

#### **⚠** Warning – Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the aftersales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

Warning – Hazard due to magnetism!

Permanent magnets are used in the control panel or in the control elements. They may affect electronic implants, e.g. heart pacemakers or insulin pumps. Wearers of electronic implants must stay at least 10 cm away from the control panel.

#### Halogen lamp

### Marning – Risk of burns!

The bulbs in the cooking compartment become very hot. There is still a risk of burning your skin for some time after they have been switched off. Do not touch the glass cover. Avoid contact with your skin when cleaning.

### 

When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

### ➤ Causes of damage

#### **General information**

#### Caution!


- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor if a temperature of over 50 °C has been set. This will cause heat to accumulate. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Aluminium foil: Aluminium foil in the cooking compartment must not come into contact with the door glass. This could cause permanent discolouration of the door glass.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the enamel.
- Moisture in the cooking compartment: Over an extended period of time, moisture in the cooking compartment may lead to corrosion. Allow the cooking compartment to dry after use. Do not keep moist food in the closed cooking compartment for extended periods of time. Do not store food in the cooking compartment.
- Cooling with the appliance door open: Following operation at high temperatures, only allow the cooking compartment to cool down with the door closed. Do not trap anything in the appliance door. Even if the door is only left open a crack, the front of nearby furniture may become damaged over time. Only leave the cooking compartment to dry with the door open if a lot of moisture was produced whilst the oven was operating.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Extremely dirty seal: If the seal is very dirty, the appliance door will no longer close properly during operation. The fronts of adjacent units could be damaged. Always keep the seal clean.
- Appliance door as a seat, shelf or worktop: Do not sit on the appliance door, or place or hang anything on it. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.

### **Environmental protection**

Your new appliance is particularly energy-efficient. Here you can find tips on how to save even more energy when using the appliance, and how to dispose of your appliance properly.


#### Saving energy


- Only preheat the appliance if this is specified in the recipe or in the tables in the operating instructions.
- Leave frozen food to defrost before placing it in the cooking compartment.






 Use baking tins that are dark-coloured, painted black or have an enamel coating. These absorb the heat particularly well.






 Remove any unnecessary accessories from the cooking compartment.







• Open the appliance door as infrequently as possible when the appliance is in use.





It is best to bake several cakes one after the other. The cooking compartment stays warm. This reduces the baking time for the second cake. You can place two cake tins next to each other in the cooking compartment.





 For longer cooking times, you can switch the appliance off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

#### **Environmentally-friendly disposal**

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

### Getting to know your appliance

In this chapter, we will explain the indicators and controls. You will also find out about the various functions of your appliance.

Note: Depending on the appliance model, individual details and colours may differ.

#### Control panel

In the control panel, set the appliance's different functions. The current settings are shown on the display.



 $\Box$ 

- 2 Touch buttons
- 3 ShiftControl control

#### **Controls**

Use the controls to set your appliance simply and directly.

#### **Touch buttons**

There are sensors under the touch buttons. Touch on the corresponding touch button to select a function.

Touch	n button	Use
1	on/off	Switching the appliance on or off → "Switching the appliance on and off" on page 12
	Main menu	Selecting operating modes and settings → "Setting and starting the appliance operation" on page 12
$\Theta$	Time-setting options	Setting the timer, cooking time, or "Ready at" start delay → "Time- setting options" on page 14
	Childproof lock	Activating or deactivating the child- proof lock → "Childproof lock" on page 15
î	Information	Displaying further information Displaying the current temperature  → "Setting and starting the appliance operation" on page 12

8 <u></u> F	Rapid heating	Activating or deactivating rapid heating → "Heating up the appliance quickly" on page 13
		Activating or deactivating Power- Boost → "Heating up the appliance quickly" on page 13
DII	Start/Stop	Starting or stopping the operation  → "Setting and starting the appliance operation" on page 12

#### ShiftControl control

Use the ShiftControl control element to navigate through the lines on the display and select the settings. Settings that you can change have left and right arrows ().

Butto	n	Use
<	Left	Navigates to the left on the display
>	Right	Navigates to the right on the display
^	Up	Navigates upwards on the display
~	Down	Navigates downwards on the display

**Note:** You can also scroll through the settings values quickly by pressing and holding a button. As soon as you release the button, you stop scrolling through the values quickly.

#### Main menu

Touch the  $\widehat{\ }$  touch button to access the main menu.

Menu	Use
	Types of heating Selecting the required type of heating and temperature for your dish → "Switching the appliance on and off" on page 12

€	Basic settings Individually adjusting the appliance settings → "Basic settings" on page 16
<u> </u>	EasyClean Cleaning light soiling from the cooking compartment  → "Cleaning function" on page 19

### Menu for the types of heating

Your appliance has different types of heating. After switching on the appliance, you are taken directly to the menu for the types of heating.

Type of I	heating	Temperature	Use
L	CircoTherm	40-200°C	For baking and cooking on one or more levels.  The fan distributes the heat from the ring heating element in the back panel evenly around the cooking compartment.
<del>-</del>	Top/bottom heating	50-275°C	For traditional baking and roasting on one level. Especially suitable for cakes with moist toppings. Heat is emitted evenly from the top and bottom.
Ž	Circo-roasting	50-250°C	For roasting poultry, whole fish and larger pieces of meat.  The grill element and the fan switch on and off alternately. The fan circulates the hot air around the food.
<u>&amp;</u>	Circotherm intensive	50-275°C	For preparing pizza and dishes which require a lot of heat from underneath.  The bottom heating element and the ring heating element in the back panel heat up.
<u></u>	Bread-baking	180 - 240 °C	For baking bread, bread rolls and baked items that require high temperatures.
****	Full-surface grill	50 - 290 °C	For grilling flat items, such as steaks or sausages, for making toast, and for au gratin dishes.  The whole area below the grill element becomes hot.
****	Centre-area grill	50 - 290 °C	For grilling small amounts of steaks or sausages, for making toast, and for au gratin dishes.  The centre area under the grill heating element becomes hot.
_	Bottom heat	50 - 250 °C	For cooking in a bain marie and for the final baking stage. The heat is emitted from below.
8	Low temperature cooking	70 - 120 °C	For gentle and slow cooking of seared, tender pieces of meat in ovenware without a lid.  The heat is emitted evenly from the top and bottom at low temperatures.
	Dough proving	35 - 55 °C	For leaving yeast dough and sourdough to prove and for culturing yogurt.  Dough will prove more quickly than at room temperature. The surface of the dough does not dry out.
eco	Top/bottom heating eco	50-275°C	For gently cooking selected types of food.  Heat is emitted from above and below.  This heating function is most effective between 150 and 250 °C.  This heating function is used to measure the energy consumption in the conventional mode.
eco	CircoTherm eco	40-200°C	For gently cooking selected types of food on one level without preheating.  The fan distributes the heat from the ring-shaped heating element in the back panel around the cooking compartment.  This heating function is most effective between 125 and 200 °C.  This heating function is used to measure both the energy consumption in air recirculation mode and the energy efficiency class.

#### **Cooking compartment functions**

The functions in the cooking compartment make your appliance easier to use. This, for example, enables the cooking compartment to be well lit and a cooling fan to prevent the appliance from overheating.

#### Opening the appliance door

If you open the appliance door during an operation, the operation is paused. The operation continues to run when you close the door.

**Note:** For some types of heating, the operation continues to run even when the appliance door is open.

#### Interior lighting

If you open the appliance door, the interior lighting switches on. If the door remains open for longer than around 15 minutes, the lighting switches off again.

For most operating modes, the interior lighting switches on as soon as the operation is started. When the operation has finished, the lighting switches off.

**Note:** You can set the interior lighting not to come on during the operation in the basic settings.  $\rightarrow$  "Basic settings" on page 16

#### Cooling fan

The cooling fan switches on and off as required. The hot air escapes above the door.

#### Caution

Do not cover the ventilation slots. Otherwise, the appliance may overheat.

So that the cooking compartment cools down more quickly after the operation, the cooling fan continues to run for a certain period afterwards.

**Note:** You can change how long the cooling fan continues to run for in the basic settings.  $\rightarrow$  "Basic settings" on page 16

### Accessories

Your appliance is accompanied by a range of accessories. Here, you can find an overview of the accessories included and information on how to use them correctly.

#### **Accessories included**

Your appliance is equipped with the following accessories:



Only use genuine accessories. They are specially adapted for your appliance.


You can buy accessories from the after-sales service, from specialist retailers or online.

**Note:** The accessories may become deformed when they become hot. This does not affect their function. Once they cool down again, they regain their original shape.

#### **Inserting accessories**

The cooking compartment has four shelf positions. The shelf positions are counted from the bottom up.

In some appliances, the top shelf position in the cooking compartment features a grill symbol.



The accessories can be pulled out up to approximately halfway without tipping.


#### **Notes**

- Ensure that you always insert the accessories into the cooking compartment the right way round.
- Always insert the accessories fully into the cooking compartment so they do not touch the appliance door.


#### **Locking function**

The accessories can be pulled out approximately halfway until they lock in place. The locking function prevents the accessories from tilting when they are pulled out. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

When inserting the wire rack, ensure that the lug **a** is at the rear and is facing downwards. The open side must be facing the appliance door and the curvature must be facing downwards —.




When inserting the baking tray or the universal pan, ensure that the lug **b** is at the rear and is facing downwards. The sloping edge of the accessory **c** must be facing towards the appliance door.



#### **Combining accessories**

You can insert the wire rack and the universal pan at the same time to catch drops of liquid.

When inserting the wire rack, ensure that both spacers **a** are at the rear edge. When the universal pan is inserted, the wire rack is on top of the upper guide rod of the shelf position.



#### **Optional accessories**

You can purchase optional accessories from the aftersales service and specialist retailers, or on the Internet. You will find a comprehensive range of products for your appliance in our brochures and on the Internet.

Both availability and whether it is possible to order online differ between countries. Please see your sales documents for more details.

**Note:** Not all optional accessories are suitable for every appliance. When purchasing, please always quote the exact designation (E no.) of your appliance.

→ "Customer service" on page 24

Accessories
Baking and roasting shelf
Baking tray
Universal pan
Baking tray, non-stick
Universal pan, non-stick
Extra-deep pan
Steaming set for ovens
Profi pan
Lid for the Profi pan
Pizza tray
Grill tray
Ceramic brick
Glass roasting dish, 5.1 litres
Glass pan
ComfortFlex rail (1 level)*
3 x fully extendable pull-out rack*
*Accessory does not fit in every appliance, quote the E no. when ordering

# Before using for the first time

Before you can use your new appliance, you must make some settings. You must also clean the cooking compartment and accessories.

#### Initial use

As soon as the appliance is connected to the power supply, the first setting "Language" appears on the display.

#### Setting the language

- **1.** Use the  $\sim$  button to navigate to the bottom line.
- **2.** Use the  $\langle$  or  $\rangle$  button to select the language.
- 3. Use the \( \simega \) button to return to "Language".
- **4.** Use the button to select the next setting.

#### Setting the time

- **1.** Use the  $\sim$  button to navigate to the next line.
- **2.** Use the  $\langle$  or  $\rangle$  button to select the current time.
- **3.** Press the  $\sim$  button.
- **4.** Use the > button to select the next setting.

#### Setting the date

- **1.** Use the  $\sim$  button to navigate to the next line.
- **2.** Use the  $\langle$  or  $\rangle$  button to select the current day.
- 3. Use the \( \simega \) button to return to "Day".
- 4. Use the > button to select the next setting.
- **5.** Use the  $\sim$  button to navigate to the next line.
- **6.** Use the  $\langle$  or  $\rangle$  button to select the current month.
- 7. Use the button to return to "Month".
- 8. Use the > button to select the next setting.
- **9.** Use the  $\sim$  button to navigate to the next line.
- **10.** Use the  $\langle$  or  $\rangle$  button to select the current year.
- 11. Use the button to return to "Year".
- **12.** Use the > button to apply the settings. The initial use is complete.

#### **Notes**

- You can change these settings at any time in the basic settings. → "Basic settings" on page 16
- After connecting the appliance to the power or following a power cut, the settings for initial use are shown in the display.

#### Cleaning the cooking compartment

To remove the new-appliance smell, heat up the cooking compartment when it is empty and with the oven door closed.

- 1. Remove the accessories from the cooking compartment.
- 2. Remove leftover packaging, such as polystyrene pellets, from the cooking compartment.
- 3. Before heating the appliance, wipe the smooth surfaces in the cooking compartment with a soft, wet
- **4.** Use the ① touch button to switch on the appliance.

5. Set the heating type and temperature, then start the appliance operation. → "Setting and starting the appliance operation" on page 12

Settings	
Heating type	Top/bottom heating $\overline{\underline{}}$
Temperature	240 °C
Cooking time	1 hour

- **6.** Keep the kitchen ventilated while the appliance is heating up.
- 7. Use the ① touch button to switch off the appliance after the indicated cooking time.
- 8. Wait until the cooking compartment has cooled down
- **9.** Clean the smooth surfaces with soapy water and a dish cloth.

#### Cleaning the accessories

Clean the accessories thoroughly using soapy water and a dish cloth or soft brush.

### Operating the appliance

You have already learnt about the controls and how they work. Now we will explain how to set your appliance. You will learn about what happens when you switch the appliance on and off, and how to select the operating mode.

#### Switching the appliance on and off

Touch the ① touch button to switch the appliance on or off

After switching off the appliance, on the display you can see if the residual heat in the cooking compartment is high or low.

Display	Meaning
-H-	Residual heat high (above 120 °C)
-h-	Residual heat low (between 60 °C and 120 °C)

#### **Notes**

- Certain displays and notes, such as the residual heat in the cooking compartment, remain visible on the display even when the appliance is switched off.
- After an appliance operation, the cooling fan runs on audibly until the cooking compartment has been cooled as far as possible.
- Switch off your device when you do not need to use it. If no settings are applied for a long time, the appliance switches itself off automatically.

#### Setting and starting the appliance operation

Example: CircoTherm hot air & at 170 °C

1. Touch the ① touch button to switch on the appliance.

You are taken directly to the  $\square$  menu for the types of heating.



- **2.** Use the  $\langle$  or  $\rangle$  button to select the type of heating.
- **3.** Use the  $\sim$  button to navigate to the next line.

**4.** Use the  $\langle$  or  $\rangle$  button to select the temperature.



**Note:** Depending on the operating mode, different settings are available. For each further setting, use the  $\sim$  button to navigate to the next line. Use the  $\langle$  or  $\rangle$  button to select the setting.

5. Touch the || touch button to start the appliance operation.

The heating bar and run time appear on the display.

**Note:** If you would like to go directly to the ☐ main menu after switching on the appliance, you can select the main menu under "Operation after switching on" in the basic settings chapter. → "Basic settings" on page 16

#### **Default values**

The appliance suggests a temperature or setting for each type of heating. You can accept this value or change it in the appropriate area.

#### **Heating bar**

As soon as a type of heating has started, the heating bar appears on the display. The heating bar shows the temperature increase in the cooking compartment.

#### Run time

When a type of heating has been started, the run time is displayed. The run time counts upwards during the operation. You can therefore check how long the operation has already been running.

#### Displaying the current temperature

To show the current temperature on the display, press the  $\ensuremath{\mbox{\it f}}$  touch button.

The current temperature is shown briefly only when heating up.

#### **Further information**

If the  $\mathring{1}$  touch button lights up, information can be displayed. Touch the  $\mathring{1}$  touch button to do this. The information is displayed for a few seconds.

## Changing or cancelling the appliance operation

#### Changing the appliance operation

- 1. Use the \| button to stop the operation.
- 2. Use the  $\sim$  or  $\sim$  button to navigate to the line for the setting that should be changed.
- **3.** Use the  $\langle$  or  $\rangle$  button to change the setting.
- Use the | | | | | touch button to start the changed operation.

#### **Notes**

- The cooling fan may continue to run while an operation is interrupted.
- After a temperature change, the paused running time continues to count. After a change in the type of heating, the running time starts again from zero.

#### Cancelling the appliance operation

Press and hold the \( \) | | touch button until the appliance operation is cancelled.

**Note:** Operating modes such as the cleaning function cannot be cancelled.

#### Heating up the appliance quickly

You can use the "Rapid heat-up" and "PowerBoost" functions to reduce the preheat time. Whether the appliance is preheated with the "Rapid heat-up" function or the "PowerBoost" function depends on the type of heating that has been set. With the "PowerBoost" function, unlike with the "Rapid heat-up" function, you can place your food into the cold cooking compartment even before preheating has begun. Only cook on one level when using the "PowerBoost" function.

Function	Type of heating	Place the food in the cooking compartment
Rapid heat-up	Top/bottom heating =	after preheating
PowerBoost*	CircoTherm hot air 👃	before preheating
	Bread-baking setting @	
* Do not use more that	n one level for cooking	

#### **Notes**

- If the <sup>8</sup>€ touch button is lit, the "Rapid heat-up" or "PowerBoost" function can be activated.
- To deactivate the "Rapid heat-up" or "PowerBoost" function before it has finished, touch the 🖟 touch button.

#### Activating the "Rapid heat-up" function

- Set top/bottom heating = and the temperature.
   Note: Set a temperature above 100 °C to allow the appliance to preheat quickly.
- 2. Touch the | | | touch button to start the appliance operation.
- 3. Touch the 8\times touch button to activate the "Rapid heat-up" function.
  - The & symbol appears on the display.
- 4. Once the set temperature has been reached, the "Rapid heat-up" function switches itself off automatically. The <sup>1</sup>/<sub>8</sub> symbol disappears from the display. Place the food in the cooking compartment

#### **Activating the "PowerBoost" function**

- 1. Set CircoTherm hot air ∠ or the bread baking setting and the temperature.
  - **Note:** Set a temperature above 100 °C to allow the appliance to preheat quickly.
- 2. Place the food on a single level in the cooking compartment.
- Touch the | | | | touch button to start the appliance operation.
- 4. Touch the 8 touch button to activate the "PowerBoost" function.

The & symbol appears on the display. Once the set temperature has been reached, the "PowerBoost" function switches itself off automatically. The & symbol disappears from the display.

## **Time-setting options**

Your appliance has different time-setting options.

Time-setting option		Use		
Ô	Timer	The timer functions like an egg timer. The appliance does not switch on and off automatically.		
<b>→</b>	Cooking time	Once the set cooking time has elapsed, the appliance switches off automatically.		
$\rightarrow$	Ready at	The appliance switches on automatically, and once the set cooking time has elapsed and the end time has passed, it switches off automatically.		

**Note:** If you have set a time-setting option, the time interval increases if you set a higher value. Example: You can set a cooking time of up to one hour in one-minute increments; for cooking times over one hour, you can set a cooking time in five-minute increments.

#### Showing and hiding the time-setting options

To show or hide the time-setting options, touch the  $\odot$  touch button.

**Note:** After a particular length of time, the time-setting options that are shown are automatically hidden. If you have already set a cooking time, it will be applied.



#### Setting the timer

The timer can be set when the appliance is switched on or off.

- 1. Touch the ① touch button.
  The time-setting options are shown on the display.
- 2. Select the cooking time using the > button.
  Note: When the appliance is switched on, use the > button to navigate to the Timer ♀ line and then select the cooking time using the > button.
- Touch the ⊕ touch button to start the timer. The ⊕ symbol appears on the display. The timer counts down.

**Note:** As soon as the set time has elapsed, a signal sounds. To cancel the signal tone, touch the 5 touch button.

#### Setting the cooking time

Once the set cooking time has elapsed, the appliance switches off automatically. The function can only be used in combination with a type of heating.

- 1. Touch the ① touch button.
- 2. Set the type of heating and temperature.
- 3. Touch the (b) touch button.

  The time-setting options are shown in the display.
- **4.** Use the  $\langle$  or  $\rangle$  button to set the cooking time.
  - Default value for the \( \) button = 10 minutes
  - Default value for the > button = 30 minutes
- Touch the ▷|| touch button to start the set cooking time.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the ① touch button to end the audible signal.

#### Start delay - "Ready at"

The appliance switches on automatically and switches off at the preset end time. To do this, set the cooking time and determine the end time for the operation.

The start delay can only be used in combination with a type of heating.

#### **Notes**

- Ensure that food is not left in the cooking compartment for too long as it may spoil.
- It is not possible to start every type of heating with a start delay.
- 1. Slide food into the cooking compartment on a suitable accessory and close the appliance door.
- 2. Touch the ① touch button.
- **3.** Set the type of heating and temperature.
- **4.** Touch the (b) touch button. The time-setting options are shown on the display.
- **5.** Select the cooking time using the > button.
- Use the 

  button to navigate to the 

  Ready at 
  line.
- 7. Select the end time using the > button.
- 8. Touch the || touch button.

  The appliance waits until the appropriate time to start the operation.

As soon as the end time has passed, a signal sounds and the appliance stops the operation automatically. To cancel the signal tone, touch the  $\bigcirc$  touch button.

#### Checking, changing or deleting settings

- Touch the touch button.
   The time-setting options are shown on the display.
- **2.** Use the  $\sim$  or  $\sim$  button to navigate through the lines.
- 3. If necessary, change the setting using the 〈 or 〉 button. Set "00:00" to delete a time function. The setting is applied automatically.

### **Childproof lock**

Your appliance is equipped with a childproof lock so that children cannot switch it on accidentally or change any settings.

Your appliance has two different locks.

Lock	Activate/deactivate
Automatic childproof lock	Via the Settings menu → "Basic settings" on page 16
One-time childproof lock	Via the 🕒 touch button

**Note:** As soon as you activate the childproof lock, the control panel is locked. The ① and ① touch buttons are not included. You can deactivate the childproof lock at any time.

#### **Automatic childproof lock**

The control panel is locked so that the appliance cannot be switched on. To switch it on, the automatic childproof lock must be interrupted. After the appliance operation, the control panel is locked automatically.

#### **Activating**

- 1. Touch the ① touch button.
- 2. Touch the \(\hat{\to}\) touch button.
- **3.** Use the  $\langle$  or  $\rangle$  button to select the "Settings".
- **4.** Use the  $\sim$  button to navigate to the next line.
- 5. Use the 〈 or 〉 button to select "Automatic childproof lock".
- **6.** Use the  $\sim$  button to navigate to the next line.
- 7. Use the  $\langle$  or  $\rangle$  button to select "Activated".
- **8.** Touch the  $\bigcirc$  touch button.
- Use the 

  ✓ button to navigate to the next line to save the setting.
  - The "Automatic childproof lock" is activated. The symbol appears on the display after switching off the appliance.

#### Cancelling

- 1. Press and hold the (b) touch button until "Childproof lock deactivated" appears on the display.
- 2. Touch the ① touch button.
- 3. Switch on the required appliance operation.

#### **Deactivating**

- 1. Press and hold the (b) touch button until "Childproof lock deactivated" appears on the display.
- 2. Touch the ① touch button.
- 3. Touch the  $\bigcirc$  touch button.
- **4.** Use the  $\langle$  or  $\rangle$  button to select the "Settings".
- **5.** Use the  $\sim$  button to navigate to the next line.
- **6.** Use the  $\langle$  or  $\rangle$  button to select "Automatic childproof lock".
- 7. Use the  $\sim$  button to navigate to the next line.
- 8. Use the ( or ) button to select "Deactivated".
- 9. Touch the \(\hat{\to}\) touch button.
- Use the 

  button to navigate to the next line to save the setting.
  - The "Automatic childproof lock" is deactivated.
- 11. Touch the ① touch button.

#### One-time childproof lock

The control panel is locked so that the appliance cannot be switched on. To switch it on, the one-time childproof lock must be deactivated. After the appliance is switched off, the control panel is no longer locked.

#### Activating and deactivating

- Press and hold the touch button until "Childproof lock activated" appears on the display.
   The childproof lock is activated.
- 2. Press and hold the ① touch button until "Childproof lock deactivated" appears on the display. The childproof lock is deactivated.

### Basic settings

There are various settings available to you in order to help use your appliance effectively and simply. You can change these settings as required.

#### Changing the basic settings

- 1. Touch the ① touch button.
- 2. Touch the \(\hat{\text{\text{1}}}\) touch button.
- 3. Use the  $\langle$  or  $\rangle$  button to select the "5 Settings".
- **4.** Use the  $\sim$  button to navigate to the next line.
- **5.** Use the  $\langle$  or  $\rangle$  button to select the setting.
- **6.** Use the  $\sim$  button to navigate to the next line.
- **7.** Use the  $\langle$  or  $\rangle$  button to select the setting.
- **8.** Touch the  $\bigcirc$  touch button.
- 9. To save the setting, use the  $\sim$  button to select "Save".

To discard the setting, use the  $\frown$  button to select "Discard".

#### List of basic settings

Setting	Selection
Language	Select language
Time of day	Sets the current time
Date	Sets the current date
Favourites	Set the heating types that should be shown in the heating types menu  → "Setting favourites" on page 16
Audible signal duration	Short
	Medium
	Long
Button tone	Switched off (Exception: The button tone for the ① touch button remains switched on)
	Switched on
Display brightness	Adjustable across 5 levels
Clock display	Digital
	Off
Lighting	On during operation
	Off during operation
Childproof lock*	Only key lock
	Door lock and key lock
Automatic childproof lock	Deactivated
	Activated
Action after switching on	Main menu
	Heating types
Night-time dimming	Switched off
	Switched on (display dimmed between 10 p.m. and 5.59 a.m.)
Brand name logo	Display
	Do not display

Fan run-on time	Recommended
	Minimum
Pull-out system	No
	Yes (double or triple pull-out system retro- fitted)
Factory settings	Load
*) Depending on the applia lected	ance model, this basic setting cannot be se-

#### **Setting favourites**

You can set which heating types are shown in the Types of heating menu.

**Note:** The "CircoTherm hot air", "Circo-roasting" and "Grill, large area" types of heating are always shown in the Types of heating menu. They cannot be deactivated.

- 1. Touch the ① touch button.
- 2. Touch the \(\hat{\psi}\) touch button.
- 3. Use the 〈 or 〉 button to select the "⑤ Settings".
- **4.** Use the  $\sim$  button to navigate to the next line.
- 5. Use the  $\langle$  or  $\rangle$  button to select "Favourites".
- **6.** Use the  $\sim$  button to navigate to the next line.
- **7.** Use the  $\langle$  or  $\rangle$  button to select the type of heating.
- **8.** Use the  $\sim$  button to navigate to the next line.
- Use the \( \) or \( \) button to select "Activated" or "Deactivated".

**Note:** If you have selected "Activated", the type of heating is shown in the Types of heating menu. If you have selected "Deactivated", the type of heating is shown in the Types of heating menu.

- **10.** Touch the  $\bigcirc$  touch button.
- **11.** To save the setting, use the  $\sim$  button to select "Save".

To discard the setting, use the  $\smallfrown$  button to select "Discard".

### III Sabbath mode

You can set a time of up to 74 hours using Sabbath mode. The food in the cooking compartment remains warm, without you having to switch the appliance on or off.

#### Starting Sabbath mode

Before you can use Sabbath mode, you must activate it under "Favourites" in the basic settings. → "Setting" favourites" on page 16

Once the Sabbath mode has been activated, you can select it under the menu for the types of heating.

The appliance heats up with top/bottom heating. The temperature can be set between 85 °C and 140 °C.

- 1. Touch the ① touch button.
- 2. Use the  $\langle$  or  $\rangle$  button to select "Sabbath mode".
- **3.** Use the  $\sim$  button to navigate to the next line.
- **4.** Use the  $\langle$  or  $\rangle$  button to select the temperature.
- **5.** Use the  $\sim$  button to navigate to the next line.
- **6.** Use the  $\langle$  or  $\rangle$  button to select the cooking time.
- 7. Touch the | touch button. The appliance starts the operation.

#### **Notes**

- Once Sabbath mode has started, you can no longer change any settings or cancel the operation using the | | | touch button.
- The operation is not interrupted if you open the appliance door.

Once the Sabbath mode duration has elapsed, a signal sounds. The appliance stops heating. Use the ① touch button to switch off the appliance.

#### Cancelling Sabbath mode

Touch the ① touch button to cancel Sabbath mode.

### Cleaning agent

With good care and cleaning, your appliance will retain its appearance and remain fully functioning for a long time to come. We will explain here how you should correctly care for and clean your appliance.

#### Suitable cleaning agents

To ensure that the different surfaces are not damaged by using the wrong cleaning agent, observe the information in the table. Depending on the appliance model, not all of the areas listed may be on/in your appliance.

#### Caution!

#### Risk of surface damage

Do not use:

- Harsh or abrasive cleaning agents,
- Cleaning agents with a high alcohol content,
- Hard scouring pads or cleaning sponges,
- High-pressure cleaners or steam cleaners,
- Special cleaners for cleaning the appliance while it is

Wash new sponge cloths thoroughly before use.

**Tip:** Highly recommended cleaning and care products can be purchased through the after-sales service. Observe the respective manufacturer's instructions.

#### ⚠ Warning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

Area	Cleaning			
Appliance exterior				
Stainless steel front	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth.			
	Remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such flecks.			
	Special stainless steel cleaning products suitable for hot surfaces are available from our after-sales service or from specialist retailers. Apply a very thin layer of the cleaning product with a soft cloth.			
Plastic	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth.			
Painted surfaces	Do not use glass cleaner or a glass scraper.  Hot soapy water:			
Taintou duriados	Clean with a dish cloth and then dry with a soft cloth.			
Control panel	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth.			
	Do not use glass cleaner or a glass scraper.			

en

Door panels	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Do not use a glass scraper or a stainless steel scouring pad.
Door handle	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth.  If descaler comes into contact with the door handle, wipe it off immediately. Otherwise, any stains will not be able to be removed.
Appliance interio	r
Enamel surfaces and self-cleaning surfaces	Observe the instructions for the surfaces of the cooking compartment that follow the table.
Glass cover for the interior light- ing	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. If the cooking compartment is heavily soiled, use oven cleaner.
Door seal Do not remove.	Hot soapy water: Clean with a dish cloth. Do not scour.
Door cover	made from stainless steel: Use stainless steel cleaner. Follow the manufacturers' instructions. Do not use stainless steel care products. made from plastic: Clean using hot soapy water and a dish cloth. Dry with a soft cloth. Do not use glass cleaner or a glass scraper. Remove the door cover for cleaning.
Rails	Hot soapy water: Soak and clean with a dish cloth or brush.
Pull-out system	Hot soapy water: Clean with a dish cloth or a brush. Do not remove the lubricant while the pull-out rails are pulled out – it is best to clean them when they are pushed in. Do not clean in the dishwasher.
Accessories	Hot soapy water: Soak and clean with a dish cloth or brush. If there are heavy deposits of dirt, use a stainless steel scouring pad.

#### Notes

- Slight differences in colour on the front of the appliance are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panels, which look like streaks, are caused by reflections made by the interior lighting.
- Enamel is baked on at very high temperatures. This can cause some slight colour variation. This is normal and does not affect operation. The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough. This does not impair the anti-corrosion protection.

#### Surfaces in the cooking compartment

The back wall in the cooking compartment is selfcleaning. You can tell this from the rough surface.

The base, ceiling and side panel are enamelled and have smooth surfaces.

#### Cleaning enamel surfaces

Clean the smooth enamel surfaces with a dish cloth and hot soapy water or a vinegar solution. Then dry them with a soft cloth.

Soften baked-on food remnants with a damp cloth and soapy water. Use stainless steel wire wool or oven cleaner to remove stubborn dirt.

#### Caution!

Never use oven cleaner in the cooking compartment when it is still warm. This may damage the enamel. Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

Leave the cooking compartment open to dry after cleaning it.

**Tip:** It is best to use the cleaning aid. → "Cleaning function" on page 19

**Note:** Food residues can cause white deposits to form. These are harmless and do not affect how the appliance works. You can remove these residues using lemon juice if required.

#### Cleaning self-cleaning surfaces

The self-cleaning surfaces are coated with a porous, matte ceramic layer. This coating absorbs and dispels splashes from baking and roasting while the appliance is in operation.

If the self-cleaning surfaces no longer clean themselves sufficiently and dark stains appear, they can be cleaned using targeted heating.

#### Making settings

Remove the rails, pull-out shelves, accessories and ovenware from the cooking compartment beforehand. Thoroughly clean the smooth enamel surfaces in the cooking compartment, the inside of the appliance door and the glass cover on the interior lighting.

- **1.** Set the type of heating for baking bread.
- 2. Set the maximum temperature.
- Start the mode and leave it to run for at least one hour.

The ceramic coating is regenerated.

When the cooking compartment has cooled down, remove the brown or white residue with water and a soft sponge.

**Note:** During operation, reddish spots form on the surfaces. This is not rust, but residues from food. These spots are not harmful and do not restrict the cleaning ability of the self-cleaning surfaces.

#### Caution!

Do not use oven cleaner on the self-cleaning surfaces. This will damage the surfaces. If oven cleaner does get onto these surfaces, dab it off immediately using water and a sponge cloth. Do not rub the surface and do not use abrasive cleaning aids.

#### Keeping the appliance clean

Always keep the appliance clean and remove dirt immediately so that stubborn deposits of dirt do not build up.

#### **⚠** Warning – Risk of fire!

Loose food remnants, fat and meat juices may catch fire. Before using the appliance, remove the worst of the food remnants from the cooking compartment, heating elements and accessories.

#### **Tips**

- Clean the cooking compartment after each use. This will ensure that dirt cannot be baked on.
- Always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately.
- Use the universal pan for baking very moist cakes.
- Use suitable ovenware for roasting, e.g. a roasting dish.

### Cleaning function

The EasyClean cleaning aid makes it easier to clean the cooking compartment. Dirt is softened beforehand by vaporizing soapy water. It can then be removed more easily.

#### ⚠ Warning – Risk of scalding!

Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

#### **Starting**

#### **Notes**

- The "EasyClean 🔯" cleaning aid can only be started once the cooking compartment is cold (room temperature) and the appliance door is closed.
- Do not open the appliance door during operation.

  Doing this will interrupt the "EasyClean o" cleaning aid
- Remove the accessories from the cooking compartment.
- 2. Mix 0.4 litres of water (not distilled water) with a drop of washing-up liquid and pour into the middle of the cooking compartment floor.
- 3. Touch the ① touch button.
- **4.** Touch the  $\bigcirc$  touch button.
- 5. Use the ⟨or⟩ button to select "EasyClean or".
- **6.** Use the  $\sim$  button to navigate to the next line.
- 7. Touch the | touch button.

  The appliance starts EasyClean. The remaining time appears on the display.

#### **Finishing**

As soon as the cleaning aid has finished, an audible signal sounds and the appliance ends the operation automatically.

As soon as you open the appliance door, the interior lighting is switched on so that you can finish cleaning the cooking compartment more easily. The remaining water in the cooking compartment must be removed promptly. Do not leave the remaining water in the cooking compartment for a long time (e.g. overnight). The appliance must not be operated when the cooking compartment is still wet or damp.

#### Final cleaning

- 1. Open the appliance door and remove the remaining water with an absorbent sponge cloth.
- 2. Clean the smooth surfaces in the cooking compartment with a dish cloth or a soft brush. Stubborn residues can be removed using a stainless steel scouring pad.
- 3. Remove limescale with a cloth soaked in vinegar. Then wipe with clean water and rub dry with a soft cloth (including under the door seal).
- **4.** Use the ① touch button to switch off the appliance.
- 5. Leave the appliance door ajar in the locking position (approx. 30°) for approx. 1 hour to allow the enamel surfaces in the cooking compartment to dry. Alternatively, you can also run the rapid drying function for the cooking compartment.

#### Running the rapid drying function for the cooking compartment

- 1. After the cleaning aid process has finished, leave the appliance door ajar in the locking position (approx. 30°).
- 2. Touch the ① touch button.
- 3. Start CircoTherm hot air at 50 °C.
- 4. After 5 minutes, switch off the appliance and close the appliance door.

#### Removing heavy deposits of dirt

You have several options for removing particularly stubborn deposits of dirt.

- Leave the soapy water to work for some time before starting the cleaning aid.
- Rub soapy water onto the dirt on the smooth surfaces before starting the cleaning aid.
- Repeat the cleaning aid once the cooking compartment has cooled down.



With good care and cleaning, your appliance will retain its appearance and remain fully functional for a long time to come. This will tell you how to remove the shelves and clean them.


#### Detaching and refitting the rails


#### ⚠ Warning – Risk of burns!

The rails become very hot. Never touch the hot rails. Always allow the appliance to cool down. Keep children away from the appliance.

#### Detaching the rails

- 1. Lift the rail slightly at the front **a** and detach it **b** (figure 1).
- 2. Then pull the whole rail towards you and take it out (figure 2).







Clean the rails with cleaning agent and a sponge. For stubborn deposits of dirt, use a brush.

#### Attaching the rails

The rails only fit on the right or the left side. For both rails, ensure that the retaining bracket is at the front.

- 1. First, insert the rail in the middle of the rear socket a, until the rail rests against the cooking compartment wall, and push it back **b** (figure 11).
- 2. Then insert the rail into the front socket **c**, until the rail also rests against the cooking compartment wall here, and press it downwards **d** (figure **2**).





### Appliance door


With good care and cleaning, your appliance will retain its appearance and remain fully functional for a long time to come. This will tell you how to remove the appliance door and clean it.


#### Removing and fitting the appliance door

For cleaning purposes and to remove the door panels, you can detach the appliance door.

The appliance door hinges each have a locking lever. When the locking levers are closed (figure 1), the appliance door is secured in place. It cannot be detached.

When the locking levers are open in order to detach the appliance door (figure 2), the hinges are locked. They cannot snap shut.







## ⚠ Warning Risk of injury!

- If the hinges are not locked, they can snap shut with great force. Ensure that the locking levers are always fully closed or, when detaching the appliance door, fully open.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.

#### Removing the appliance door

- 1. Open the appliance door fully and push it in the direction of the appliance.
- 2. Fold up the two locking levers on the left and right (figure 1).
- 3. Close the appliance door as far as it goes a. With both hands, grip the door on the left- and right-hand side and pull it up and out (figure 2).






#### Fitting the appliance door

Reattach the appliance door in the opposite sequence to removal.


 When attaching the appliance door, ensure that both hinges are inserted straight into the opening (figure 1).

Place both hinges at the bottom on the outer panel and use this as a guide.

Ensure that the hinges are inserted into the correct opening. You must be able to insert them easily and without resistance. If you can feel any resistance, check that the hinges are inserted into the correct opening.



2. Open the appliance door fully. Fold both locking levers closed again (figure 2).





3. Close the cooking compartment door.

#### Removing the door cover

The stainless steel inlay in the door cover may become discoloured. To carry out thorough cleaning, you can remove the cover.


- 1. Open the appliance door slightly.
- 2. Press on the right and left side of the cover (figure 1).
- Remove the cover (figure 2). Close the appliance door carefully.





**Note:** Clean the stainless steel inlay in the cover with stainless steel cleaner. Clean the rest of the door cover with soapy water and a soft cloth.

**4.** Open the appliance door again slightly. Put the cover back in place and press on it until it clicks audibly into place (figure 3).




5. Close the appliance door.


#### Removing and installing the door panels

To facilitate cleaning, you can remove the glass panels from the appliance door.


#### Removing the door from the appliance


- 1. Open the appliance door slightly.
- Press on the right and left side of the cover (figure).
- **3.** Remove the cover (figure **2**).





- **4.** Loosen and remove the screws on the left and right of the appliance door (figure 3).
- 5. Before closing the door again, trap a tea towel which has been folded several times in the door (figure 4). Pull out the front panel upwards and lay it on a flat surface with the door handle facing downwards.





Clean the panels with glass cleaner and a soft cloth.


### **⚠** Warning


#### Risk of injury!

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.


#### Fitting the door on the appliance


- 1. Insert the front panel at the bottom into the retainers (figure 1).
- 2. Close the front panel until both upper hooks are opposite the opening (figure 2).





- 3. Press the front panel at the bottom until it clicks audibly into place (figure 3)
- Open the appliance door again slightly and remove the tea towel.
- 5. Screw both screws back in on the left and right.
- **6.** Put the cover back in place and press on it until it clicks audibly into place (figure 4).





7. Close the appliance door.

#### Caution!

Do not use the cooking compartment again until the panels have been correctly fitted.

### ? Trouble shooting

If a fault occurs, there is often a simple explanation. Before calling the after-sales service, please refer to the fault table and attempt to correct the fault yourself.

Tip: If a meal does not turn out exactly as you wanted, refer to the "Tested for you in our cooking studio" section. Here, you will find plenty of cooking tips and

#### Marning – Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

#### Fault table

#### ⚠ Warning – Risk of electric shock!

- Work on the appliance electronics may only be performed by a specialist.
- Always disconnect the appliance from the power supply when work is carried out on the electronics. Switch off the circuit breaker or remove the fuse from your household fuse box.

Fault	Possible cause	Notes/remedy
The appliance does not work	The plug is not plugged into the mains	Connect the appliance to the power supply
	Power cut	Check whether other kitchen appliances are working
	The circuit breaker is faulty	Check in the fuse box to make sure that the fuse for the appliance is OK
After switching on an operating mode, a message is shown on the display which indicates that the temperature is too high	The appliance has not cooled down sufficiently	Allow the appliance to cool down and switch the operating mode on again
The appliance cannot be switched on; the ⇐⇒ symbol is shown on the display	The automatic childproof lock is activated	Press and hold the $\bigcirc$ touch button until the $\Longrightarrow$ symbol goes out
The appliance cannot be operated when it is switched on; the ← symbol is shown on the display	The childproof lock is activated	Press and hold the $igoplus$ touch button until the $\mbox{\ensuremath{\iff}}$ symbol goes out
The appliance does not heat up; □ is shown on the display	Demo mode is activated in the basic settings	Disconnect the appliance from the mains for approx. 10 seconds (switch off the circuit breaker in the fuse box) and then deactivate demo mode in the basic settings within 3 minutes  — "Basic settings" on page 16
"D" or "E" appears on the display, e.g. D0111 or E0111	Technical problem	Switch the appliance off and on again  If the message appears again, call the after-sales service. Quote the exact error message

#### Maximum operating time exceeded

Your appliance ends the operation automatically when no cooking time is set and the setting has not been changed for a long time.

The actual cooking time until the operation is stopped automatically varies according to the selected settings.

The appliance display indicates that the operation will end automatically. Afterwards, the operation is stopped.

To use the appliance again, switch it off beforehand. Then switch the appliance on again and set the required operation.

#### Replacing the bulb in the top of the cooking compartment

If the cooking compartment light bulb fails, it must be replaced. Heat-resistant, 40 watt, 230 V halogen bulbs are available from the after-sales service or specialist retailers.

When handling the halogen bulb, use a dry cloth. This will increase the service life of the bulb. Only use these

#### Marning – Risk of electric shock!


When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

#### **⚠** Warning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

- 1. Place a tea towel in the cold cooking compartment to prevent damage.
- 2. Turn the glass cover anti-clockwise to remove it (figure 1).
- **3.** Pull out the bulb do not turn it (figure 2). Insert the new bulb, making sure that the pins are in the correct position. Push the bulb in firmly.





- 4. Screw the glass cover back on. Depending on the appliance model, the glass cover may have a sealing ring. If the glass cover has a sealing ring, put it back in place before screwing the cover back on.
- 5. Remove the tea towel and switch on the circuit breaker.

#### Glass cover

If the glass cover of the halogen bulb is damaged, it must be replaced. You can obtain a new glass cover from the after-sales service. Please specify the E number and FD number of your appliance.

### **Customer service**

Our after-sales service is there for you if your appliance needs to be repaired. We will always find an appropriate solution, also in order to avoid after-sales personnel having to make unnecessary visits.

#### E number and FD number

When calling us, please quote the full product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate bearing these numbers can be found when you open the appliance door.

On some appliances with a steam-assisted cooking function, you will find the rating plate behind the control panel.



To save time, you can make a note of the numbers for your appliance and the telephone number of the aftersales service in the space below in case you need them.

E no. FD no.

#### After-sales service ®

Please note that a visit from an after-sales service engineer is not free of charge in the event that the appliance has been misused, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

#### To book an engineer visit and product advice GB 0344 892 8989

Calls charged at local or mobile rate.

ΙE 01450 2655

0.03 € per minute at peak. Off peak 0.0088 € per minute.

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

# Tested for you in our cooking studio

Here, you can find a selection of dishes and the ideal settings for them. We will show you which type of heating and temperature are best suited to your dish. You will get information on suitable cooking accessories and the height at which they should be placed in the oven. You will also get tips about cookware and preparation methods.

**Note:** A lot of steam can build up in the cooking compartment when cooking food.

Your appliance is very energy-efficient and radiates very little heat to its surroundings during operation. Due to the high difference in temperature between the appliance interior and the external parts of the appliance, condensation may build up on the door, control panel or adjacent kitchen cabinet panels. This is a normal physical phenomenon. Condensation can be reduced by preheating the oven or opening the door carefully.

#### Silicone moulds

For the best cooking results, we recommend dark-coloured metal baking tins/dishes.

Nevertheless, if you wish to use silicone moulds, follow the manufacturer's instructions and recipes. Silicone moulds are often smaller than normal baking tins. Quantity and recipe specifications may vary.

#### Cakes and small baked items

Your appliance offers you a range of heating types for the preparation of cakes and small baked items. You can find the ideal settings for many dishes in the settings tables.

Also refer to the notes in the section on allowing dough to rise.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

#### **Shelf positions**

Use the indicated shelf positions.

#### Baking on one level

When baking on one level, use the following shelf positions:

Tall baked items: Level 2Flat baked items: Level 3

If you are using CircoTherm Hot air as the type of heating, you can choose between levels 1, 2, 3 and 4.

#### Baking on several levels

Use CircoTherm. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

Baking on two levels:

Universal pan: Level 3
 Baking tray: Level 1

 Baking tins/dishes on the wire rack First wire rack: Level 3 Second wire rack: Level 1

Baking on three levels:

Baking tray: Level 4
 Universal pan: Level 3
 Baking tray: Level 1

Baking on four levels:

4 wire racks with greaseproof paper First wire rack: Level 4 Second wire rack: Level 3 Third wire rack: Level 2 Fourth wire rack: Level 1

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another or offset and vertically stacked in the cooking compartment.

#### Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

#### Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

#### Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

When baking moist cakes or pastries with many toppings, use the universal pan so that any excess liquid does not overflow and make the cooking compartment dirty.

#### **Baking tins**

Dark- coloured metal baking tins are most suitable.

Tinplate baking tins, ceramic dishes and glass dishes extend baking time and mean that the baked item will not brown evenly. If you wish to bake using these baking tins/dishes and using top/bottom heating, slide in the tin/dish at level 1.

#### Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

#### **Recommended setting values**

The table lists the optimal heating type for various baked items. The temperature and baking time depend on the amount and consistency of the dough/mixture. For this reason, the table specifies setting ranges. Try using the lower values to start with. A lower temperature will result in more even browning. You can use a higher setting next time if necessary.

**Note:** Baking times cannot be reduced by using higher temperatures. Cakes or small baked items would only be cooked on the outside, and would not be fully baked in the middle.

The setting values apply to food that is placed into a cold cooking compartment; by doing this, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated baking times by several minutes.

Preheating is necessary for selected food, and this is indicated in the table. Do not place your food or accessories into the cooking compartment until it has finished preheating.

If you wish to follow one of your own recipes when baking, you should use the setting values listed for similar baked items in the table as reference.

Additional information can be found in the baking tips listed after the settings table.

Remove unused accessories from the cooking compartment. This will ensure that you achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- Top/bottom heating
- <u>& Circotherm intensive</u>
- Bread baking

Dish	Accessories/cookware	Shelf posi- tion	Heating function	Tempera- ture in °C	Cooking time in mins.
Cakes in tins					
Sponge cake, simple	Ring tin/cake tin	2	ک	140-160	50-70
Sponge cake, simple	Ring tin/cake tin	2	=	150-170	50-70
Sponge cake, simple, 2 levels	Ring tin/cake tin	3+1	S	140-160	60-80
Sponge cake, delicate	Ring tin/cake tin	2	=	150-170	60-80
Fruit flan made from sponge mixture, delicate	Ring/springform cake tin	2	Ξ	160-180	40-60
Fruit flan made from sponge mixture, delicate	Ring/springform cake tin	2	ک	150-170	40-60
Sponge flan base	Flan base tin	3	Ξ	160-180	20-30
Sponge flan base	Flan base tin	3	L	150-170	20-30
Fruit tart or cheesecake with shortcrust pastry base	Springform cake tin, Ø 26 cm	2	Ξ	170-190	60-80
Swiss flan	Pizza tray	3	=	220-240	35-45
Swiss flan	Pizza tray	3	<u> </u>	170-190	45-55
Tart	Flan-base cake tin, black	3	<u> </u>	190-210	25-40
Bundt yeast cake	Ring cake tin	2	Ξ	150-170	50-70
Bundt yeast cake	Ring cake tin	2	L	150-160	50-70
Yeast cake	Springform cake tin, Ø 28 cm	2	ک	150-160	20-30
Yeast cake	Springform cake tin, Ø 28 cm	2	Ξ	160-170	20-30
Sponge base, 2 eggs	Flan base tin	3	S	160-180*	20-30
Sponge base, 2 eggs	Flan base tin	3	Ξ	150-170*	20-30
Sponge flan, 3 eggs	Springform cake tin, Ø 26 cm	2	Ξ	160-170*	25-35
Sponge flan, 3 eggs	Springform cake tin, Ø 26 cm	2	ک	160-170*	30-40
Sponge flan, 6 eggs	Springform cake tin, Ø 28 cm	2	L	150-170*	30-50
Sponge flan, 6 eggs	Springform cake tin, Ø 28 cm	2	Ξ	150-170*	30-50
Cakes on baking trays					
Sponge cake with topping	Baking tray	3	Ξ	160-180	20-40
Sponge cake with topping	Baking tray	3	L	150-170	25-40
Sponge cake, 2 levels	Universal pan + baking tray	3+1	L	140-160	30-50
Shortcrust tart with dry topping	Baking tray	3	Ξ	170-190	25-35
Shortcrust tart with dry topping, 2 levels	Universal pan + baking tray	3+1	ک	160-170	35-45
Shortcrust tart with moist topping	Universal pan	3	Ξ	160-180	55-65
Shortcrust tart with moist topping	Universal pan	3	ک	150-170	55-85
Swiss flan	Universal pan	3	Ξ	200-210	40-50
Swiss flan	Universal pan	3	<u>&amp;</u>	170-190	45-55
* Preheat  ** Preheat for 5 mins., do not use quick heat fu	nction				

Dish	Accessories/cookware	Shelf posi-	Heating	Tempera-	Cooking
		tion	function	ture in °C	time in mins.
Yeast cake with dry topping	Universal pan	3	=	160-180	15-20
Yeast cake with dry topping	Universal pan	3	L	150-170	25-35
Yeast cake with dry topping, 2 levels	Universal pan + baking tray	3+1	L	150-170	20-30
Yeast cake with moist topping	Universal pan	3	=	180-200	30-40
Yeast cake with moist topping	Universal pan	3	S	160-170	40-50
Yeast cake with moist topping, 2 levels	Universal pan + baking tray	3+1	S	150-170	45-60
Plaited loaf, savarin	Baking tray	2	L	150-160	30-40
Plaited loaf, savarin	Baking tray	2	=	160-170	25-35
Swiss roll	Baking tray	3	S	180-200*	8-15
Swiss roll	Baking tray	3	Ξ	180-190*	15-20
Stollen with 500 g flour	Baking tray	2	Ξ	150-170	45-60
Stollen with 500 g flour	Baking tray	3	L	150-170	55-65
Strudel, sweet	Universal pan	2	Ξ	190-210	55-65
Strudel, sweet	Universal pan	2	ک	170-180	50-60
Strudel, frozen	Universal pan	3	<u></u>	200-220	35-45
Small baked items					
Small cakes	Baking tray	3	Ξ	160**	20-30
Small cakes	Baking tray	3	ک	150**	25-35
Small cakes, 2 levels	Universal pan + baking tray	3+1	ک	150**	25-35
Small cakes, 3 levels	Baking trays + universal pan	4+3+1	ک	140**	35-45
Muffins	Muffin tray	3	ک	160-180*	15-25
Muffins	Muffin tray	3	=	170-190	15-20
Muffins, 2 levels	Muffin trays	3+1	ک	160-180*	15-30
Small yeast cakes	Baking tray	3	Ξ	160-180	25-35
Small yeast cakes	Baking tray	3	L	150-170	25-35
Small yeast cakes, 2 levels	Universal pan + baking tray	3+1	ک	150-170	25-40
Puff pastry	Baking tray	3	L	170-190*	20-35
Puff pastry	Baking tray	3	=	180-200	20-35
Puff pastry, 2 levels	Universal pan + baking tray	3+1	ک	170-190*	20-45
Puff pastry, 3 levels	Baking trays + universal pan	4+3+1	ک	170-190*	20-45
Puff pastry, flat, 4 levels	4 wire racks	4+3+2+1	ک	180-200*	20-35
Choux pastry	Baking tray	3	Ξ	200-220	30-40
Choux pastry	Baking tray	3		190-210	30-40
Choux pastry, 2 levels	Universal pan + baking tray	3+1	<u></u>	190-210	35-45
Danish pastry	Baking tray	3	ک	160-180	20-30
Danish pastry	Baking tray	3	Ξ	170-190	15-25
Biscuits					
Viennese whirls	Baking tray	3	=	140-150**	25-40
Viennese whirls	Baking tray	3	L	140-150**	25-40
Whirls, 2 levels	Universal pan + baking tray	3+1	L	140-150**	30-40
Whirls, 3 levels	Baking trays + universal pan	4+3+1	L	130-140**	35-55
Biscuits	Baking tray	3	Ξ	150-160	15-25
Biscuits	Baking tray	3	S	140-160	15-30
* Preheat					
** Preheat for 5 mins., do not use quick heat fu	unction				

Dish	Accessories/cookware	Shelf posi- tion	Heating function	Tempera- ture in °C	Cooking time in mins.
Biscuits, 2 levels	Universal pan + baking tray	3+1	S	140-160	15-30
Biscuits, 3 levels	Baking trays + universal pan	4+3+1	L	140-160	15-30
Meringue	Baking tray	3	S	80-90*	120-150
Meringue, 2 levels	Universal pan + baking tray	3+1	S	80-90*	120-180
Macaroons	Baking tray	3	L	90-110	20-40
Macaroons, 2 levels	Universal pan + baking tray	3+1	L	90-110	25-45
Macaroons, 3 levels	Baking trays + universal pan	4+3+1	S	90-110	30-50
* Preheat					
** Preheat for 5 mins., do not use quick heat	function				

#### Tips on baking

You want to find out whether the cake is completely cooked in the middle.	Push a cocktail stick into the highest point on the cake. If the cocktail stick comes out clean with no dough residue, the cake is ready.
The cake collapses.	Next time, use less liquid. Alternatively, set the temperature to be 10 °C lower and extend the baking time. Adhere to the specified ingredients and preparation instructions in the recipe.
The cake has risen in the middle but is lower around the edge.	Only grease the base of the springform cake tin. After baking, loosen the cake carefully with a knife.
The fruit juice overflows.	Next time, use the universal pan.
Small baked items stick to one another during baking.	There should be a gap of approx. 2 cm around each item. This gives enough space for the baked items to expand well and brown on all sides.
The cake is too dry.	Set the temperature 10 °C higher and shorten the baking time.
The cake is generally too light in colour.	If the shelf position and the cookware are correct, then you should increase the temperature if necessary or extend the baking time.
The cake is too light on top, and too dark underneath.	Bake the cake one level higher in the oven the next time.
The cake is too dark on top, and too light underneath.	Bake the cake one level lower in the oven the next time. Select a lower temperature and extend the baking time.
Cakes baked in a tray or tin are too brown at the back.	Place the baking tray in the middle of the accessories, not directly against the back wall.
The whole cake is too dark.	Select a lower temperature next time and extend the baking time if necessary.
The cake is unevenly browned.	Select a slightly lower temperature.  Protruding greaseproof paper can affect the air circulation. Always cut greaseproof paper to size.  Ensure that the baking tin does not stand directly in front of the openings in the cooking compartment back wall.  When baking small items, you should use similar sizes and thicknesses wherever possible.
You were baking on several levels. The items on the top baking tray are darker than those on the lower baking tray.	Always use CircoTherm when baking on several levels. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.
The cake looks good, but is not cooked properly in the middle.	Use a lower temperature and bake slightly longer; if necessary, add slightly less liquid. For cakes with a moist topping, bake the base first. Sprinkle it with almonds or breadcrumbs and then place the topping on top.
The cake cannot be turned out of the dish when it is turned upside down.	Allow the cake to cool down for 5 to 10 minutes after baking. If it still sticks, carefully loosen the cake around the edges again using a knife. Turn the cake tin upside down again and cover it several times with a cold, wet cloth. Next time, grease the baking tin/dish and sprinkle with breadcrumbs.

#### **Bread and rolls**

Your appliance offers you a range of heating types for baking bread and rolls. You can find the ideal settings for many dishes in the settings tables.

Also refer to the notes in the section on allowing dough to rise.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

#### **Shelf positions**

Use the indicated shelf positions.

#### Baking on one level

When baking on one level, use the following shelf positions:

Tall baked items: Level 2Flat baked items: Level 3

If you are using CircoTherm Hot air as the type of heating, you can choose between levels 1, 2, 3 and 4.

#### Baking on two levels

Use CircoTherm. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

Universal pan: Level 3 Baking tray: Level 1

Baking tins/dishes on the wire rack

First wire rack: Level 3
Second wire rack: Level 1

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another or offset and vertically stacked in the cooking compartment.

#### **Accessories**

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

#### Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

#### Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

#### **Baking tins**

Dark- coloured metal baking tins are most suitable.

Tinplate baking tins, ceramic dishes and glass dishes extend baking time and mean that the baked item will not brown evenly. If you wish to bake using these baking tins/dishes and using top/bottom heating, slide in the tin/dish at level 1.

#### Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

#### Frozen products

Do not use frozen products that are heavily frosted. Remove any ice on the food.

Some frozen products may be unevenly pre-baked. Uneven browning may remain even after baking.

#### Recommended setting values

The table lists the optimal heating type for various kinds of bread and bread roll. The temperature and baking time depend on the amount and consistency of the dough/mixture. For this reason, the table specifies setting ranges. Try using the lower values to start with. A lower temperature will result in more even browning. You can use a higher setting next time if necessary.

**Note:** Baking times cannot be reduced by using higher temperatures. The bread or bread rolls would only be cooked on the outside, but would not be fully baked in the middle.

The setting values apply to food that is placed into a cold cooking compartment; by doing this, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated baking times by several minutes.

Preheating is necessary for selected food, and this is indicated in the table. Do not place your food or accessories into the cooking compartment until it has finished preheating. Some food turns out best if it is baked in several stages. These foods are indicated in the table.

The setting values for bread dough apply to both dough placed on a baking tray and dough placed in a loaf tin.

If you wish to follow one of your own recipes when baking, you should use the setting values listed for similar baked items in the table as reference.

Remove unused accessories from the cooking compartment. This will ensure that you achieve the best possible cooking results and energy savings of up to 20 per cent.

#### Caution!

Never pour water into the hot cooking compartment or place cookware containing water onto the bottom of the cooking compartment. The change in temperature can cause damage to the enamel.

Types of heating used:

- & CircoTherm
  Top/bottom heating
  Circo-roasting

- ∆ Circotherm intensive
- Bread baking
- Full-surface grill

Dish	Accessories	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Bread					
White bread, 750 g	Universal pan or cake tin	2	Ξ	180-200*	30-40
White bread, 750 g	Universal pan or cake tin	2		210-220*	10-15
				180-190*	25-35
Multigrain bread, 1.5 kg	Universal pan or cake tin	2	<u></u>	210-220*	10-15
				180-190*	40-50
Multigrain bread, 1.5 kg	Universal pan or cake tin	2	=	230-240*	10-15
				200-210*	40-50
Wholemeal bread, 1 kg	Universal pan	2	<u></u>	210-220*	10-15
				180-190*	40-50
Wholemeal bread, 1 kg	Universal pan	2	=	230-240*	10-15
				200-210*	40-50
Flatbread	Universal pan	3	=	250-270	20-25
Flatbread	Universal pan	3	<u></u>	220-240	25-35
Bread rolls					
Part-cooked rolls or baguette, pre-baked	Universal pan	3	<u>&amp;</u>	180-200	10-15
Bread rolls, sweet, fresh	Baking tray	3	Ξ	170-190*	15-20
Bread rolls, sweet, fresh	Baking tray	3	L	150-170*	15-25
Bread rolls, sweet, fresh, 2 levels	Universal pan + baking tray	3+1	L	150-170*	20-30
Bread rolls, fresh	Baking tray	3	Ξ	180-200	20-30
Bread rolls, fresh	Baking tray	3	S	170-190	20-30
Baguette, pre-baked, chilled	Universal pan	3	₹	180-200	20-30
Bread rolls, frozen					
Part-cooked rolls or baguette, pre-baked	Universal pan	3	<u></u>	180-200	10-15
Lye bread, pieces of dough	Universal pan	3	<u>&amp;</u>	180-200	20-25
Croissant, pieces of dough	Universal pan	3	ک	170-190	30-35
Toast					
Toast with topping, 4 slices	Wire rack	3	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	190-210	10-15
Toast with topping, 12 slices	Wire rack	3	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	230-250	10-15
Toasting bread (do not preheat)	Wire rack	4	***	290	4-6
* Preheat					

#### Pizza, quiche and savoury cakes

Your appliance offers you a range of heating types for preparing pizza, quiche and savoury cakes. You can find the ideal settings for many dishes in the settings tables.

Also refer to the notes in the section on allowing dough

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

#### **Shelf positions**

Use the indicated shelf positions.

#### Baking on one level

When baking on one level, use the following shelf positions:

■ Tall baked items: Level 2 ■ Flat baked items: Level 3

If you are using CircoTherm Hot air as the type of heating, you can choose between levels 1, 2, 3 and 4.

#### Baking on several levels

Use CircoTherm. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time. Baking on two levels:

 Universal pan: Level 3 Baking tray: Level 1

Baking tins/dishes on the wire rack

First wire rack: Level 3 Second wire rack: Level 1

#### Baking on four levels:

 4 wire racks with greaseproof paper First wire rack: Level 4 Second wire rack: Level 3

Third wire rack: Level 2 Fourth wire rack: Level 1

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another or offset and vertically stacked in the cooking compartment.

#### **Accessories**

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

#### Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

#### Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

Use the universal pan for pizzas with many toppings.

#### **Baking tins**

Dark- coloured metal baking tins are most suitable.

Tinplate baking tins, ceramic dishes and glass dishes extend baking time and mean that the baked item will not brown evenly. If you wish to bake using these baking tins/dishes and using top/bottom heating, slide in the tin/dish at level 1.

#### **Greaseproof paper**

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

#### Frozen products

Do not use frozen products that are heavily frosted. Remove any ice on the food.

Some frozen products may be unevenly pre-baked. Uneven browning may remain even after baking.

#### Recommended setting values

The table lists the optimal heating type for various types of food. The temperature and baking time depend on the amount and consistency of the dough/mixture. For this reason, the table specifies setting ranges. Try using the lower values to start with. A lower temperature will result in more even browning. You can use a higher setting next time if necessary.

**Note:** Baking times cannot be reduced by using higher temperatures. The food would only be cooked on the outside, but would not be fully baked in the middle.

The setting values apply to food that is placed into a cold cooking compartment; by doing this, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated baking times by several minutes.

Preheating is necessary for selected food, and this is indicated in the table. Do not place your food or accessories into the cooking compartment until it has finished preheating.

If you wish to follow one of your own recipes when baking, you should use the setting values listed for similar baked items in the table as reference.

Remove unused accessories from the cooking compartment. This will ensure that you achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- ∠ CircoTherm

- Bread baking

Dish	Accessories	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Pizza					
Pizza, fresh	Baking tray	3	<u>&amp;</u>	200-220	25-35
Pizza, fresh, 2 levels	Universal pan + baking tray	3+1	S	180-200	35-45
Pizza, fresh, thin base	Pizza tray	2	<u>&amp;</u>	220-230	20-30
Pizza, chilled	Wire rack	3	<u>&amp;</u>	190-210	10-15
Pizza, frozen					
Pizza with thin base x 1	Wire rack	3	<u>&amp;</u>	190-210	15-20
Pizza with thin base x 2	Universal pan + wire rack	3+1	<u></u>	190-210	20-25
Pizza, deep-pan, x 1	Wire rack	3	<u>&amp;</u>	180-200	20-25
Pizza, deep-pan, x 2	Universal pan + wire rack	3+1	<u></u>	190-210	20-30
* Preheat					

Dish	Accessories	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Pizza baguette	Wire rack	3	<u>&amp;</u>	200-220	15-20
Mini pizzas	Universal pan	3	<u>&amp;</u>	180-200	15-20
Mini pizzas, diameter 7 cm, 4 levels	4 wire racks	4+3+2+1	S	180-200*	20-30
Savoury cakes and quiches					
Savoury cakes in a tin	Springform cake tin, diameter 28 cm	2	L	170-190	50-60
Savoury cakes in a tin	Springform cake tin, diameter 28 cm	2	<u>&amp;</u>	170-190	55-65
Quiche	Flan-base cake tin, black	3	<u>&amp;</u>	190-210	30-40
Tarte flambée	Universal pan	3	Ξ	260-280*	10-15
Tarte flambée	Universal pan	3	<u>&amp;</u>	200-210*	15-25
Pierogi	Ovenproof dish	2	_	190-200	30-45
Pierogi	Ovenproof dish	2	S	170-190	50-70
Empanada	Universal pan	3	L	180-190	30-45
Börek	Universal pan	2	_	180-200	35-45
Börek	Universal pan	1	<u></u>	200-220*	20-30
* Preheat					

#### Bakes and soufflés

Your appliance offers a range of heating types for preparing bakes and soufflés. You can find the ideal settings for many dishes in the settings tables.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

#### Shelf positions

Always use the indicated shelf positions.

You can prepare dishes on one level using a baking tin/dish or the universal pan.

- Baking tins/dishes on the wire rack: Level 2
- Universal pan: Level 3

You can also prepare soufflés in a water bath in the universal pan. To do so, slide the universal pan in at level 2.

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another in the cooking compartment.

#### **Accessories**

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

#### Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

#### Universal pan

Slide in the universal pan carefully as far as the limit stop, with the bevelled edge facing the appliance door.

#### Cookware

Use wide, shallow cookware for bakes and gratins. In deep, narrow cookware, food requires more time to cook, and the top will be darker.

#### Recommended setting values

In the table, you can find the ideal heating type for various bakes and soufflés. The temperature and cooking time are dependent on the quantity of food and the recipe. How well cooked a bake is will depend on the size of the cookware and the depth of the bake. Settings ranges are indicated for this reason. Try using the lower values at first. A lower temperature results in more even browning. You can increase the temperature next time if necessary.

**Note:** Cooking times cannot be reduced by using higher temperatures. Bakes or soufflés would only be cooked on the outside, but would be raw in the middle.

The setting values apply to dishes placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, the indicated cooking times will be reduced by several minutes.

If you wish to follow one of your own recipes when cooking, you can use similar dishes in the table as a reference

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent

Types of heating used:

- Top/bottom heating

- <u>&</u> Circotherm intensive
- Bread baking

Bakes & soufflés	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Bake, savoury, cooked ingredients	Ovenproof dish	2	S	170-190	35-50
Bake, savoury, cooked ingredients	Ovenproof dish	2	=	200-220	30-50
Bake, sweet	Ovenproof dish	2	S	160-180	40-50
Bake, sweet	Ovenproof dish	2	_	170-190	40-60
Lasagne, fresh, 1 kg	Ovenproof dish	2	_	170-190	50-60
Lasagne, fresh, 1 kg	Ovenproof dish	2	L	160-180	50-60
Lasagne, frozen, 400 g	Wire rack	2	<u>&amp;</u>	190-210	30-35
Potato gratin, raw ingredients, 4 cm deep	Ovenproof dish	2	$\underline{\&}$	160-190	50-70
Potato gratin, raw ingredients, 4 cm deep, 2 levels	Ovenproof dish	3+1	٨	150-170	60-80
Soufflé	Ovenproof dish	2	S	160-180*	35-45
Soufflé	Individual moulds	2	_	170-190	65-75

#### **Poultry**

Your appliance offers you a range of heating types for preparing poultry. You can find the ideal settings for certain dishes in the settings tables.

#### Roasting on the wire rack

Roasting on the wire rack is particularly well suited for larger poultry or for multiple pieces at the same time.

Slide the universal pan into the oven at the indicated shelf position with the wire rack attached. Ensure that the wire rack is correctly positioned on the universal pan.  $\rightarrow$  "Accessories" on page 9

Depending on the size and type of the poultry, pour up to ½ litres of water into the universal pan. Any dripping fat will be caught. You can make a sauce from these juices. This will also result in less smoke and ensure that the cooking compartment stays cleaner.

#### Roasting in cookware

Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The poultry cooks slower and does not brown so well. Use a higher temperature and/ or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

#### **Uncovered cookware**

It is best to use a deep roasting tin/dish for roasting poultry. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

#### **Covered cookware**

When cooking with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

Poultry can also become crispy in a covered roasting dish. To do so, use a roasting dish with a glass lid and set a higher temperature.

#### Grilling

Keep the appliance door closed when using the grill. Never grill with the appliance door open.

Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. Any dripping fat will be caught.

When grilling, try wherever possible to use pieces of food which are of a similar thickness and weight. This will allow them to brown evenly and remain succulent and juicy. Place the food to be grilled directly onto the wire rack.

Use tongs to turn the pieces of food you are grilling. If you pierce the meat with a fork, the juices will run out and it will become dry.

#### **Notes**

- The grill element switches itself continuously on and off; this is normal. The set temperature determines how frequently this occurs.
- Smoke may be produced when grilling.

#### Recommended setting values

In the table, you can find the ideal heating type for the kind of poultry you are cooking. The temperature and cooking time depend on the amount, composition and temperature of the food. Setting ranges are indicated for this reason. Try using the lower values at first. You can increase the temperature next time if necessary.

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry is placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, the indicated cooking times will be reduced by several minutes.

In the table, you can find specifications for poultry with default values for the weight. If you wish to cook heavier poultry, use the lower temperature in every case. If cooking multiple pieces, use the weight of the heaviest piece as a reference for determining the cooking time. The individual pieces should be approximately equal in

A general rule: the larger the poultry is, the lower the cooking temperature and the longer the cooking time. Turn the poultry after approx. ½ to ¾ of the indicated time.

**Note:** Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

#### **Tips**

- For duck or goose, pierce the skin on the underside of the wings. This allows the fat to run out.
- If using duck breast, score the skin. Do not turn duck
- When you turn poultry, ensure that the breast side or the skin side is underneath at first.
- Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water or orange juice.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per

Types of heating used:

- Top/bottom heating
- T Circo-roasting

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Chicken					
Chicken, 1 kg	Wire rack	2	Ž	200-220	60-70
Chicken breast fillet, 150 g each (grilling)	Wire rack	4	****	275*	15-20
Small chicken portions, 250 g each	Wire rack	3	Ĭ	220-230	30-35
Chicken goujons, nuggets, frozen	Universal pan	3	<u>&amp;</u>	190-210	20-25
Poulard, 1.5 kg	Wire rack	2	Ĭ	200-220	70-90
Duck and goose					
Duck, 2 kg	Wire rack	1	Ĭ	180-200	90-110
Duck breast, 300 g each	Wire rack	3	Ĭ.	230-250	25-30
Goose, 3 kg	Wire rack	2	Ž	160-180	120-150
Goose legs, 350 g each	Wire rack	2	Ĭ.	210-230	40-50
Turkey					
Small turkey, 2.5 kg	Wire rack	2	Ĭ.	180-200	70-90
Turkey breast, boned, 1 kg	Cookware, covered	2	Ξ	240-260	80-100
Turkey thigh, with bone, 1 kg	Wire rack	2	~~~	180-200	80-100
* Preheat for 5 mins					

#### Meat

Your appliance offers you many heating types for preparing meat. You can find the ideal settings for many dishes in the settings tables.

#### Roasting and braising

Baste lean meat with fat as required or cover it with strips of bacon.

Score the rind crosswise. If you turn the joint when cooking, ensure that the rind is underneath at first.

When the joint is ready, turn off the oven and allow it to rest for another 10 minutes in the cooking compartment. This allows the meat juices to be better distributed. Wrap the joint in aluminium foil if necessary. The recommended standing time is not included in the cooking time specified.

#### Roasting on the wire rack

On the wire rack, meat will become very crispy on all

Pour up to ½ litres of water into the universal pan, depending on the size and type of the meat. Dripping fat and meat juices will be caught. You can make a sauce using these juices. This will also result in less smoke and ensure that the cooking compartment stays cleaner.

Slide the universal pan into the oven at the indicated shelf position with the wire rack attached. Ensure that the wire rack is correctly positioned on the universal pan. → "Accessories" on page 9

#### Roasting and braising in cookware

It is more convenient to roast and braise meat in cookware. You can take the joint out of the cooking compartment more easily in the cookware, and prepare the sauce in the cookware itself.

Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Add in a little liquid for roasting if the meat is lean. A covering of approx. ½ cm depth should be applied to the base of any glass cookware.

The amount of liquid is dependent on the type of meat, the cookware material and also on whether or not a lid is used. If preparing meat in an enamelled or dark metal roasting dish, it will need a little more liquid than if cooked in glass cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The meat cooks more slowly and will not brown so much. Use a higher temperature and/or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

#### **Uncovered cookware**

Use a deep roasting tin/dish for roasting meat. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

#### **Covered cookware**

When cooking with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

The distance between the meat and the lid must be at least 3 cm. The meat may rise.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

If necessary, braise the meat first by searing it. Add water, wine, vinegar or a similar liquid to the braising liquid. A covering approx. 1-2 cm deep should be applied to the base of the cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Meat can also become crispy in a covered roasting dish. To do so, use a roasting dish with a glass lid and set a higher temperature.

#### Grilling

Keep the appliance door closed when using the grill. Never grill with the appliance door open.

Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. Any dripping fat will be caught.

When grilling, try wherever possible to use pieces of food which are of a similar thickness and weight. This will allow them to brown evenly and remain succulent and juicy. Place the food to be grilled directly onto the wire rack.

Use tongs to turn the pieces of food you are grilling. If you pierce the meat with a fork, the juices will run out and it will become dry.

Do not add salt until after the meat has been grilled. Salt draws water from the meat.

#### **Notes**

- The grill element switches itself continuously on and off; this is normal. The set temperature determines how frequently this occurs.
- Smoke may be produced when grilling.

#### **Recommended setting values**

You can find the ideal heating type for many meat dishes in the table. Temperature and cooking time depend on the amount, composition and temperature of the food. Settings ranges are indicated for this reason. Try using the lower values at first. You can increase the temperature next time if necessary.

The setting values apply to chilled meat placed into the cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated cooking times by several minutes.

You can find information on roasts and default values for weights in the table. If you wish to roast a heavy joint of meat, you should definitely use a lower temperature. If roasting several joints, use the weight of the heaviest piece as a basis for determining the cooking time. The individual pieces should be approximately equal in size.

As a general rule: the larger a roasting joint is, the lower the cooking temperature and the longer the cooking time.

Turn roasting joints and grilled items after approx. ½ to % of the indicated time.

If you wish to follow one of your own recipes, you should use similar dishes as a reference. You can find additional information in the tips on roasting, braising and grilling attached to the settings table.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:
■ ☐ Top/bottom heating

Circo-roasting
Full-surface grill

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Pork					
Joint of pork without rind, e.g. neck, 1.5 kg	Cookware, uncovered	2	Ĭ.	180-190	110-130
Joint of pork with rind, e.g. shoulder, 2 kg	Wire rack	2	Ž.	190-200	130-140
Pork tenderloin steak, 1.5 kg	Cookware, uncovered	2	Ž.	220-230	70-80
Fillet of pork, 400 g	Wire rack	3	Ž.	220-230	20-25
Smoked pork on the bone, 1 kg (with a little added water)	Cookware, covered	2	Ĭ.	210-230	70-90
Pork steaks, 2 cm thick	Wire rack	4	***	275	16-20
Pork medallions, 3 cm thick	Wire rack	4	****	290*	10-14
Beef					
Fillet of beef, medium, 1 kg	Wire rack	2	Ĭ.	210-220	40-50
Pot-roasted beef, 1.5 kg	Cookware, covered	2	Ĭ.	200-220	130-160
Sirloin, medium, 1.5 kg	Wire rack	2	Ĭ.	220-230	60-70
Steak, 3 cm thick, medium	Wire rack	4	***	290	15-20
Burger, 3-4 cm thick	Wire rack	4	***	290	25-30
Veal					
Joint of veal, 1.5 kg	Cookware, uncovered	2	Ž.	160-170	100-120
Knuckle of veal, 1.5 kg	Cookware, uncovered	2	Ξ	200-210	100-120
Lamb					
Leg of lamb, boned, medium, 1.5 kg	Cookware, uncovered	2	Ĭ.	170-190	50-80
Saddle of lamb on the bone***	Wire rack	2	Ž.	180-190	40-50
Lamb cutlet**	Wire rack	4	***	290	14-18
Sausages					
Grilled sausages	Wire rack	4	****	290	10-15
Meat dishes					
Meat loaf, 1 kg	Cookware, uncovered	2	~~~ L	170-180	60-70
* Preheat					

### Tips on roasting and braising

The cooking compartment becomes very dirty.	Prepare your food in an enclosed roasting dish with higher temperature or use the grill tray. You will achieve the best roasting results if you use the grill tray. The grill tray can be bought later as a special accessory.
The roast is too dark and the crackling is burned in places, and/or the roast is too dry.	Check the shelf position and temperature. Select a lower temperature the next time and reduce the roasting time if necessary.
The crackling is too thin.	Increase the temperature or switch on the grill briefly at the end of the roasting time.
The roast looks good but the juices are burnt.	Next time, use a smaller roasting dish and add more liquid if necessary.
The roast looks good but the juices are too clear and watery.	Next time, use a larger roasting dish and add less liquid if necessary.
The meat gets burned during braising.	The roasting dish and lid must fit together well and close properly.  Reduce the temperature and add more liquid when braising if necessary.

#### **Fish**

Your appliance offers you a range of heating types for preparing fish. You can find the ideal settings for many dishes in the settings tables.

The whole fish does not have to be turned. Place the whole fish into the cooking compartment in swimming position with the dorsal fin facing upwards. Placing half a potato or a small oven-proof container in the stomach cavity of the fish will provide stability.

You can tell when the fish is cooked because the dorsal fin can be removed easily.

#### Roasting and grilling on the wire rack

Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door.

Pour up to ½ litres of water into the universal pan, depending on the size and type of the fish. Any dripping liquid will be caught. Less smoke is generated and the cooking compartment stays cleaner.

Keep the appliance door closed when using the grill. Never grill with the appliance door open.

When grilling, try wherever possible to use pieces of food which are of a similar thickness and weight. This will allow them to brown evenly and remain succulent and juicy. Place the food to be grilled directly onto the wire rack.

Use tongs to turn the pieces of food you are grilling. If you pierce the fish with a fork, the juices will run out and it will become dry.

# **Notes**

- The grill element switches itself continuously on and off; this is normal. The set temperature determines how frequently this occurs.
- Smoke may be produced when grilling.

#### Roasting and stewing in cookware

Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The fish cooks more slowly and browns less. Use a higher temperature and/or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

#### **Uncovered cookware**

To cook a whole fish, it is best to use a deep roasting tin/dish. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

#### Covered cookware

When cooking with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

When stewing, add two to three tablespoons of liquid and a little lemon juice or vinegar into the cookware.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

Fish can also become crispy in a covered roasting dish. Here, use a roasting dish with a glass lid and set a higher temperature.

#### Recommended setting values

You can find the ideal heating type for your fish dishes in the table. The temperature and cooking time depend on the amount, composition and temperature of the food. Settings ranges are indicated for this reason. Try using lower setting values first. You can use a higher setting next time if necessary.

The setting values are based on the assumption that chilled fish is placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated cooking times by several minutes.

In the table, you can find information for fish with default values for the weight. If you want to cook a heavier fish, you should definitely use the lower temperature. If cooking several fish, you should use the weight of the heaviest fish as a reference for determining the cooking time. The individual fish should be approximately the same size.

As a general rule: the larger a fish, the lower the cooking temperature and the longer the cooking time.

Turn any fish which is not in swimming position after approx. ½ to ¾ of the indicated time.

**Note:** Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

# Types of heating used:

■ Top/bottom heating

■ ☐ Circo-roasting
■ Full-surface grill

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Fish					
Fish, grilled, whole 300 g, e.g. trout	Wire rack	2	~~~	170-190	20-30
Fish, grilled, whole 1.5 kg, e.g. salmon	Wire rack	2	Ĭ	170-190	30-40
Fish fillets					
Fish fillet, plain, grilled	Wire rack	4	***	220*	15-25
Fish steaks					
Fish steak, 3 cm thick**	Wire rack	4	***	290	10-20
Fish, frozen					
Fish fillet, plain	Cookware, covered	2	Ξ	210-230	20-30
Fish fillet, au gratin	Wire rack	2	~~~	200-220	45-60
Fish fingers (turn during cooking)	Universal pan	3	Ξ	200-220	20-30
* Preheat					
** Slide the universal pan in underneath at	shelf position 2				

# Vegetables and side dishes

Here, you can find information for preparing grilled vegetables, potatoes and frozen potato products.

Remove unused accessories from the cooking compartment. This will allow you to achieve ideal cooking results and save energy.

#### **Shelf positions**

Use the indicated shelf positions.

#### Cooking on one level

Adhere to the specifications in the table.

#### Cooking on two levels

Use CircoTherm. Food on baking trays that are placed in the oven at the same time will not necessarily be ready at the same time.

- Universal pan: Level 3
- Baking tray: Level 1

#### **Accessories**

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

#### Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

#### Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

# Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

# **Recommended setting values**

In the table, you can find the ideal heating types for various dishes. The temperature and cooking time depend on the amount and composition of the food. Setting ranges are indicated for this reason. Try using the lower values at first. A lower temperature results in more even browning. You can use a higher setting next time if necessary.

The setting values apply to dishes placed into a cold cooking compartment. If you preheat the oven, the indicated cooking times will be reduced by several minutes.

If you wish to follow one of your own recipes when cooking, you can use similar dishes in the table as a reference.

Types of heating used:

- & CircoTherm
- <u>&</u> Circotherm intensive

■ Bread baking■ Full-surface grill

Dish	Accessories	Shelf position	Type of heating	Tempera- ture in °C	Cooking time in mins.
Vegetable dishes					
Grilled vegetables	Universal pan	4	***	290	10-15
Potatoes					
Baked potatoes, halved	Universal pan	3	L	160-180	45-60
Potato products, frozen					
Potato rösti	Universal pan	3	<u></u>	200-220	25-35
Potato pockets, filled	Universal pan	3	<u></u>	190-210	20-30
Croquettes	Universal pan	3	<u>&amp;</u>	200-220	25-35
Chips	Universal pan	3	<u>&amp;</u>	190-210	25-35
Chips, 2 levels	Universal pan + baking tray	3+1	<u></u>	190-210	30-40

# **Yogurt**

You can make your own yogurt using your appliance.

#### **Making yoghurt**

Remove accessories and shelf supports from the cooking compartment. The cooking compartment must be empty. Do not open the appliance door while the appliance is in operation.

1. Heat 1 litre of milk (3.5% fat) to 90 °C on the hob and then leave it to cool down to 40 °C.

It is sufficient to heat UHT milk to 40 °C.

- 2. Stir in 150 g (chilled) yoghurt.
- 3. Pour into cups or small jars and cover with cling film.
- Place the cups or jars onto the cooking compartment floor and use the settings indicated in the table.
- **5.** After making the yoghurt, leave it to cool in the refrigerator.

Type of heating used:

■ ⊖ Dough proving

Dish	Accessories	Shelf position	Type of heating	Tempera- ture in °C	Cooking time in hours
Yogurt	Individual moulds	Cooking compart- ment floor		35-40	8-9

# **Eco heating functions**

CircoTherm eco and Top/bottom heating eco are intelligent heating functions that allow you to gently cook meat, fish and baked items. The appliance optimally controls the supply of energy to the cooking compartment. The food is cooked in phases using residual heat. This means that it remains more succulent and browns less. Depending on the method of preparation and the type of food, it is possible to save energy. If you open the appliance door before the food has finished cooking or if you preheat the appliance, you may not be able to achieve this result.

Only use genuine accessories for your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance. Remove any accessories that are not being used from the cooking compartment.

Place the food into the empty cooking compartment before the oven is heated up. For CircoTherm eco, select a temperature of between 125 and 200 °C, and for Top/bottom heating eco, select a temperature of

between 150 and 250  $^{\circ}\text{C}.$  Always keep the appliance door closed when cooking. Only cook on one level when using this function.

The CircoTherm eco heating function is used to measure both the energy consumption in air recirculation mode and the energy efficiency class. The Top/bottom heating eco heating function is used to measure the energy consumption in the conventional mode.

The CircoTherm eco heating type is used to determine the energy efficiency class.

#### Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

#### Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack

# Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

### Baking tins and cookware

Dark- coloured metal baking tins are most suitable. These allow you to make energy savings of up to 35 per cent.

Cookware made from stainless steel or aluminium reflects heat like a mirror. Non-reflective cookware made from enamel, heat-resistant glass or coated, diecast aluminium is more suitable.

Tinplate baking tins, ceramic dishes or glass dishes prolong baking time, and the cake will not brown so evenly.

#### Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

#### Recommended setting values

Here, you can find specifications for the various dishes with CircoTherm Eco and Top/bottom heating Eco. The temperature and baking time depend on the consistency and amount of the dough. Settings ranges are indicated for this reason. Try with the lower values first. A lower temperature results in more even browning. You can increase the temperature next time if necessary.

**Note:** Baking times can not be reduced by using higher temperatures. Cakes or baked items would only be cooked on the outside, but would not be fully cooked in the middle.

Types of heating used:

- □ CircoTherm eco
- Top/bottom heating Eco

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Cakes in tins					
Sponge cake in a tin	Ring tin/cake tin	2	eco L	140-160	60-80
Sponge flan base	Flan base tin	2	eco	150-170	20-30
Sponge base, 2 eggs	Flan base tin	2	eco	150-170	20-30
Sponge flan, 3 eggs	Springform cake tin, diameter 26 cm	2	eco	160-170	30-45
Sponge flan, 6 eggs	Springform cake tin, diameter 28 cm	2	eco &	150-160	50-60
Bundt yeast cake	Ring cake tin	2	eco	150-170	50-70
Cakes on baking trays					
Sponge cake with dry topping	Baking tray	3	eco	150-170	25-40
Shortcrust tart with dry topping	Baking tray	3	eco	170-180	25-35
Swiss roll	Baking tray	3	eco	180-190	15-20
Plaited loaf, savarin	Baking tray	3	eco	160-170	25-35
Yeast cake with dry topping	Baking tray	3	eco	160-180	15-20
Small baked items					
Muffins	Muffin tray	2	eco	160-180	15-25
Small cakes	Baking tray	3	eco	150-160	25-35
Puff pastry	Baking tray	3	eco &	170-190	20-35
Choux pastry	Baking tray	3	eco &	190-200	40-50
Biscuits	Baking tray	3	eco L	140-160	15-30
Whirls	Baking tray	3	eco	140-150	25-35
Small yeast cakes	Baking tray	3	eco	160-180	25-35
Bread and bread rolls					
Multigrain bread, 1.5 kg	Cake tin	2	eco	200-210	35-45
Flatbread	Universal pan	3	eco	250-275	15-20
Bread rolls, sweet, fresh	Baking tray	3	eco	170-190	15-20
Bread rolls, fresh	Baking tray	3	eco	180-200	20-30
Meat					
Joint of pork without rind, e.g. neck, 1.5 kg	Cookware, uncovered	2	eco	180-190	120-140
Pot-roasted beef, 1.5 kg	Cookware, covered	2	eco	200-220	140-160
Joint of veal, 1.5 kg	Cookware, uncovered	2	eco	170-180	110-130

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Fish					
Fish, braised, whole 300 g, e.g. trout	Cookware, covered	2	eco	190-210	25-35
Fish, braised, whole 1.5 kg, e.g. salmon	Cookware, covered	2	eco	190-210	45-55
Fish fillet, plain, braised	Cookware, covered	2	eco	190-210	15-25

# Acrylamide in foodstuffs

Acrylamide is mainly produced in grain and potato products prepared at high temperatures, such as potato

crisps, chips, sliced bread, bread rolls, bread or fine baked goods (biscuits, gingerbread, spiced biscuit).

Tips for keeping acrylamic	de to a minimum
General	<ul> <li>Keep cooking times as short as possible.</li> <li>Cook food until it is golden brown, but not too dark.</li> <li>Large, thick pieces of food contain less acrylamide.</li> </ul>
Baking	With top/bottom heating at max. 200 °C. With hot air at max. 180 °C.
Biscuits	With top/bottom heating at max. 190 °C. With hot air at max. 170 °C. Egg or egg yolk reduces the production of acrylamide.
Oven chips	Spread out a single layer evenly on the baking tray. Cook at least 400 g at once on a baking tray so that the chips do not dry out.

# Slow cook

Slow cooking is a technique for cooking food over a long period at low temperatures. For this reason, it is also called "low-temperature cooking".

Slow cooking is ideal for all prime cuts (e.g. tender portions of beef, veal, pork, lamb or poultry) which are to be cooked "à point". The meat will remain succulent and tender.

The benefit of this cooking method is that it allows lots of scope for menu planning because slow-cooked meat is easy to keep warm. You do not have to turn the meat when cooking. Keep the appliance door closed in order to maintain an even cooking climate.

Only use fresh, clean and hygienic meat without bones. Carefully remove sinews and fat from around the edge. Fat develops a strong, distinct flavour during slow cooking. You can also use seasoned or marinated meat. Do not use defrosted meat.

Meat can be carved immediately following slow cooking. No standing time is required. Due to the special cooking method, the meat looks pink, but is not raw or undercooked.

**Note:** Delayed-start operation with an end time is not possible for the slow cooking heating type.

#### Cookware

Use shallow cookware, e.g. a glass/porcelain serving dish. Place the cookware into the cooking compartment to preheat it.

Always place the uncovered cookware onto the wire rack at level 2.

You can find additional information in the tips on slow cooking attached to the settings table.

Your appliance features the heating type "Slow cook". Only start operation when the cooking compartment has fully cooled down. Allow the cooking compartment to warm up for approx. 15 minutes with the cookware inside.

Sear the meat on the hotplate at a very high heat and for a sufficiently long time on all sides, even on the ends. Place into the preheated cookware right away. Place the cookware containing the meat into the cooking compartment once again and cook slowly.

#### Recommended setting values

The slow cooking temperature and cooking time are dependent on the size, thickness and quality of the meat. Different settings ranges are indicated for this reason.

Type of heating used:

# ■ Some Low temperature cooking

Dish	Cookware	Shelf posi- tion	Heating function	Searing time in mins	Tempera- ture in °C	Cooking time in mins
Poultry						
Duck breast, medium rare, 300 g each	Cookware, uncovered	2	8	6-8	90*	45-60
Chicken breast fillet, 200 g each, well done	Cookware, uncovered	2	8	4	120*	45-60
Turkey breast, boned, 1 kg, well done	Cookware, uncovered	2	<u>8</u>	6-8	120*	110-130
Pork						
Pork tenderloin steak, 5-6 cm thick, 1.5 kg	Cookware, uncovered	2	8	6-8	80*	130-180
Fillet of pork, whole	Cookware, uncovered	2	8	4-6	80*	45-70
Beef						
Joint of beef (rump), 6-7 cm thick, 1.5 kg	Cookware, uncovered	2	8	6-8	100*	150-180
Fillet of beef, 1 kg	Cookware, uncovered	2	8	4-6	80*	90-120
Sirloin, 5-6 cm thick	Cookware, uncovered	2	8	6-8	80*	120-180
Beef medallions/rump steak, 4 cm thick	Cookware, uncovered	2	8	4	80*	30-60
Veal						
Joint of veal, 4-5 cm thick, 1.5 kg	Cookware, uncovered	2	<b>©</b>	6-8	80*	80-140
Joint of veal, 7-10 cm thick, 1.5 kg	Cookware, uncovered	2	8	6-8	80*	140-200
Fillet of veal, whole, 800 g	Cookware, uncovered	2	8	4-6	80*	70-120
Veal medallions, 4 cm thick	Cookware, uncovered	2	8	4	80*	30-50
Lamb						
Saddle of lamb, boneless, 200 g each	Cookware, uncovered	2	8	4	80*	30-45
Leg of lamb, boned, medium, 1 kg, tied	Cookware, uncovered	2	8	6-8	95*	120-180
* Preheat						

#### Tips for slow cooking

Slow-cooking duck breast.	Place the cold duck breast into a pan and fry the skin side first. After slow cooking, grill for 3 to 5 minutes until crispy.
The slow-cooked meat is not as hot as conventionally roasted meat.	So that the roasted meat does not cool so quickly, warm the plates and serve the sauces very hot.

# **Drying**

You can achieve outstanding drying results with CircoTherm. With this type of preserving, flavourings are concentrated by the dehydration.

Only use unblemished fruit, vegetables and herbs and wash them thoroughly. Line the wire rack with greaseproof paper or parchment paper. Drain the excess water from the fruit and dry it.

If necessary, cut it into equal chunks or thin slices. Place unpeeled fruit onto the dish with the sliced surfaces facing upwards. Ensure that neither fruit nor mushrooms overlap on the wire rack.

Grate vegetables and then blanch them. Allow the blanched vegetables to drain off and distribute them evenly on the wire rack.

Dry herbs on the stem. Position the herbs evenly and slightly heaped on the wire rack.

Use the following shelf positions for drying:

- 1 wire rack: Level 3
- 2 wire racks: Level 3+1

Turn very juicy fruit and vegetables several times. After drying, remove the dried products from the paper immediately.

#### Recommended setting values

In the table, you can find settings for drying various foodstuffs. The temperature and cooking time are dependent on the type, moisture, ripeness and thickness of the food to be dried. The longer you leave the food to be dried, the better it will be preserved. The thinner the slices are, the quicker the drying process will be and the more aromatic the dried food will remain. Setting ranges are indicated for this reason.

If you wish to dry additional foodstuffs, you should use similar foodstuffs in the table as a reference.

#### Type of heating used:

#### ■ & CircoTherm

Fruit, vegetables and herbs	Accessories	Type of heating	Tempera- ture in °C	Cooking time in hours
Pomes (apple rings, 3 mm thick, 200 g per wire rack)	1-2 wire racks	S	80	5-9
Stone fruit (plums)	1-2 wire racks	S	80	8-10
Root vegetables (carrots), grated, blanched	1-2 wire racks	S	80	5-8
Sliced mushrooms	1-2 wire racks	S	60	6-9
Herbs, washed	1-2 wire racks	L	60	2-6

# **Preserving**

You can preserve fruit and vegetables using your appliance.

# **⚠** Warning – Risk of injury!

If the food is preserved incorrectly, the preserving jars may burst. Follow the instructions for preserving.

#### **Jars**

Use only clean and undamaged preserving jars. Only use heat-resistant, clean and undamaged rubber rings. Check clips and clamps in advance.

For each preserving process, only use preserving jars that are the same size and contain the same food. In the cooking compartment, you can preserve the contents of a maximum of six ½, 1 or 1½-litre preserving jars at the same time. Do not use jars that are larger or taller than this. The lids could rupture.

Preserving jars must not touch one another in the cooking compartment during the preserving process.

#### Preparing fruit and vegetables

Only use fruit and vegetables that are in good condition. Wash them thoroughly.

Peel, core and chop fruit and vegetables appropriate to their type and fill the preserving jars with them up to approx. 2 cm below the rim.

#### Fruit

Fill the preserving jars with the fruit along with a hot, skimmed sugar solution (approx. 400 ml for a 1-litre jar). For one litre of water:

- Approx. 250 g sugar for sweet fruit
- Approx. 500 g sugar for sour fruit

### Vegetables

Fill the jars with the vegetables along with hot, boiled water.

Wipe the rims of the jars, as they must be clean. Place a damp rubber ring and a lid on each jar. Seal the jars with clamps. Place the jars into the universal pan so that they do not touch each other. Pour 500 ml hot water (approx. 80 °C) into the universal pan. Use the settings indicated in the table.

#### **Ending the preserving process**

#### Fruit

After a short while, small bubbles will form at short intervals. Switch off the appliance once all preserving jars are bubbling. Remove the jars from the cooking compartment after the indicated cooling time.

#### Vegetables

After a short while, small bubbles will form at short intervals. As soon as all preserving jars are bubbling, reduce the temperature to 120 °C and allow the jars to continue to bubble in the closed cooking compartment as indicated in the table. After this time has elapsed, switch off the appliance and make use of the residual heat for several minutes as indicated in the table.

After preserving, remove the jars from the cooking compartment and place them onto a clean cloth. Do not place these hot jars onto a cold or damp surface, as they may crack. Cover the preserving jars to protect them from draughts. Only remove the clamps once the jars are cold.

#### Recommended setting values

The indicated times in the settings table are average values for preserving fruit and vegetables. They may be influenced by room temperature, the number of jars, quantity, heat and quality of the jar contents. The specifications are based on 1-litre round jars. Before you switch off the appliance or change the cooking mode, check whether the contents of the jars are bubbling as they should. The bubbling process starts after approx. 30-60 minutes.

#### Type of heating used:

# ■ & CircoTherm

Preserving	Cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Vegetables, e.g. carrots	etables, e.g. carrots 1-litre preserving jars 1 &		160-170	Before it starts bubbling:30-40	
				120	When it starts to bubble: 30-40
				-	Residual heat: 30
Vegetables, e.g. cucumbers	getables, e.g. cucumbers 1-litre preserving jars 1 &		L	160-170	Before it starts bubbling: 30-40
				-	Residual heat: 30
Stone fruit, e.g. cherries, damsons	1-litre preserving jars	1	L	160-170	Before it starts bubbling:30-40
				-	Residual heat:35
Pomes, e.g. apples, strawberries 1-litre preserving jars 1	L	160-170	Before it starts bubbling:30-40		
				-	Residual heat: 25

# Allowing the dough to prove at dough proving setting

Yeast dough will prove considerably more quickly using the "Dough proving" heating type than at room temperature and does not dry out. Only start operation when the cooking compartment has fully cooled down.

Always allow yeast dough to prove twice. Observe the specifications in the settings tables for the 1st and 2nd proving processes (dough fermentation and final fermentation).

#### **Dough fermentation**

Pour 200 ml water onto the cooking compartment floor for the dough fermentation.

#### Caution!

# Surface damage

- Never pour water into the hot cooking compartment.
   The temperature change can cause damage to the enamel.
- Do not use distilled water. Use tap water only.

Place the dough into a heat-resistant bowl and place it onto the wire rack. Use the settings indicated in the table.

Do not open the appliance door during the proving process, as moisture will escape. Do not cover the dough.

Condensation builds during operation which steams up the door pane. Wipe out the cooking compartment after dough proving. Loosen any limescale with a little vinegar and wipe with clean water.

# **Final fermentation**

Place your baked item into the oven at the shelf position indicated in the table.

If you want to preheat the oven, the final fermentation takes place outside the appliance in a warm place.

#### **Recommended setting values**

The temperature and proving time are dependent on the type and quantity of the ingredients. The values in the table are therefore only meant to be average values.

Type of heating used:

■ ⊖ Dough proving

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Step	Tempera- ture in °C	Cooking time in mins.
Yeast dough, light	Bowl	2		Dough fer- mentation	35-40	25-30
	Baking tray	2		Final fermen- tation	35-40	10-20
Yeast dough, heavy and rich	Bowl	2		Dough fer- mentation	35-40	20-40
	Baking tray	2		Final fermen- tation	35-40	15-25

# **Defrosting**

Use heating type "CircoTherm" to defrost frozen fruit, vegetables and baked items. Poultry, meat and fish should ideally be defrosted in the refrigerator.

Use the following shelf positions when defrosting:

1 wire rack: Level 22 wire racks: Level 3+1

#### Recommended setting values

The times in the table are average values. They are dependent on the quality, freezing temperature (-18  $^{\circ}$ C) and composition of the food. Time ranges are indicated. Set the shortest time first and then extend the time if necessary.

**Tip:** Items which were frozen flat or portioned defrost faster than those frozen in a block.

Remove frozen food from the packaging and place it in suitable cookware onto the wire rack.

Stir the food or turn it once or twice in between. Large pieces of food should be turned several times.

Occasionally split the food or remove items which have already defrosted from the cooking compartment.

Leave the defrosted food to rest for another 10 to 30 minutes in the appliance whilst it is switched off, so that the temperature balances out.

Type of heating used:

■ & CircoTherm

Dish	Accessories	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Bread, bread rolls					
Bread & bread rolls general	Baking tray	2	L	50	40-70
Cake					
Cake, moist	Baking tray	2	L	50	70-90
Cake, dry	Baking tray	2	L	60	60-75

# **Keeping warm**

You can keep cooked dishes warm using the top/bottom heating type at 70 °C. This will avoid condensation developing, and means you will not have to wipe out the cooking compartment.

Do not keep cooked dishes warm for longer than two hours. Be aware that some dishes may continue cooking whilst being kept warm. Cover the dishes if necessary.

#### **Test dishes**

These tables have been produced for test institutes to facilitate appliance testing.

As per EN 60350-1.

# **Baking**

Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

Shelf positions for baking on two levels:

 Universal pan: Level 3 Baking tray: Level 1

Baking tins/dishes on the wire rack First wire rack: Level 3

Second wire rack: Level 1

Shelf positions for baking on three levels:
Baking tray: Level 4
Universal pan: Level 3
Baking tray: Level 1

#### Apple pie

Apple pie on one level: place dark-coloured springform cake tins diagonally next to each other.

Apple pie on two levels: position dark-coloured springform cake tins above each other so that they are offset.

Cakes in tinplate springform cake tins: bake on one level with top/bottom heating. Place the springform cake tin onto the universal pan instead of onto the wire rack.

#### Fatless sponge cake

Fatless sponge cake on two levels: vertically stack springform cake tins in an offset manner on the wire racks.

#### Notes

- The setting values apply to dishes placed into a cold cooking compartment.
- Please note the information in the tables about preheating. The setting values are valid without rapid heating-up.
- For baking, use the lower of the indicated temperatures first.

# 

 $\equiv$  Top/bottom heating  $\underline{\&}$  Circotherm intensive

Dish	Accessory	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Baking					
Shortbread	Baking tray	3	Ξ	140-150*	25-40
Shortbread	Baking tray	3	ک	140-150*	25-40
Shortbread, 2 levels	Universal pan + baking tray	3+1	ک	140-150*	30-40
Shortbread, 3 levels	Baking trays + universal pan	4+3+1	ک	130-140*	35-55
Small cakes	Baking tray	3	Ξ	160*	20-30
Small cakes	Baking tray	3	ک	150*	25-35
Small cakes, 2 levels	Universal pan + baking tray	3+1	ک	150*	25-35
Small cakes, 3 levels	Baking trays + universal pan	4+3+1	ک	140*	35-45
Fatless sponge cake	Springform cake tin, diameter 26 cm	2	Ξ	160-170**	25-35
Fatless sponge cake	Springform cake tin, diameter 26 cm	2	ک	160-170**	30-40
Fatless sponge cake, 2 levels	Springform cake tin, diameter 26 cm	3+1	ک	150-170**	30-50
Apple pie	2 x black plate tins, diameter 20 cm	2	<u>&amp;</u>	170-180	60-80
Apple pie	2 x black plate tins, diameter 20 cm	2	Ξ	180-200	60-80
Apple pie, 2 levels	2 x black plate tins, diameter 20 cm	3+1	٨	170-190	70-90

# Grilling

Also slide in the universal pan. The liquid will be caught and the cooking compartment stays cleaner.

Type of heating used:
■ Full-surface grill

Dish	Accessories	Shelf posi- tion		Tempera- ture in °C	Cooking time in mins.
Grilling					
Toasting bread*	Wire rack	4	****	290	4-6
Beefburger, 12 pieces**	Wire rack	4	***	290	25-30
* Do not preheat					
** Turn after 2/3 of the total time					







REGISTER YOUR PRODUCT ONLINE NEFF-HOME.COM

Constructa NEFF Vertriebs-GmbH | Carl-Wery-Straße 34 | 81739 Munich | Germany



9001100445 980126 en