

Table of contents

Intended use	4
Important safety information General information Steam. Meat thermometer Cleaning function.	5 6 6
Causes of damage	7 7
Environmental protection	8
Getting to know your appliance Control panel	9 0 0 1
Accessories	2 3
Before using for the first time	4 4 4
Operating the appliance	5 5 6
Steam Noise VarioSteam – Steam-assisted cooking. Dough proving setting Reheating. Filling the water tank After every steam operation.	7 7 8 8

Time-setting options
Childproof lock
Basic settings22Changing MyProfile.22List of basic settings.22Setting favourites.23
Baking and roasting assistant
Programmes
Meat thermometer
Starting the Sabbath mode
Cleaning agent
Cleaning function30Self-cleaning.30EasyClean.31Descaling.32
Rails
Appliance door

Trouble shooting Fault table Maximum operating time exceeded Cooking compartment bulbs	38 39
Customer service	
Tested for you in our cooking studio. Silicone moulds Cakes and small baked items Bread and rolls. Pizza, quiche and savoury cakes Bakes and soufflés. Poultry Meat Fish Vegetables and side dishes Yogurt Eco heating functions. Acrylamide in foodstuffs. Slow cook Drying.	40 40 44 46 48 51 54 57 58 59
Preserving	61 62 63 64

Additional information on products, accessories, replacement parts and services can be found at **www.neff-international.com** and in the online shop **www.neff-eshop.com**

Intended use

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 2000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 15 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment the right way round.

→ "Accessories" on page 12

Important safety information

General information

▲ Warning – Risk of fire!

- Combustible items stored in the cooking compartment may catch fire. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug it from the mains or switch off the circuit breaker in the fuse box.
- Loose food remnants, fat and meat juices may catch fire. Before using the appliance, remove the worst of the food remnants from the cooking compartment, heating elements and accessories.
- A draught is created when the appliance door is opened. Greaseproof paper may come into contact with the heating element and catch fire. Do not place greaseproof paper loosely over accessories during preheating. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. Greaseproof paper must not protrude over the accessories.

⚠ Warning – Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.

Marning − Risk of scalding!

- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.
- Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

⚠ Warning – Risk of injury!

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.

⚠ Warning – Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the aftersales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

⚠ Warning – Hazard due to magnetism!

Permanent magnets are used in the control panel or in the control elements. They may affect electronic implants, e.g. heart pacemakers or insulin pumps. Wearers of electronic implants must stay at least 10 cm away from the control panel.

Steam

- The water in the water tank may become very hot if you continue to operate the appliance. Empty the water tank after every operation with steam.
- Hot steam is generated in the cooking compartment. Do not reach into the cooking compartment during any operation with steam.
- Hot liquid may spill over the sides of the accessory when it is removed from the cooking compartment. Remove hot accessories with care and always wear oven gloves.

Warning – Risk of injury and risk of fire! Flammable liquids can catch fire in the cooking compartment when it is hot (explosion). Do not fill the water tank with any flammable fluids (e.g. alcoholic drinks). Only fill the water tank with water or with the descaling solution that is recommended by us.

Meat thermometer

⚠ Warning – Risk of electric shock!

The insulation of an incompatible meat thermometer may be damaged. Only use the meat thermometer which is recommended for this appliance.

Cleaning function

▲ Warning – Risk of fire!

- Loose food residues, grease and meat juices may catch fire during the cleaning function. Before starting the cleaning function, remove coarse dirt from the cooking compartment and from the accessories.
- The appliance will become very hot on the outside during the cleaning function. Never hang combustible objects, e.g. tea towels, on the door handle. Do not place anything against the front of the appliance. Keep children away from the appliance.
- If the door seal is damaged, a large amount of heat will be generated around the door. Do not scrub or remove the seal. Never operate the appliance if the seal is damaged or missing.

⚠ Warning – Risk of serious damage to health!

The appliance will become very hot during the cleaning function. The non-stick coating on baking trays and tins is destroyed and noxious gases are released. Never clean non-stick baking trays and baking tins using the cleaning function. Only clean enamelled accessories using the cleaning function.

⚠ Warning – Risk of harm to health!

The cleaning function heats up the cooking compartment to a very high temperature so that food remnants left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate the mucous membranes. While the cleaning function is running, keep the kitchen well ventilated. Do not remain in the room for long periods. Keep children and pets away. Follow the instructions even when using the Delayed start function with a delayed end time.

Marning – Risk of burns!

- The cooking compartment becomes extremely hot during the cleaning function. Never open the appliance door. Allow the appliance to cool down. Keep children away from the appliance.
- A The appliance will become very hot on the outside during the cleaning function. Never touch the appliance door. Allow the appliance to cool down. Keep children away from the appliance.

Causes of damage

General information

Caution!

- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor if a temperature of over 50 °C has been set. This will cause heat to accumulate. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Aluminium foil: Aluminium foil in the cooking compartment must not come into contact with the door glass. This could cause permanent discolouration of the door glass.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the enamel.
- Moisture in the cooking compartment: Over an extended period of time, moisture in the cooking compartment may lead to corrosion. Allow the cooking compartment to dry after use. Do not keep moist food in the closed cooking compartment for extended periods of time. Do not store food in the cooking compartment.
- Cooling with the appliance door open: Following operation at high temperatures, only allow the cooking compartment to cool down with the door closed. Do not trap anything in the appliance door. Even if the door is only left open a crack, the front of nearby furniture may become damaged over time. Only leave the cooking compartment to dry with the door open if a lot of moisture was produced whilst the oven was operating.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Extremely dirty seal: If the seal is very dirty, the appliance door will no longer close properly during operation. The fronts of adjacent units could be damaged. Always keep the seal clean.
- Appliance door as a seat, shelf or worktop: Do not sit on the appliance door, or place or hang anything on it. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.

Steam

Caution!

- Baking tins: Ovenware must be heat and steam resistant. Silicone baking tins are not suitable for combined operation with steam.
- Ovenware with areas of rust: Do not use any ovenware which displays areas of rust. Even the smallest spots of rust can lead to corrosion in the cooking compartment.
- Dripping liquids: When steaming with a perforated cooking container, always insert the baking tray, the universal pan or the solid cooking container underneath. Dripping liquid is caught.
- Hot water in the water tank: Hot water can damage the pump. Only fill the water tank with cold water.
- Enamel damage: Do not start any operations when there is water on the cooking compartment floor.
 Before operation, wipe away the water from the cooking compartment floor.
- Descaling solution: Do not allow any descaling solution to come into contact with the control panel or other surfaces on the appliance. This damages the surfaces. If this does happen, remove the descaling solution immediately with water.
- Cleaning the water tank: Do not clean the water tank in the dishwasher. Otherwise, the water tank will be damaged. Clean the water tank with a soft cloth and standard washing-up liquid.

Environmental protection

Your new appliance is particularly energy-efficient. Here you can find tips on how to save even more energy when using the appliance, and how to dispose of your appliance properly.


Saving energy


- Only preheat the appliance if this is specified in the recipe or in the tables in the operating instructions.
- Leave frozen food to defrost before placing it in the cooking compartment.





 Use baking tins that are dark-coloured, painted black or have an enamel coating. These absorb the heat particularly well.





 Remove any unnecessary accessories from the cooking compartment.






• Open the appliance door as infrequently as possible when the appliance is in use.





It is best to bake several cakes one after the other. The cooking compartment stays warm. This reduces the baking time for the second cake. You can place two cake tins next to each other in the cooking compartment.





 For longer cooking times, you can switch the appliance off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.


Getting to know your appliance

In this chapter, we will explain the indicators and controls. You will also find out about the various functions of your appliance.

Note: Depending on the appliance model, individual details and colours may differ.

Control panel

In the control panel, set your appliance's different functions using the FullTouch TFT display. The current settings are shown on the FullTouch TFT display.



1 FullTouch TFT display
2 Touch buttons

Controls

Use the controls to set your appliance simply and directly.

Touch buttons

There are sensors under the touch buttons. Touch on the corresponding touch button to select a function.

Touch	button	Use
1	on/off	Switching the appliance on or off → "Switching the appliance on and off" on page 15
>> >	Steam-assisted cooking	Switching on steam-assisted cooking → "VarioSteam - Steam-assisted cooking" on page 17
Θ	Time-setting options	Setting the timer, cooking time, or "Ready at" start delay → "Time- setting options" on page 20
	Childproof lock	Activating or deactivating the child- proof lock → "Childproof lock" on page 21
	Main menu	Selecting operating modes and settings → "Setting and starting the appliance operation" on page 15

& Rapid	Rapid heating	Activating or deactivating rapid heating → "Heating up the appliance quickly" on page 16
		Activating or deactivating Power- Boost → "Heating up the appliance quickly" on page 16
í	Information	Displaying further information Displaying the current temperature → "Setting and starting the appliance operation" on page 15
日	Open cover	Filling or emptying the water tank → "Filling the water tank" on page 18
DII	Start/Stop	Starting or stopping the operation → "Setting and starting the appliance operation" on page 15

FullTouch TFT display

With the FullTouch TFT display, you can navigate through the lines and select settings.

To adjust a setting, touch the appropriate point on the display using your finger. The area is displayed more brightly. With your finger touching this area of the display, swipe to the left or right until the required setting is displayed larger.

Direction	Use
Navigate to the left	On the display, use your finger to swipe to the right
Navigate to the right	On the display, use your finger to swipe to the left

Direction	Use
Navigate upwards	Touch the top line of the display
Navigate downwards	Touch the bottom line of the display

Main menu

Touch the $\ensuremath{\square}$ touch button to access the main menu.

Menu	Use
	Types of heating Selecting the required type of heating and temperature for your dish → "Switching the appliance on and off" on page 15
	Baking and roasting assistant Recommended settings for baking and roasting → "Baking and roasting assistant" on page 23

PX	Steam programmes Preparing dishes with steam → "Programmes" on page 24
©# ○	MyProfile Individually adjusting the appliance settings → "Basic settings" on page 22
*	Descale
\$ \$\$	Drying Drying the cooking compartment after a steam operation "After every steam operation" on page 19
<u> </u>	EasyClean Cleaning light soiling from the cooking compartment → "Cleaning function" on page 30
***	Pyrolytic self-cleaning Clean the cooking compartment. → "Cleaning function" on page 30

Menu for the types of heating

Your appliance has different types of heating. After switching on the appliance, you are taken directly to the menu for the types of heating.

Type of	heating	Temperature	Use
S	CircoTherm *	40 - 200 °C	For baking and cooking on one or more levels. The fan distributes the heat from the ring heating element in the back panel evenly around the cooking compartment.
=	Top/bottom heating *	50 - 275 °C	For traditional baking and roasting on one level. Especially suitable for cakes with moist toppings. Heat is emitted evenly from the top and bottom.
Ž	Circo-roasting *	50 - 250 °C	For roasting poultry, whole fish and larger pieces of meat. The grill element and the fan switch on and off alternately. The fan circulates the hot air around the food.
<u>\$</u>	Circotherm intensive	50 - 275 °C	For preparing pizza and dishes which require a lot of heat from underneath. The bottom heating element and the ring heating element in the back panel heat up.
<u></u>	Bread-baking *	180 - 240 °C	For baking bread, bread rolls and baked items that require high temperatures.
****	Full-surface grill	50 - 290 °C	For grilling flat items, such as steaks or sausages, for making toast, and for au gratin dishes. The whole area below the grill element becomes hot.
***	Centre-area grill	50 - 290 °C	For grilling small amounts of steaks or sausages, for making toast, and for au gratin dishes. The centre area under the grill heating element becomes hot.
_	Bottom heat	50-250°C	For cooking in a bain marie and for the final baking stage. The heat is emitted from below.
8	Low temperature cooking	70 - 120 °C	For gentle and slow cooking of seared, tender pieces of meat in ovenware without a lid. The heat is emitted evenly from the top and bottom at low temperatures.
	Dough proving **	2 levels	For leaving yeast dough and sourdough to prove and for culturing yogurt. Dough will prove more quickly than at room temperature. The surface of the dough does not dry out.
*	Defrost setting	30 - 60 °C	For gently defrosting frozen food.

\equiv	Plate warming	30-70 °C	For preheating ovenware.
\cong	Keep warm *	60 - 100 °C	For keeping cooked food warm.
eco	Top/bottom heating eco	50-275 °C	For gently cooking selected types of food. Heat is emitted from above and below. This heating function is most effective between 150 and 250 °C. This heating function is used to measure the energy consumption in the conventional mode.
eco L	CircoTherm eco	40-200 °C	For gently cooking selected types of food on one level without preheating. The fan distributes the heat from the ring-shaped heating element in the back panel around the cooking compartment. This heating function is most effective between 125 and 200 °C. This heating function is used to measure both the energy consumption in air recirculation mode and the energy efficiency class.
<u></u>	Reheat **	80 - 180 °C	For gently reheating food or for crisping up pastries.

- Possible to use steam for this type of heating (operation only possible when the water tank is full)
- ** Type of steam heating (operation only possible when the water tank is full

Cooking compartment functions

The functions in the cooking compartment make your appliance easier to use. This, for example, enables the cooking compartment to be well lit and a cooling fan to prevent the appliance from overheating.

Opening the appliance door

If you open the appliance door during an operation, the operation is paused. The operation continues to run when you close the door.

Note: For some types of heating, the operation continues to run even when the appliance door is open.

Interior lighting

If you open the appliance door, the interior lighting switches on. If the door remains open for longer than around 15 minutes, the lighting switches off again.

For most operating modes, the interior lighting switches on as soon as the operation is started. When the operation has finished, the lighting switches off.

Note: You can set the interior lighting not to come on during the operation in the basic settings. \rightarrow "Basic settings" on page 22

Cooling fan

The cooling fan switches on and off as required. The hot air escapes above the door.

Caution!

Do not cover the ventilation slots. Otherwise, the appliance may overheat.


So that the cooking compartment cools down more quickly after the operation, the cooling fan continues to run for a certain period afterwards.

Note: You can change how long the cooling fan continues to run for in the basic settings. \rightarrow "Basic settings" on page 22

Water tank

The appliance is fitted with a water tank. The water tank is behind the panel. For operations with steam, fill the water tank with water. \rightarrow "Steam" on page 17






- 1 Tank cover 2 Filling opening
- 3 Handle for removing and inserting the water tank

Accessories

Your appliance is accompanied by a range of accessories. Here, you can find an overview of the accessories included and information on how to use them correctly.

Accessories included

Your appliance is equipped with the following accessories:



Only use genuine accessories. They are specially adapted for your appliance.

You can buy accessories from the after-sales service, from specialist retailers or online.

Note: The accessories may become deformed when they become hot. This does not affect their function. Once they cool down again, they regain their original shape.


Inserting accessories

The cooking compartment has four shelf positions. The shelf positions are counted from the bottom up.

In some appliances, the top shelf position in the cooking compartment features a grill symbol.

Warning – Risk of burns!


The telescopic shelves become hot when the appliance is in use. Take special care not to get burnt when they are pulled out.




The accessories can be pulled out approximately halfway without tipping. You can use the pull-out rails to pull the accessories out further.


Ensure that the accessory is placed under the lug a on the pull-out rail.

Example in the picture: Universal pan



Accessories on the telescopic shelf can be pulled out as far as the notch **b** (fig. **1**). Hold the accessory on both sides in the area marked **c** and remove it (fig. **2**).






- Ensure that you always insert the accessories into the cooking compartment the right way round.
- Always insert the accessories fully into the cooking compartment so that they do not touch the appliance door.


Locking function

The accessories can be pulled out approximately halfway until they lock in place. The locking function prevents the accessories from tilting when they are pulled out. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

When inserting the wire rack, ensure that the lug **a** is facing downwards.




When inserting baking trays, ensure that the lug ${\bf b}$ is at the rear and is facing downwards. The sloping edge of the accessory ${\bf c}$ must be facing towards the appliance door.



Combining accessories

You can insert the wire rack and the universal pan at the same time to catch drops of liquid.

When inserting the wire rack, ensure that both spacers **a** are at the rear edge. When the universal pan is inserted, the wire rack is on top of the upper guide rod of the shelf position.



Optional accessories

You can purchase optional accessories from the aftersales service and specialist retailers, or on the Internet. You will find a comprehensive range of products for your appliance in our brochures and on the Internet.

Both availability and whether it is possible to order online differ between countries. Please see your sales documents for more details.

Note: Not all optional accessories are suitable for every appliance. When purchasing, please always quote the exact designation (E no.) of your appliance.

→ "Customer service" on page 40

Accessories

Baking and roasting shelf

Baking tray, suitable for pyrolytic cleaning

Universal pan, suitable for pyrolytic cleaning

Extra-deep pan, suitable for pyrolytic cleaning

Steaming set for ovens

Profi pan, suitable for pyrolytic cleaning

Lid for the Profi pan

Pizza tray

Grill tray, suitable for pyrolytic cleaning

Bread-baking stone, suitable for pyrolytic cleaning

Glass roasting dish, 5.1 litres

Glass pan

ComfortFlex shelf (1 level) + frame*

ComfortFlex rail (1 level)*

3 x fully extendable pull-out rack*

*Accessory does not fit in every appliance, quote the E no. when ordering

Before using for the first time

Before you can use your new appliance, you must make some settings. You must also clean the cooking compartment and accessories.

Before using for the first time

Before using the appliance for the first time, ask your water supplier about the hardness of your tap water.

To ensure that the appliance can reliably remind you to descale it when required, you must set your water hardness range correctly.

Caution!

- The appliance may become damaged due to the use of unsuitable liquids.
 - Do not use distilled water, highly chlorinated tap water (>40 mg/l) or other liquids.
 - Only use cold, fresh tap water, softened water or non-carbonated mineral water.
- Malfunctions may occur when using filtered or demineralised water.
 - The appliance may request that you top up the water tank even though it may be full, or operation with steam is cancelled after approx. two minutes. If required, mix filtered or demineralised water with the bottled non-carbonated mineral water with a ratio of one to one.

Notes

- If your water is very hard, we recommend that you use softened water.
- If you only use softened water, you can set the water hardness range to "softened".
- If you use mineral water, set the water hardness range to "4 very hard".
- If you use mineral water, you must only use noncarbonated mineral water.

Water hardness range	Setting
0	0 softened
1 (up to 1.3 mmol/l)	1 soft
2 (1.3 - 2.5 mmol/l)	2 medium
3 (2.5 - 3.8 mmol/l)	3 hard
4 (above 3.8 mmol/l)	4 very hard

Initial use

As soon as the appliance is connected to the power supply, the first setting "Language" appears on the display.

Setting the language

- **1.** Touch the bottom line.
- 2. Swipe to the left or right to select the required language.
- 3. Touch the top line.

Setting the time

- 1. Touch "Clock".
- 2. Touch the bottom line.
- **3.** Swipe to the left or right to select the current hour.
- 4. Touch "Minutes".
- **5.** Swipe to the left or right to select the current minute.
- **6.** Touch the \subseteq symbol to apply the setting.

Setting the date

- 1. Touch "Date".
- 2. Touch the bottom line.
- 3. Swipe to the left or right to select the current day.
- 4. Touch "Month".
- 5. Swipe to the left or right to select the current month.
- 6. Touch "Year".
- 7. Swipe to the left or right to select the current year.
- **8.** Touch the \square symbol to apply the setting.

Setting the water hardness

- 1. Touch "Water hardness".
- 2. Touch the bottom line.
- **3.** Swipe to the left or right to select the appropriate water hardness.
- **4.** Touch the ✓ symbol to complete the initial use. The initial use is complete.

Notes

- You can change these settings at any time in the basic settings. → "Basic settings" on page 22
- After connecting the appliance to the power or following a power cut, the settings for initial use are shown in the display.

Cleaning the cooking compartment

To eliminate the new-appliance smell, heat up the cooking compartment without anything in it and with the oven door closed.

- **1.** Remove the accessories from the cooking compartment.
- 2. Remove any leftover packaging, such as polystyrene pellets, from the cooking compartment.
- 3. Before heating the appliance, wipe the smooth surfaces in the cooking compartment with a soft, damp cloth.
- **4.** Use the ① touch button to switch on the appliance.
- Fill the water tank. → "Filling the water tank" on page 18

on page 17

Set the specified type of heating, temperature and steam assistance, then start the appliance.
 → "VarioSteam - Steam-assisted cooking"

Settings		
Type of heating	CircoTherm hot air ∠ with steam assistance ĕ (high)	
Temperature	Maximum	
Cooking time	1 hour	

- Keep the kitchen ventilated while the appliance is heating.
- **8.** Use the ① touch button to switch off the appliance once the specified time has elapsed.
- 9. Wait for the cooking compartment to cool down.

- 10. Clean the smooth surfaces with soapy water and a dish cloth.
- 11. Empty the water tank and dry the cooking compartment. → "After every steam operation" on page 19

Cleaning the accessories

Clean the accessories thoroughly using soapy water and a dish cloth or soft brush.

Operating the appliance

You have already learnt about the controls and how they work. Now we will explain how to set your appliance. You will learn about what happens when you switch the appliance on and off, and how to select the operating mode.

Switching the appliance on and off

To switch the appliance on or off, touch the ① touch button.

After the appliance has switched off, the display shows whether the residual heat in the cooking compartment is high or low.

Display	Temperature
Residual heat high	above 120 °C
Residual heat low	between 60 °C und 120 °C

Notes


- Certain indicators and instructions (e.g. about residual heat in the cooking compartment) remain visible on the display even when the appliance is switched off.
- After the appliance has completed an operation, you will hear the cooling fan continuing to run until the cooking compartment is cooled as much as possible.
- Switch off your appliance when you do not need to use it. If no settings are made for a long time, the appliance switches off automatically.

Setting and starting the appliance operation

Example: & CircoTherm hot air at 170 °C

1. Touch the ① touch button to switch on the appliance.

You go directly to the 🗇 Types of heating menu.



- 2. Swipe to the left or right to select the type of heating.
- 3. Touch the bottom line.
- **4.** Swipe to the left or right to select the temperature.



5. Touch the \| touch button to start the appliance operation.

The heat-up indicator bar and the run time appear in the display.

Note: If you want to go directly to the $\widehat{\ }$ main menu when you switch on the appliance, you can find instructions on how to do this in the Basic settings chapter under "Operation after switching on".

Default values

The appliance suggests a temperature or setting for each type of heating. You can accept this value or change it in the appropriate area.

Heating bar

As soon as a type of heating has started, the heating bar appears on the display. The heating bar shows the temperature increase in the cooking compartment.

Run time

When a type of heating has been started, the run time is displayed. The run time counts upwards during the operation. You can therefore check how long the operation has already been running.

Displaying the current temperature

To show the current temperature on the display, press the $\ensuremath{\mathring{\mathbb{I}}}$ touch button.

The current temperature is shown briefly only when heating up.

Further information

If the $\mathring{\mbox{\it l}}$ touch button lights up, information can be displayed. Touch the $\mathring{\mbox{\it l}}$ touch button to do this. The information is displayed for a few seconds.

Changing or cancelling the appliance operation

Changing the appliance operation

- 1. Use the || button to stop the operation.
- 2. Tap the line for the setting that should be changed.
- 3. Swipe to the left or right to change the setting.
- Use the | | | | | touch button to start the changed operation.

Notes

- The cooling fan may continue to run while an operation is interrupted.
- After a temperature change, the paused running time continues to count. After a change in the type of heating, the running time starts again from zero.

Cancelling the appliance operation

Press and hold the || touch button until the appliance operation is cancelled.

Note: Operating modes such as the cleaning function cannot be cancelled.

Heating up the appliance quickly

You can use the "Rapid heat-up" and "PowerBoost" functions to reduce the preheat time. Whether the appliance is preheated with the "Rapid heat-up" function or the "PowerBoost" function depends on the type of heating that has been set. With the "PowerBoost" function, unlike with the "Rapid heat-up" function, you can place your food into the cold cooking compartment even before preheating has begun. Only cook on one level when using the "PowerBoost" function.

Function	Type of heating	Place the food in the cooking compartment	
Rapid heat-up	Top/bottom heating =	after preheating	
PowerBoost*	CircoTherm hot air 👃	before preheating	
	Bread-baking setting <u></u>		
* Do not use more than one level for cooking			

Notes

- If the \(\begin{aligned}
 \exists touch button is lit, the "Rapid heat-up" or "PowerBoost" function can be activated.
- To deactivate the "Rapid heat-up" or "PowerBoost" function before it has finished, touch the 🗟 touch button.

Activating the "Rapid heat-up" function

- 2. Touch the \| touch button to start the appliance operation.
- 3. Touch the € touch button to activate the "Rapid heat-up" function.
 - The \$ symbol appears on the display.
- 4. Once the set temperature has been reached, the "Rapid heat-up" function switches itself off automatically. The ¹/₈ symbol disappears from the display. Place the food in the cooking compartment

Activating the "PowerBoost" function

- - **Note:** Set a temperature above 100 °C to allow the appliance to preheat quickly.
- 2. Place the food on a single level in the cooking compartment.
- 3. Touch the I touch button to start the appliance operation.
- Touch the [§] touch button to activate the "PowerBoost" function.

The & symbol appears on the display. Once the set temperature has been reached, the "PowerBoost" function switches itself off automatically. The & symbol disappears from the display.

Steam

With some heating modes, you can prepare food with steam assistance. In addition, the Dough proving and Reheat heating modes are available.

⚠ Warning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

Noise

Pump

You will hear a humming noise while the pump is in operation and after switching it off. This noise is caused by the pump function test. It is a normal operating noise.

Control panel

You will hear a humming or clicking noise when opening the control panel. These noises are caused by the control panel being pushed out. They are normal operating noises.

VarioSteam - Steam-assisted cooking

When you cook with steam assistance, steam is introduced into the cooking compartment at various intervals and with varying degrees of intensity. This gives you a better cooking result.

Your food

- Becomes crispy on the outside
- Develops a shiny surface
- Is succulent and tender on the inside
- Only undergoes a minimum reduction in volume

You set the combination of heating mode and steam intensity that you want. Use the information in the tables to select a suitable heating mode and steam intensity. Alternatively, select a program from the steam programs.

"Tested for you in our cooking studio" on page 40—"Programmes" on page 24

Steam intensity

Different intensity levels are available when adding steam:

- Low
- Medium
- High

Suitable heating modes

You can switch on steam assistance for these heating modes:

- CircoTherm hot air &
- Top/bottom heating =
- Circo-roasting \(\infty \)
- Bread-baking @
- Keeping warm ⊕

Starting

- 1. Touch the ① touch button.
- 2. Fill the water tank.
- **3.** Set the type of heating and temperature.
- 5. On the display, swipe to the left or right to select the steam intensity.
- **6.** Touch the \subseteq symbol to apply the setting.
- 7. Touch the I touch button.

 The appliance starts the operation.

Note: If the water tank runs dry during an operation with steam assistance, a message appears on the display prompting you to fill up the water tank.

Cancelling steam addition

- 2. Touch the set added steam in the bottom line.
- 3. On the display, swipe to the left or right to select "Off"
- **4.** Touch the \square symbol to apply the setting.

Note: The operation continues without adding steam.

Cancelling appliance operation

Press and hold the \| touch button until the appliance operation is cancelled.

Finishing

Touch the ① touch button to switch the appliance off.

Dough proving setting

Dough will prove considerably more quickly using the "Dough proving ⊕" heating mode than at room temperature and does not dry out.

There are two levels available for the Dough proving setting. Use the information in the tables to select the appropriate level. \rightarrow "Tested for you in our cooking studio" on page 40

Note: If the water tank runs dry during operation with the Dough proving setting, operation is interrupted. Fill the water tank.

Starting

- 1. Touch the ① touch button.
- 2. Fill the water tank.

Note: Only switch on the Dough proving setting once the cooking compartment has completely cooled down (to room temperature).

- 3. Swipe to the left or right to select "Dough proving".
- 4. Touch "1" in the bottom line.
- **5.** Swipe to the left or right to select the required level.
- **6.** Touch the \square symbol to apply the setting.
- 7. Touch "|→|" in the bottom line.
- 8. Swipe to the left or right to select the required duration.
- **9.** Touch the \square symbol to apply the setting.
- **10.** Touch the | | | | touch button.

The appliance starts the operation.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the (b) touch button to end the audible signal.

Cancelling

Press and hold the || touch button until the appliance operation is cancelled.

Finishing

Touch the ① touch button to switch the appliance off.

Reheating

With the "Reheat " heating mode, you can gently reheat food that has already been cooked or crisp up day-old baked goods. Steam is switched on automatically.

Note: If the water tank runs dry during operation with the Reheat setting, operation is interrupted. Fill the water tank.

Starting

- 1. Touch the ① touch button.
- 2. Fill the water tank.
- 3. Swipe to the left or right to select "Reheat \(\exists\)".
- 4. Touch the temperature in the bottom line.
- 5. Swipe to the left or right to select the required temperature.
- **6.** Touch the \square symbol to apply the setting.
- Touch "|→|" in the bottom line.
- 8. Swipe to the left or right to select the required duration.
- **9.** Touch the \square symbol to apply the setting.
- **10.** Touch the > | touch button. The appliance starts the operation.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the (5) touch button to end the audible signal.

Cancelling

Press and hold the | touch button until the appliance operation is cancelled.

Finishing

Touch the ① touch button to switch the appliance off.

Filling the water tank

The water tank is located behind the control panel. Before starting an operation with steam, open the control panel and fill the water tank with water.

Make sure that you have set the water hardness range correctly. → "Basic settings" on page 22

Marning – Risk of injury and risk of fire!

Only fill the water tank with water or with the descaling solution that is recommended by us. Do not pour any flammable liquids (e.g. alcoholic drinks) into the water tank. Due to hot surfaces, vapours from flammable liquids may catch fire in the cooking compartment

(explosion). The appliance door may spring open. Hot steam and jets of flame may escape.

⚠ Warning – Risk of burns!

The water tank may heat up while the appliance is in operation. Wait until the water tank has cooled down after the previous appliance operation. Remove the water tank from the water tank recess.

The appliance may become damaged due to the use of unsuitable liquids.

Do not use distilled water, highly chlorinated tap water (> 40 mg/l) or other liquids.

Only use cold, fresh tap water, softened water or uncarbonated mineral water.

Caution!


Malfunctions may occur when using filtered or demineralised water.


The appliance may request that you top up the water tank even though it may be full, or operation with steam is cancelled after approx. two minutes.

If required, mix filtered or demineralised water with the bottled non-carbonated mineral water with a ratio of one to one.

Notes

- If your water is very hard, we recommend that you use softened water.
- If you use only softened water, you can set your appliance to the "softened" water hardness range.
- If you use mineral water, set the water hardness range to "4 very hard".
- If you use mineral water, you must only use noncarbonated mineral water.
- 1. Touch the T touch button.
 - The control panel is pushed forwards automatically.
- 2. Pull the control panel forwards with both hands and then push it upwards until it locks into place (Fig. 1).
- 3. Lift the water tank and remove it from the water tank recess (Fig. 2).







4. Press down on the cover along the seal to prevent water from leaking out of the water tank.

5. Take out the cover a (Fig. 3).


Note: Whether or not there is a cover **a** depends on the appliance type.


Fill the water tank with cold water up to the "max." mark (Fig. 4).





- Put the cover a back into the opening on the water tank.
- Insert the filled water tank (Fig. 5). Ensure that the water tank locks into place behind both holders b (Fig. 6).





9. Slowly slide the control panel downwards and then push it towards the rear until it is closed completely. The water tank has been filled. You can start using operating modes with steam.

Refilling the water tank

Notes

- Steam-assisted operations continue without adding steam.
- If the water tank runs dry during operation with the Dough proving or Reheat settings, operation is interrupted. Fill the water tank.
- 1. Open the control panel.
- 2. Remove and refill the water tank.
- 3. Insert the filled water tank and close the control panel.

After every steam operation

⚠ Warning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

⚠ Warning – Risk of burns!

The appliance becomes hot during operation. Allow the appliance to cool down before cleaning.

Caution!

Enamel damage: Do not start any operations when there is water on the cooking compartment floor. Before operation, wipe away the water from the cooking compartment floor.

Notes

- Once the appliance has been switched off, the ☐ touch button remains lit for a little longer to remind you to empty the water tank.
- Remove limescale marks with a cloth soaked in vinegar, then wipe with clean water and dry with a soft cloth.

Emptying the water tank

Caution!

- Do not dry the water tank in the hot cooking compartment. This will damage the water tank.
- Do not clean the water tank in the dishwasher. This will damage the water tank.
- 1. Open the control panel.
- 2. Remove water tank.
- **3.** Carefully remove the lid of the water tank.
- **4.** Empty the water tank, clean it with detergent and then rinse it thoroughly with clean water.
- 5. Dry all parts with a soft cloth.
- 6. Rub the seal on the lid until dry.
- 7. Leave to dry with the lid open.
- 8. Place the lid on the water tank and push it down.
- 9. Insert the water tank and close the control panel.

Starting drying

To dry the cooking compartment, it is heated up so that the moisture in the cooking compartment evaporates. You will then need to open the appliance door to allow the steam to escape from the cooking compartment.

Caution

Enamel damage: Do not start any operations when there is water on the cooking compartment floor. Before operation, wipe away the water from the cooking compartment floor.

- 1. Allow the appliance to cool down.
- 2. Remove the worst of the food remnants from the cooking compartment immediately and use a sponge to wipe away moisture from the cooking compartment floor.
- 3. If necessary, touch the \bigcirc touch button to switch the appliance on.
- **4.** Touch the \bigcirc field to display the operating modes.
- **6.** Touch the line at the bottom. The duration will be displayed. It cannot be changed.
- 7. Touch the line at the bottom.

- 8. Touch the || field.
 This starts the drying function; it will end automatically after 10 minutes.
- **9.** Open the appliance door and leave it open for 1 to 2 minutes so that the moisture in the cooking compartment can escape.

Drying the cooking compartment by hand

- 1. Allow the appliance to cool down.
- Remove any food remnants from the walls of the cooking compartment.
- 3. Dry the cooking compartment with a sponge.
- **4.** Leave the appliance door open for 1 hour so that the cooking compartment dries completely.



Your appliance has different time-setting options.

Time-	setting option	Use
Ĉ	Timer	The timer functions like an egg timer. The appliance does not switch on and off automatically.
 →	Cooking time	Once the set cooking time has elapsed, the appliance switches off automatically.
\rightarrow	Ready at	The appliance switches on automatically, and once the set cooking time has elapsed and the end time has passed, it switches off automatically.

Note: If you have set a time-setting option, the time interval increases if you set a higher value. Example: You can set a cooking time of up to one hour in one-minute increments; for cooking times over one hour, you can set a cooking time in five-minute increments.

Showing and hiding the time-setting options

To show or hide the time-setting options, touch the \bigcirc touch button.

Note: After a particular length of time, the time-setting options that are shown are automatically hidden. If you have already set a cooking time, it will be applied.



Setting the timer

The timer can be set when the appliance is switched on or off.

- Touch the touch button.
 The time-setting options are shown on the display.
- 2. Swipe to the left or right to select the duration.
 Note: With the appliance switched on, first touch "Q
 Timer" and then swipe to the left or right to select the duration.
- 3. Touch the ⊕ touch button. The ♀ symbol appears on the display.

Note: As soon as the set time has elapsed, a signal sounds. Touch the (5) touch button to end the audible signal.

Setting the cooking time

Once the set cooking time has elapsed, the appliance switches off automatically. The function can only be used in combination with a type of heating.

- 1. Touch the ① touch button.
- **2.** Set the type of heating and temperature.
- 3. Touch the ⑤ touch button.

 The time-setting options are shown on the display.
- 4. Swipe to the left or right to select the cooking time.
- 5. Touch the || touch button to start the set cooking time.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the ① touch button to end the audible signal.

Start delay - "Ready at"

The appliance switches on automatically and switches off at the preset end time. To do this, set the cooking time and determine the end time for the operation.

The start delay can only be used in combination with a type of heating.

Notes

- Ensure that food is not left in the cooking compartment for too long as it may spoil.
- The option to delay the start of operation is not available for every type of heating.
- Place the food onto the appropriate accessory in the cooking compartment and close the appliance door.
- 2. Touch the ① touch button.
- 3. Set the type of heating and temperature.
- 4. Touch the 🖰 touch button.
 - The time-setting options are shown in the display.
- **5.** Swipe to the left or right to select the cooking time.
- 6. Touch "→ Ready at".
- 7. Swipe to the left to select the end time.
- 8. Touch the || touch button.
 - The appliance waits until the appropriate time to start the operation.

As soon as the end time has been reached, an audible signal sounds and the appliance ends the operation automatically. Touch the (5) touch button to end the audible signal.

Checking, changing or deleting settings

- 1. Touch the (field.
 - The time-setting options are shown on the display.
- 2. Touch the time-setting option.
- 3. If required, swipe to the left or right in the touch display to change the settings. To delete a time-setting option, set "- : -".

The setting is applied automatically.

Childproof lock

Your appliance is equipped with a childproof lock so that children cannot switch it on accidentally or change any settings.

Your appliance has two different locks.

Lock	Activate/deactivate
Automatic childproof lock	Via the MyProfile menu → "Basic settings" on page 22
One-time childproof lock	Via the 🕒 touch button

Note: As soon as you activate the childproof lock, the control panel is locked. The ① and ① touch buttons are not included. You can deactivate the childproof lock at any time.

Automatic childproof lock

The control panel is locked so that the appliance cannot be switched on. To switch it on, the automatic childproof lock must be interrupted. After the appliance operation, the control panel is locked automatically.

Activation

- 1. Touch the ① touch button.
- 2. Touch the \(\hat{\cap}\) touch button.
- 3. Swipe to the left or right to select "MyProfile".
- 4. Touch the bottom line.
- **5.** Swipe to the left or right to select the "Automatic childproof lock".
- 6. Touch the bottom line.
- 7. Swipe to the left or right to select "Activated".
- 8. Touch the \(\hat{\to}\) touch button.
- 9. Touch "Save".

The settings are saved. The automatic childproof lock is active. After the appliance is switched off, the ⇔ symbol appears in the display.

Cancelling

- 1. Press and hold the (b) touch button until "Childproof lock deactivated" appears on the display.
- 2. Touch the ① touch button.
- 3. Switch on the required appliance operation.

Deactivation

- 1. Press and hold the (5) touch button until "Childproof lock deactivated" appears on the display.
- 2. Touch the ① touch button.
- **3.** Touch the $\widehat{\Box}$ touch button.
- 4. Swipe to the left or right to select "MyProfile".
- 5. Touch the bottom line.
- 6. Touch the top line.
- 7. Swipe to the left or right to select the "Automatic childproof lock".
- 8. Touch the bottom line.
- 9. Swipe to the left or right to select "Deactivated".
- **10.** Touch the \bigcirc touch button.
- 11. Touch "Save".

The "Automatic childproof lock" is deactivated.

12. Touch the ① touch button.

One-time childproof lock

The control panel is locked so that the appliance cannot be switched on. To switch it on, the one-time childproof lock must be deactivated. After the appliance is switched off, the control panel is no longer locked.

Activating and deactivating

- 1. Press and hold the (b) touch button until "Childproof lock activated" appears on the display. The childproof lock is activated.
- 2. Press and hold the (b) touch button until "Childproof lock deactivated" appears on the display. The childproof lock is deactivated.

Basic settings

There are various settings available to you in order to help use your appliance effectively and simply. If necessary, you can change these settings in MyProfile ...

Changing MyProfile

- 1. Touch the ① touch button.
- 2. Touch the \bigcirc touch button.
- 3. Swipe to the left or right to select "MyProfile $^{\circ}_{\text{LB}}$ ".
- 4. Touch the bottom line.
- Swipe to the left or right to select the required setting.
- 6. Touch the bottom line.
- Swipe to the left or right to select the required setting.
- 8. Touch the \bigcirc touch button.
- 9. Touch "Save".

List of basic settings

Setting	Selection	
Language	Select language	
Time of day	Sets the current time	
Date	Sets the current date	
Water hardness	0 (softened)	
	1 (soft)	
	2 (medium)	
	3 (hard)	
	4 (very hard)	
Favourites	Set the heating types that should be shown in the heating types menu	
Audible signal	Short duration	
	Medium duration	
	Long duration	
Volume	Can be adjusted to one of five different levels	
Button tone	Switched off (Exception: The button tone for the ① touch button remains switched on)	
	Switched on	
Display brightness	Adjustable across 5 levels	
Clock display	Off	
	Digital	
	Analogue	
Lighting	On during operation	
	Off during operation	
Childproof lock*	Only key lock	
	Door lock and key lock	
Automatic childproof lock	Deactivated	
	Activated	

Action after switching on	Main menu
	Heating types
	Baking and roasting assistant
	Steam programmes
Night-time dimming	Switched off
	Switched on (display dimmed between 10 p.m. and 5.59 a.m.)
Brand name logo	Display
	Do not display
Fan run-on time	Recommended
	Minimum
Pull-out system*	Not retrofitted (rack or single pull-out system)
	Retrofitted (double or triple pull-out system)
Factory settings	Restore
*) Depending on the applia	ance model, this basic setting cannot be se-

Setting favourites

You can set which types of heating are shown in the Types of heating menu.

Note: The "CircoTherm hot air", "Circo-roasting" and "Grill, large area" types of heating are always shown in the Types of heating menu. They cannot be deactivated.

- 1. Touch the ① touch button.
- 2. Touch the \bigcirc touch button.
- 3. Swipe to the left or right to select "MyProfile ...".
- 4. Touch the bottom line.
- 5. Swipe to the left or right to select "Favourites".
- 6. Touch the bottom line.
- **7.** Swipe to the left or right to select the required type of heating.
- 8. Touch "Activated" or "Deactivated".
- 9. Touch the \bigcirc touch button.
- 10. Touch "Save".

Baking and roasting assistant

The baking and roasting assistant helps you to prepare meals with ease. The appliance applies the most suitable settings.

To achieve good results, the cooking compartment must not be too hot for the type of food you have selected. If it is, a message will appear on the display. Allow the cooking compartment to cool down and start again.

Information on the settings

- The cooking result depends on the quality of the food and the type of cookware. For an optimal cooking result, use food that is in good condition and chilled meat only.
- The baking and roasting assistant helps you to prepare classic cakes, bread and roasts. The appliance selects the optimal type of heating for you. It suggests a suitable temperature and cooking time, which you can change if you wish.
- Information is provided, e.g. on cookware, shelf position or the addition of liquid when cooking meat. Some food requires turning or stirring, etc. during cooking. This is shown in the display shortly after operation starts. An audible signal will remind you at the right time.
- Information on the right kind of cookware to use and tips and tricks for preparation can be found at the end of the instruction manual.

Selecting a meal

The following table shows the corresponding setting values for the listed meals.

Dishes
Sponge springform tin/loaf tin
Sponge (6 eggs)
Swiss roll
Yeast dough cake on baking sheet with dry topping
Plaited ring/loaf
Small baked puff-pastry items
Muffins, on one level
White bread in a loaf tin
Part-baked bread rolls/baguettes
Frozen pizza with thin base, 1 piece
Chips, frozen, on one level
Potato gratin, made from raw potatoes
Baked potatoes
Lasagne, fresh
Joint of pork, marbled, without rind
Meat loaf (1 kg)
Sirloin, medium (1.5 kg)
Beef pot roast

Dishes Leg of lamb, boned Chicken, whole

-...

Chicken legs

Goose, whole (3-4 kg)

Selecting and setting food

You will be guided through the entire setting process for your chosen food.

- Touch the ① touch button to switch on the appliance.
- 2. Touch the \bigcirc touch button.
- 3. Swipe to the left or right to select "Baking and roasting assistant".
- 4. Touch the bottom line.
- 5. Touch the required category.
- 6. Swipe to the left or right to select the required dish.
- 7. Touch the required dish. The recommended settings appear on the display. Note: For some meals, you can also display notes, e.g. on the shelf height and cookware. To do this, swipe to the left until all of the notes are displayed.
- **8.** If required, you can change the recommended settings. To do this, touch "Adjust" in the bottom line. Touch the appropriate setting and adjust it.
- 9. Touch the || touch button to start the appliance operation.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the \odot touch button to end the audible signal.

Some recommended settings offer you the opportunity to continue cooking your dish.

If you are satisfied with the cooking result, touch "End". If you are not happy with the cooking result, you can continue cooking your dish.

Continue cooking

- 1. Touch "Continue cooking".
- 2. If necessary, adjust the recommended setting.
- 3. Touch the III touch button to start "Continue cooking".

Cancelling

Press and hold the || touch button until the appliance operation is cancelled.

Switching off the appliance

Touch the ① touch button to switch off the appliance.

Programmes

You can prepare food very easily using the various programmes. You select a programme and enter the weight of your food. The program then applies the most suitable settings.

To achieve good results, the cooking compartment must not be too hot for the type of food you have selected. If it is, a message will appear on the display. Allow the cooking compartment to cool down and start again.

Information on the settings

weight range.

- The cooking result depends on the quality of the food and the type of cookware used. For best results, only use high-quality food and refrigerated meat. For frozen products, only use food directly from the freezer.
- For some dishes, you will be required to enter the weight. The appliance will then apply the time and temperature settings for you.

 It is not possible to set weights outside the intended
- For roasting programmes, for which the appliance applies the temperature selection, temperatures can be as high as 300 °C. Therefore ensure that you are using heat-resistant cookware.
- Information about cookware, shelf position or adding liquid for meat is provided for you. For some dishes, the food needs to be turned or stirred during cooking. This is shown briefly on the display after the start. A signal reminds you to do this at the right time.
- Information about suitable cookware and preparation tips and tricks can be found at the end of the instruction manual.

Steam

For the steam programme, the appliance provides you with programmes you can use to prepare your meals easily and professionally.

Information about the steam functions can be found in the relevant sections. \rightarrow "Steam" on page 17

⚠ Warning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

Selecting a dish

The following table shows the corresponding setting values for the listed dishes.

Dishes
White bread, without a tin
Wheat bread, multi-grain wheat bread, without a tin
Wheat bread, multi-grain wheat bread in loaf tin
Multi-grain rye bread with yeast in a loaf tin
Flatbread
Plaited loaf, unfilled/savarin
Fatless sponge cake
Joint of pork with crackling
Pork neck joint, boned
Smoked pork, boned/rolled joint
Fillet of beef, medium
Sirloin, fresh, medium
Sirloin, fresh, rare
Chicken, whole, fresh
Chicken portions, fresh
Goose, duck, unstuffed, fresh
Whole fish
Reheat cooked side dishes

Setting a programme

You will be guided through the entire setting process for your chosen food.

- **1.** Touch the ① touch button to switch on the appliance.
- 2. Touch the 1 touch button.
- **3.** Swipe to the left or right to select "Steam programmes".
- 4. Touch the bottom line.
- 5. Touch the required category.
- **6.** Swipe to the left or right to select the required steam programme.
- 7. Touch the required steam programme.

The settings for this dish appear on the display.

Note: For some meals, you can also display notes, e.g. on the shelf height and cookware. To do this, swipe to the left until all of the notes are displayed.

- 8. If required, you adjust can set the weight for some meals. To do this, touch "Adjust" in the bottom line. Touch the appropriate setting and adjust it.
- 9. Touch the | | | touch button to start the appliance operation.

The estimated cooking time is shown.

Note: For some programmes, the displayed cooking time may change during the first few minutes, as the heating-up time depends on the temperature of the food and the water, amongst other things.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the ① touch button to end the audible signal.

Some programmes offer you the opportunity to continue cooking your dish.

If you are satisfied with the cooking result, touch "End". If you are not happy with the cooking result, you can continue cooking your dish.

Continue cooking

- 1. Touch "Continue cooking".
- 2. If necessary, adjust the recommended setting.
- 3. Touch the pil touch button to start "Continue cooking".

Cancelling

Press and hold the $\|\cdot\|$ touch button until the appliance operation is cancelled.

Switching off the appliance

Touch the ① touch button to switch off the appliance.

Meat thermometer

The MultiPoint meat thermometer makes precise cooking possible. It measures the temperature inside the food. Once the set temperature has been reached, the appliance automatically switches itself off.

Suitable types of heating

0	CircoTherm hot air
	OII CO FITE HIT HOL AII
=	Top/bottom heating
Ž.	Circo-roasting
$\frac{2}{8}$	Pizza setting
	Bread-baking
eco	Top/bottom heating eco
eco	CircoTherm eco
	Reheating

Notes

- The meat thermometer measures the temperature on the inside of the food between 30 °C and 99 °C.
- Use only the meat thermometer supplied. You can purchase it as a spare part from the after-sales service.
- After use, always remove the meat thermometer from the cooking compartment. Never store it inside the cooking compartment.

Inserting the meat probe into the food


Before placing your food into the cooking compartment, insert the meat probe into the food.


The meat probe has three measuring points. Ensure that the middle measuring point is inserted in the food.

Meat: For large pieces of meat, insert the meat probe at an angle from above as far as it will go into the meat. For relatively thin pieces of meat, insert the meat probe from the side at the thickest point.




Poultry: Insert the meat probe as far as it will go into the thickest point in the breast. Insert the meat probe into the poultry crossways or lengthways depending on its structure. Then turn the poultry and place it on the wire rack breast-side down.





Fish: Insert the meat probe behind the head as far as it will go towards the spine. Place the whole fish onto the wire rack and prop it up in the swimming position using half a potato.



Turning the food: If you wish to turn the food, do not remove the meat probe. Once you have turned the food, check that the meat probe is correctly positioned in the food.

If you remove the meat probe while the food is cooking, all settings will be reset and you will have to apply them again.

Caution!

Ensure that the meat probe's cable does not become trapped.

To prevent the meat probe from being damaged by excessive heat, there must be a gap of a few centimetres between the grill element and the meat probe. The meat may expand during the cooking process.

Setting and starting the appliance operation

⚠ Warning – Risk of burns!

The cooking interior and the core temperature probe become very hot. Use oven mitts to plug and unplug the core temperature probe.

⚠ Warning – Risk of electric shock!

The insulation of an incompatible meat probe may be damaged. Only use the meat probe which is recommended for this appliance.

Notes

- The set cooking compartment temperature must be at least 10 °C higher than the core temperature.
- To prevent the meat thermometer from being damaged, the cooking compartment temperature must not be set higher than 250 °C.
- 1. Insert the meat thermometer in the socket on the left-hand side of the cooking compartment.
- 2. Close the appliance door.

Caution!

When doing so, ensure that the meat thermometer's cable is not trapped in the appliance door. It may be damaged.

- 3. Touch the ① touch button.
- **4.** Set the type of heating.

Note: When the meat thermometer is plugged into the socket, you can only select a type of heating with which the meat thermometer can be used.

- **5.** Touch the cooking compartment temperature on the left in the bottom line.
- **6.** Swipe to the left or right to select the required cooking compartment temperature.
- **7.** Touch the \square symbol to apply the setting.
- 8. Touch the / core temperature on the right in the bottom line.
- **9.** Swipe to the left or right to select the required core temperature.
- **10.** Touch the || touch button. The appliance starts the operation.

Changing or cancelling the appliance operation

Changing the appliance operation

During appliance operation, you can change the cooking compartment temperature and core temperature.

- Touch the cooking compartment temperature or core temperature twice.
- 2. Swipe to the left or right to change the temperature.
- 3. Touch the \subseteq symbol to apply the setting.

Stopping the appliance operation

Once the set core temperature has been reached, a signal sounds and the appliance stops the operation automatically.

- **1.** Touch the \odot touch button to end the signal.
- 2. Use the ① touch button to switch off the appliance.
- **3.** Using an oven glove, unplug the meat thermometer from the socket.

Core temperatures of different foods

Do not use frozen food. The figures in the table are given as a guide. They depend on the quality and composition of the food. \rightarrow "Tested for you in our cooking studio" on page 40

You can find comprehensive information on the heating mode and temperature at the end of the instruction manual.

Food	Core temperature in °C
Pork	
Shoulder of pork	85-90
Fillet of pork, medium rare	62-70
Loin of pork, well done	72-80
Beef	
Tenderloin or sirloin, rare	45-52
Tenderloin or sirloin, medium rare	55-62
Tenderloin or sirloin, well done	65-75
Veal	
Joint of veal or shoulder, lean	75-80
Joint of veal, shoulder	75-80
Knuckle of veal	85-90
Lamb	
Leg of lamb, medium rare	60-65
Leg of lamb, well done	70-80
Saddle of lamb, medium rare	55-60
Miscellaneous	
Heating/reheating food	65-75

Sabbath mode

You can set a time of up to 74 hours using Sabbath mode. The food in the cooking compartment remains warm, without you having to switch the appliance on or off

Starting the Sabbath mode

Before you can use Sabbath mode, you must activate it under "Favourites" in the basic settings.

Once the Sabbath mode has been activated, you can select it under the menu for the types of heating.

The appliance heats up with top/bottom heating. The temperature can be set between 85 °C and 140 °C.

- 1. Touch the ① touch button.
- Swipe to the left or right to select the "Sabbath mode".
- **3.** Touch the temperature in the bottom line.
- **4.** Swipe to the left or right to select the required temperature.
- **5.** Touch the \square symbol to apply the setting.
- **6.** Touch the $|\rightarrow|$ duration in the bottom line.
- Swipe to the left or right to select the required duration.
- **8.** Touch the \subseteq symbol to apply the setting.
- 9. Touch the || touch button.
 The appliance starts the operation.

Notes

- Once Sabbath mode has started, you can no longer change any settings or cancel the operation using the II touch button.
- The operation is not interrupted if you open the appliance door.

Once the Sabbath mode duration has elapsed, a signal sounds. The appliance stops heating. Use the ① touch button to switch off the appliance.

Cancelling Sabbath mode

Touch the ① touch button to cancel Sabbath mode.

Cleaning agent

With good care and cleaning, your appliance will retain its appearance and remain fully functioning for a long time to come. We will explain here how you should correctly care for and clean your appliance.

Suitable cleaning agents

To ensure that the different surfaces are not damaged by using the wrong cleaning agent, observe the information in the table. Depending on the appliance model, not all of the areas listed may be on/in your appliance.

Caution!

Risk of surface damage

Do not use:

- Harsh or abrasive cleaning agents,
- Cleaning agents with a high alcohol content,
- Hard scouring pads or cleaning sponges,
- High-pressure cleaners or steam cleaners.
- Special cleaners for cleaning the appliance while it is hot.

Wash new sponge cloths thoroughly before use.

Tip: Highly recommended cleaning and care products can be purchased through the after-sales service. Observe the respective manufacturer's instructions.

⚠ Warning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

Area	Cleaning		
Appliance exterior			
Stainless steel front	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such flecks. Special stainless steel cleaning products suitable for hot surfaces are available from our after-sales		
	service or from specialist retailers. Apply a very thin layer of the cleaning product with a soft cloth.		
Plastic	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Do not use glass cleaner or a glass scraper.		
Painted surfaces	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth.		
Control panel	Hot soapy water: Clean with a dish cloth and dry with a soft cloth. Do not use glass cleaner or a glass scraper. If descaler comes into contact with the control panel, wipe it off immediately. If you leave it, it may stain the control panel.		

Door panels	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Do not use a glass scraper or a stainless steel scouring pad.
Door handle	Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. If descaler comes into contact with the door han- dle, wipe it off immediately. Otherwise, any stains will not be able to be removed.
Appliance interio	or
Enamelled sur- faces	Hot soapy water or a vinegar solution: Clean with a dish cloth and then dry with a soft

Ename	led	sur-
faces		

Soften baked-on food remnants with a damp cloth and soapy water. Use stainless steel wire wool or oven cleaner to remove stubborn dirt.

Never use oven cleaner in the cooking compartment when it is still warm. This may damage the enamel. Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

Leave the cooking compartment open to dry after cleaning it.

It is best to use the cleaning function. → "Cleaning function" on page 30

Note: Food residues can cause white deposits to form. These are harmless and do not affect how the appliance works.

Remove using lemon juice if required.

Glass cover for the interior lighting

Hot soapy water:

Clean with a dish cloth and then dry with a soft

If the cooking compartment is heavily soiled, use oven cleaner.

Door cover

made from stainless steel:

Use stainless steel cleaner. Follow the manufacturers' instructions. Do not use stainless steel care products.

made from plastic:

Clean using hot soapy water and a dish cloth. Dry with a soft cloth. Do not use glass cleaner or a glass scraper.

Remove the door cover for cleaning.

Rails Hot soapy water:

Soak and clean with a dish cloth or brush.

Pull-out system

Hot soapy water:

Clean with a dish cloth or a brush.

Do not remove the lubricant while the pull-out rails are pulled out – it is best to clean them when they are pushed in. Do not clean in the dishwasher.

Accessories

Hot soapy water:

Soak and clean with a dish cloth or brush. If there are heavy deposits of dirt, use a stainless steel scouring pad.

Water tank	Hot soapy water: Clean with a dish cloth and rinse thoroughly to remove residual detergent. Then dry with a soft cloth. Leave the water tank to dry with the lid open. Rub the seal on the lid until dry. Do not clean in the dishwasher.
Meat thermome- ter	Hot soapy water: Clean with a dish cloth or a brush. Do not clean in the dishwasher.

Notes

- Slight differences in colour on the front of the appliance are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panels, which look like streaks, are caused by reflections made by the interior lighting.
- Enamel is baked on at very high temperatures. This can cause some slight colour variation. This is normal and does not affect operation. The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough. This does not impair the anti-corrosion protection.

Keeping the appliance clean

Always keep the appliance clean and remove dirt immediately so that stubborn deposits of dirt do not build up.

Marning – Risk of fire!

Loose food remnants, fat and meat juices may catch fire. Before using the appliance, remove the worst of the food remnants from the cooking compartment, heating elements and accessories.

Tips

- Clean the cooking compartment after each use. This will ensure that dirt cannot be baked on.
- Always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately.
- Use the universal pan for baking very moist cakes.
- Use suitable ovenware for roasting, e.g. a roasting dish.

Cleaning function

Your appliance is equipped with a self-cleaning function, EasyClean and a descaling function You can use the self-cleaning function to clean the cooking compartment. Use the EasyClean cleaning aid for intermediate cleaning of the cooking compartment. Dirt is softened beforehand using EasyClean. It can then be removed more easily. You can use the descaling function to remove limescale from the evaporator.

Self-cleaning

Use "Self-cleaning" mode to clean the cooking compartment.

You can choose from three cleaning settings.

Setting	Cleaning level	Duration
1	Light	Approx. 1 hour, 15 minutes
2	Medium	Approx. 1 hour, 30 minutes
3	Intensive	Approx. 2 hours

The dirtier the cooking compartment and the longer the dirt has been there, the higher the cleaning setting should be. A cleaning cycle requires only approx. 2.5 – 4.7 kilowatt hours.

Note: For your safety, the cooking compartment door locks automatically. It cannot be opened again until the ⊕ symbol for the locking mechanism goes out in the status bar. The interior lighting remains off during cleaning.

⚠ Warning Risk of burns!

- The cooking compartment becomes extremely hot during the cleaning function. Never open the appliance door. Allow the appliance to cool down. Keep children away from the appliance.
- The appliance will become very hot on the outside during the cleaning function. Never touch the appliance door. Allow the appliance to cool down. Keep children away from the appliance.

M Warning

Risk of harm to health!

The cleaning function heats up the cooking compartment to a very high temperature so that food remnants left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate the mucous membranes. While the cleaning function is running, keep the kitchen well ventilated. Do not remain in the room for long periods. Keep children and pets away. Follow the instructions even when using the Delayed start function with a delayed end time.

Preparation

- Loose food residues, grease and meat juices may catch fire during the cleaning function. Before starting the cleaning function, remove coarse dirt from the cooking compartment and from the accessories.
- The appliance will become very hot on the outside during the cleaning function. Never hang combustible objects, e.g. tea towels, on the door handle. Do not place anything against the front of the appliance. Keep children away from the appliance.
- If the door seal is damaged, a large amount of heat will be generated around the door. Do not scrub or remove the seal. Never operate the appliance if the seal is damaged or missing.

⚠ Warning – Risk of serious damage to health!

The appliance will become very hot during the cleaning function. The non-stick coating on baking trays and tins is destroyed and noxious gases are released. Never clean non-stick baking trays and baking tins using the cleaning function. Only clean enamelled accessories using the cleaning function.


Caution!

Shelf supports and pull-out rails tend to discolour if they are left in the cooking compartment when it is cleaned. Before you start the cleaning function, remove the shelf supports and pull-out rails from the cooking compartment.


- 1. Remove the shelf supports and pull-out rails from the cooking compartment. \rightarrow "Rails" on page 33
- Remove the water reservoir. → "Steam" on page 17
 Caution!


Before you start the cleaning function, remove the water reservoir from the appliance.

- **3.** Remove the worst of the food residues from the cooking compartment and accessories.
- 4. Clean the inside of the appliance door and along the edges of the cooking compartment in the area around the seal. Do not scrub the seal. → "Cleaning agent" on page 28
- 5. Insert the accessory supports if you wish to clean accessories when the cooking compartment is being cleaned. Make sure that the vertical bar **a** on the accessory support is facing the front (figure 1).



- **6.** Insert the rear end of the accessory support as far as it will go into the rear socket **b**, and push the accessory support back **c** (figure **2**).
- 7. Then insert the front end of the accessory support as far as it will go into the front socket **d**, and push the accessory support down **e** (figure **3**).






8. Whenever you wish to use the cleaning function, make sure that you never leave anything other than an enamelled accessory without anti-stick coating (e.g. the universal pan) on the accessory supports (figure 4).

Caution!

The wire rack tends to discolour if it is left in the cooking compartment when it is cleaned. Do not attempt to clean the rack using the cleaning function.



Note: Further accessories that can be cleaned using the cleaning function are listed in the table for special accessories. → "Accessories" on page 12

Starting

- 1. Touch the ① touch button.
- 2. Touch the \(\hat{\to}\) touch button.
- 3. Swipe to the left or right to select "Pyrolytic self-cleaning ******.
- 4. Touch the bottom line.
- Swipe to the left or right to select the cleaning level.
 Note: Once cleaning starts, the cleaning level can no longer be changed.
- 6. Touch the bottom line.
- 7. Touch the | | | touch button.

 The appliance starts the self-cleaning programme.

Ventilate the kitchen when the cleaning function is running.

During self-cleaning, the appliance door is automatically locked. The $\mbox{$ \hat{\Box} $}$ symbol appears on the display.

Note: If you would like to start self-cleaning later, set an end time.

Cancelling

Touch the \bigcirc touch button to cancel. The appliance door cannot be opened until the \bigcirc symbol goes out.

Finishing

As soon as self-cleaning has run through, a signal sounds. The appliance door cannot be opened until the $\frac{1}{2}$ symbol goes out.

Once the cleaning function has ended

- 1. Allow the cooking compartment to cool down.
- 2. Wipe off any ash that has been left behind in the cooking compartment and around the appliance door with a damp cloth.
- 3. If you have left an accessory inside the cooking compartment to be cleaned, remove it and wipe it down with a damp cloth.
- Lift the accessory support up at the front and remove it. → "Rails" on page 33
- Refit the shelf supports or pull-out rails. → "Rails" on page 33

EasyClean

The EasyClean cleaning aid makes it easier to clean the cooking compartment. Dirt is softened beforehand by vaporizing soapy water. It can then be removed more easily.

⚠ Warning – Risk of scalding!

Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

Starting

Notes

- The "EasyClean 🔯" cleaning aid can only be started once the cooking compartment is cold (room temperature) and the appliance door is closed.
- Do not open the appliance door during operation. Doing this will interrupt the "EasyClean or cleaning aid
- **1.** Remove the accessories from the cooking compartment.
- 2. Mix a drop of washing-up liquid into 0.4 litres of water (do not use distilled water) and pour it onto the centre of the cooking compartment floor.
- 3. Touch the ① touch button.
- **4.** Touch the \bigcirc touch button.
- 5. Swipe to the left or right to select "EasyClean <a>[∆]".
- 6. Touch the bottom line.
- 7. Touch the I touch button.

 The appliance starts EasyClean. The remaining time appears on the display.

Finishing

As soon as the cleaning aid has finished, an audible signal sounds and the appliance ends the operation automatically.

As soon as you open the appliance door, the interior lighting is switched on so that you can finish cleaning the cooking compartment more easily. The remaining water in the cooking compartment must be removed promptly. Do not leave the remaining water in the cooking compartment for a long time (e.g. overnight). The appliance must not be operated when the cooking compartment is still wet or damp.

Final cleaning

- 1. Open the appliance door and remove the remaining water with an absorbent sponge cloth.
- 2. Clean the smooth surfaces in the cooking compartment with a dish cloth or a soft brush. Stubborn residues can be removed using a stainless steel scouring pad.
- 3. Remove limescale with a cloth soaked in vinegar. Then wipe with clean water and rub dry with a soft cloth (including under the door seal).
- **4.** Use the ① touch button to switch off the appliance.
- 5. Leave the appliance door ajar in the locking position (approx. 30°) for approx. 1 hour to allow the enamel surfaces in the cooking compartment to dry. Alternatively, you can also run the rapid drying function for the cooking compartment.

Running the rapid drying function for the cooking compartment

- 1. After the cleaning aid process has finished, leave the appliance door ajar in the locking position (approx. 30°).
- 2. Touch the ① touch button.
- 3. Start CircoTherm hot air at 50 °C.
- **4.** After 5 minutes, switch off the appliance and close the appliance door.

Removing heavy deposits of dirt

You have several options for removing particularly stubborn deposits of dirt.

- Leave the soapy water to work for some time before starting the cleaning aid.
- Rub soapy water onto the dirt on the smooth surfaces before starting the cleaning aid.
- Repeat the cleaning aid once the cooking compartment has cooled down.

Descaling

The appliance must be descaled regularly in order for it to continue operating correctly.

There are several steps in the descaling programme. For hygiene reasons, the descaling programme must be run through completely so that the appliance can be ready for operation again. In total, the descaling programme runs for approx. 70-95 minutes.

- Descale (approx. 55-70 minutes), then empty and refill the water tank
- First rinsing cycle (approx. 9-12 minutes), then empty and refill the water tank
- Second rinsing cycle (approx. 9-12 minutes), then empty and dry the water tank

If the descaling process is interrupted (for example, due to a power failure or because the appliance has been switched off), you are prompted to rinse the appliance twice after it is switched back on. The appliance cannot be used until the second rinsing cycle has come to an end.

The frequency with which the appliance must be descaled depends on the hardness of the water used. When only five more steam-assisted operations are possible, or fewer, the appliance reminds you to descale it with a message on the display. The number of remaining operations is displayed after the appliance is switched on. You can therefore prepare for the descaling in good time.

Starting

Caution!

- Risk of damage to the appliance: Only use liquid descalers recommended by us for the descaling programme. The time the product needs to work during descaling depends on the type of descaler used. Other descalers may damage the appliance. Descaler order no. 311 680
- Descaling solution: Do not allow any descaling solution or descaler to come into contact with the control panel or other surfaces on the appliance. This damages the surfaces. If this does happen, remove the descaling solution immediately with water.

If you have used a steam-assisted operation immediately before descaling, you must first switch the appliance off so that the residual water is pumped out of the evaporator system.

- 1. Mix 400 ml water with 200 ml liquid descaler to make a descaling solution.
- 2. Touch the ① touch button.
- Remove the water tank and fill it with descaling solution.
- **4.** Once the water tank has been filled with descaling solution, push it back in again fully.
- 5. Close the control panel.
- **6.** Touch the \bigcirc touch button.
- 7. Swipe to the left or right to select "Descale 🔆".
- Touch the bottom line.
 The duration of the descaling programme is displayed. It cannot be changed.

- 9. Touch the bottom line.
- **10.** Touch the > | touch button.

The appliance is now descaled. The remaining time counts down on the display. As soon as the descaling programme has finished, an audible signal sounds.

First wash cycle

- 1. Open the control panel.
- Remove the water tank, rinse thoroughly, fill with water and reinsert.
- 3. Close the control panel.
- Touch the III touch button.
 The appliance is rinsed. As soon as the wash cycle has finished, an audible signal sounds.

Second wash cycle

- 1. Open the control panel.
- Remove the water tank, rinse thoroughly, fill with water and reinsert.
- 3. Close the control panel.
- **4.** Touch the | touch button. The appliance is rinsed. As soon as the wash cycle has finished, an audible signal sounds.

Final cleaning

- 1. Open the control panel.
- 2. Empty and dry the water tank.
- 3. Switch off the appliance.


 Descaling is complete and the appliance is ready for use again.


Rails

With good care and cleaning, your appliance will retain its appearance and remain fully functional for a long time to come. This will tell you how to remove the shelves and clean them.

Changing the shelf position for the telescopic rail

Bars and telescopic rails can be positioned in any order. For example, you can fit the telescopic rail to the shelf position which you use the most frequently.







Removing the bar

Telescopic rails are removed and fitted like bars.


- Push the bar towards the back a until it can be pulled out upwards b (Fig. 1).
- 2. Unhook the bar at the back and remove it (Fig. 2).







Fitting the bar

1. Fit the bar at the back (Fig. 11).



- 2. Push the bar towards the back a and down b onto the pin c (Fig. 2).
- 3. Ensure that the hook is hooked onto the pin c (Fig.






Detaching and refitting the rails


⚠ Warning – Risk of burns!

The rails become very hot. Never touch the hot rails. Always allow the appliance to cool down. Keep children away from the appliance.

Detaching the rails

- 1. Lift the rail slightly at the front **a** and detach it **b** (do not hold by the accessory holders or the telescopic shelf) (figure 11).
- 2. Then pull the whole rail towards you and take it out (figure 2).







Clean the rails with cleaning agent and a sponge. For stubborn deposits of dirt, use a brush.

Attaching the rails

The rails only fit on the right or the left side. The pull-out rails must pull out towards you.

- 1. First, insert the rail in the middle of the rear socket a, until the rail rests against the cooking compartment wall, and push it back **b** (figure **1**).
- 2. Then insert the rail into the front socket c, until the rail also rests against the cooking compartment wall here, and press it downwards d (figure 2).





☐ Appliance door

With good care and cleaning, your appliance will retain its appearance and remain fully functional for a long time to come. This will tell you how to remove the appliance door and clean it.

Removing and fitting the appliance door

To clean the door panels, you can detach the appliance door.

⚠ Warning – Risk of injury!

The hinges of the appliance door may snap shut with great force. Always fully turn the two locks for fitting and removing the appliance door.

⚠ Warning – Risk of injury!


If the appliance door has been removed without turning both locking levers to their limit stops, the hinge may snap shut. Do not reach into the hinge. Call the aftersales service.

Detaching the appliance door


1. Open the left- and right-hand door locks (fig. **1**). To do this, hold the screwdriver horizontally and use it to push the door lock (black component) on each side of the door all the way up (fig. 2).


Tip: Use a torch to light up the gap so that you can see the door locks.






Door lock closed (fig. 3) Door lock open (fig. 4)






2. Open the appliance door approx. 45° (fig. 5).




3. Using a coin, turn both the left- and right-hand locks on the inside of the appliance at the bottom as far as they will go.


Left-hand lock: Clockwise Right-hand lock: Anti-clockwise

The arrows will now be pointing to one another and the lock will click into place (fig. 6).



Left-hand lock secured (fig. 7)
Right-hand lock released (fig. 8)






 Move the appliance door back and forth until you hear a quiet click (fig. 9).

The appliance door is now in the lock position. You will only be able to move it slightly.

Caution!

Risk of damaging the door hinges. Do not force the appliance door open or closed when it is in the lock position.

If you have forced the appliance door open or closed when it was in the lock position, please contact our after-sales service.



1 Warning

Risk of injury!

The door handle may break off. Do not carry the appliance door by the door handle. To carry or remove the appliance door, take hold of it with both hands, one on the left and one on the right.


5. Take hold of the appliance door with both hands, one on the left and one on the right, and rotate the door handle upwards slightly **a** until you are able to pull up the appliance door and remove it **b**(fig. *10).

Marning

Risk of injury!

Do not drop the appliance door.


The appliance door weighs 7 - 10 kg - handle it with care.




6. Set the appliance door down on a flat, soft, clean surface.


Refitting the appliance door


1. Slide the appliance door over the left- and right-hand guide rollers simultaneously (fig. 1 and 2). Ensure that the appliance door is not wedged at an angle and that it is properly fitted in place.





- Rotate the door handle upwards slightly a (fig. 3).
 The appliance door will slide the short distance remaining to the bottom b (fig. 3).
- 3. Use a coin to release the locks on both sides of the appliance door (fig. 4).





Left-hand lock: Anti-clockwise Right-hand lock: Clockwise


4. Open the appliance door slightly until you hear a quiet click. Close the appliance door.


Warning

Risk of injury if the door locks are not closed!

The appliance door may become detached. You may be injured and the appliance door damaged. After refitting the door, always close the left- and right-hand door locks.

5. Close the left- and right-hand door locks (fig. **5**). To do this, hold the screwdriver horizontally and use it to push the door lock on each side of the door all the way down (fig. 6).





Removing and installing the door panels

For cleaning, you can remove the glass panels from the appliance door.

To do this, the appliance door must be removed beforehand (see section "Removing and fitting the appliance door").

Warning – Risk of injury!

The appliance must not be used again until the door panels and appliance door have been correctly fitted.



Warning – Risk of injury!


Components inside the appliance door may have sharp edges. Wear protective gloves.

Removing the glass panels


Note: Lay the glass panels you have removed on a flat surface that is soft and clean.


- 1. Detach the appliance door.
- 2. Lay the appliance door with the front side facing down on a flat surface that is soft and clean.
- 3. Push on the left- and right-hand side on the outside of the appliance door until the inner glass panel is released on both sides (fig. 11).
- 4. Carefully lift the inner glass panel and remove it in the direction of the arrow (fig. 2).







- 5. Slide the tip of the screwdriver in between the metal tab a and the plastic underneath it (fig. 3).
- 6. Use the tip of the screwdriver to carefully lift the reflector **b** until it is detached (fig. 4).







- 7. Lift the reflector **b** up and out (fig. 5).
- 8. Remove the second reflector in the same way as the first.
- 9. Push down on the intermediate panel around c, and carefully lift the holder **d** until you are able to pull it out (fig. 6).







10. Lift the first and second intermediate panels from below (fig. 2) and remove them in the direction of the arrow (fig. 8).





11. Remove the spacers (fig. 9) and seals (fig. 10) for cleaning if needed.





12. Clean the glass door panels and reflectors on both sides with glass cleaner and a soft cloth.


M Warning

Risk of injury!

Scratched glass in the appliance door may develop into a crack. Do not use glass scrapers, sharp or abrasive cleaning aids or aggressive or abrasive cleaning products.

Caution!

Make sure you do not damage the lighting. Do not clean or touch either of the LEDs **a**. The two LEDs are on the right and left in the appliance door.




13. Dry the door panels and refit them.


Fitting


Note: When fitting the door panels, make sure that they are in the original order.

1. Insert the intermediate panel so that the **a** arrow on the right-hand side is pointing upwards (Fig. 11).




- 2. Check the fit of the four spacers and two seals on the intermediate panel:
 - Position the spacers so that each of the lines runs through the centre (Fig. 2).
 - Attach the seals at the corners (Fig. 3).







3. Insert the intermediate panel with the seals and spacers. The arrow on the intermediate panel must line up with the arrow on the frame (Fig. 4).


4. Insert the second intermediate panel without the seals and spacers and push it in the direction of the arrow until it is fitted in the frame. The arrow on the intermediate panel must line up with the arrow on the frame (Fig. 5).





Push down on the intermediate panel around b, slide the holder c in at an angle and push down until it clicks into place (Fig. 6).
 The holder has been inserted (Fig. 7).







Caution!


Do not touch the glass rod with your bare hands. Greasy residues reduce light transmission. Clean the glass rod with glass cleaner once it has been inserted.


- 6. Select the left-hand reflector (Fig. 8).
- 7. Insert the left-hand reflector **d** at the top (Fig. 9).






- 8. Insert reflector d (Fig. 10).
- 9. Fit reflector **d** into slot **e** (Fig. **11**).






10. Insert the second reflector on the right-hand side in the same way as the left-hand reflector.

- **11.** Use glass cleaner to remove any finger marks from the reflectors if necessary.
- 12. Insert the inner glass into the mounting rail **f** at an angle towards the back (Fig. 12).
- **13.** Push the inner glass downwards until it clicks into place (Fig. 13).





Trouble shooting

If a fault occurs, there is often a simple explanation. Before calling the after-sales service, please refer to the fault table and attempt to correct the fault yourself.

Tip: If a meal does not turn out exactly as you wanted, refer to the "Tested for you in our cooking studio" section. Here, you will find plenty of cooking tips and notes.

Marning – Risk of injury!

Incorrect repairs are dangerous. Do not attempt to repair the appliance yourself. Repairs must only be carried out by one of our trained after-sales engineers. If the appliance is defective, call the after-sales service.

⚠ Warning – Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

Fault table

⚠ Warning – Risk of electric shock!

- Work on the appliance electronics may only be performed by a specialist.
- Always disconnect the appliance from the power supply when work is carried out on the electronics.
 Switch off the circuit breaker or remove the fuse from your household fuse box.

Fault	Possible cause	Notes/remedy
The appliance does not work	The plug is not plugged into the mains	Connect the appliance to the power supply
	Power cut	Check whether other kitchen appliances are working
	The circuit breaker is faulty	Check in the fuse box to make sure that the fuse for the appliance is OK
Operations with steam or descaling	Water tank empty	Refill water tank
do not start or do not continue	The panel is open	Close the panel
	Descaling locks operations with steam	Carry out descaling
	Faulty sensor	Call the after-sales service
The Neff Light reflector in the appliance door is discoloured	This is a normal occurrence as a result of high temperatures	Not possible
After switching on an operating mode, a message is shown on the display which indicates that the temperature is too high	The appliance has not cooled down sufficiently	Allow the appliance to cool down and switch the operating mode on again
The appliance prompts you to rinse	The power supply was interrupted or the appliance was switched off during the descaling process	Once the appliance is switched on again, rinse it twice
The appliance prompts you to descale without the counter appearing beforehand	The set water hardness range is too low	Carry out descaling Check the set water hardness range and adjust it, if necessary
Buttons flash	Normal occurrence caused by condensation behind the control panel	As soon as the condensation has evaporated, the buttons no longer flash

Cooked dishes turn out too moist or too dry when cooking with steam-assisted applications	The wrong steam intensity was selected	Select a higher or lower steam intensity
The "Fill water tank" message	The panel is open	Close the panel
appears even though the water tank is full	The water tank is not clicked into place	Click the water tank into place
		→ "Steam" on page 17
	Faulty sensor	Call the after-sales service
	The water tank has fallen off. Due to the impact, components inside the water tank have come loose, and the tank is leaking.	Order a new water tank
Steam escapes from the ventilation slots during cooking	Normal procedure	Not possible
The panel for removing the tank does	The plug is not plugged into the mains	Connect the appliance to the power supply
not open	Power cut	Check whether other kitchen appliances are working
	The circuit breaker is faulty	Check in the fuse box to make sure that the fuse for the appliance is OK
	Faulty sensor for the 🗇 touch button	Call the after-sales service
		If required, empty the water tank: Open the appliance door, take hold of the lower part of the panel on the left and right with your fingers and pull out the panel
The appliance cannot be switched on; the ⇐⇒ symbol is shown on the display	The automatic childproof lock is activated	Press and hold the \bigcirc touch button until the \Longrightarrow symbol goes out
The appliance cannot be operated when it is switched on; the ⇐⇒ symbol is shown on the display	The childproof lock is activated	Press and hold the \odot touch button until the \Longrightarrow symbol goes out
The appliance does not heat up; □ is shown on the display	Demo mode is activated in the basic settings	Disconnect the appliance from the mains for approx. 10 seconds (switch off the circuit breaker in the fuse box) and then deactivate demo mode in the basic settings within 3 minutes —> "Basic settings" on page 22
The appliance door cannot be opened; the ⊕ symbol is shown on	The appliance door is locked until the cooking compartment has cooled down	Wait until the ⊕ symbol goes out
the display	The childproof lock locks the appliance door	Press and hold the 🖰 touch button until the 🔓 symbol goes out; adjust the childproof lock setting
There is a "pop" noise during cooking	Cold/warm effect with frozen food, caused by the steam	Not possible
"D" or "E" appears on the display, e.g.	Technical problem	Switch the appliance off and on again
D0111 or E0111		If the message appears again, call the after-sales service. Quote the exact error message

Maximum operating time exceeded

Your appliance ends the operation automatically when no cooking time is set and the setting has not been changed for a long time.

The actual cooking time until the operation is stopped automatically varies according to the selected settings.

The appliance display indicates that the operation will end automatically. Afterwards, the operation is stopped.

To use the appliance again, switch it off beforehand. Then switch the appliance on again and set the required operation.

Cooking compartment bulbs

To light the interior of your cooking compartment, your appliance has one or more long-life LED bulbs.


However, if ever an LED bulb or the bulb's glass cover is defective, call the after-sales service. The lamp cover must not be removed.

Customer service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find an appropriate solution, also in order to avoid after-sales personnel having to make unnecessary visits.

E number and FD number

When calling us, please give the full product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate bearing these numbers can be found on the right-hand side when you open the fascia panel. Touch the ☐ touch button to do this. → "Steam" on page 17



To save time, you can make a note of the number of your appliance and the telephone number of the aftersales service in the space below, should it be required.

E no. FD no.

After-sales service 🕾

Please note that there will be a fee for a visit by a service technician in the event of a malfunction, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

To book an engineer visit and product advice GB 0344 892 8989

Calls charged at local or mobile rate.

IE 01450 2655

0.03 € per minute at peak. Off peak 0.0088 € per minute.

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

Tested for you in our cooking studio

Here, you can find a selection of dishes and the ideal settings for them. We will show you which type of heating and temperature are best suited to your dish. You will get information on suitable cooking accessories and the height at which they should be placed in the oven. You will also get tips about cookware and preparation methods.

Note: A lot of steam can build up in the cooking compartment when cooking food.

Your appliance is very energy-efficient and radiates very little heat to its surroundings during operation. Due to the high difference in temperature between the appliance interior and the external parts of the appliance, condensation may build up on the door, control panel or adjacent kitchen cabinet panels. This is a normal physical phenomenon. Condensation can be reduced by preheating the oven or opening the door carefully.

During operation with steam assistance, it is desirable that there is a significant build-up of steam in the cooking compartment. Wipe the cooking compartment clean after cooking, once it has cooled off.

Silicone moulds

We recommend dark-coloured metal baking tins for ideal cooking results.

Nevertheless, if you wish to use silicone moulds, follow the manufacturer's instructions and recipes. Silicone moulds are often smaller than normal baking tins. Quantity and recipe specifications may vary.

Silicone moulds are unsuitable for steam-assisted cooking.

Cakes and small baked items

Your appliance offers you a range of heating types for the preparation of cakes and small baked items. You can find the ideal settings for many dishes in the settings tables.

Also refer to the notes in the section on allowing dough to rise.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

Steam- assisted baking

Certain types of baked item (e.g. yeast-risen pastries) get a more crispy crust and a more glossy surface if baked with the steam assist mode. The baked item does not dry out as much.

Steam-assisted baking is only possible on one level. Some food turns out better if it is baked in several stages. These dishes are indicated in the table.

Shelf positions

Use the indicated shelf positions.

Baking on one level

When baking on one level, use the following shelf positions:

Tall baked items: Level 2 Flat baked items: Level 3

If you are using CircoTherm Hot air as the type of heating, you can choose between levels 1, 2, 3 and 4.

Baking on several levels

Use CircoTherm. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time. Baking on two levels:

Universal pan: Level 3 Baking tray: Level 1

Baking tins/dishes on the wire rack

First wire rack: Level 3 Second wire rack: Level 1

Baking on three levels:

Baking tray: Level 4 Universal pan: Level 3 Baking tray: Level 1

Baking on four levels:

4 wire racks with greaseproof paper First wire rack: Level 4

Second wire rack: Level 3 Third wire rack: Level 2 Fourth wire rack: Level 1

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another or offset and vertically stacked in the cooking compartment.

Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire

Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

When baking moist cakes or pastries with many toppings, use the universal pan so that any excess liquid does not overflow and make the cooking compartment dirty.

Baking tins

Dark- coloured metal baking tins are most suitable.

Tinplate baking tins, ceramic dishes and glass dishes extend baking time and mean that the baked item will not brown evenly. If you wish to bake using these baking tins/dishes and using top/bottom heating, slide in the tin/dish at level 1.

The baking tins must be resistant to heat and steam for use in steam-assisted baking.

Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

Recommended setting values

The table lists the optimal heating type for various baked items. The temperature and baking time depend on the amount and consistency of the dough/mixture. For this reason, the table specifies setting ranges. Try using the lower values to start with. A lower temperature will result in more even browning. You can use a higher setting next time if necessary.

Note: Baking times cannot be reduced by using higher temperatures. Cakes or small baked items would only be cooked on the outside, and would not be fully baked in the middle.

The setting values apply to food that is placed into a cold cooking compartment; by doing this, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated baking times by several minutes.

Preheating is necessary for selected food, and this is indicated in the table. Do not place your food or accessories into the cooking compartment until it has finished preheating.

If you wish to follow one of your own recipes when baking, you should use the setting values listed for similar baked items in the table as reference. Additional information can be found in the baking tips listed after the settings table.

Remove unused accessories from the cooking compartment. This will ensure that you achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- Top/bottom heating
 Circotherm intensive
- Bread baking

- $1 = I \circ w$
- 2 = Medium
- 3 = High

Dish	Accessories/cookware	Shelf posi- tion	Heating function	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Cakes in tins						
Sponge cake, simple	Ring tin/cake tin	2	ک	140-160	-	50-70
Sponge cake, simple	Ring tin/cake tin	2	ک	150-160	1	50-70
Sponge cake, simple, 2 levels	Ring tin/cake tin	3+1	ک	140-160	-	60-80
Sponge cake, delicate	Ring tin/cake tin	2	=	150-170	-	60-80
Fruit flan made from sponge mixture, delicate	Ring/springform cake tin	2	Ξ	160-180	-	40-60
Fruit flan made from sponge mixture, delicate	Ring/springform cake tin	2	ک	150-170	-	40-60
Sponge flan base	Flan base tin	3	ک	150-170	-	20-30
Sponge flan base	Flan base tin	2	ک	150-160	1	25-35
Fruit tart or cheesecake with shortcrust pastry base	Springform cake tin, Ø 26 cm	2	Ξ	170-190	-	60-80
Swiss flan	Pizza tray	3	Ξ	220-240	-	35-45
Swiss flan	Pizza tray	3	&	170-190	-	45-55
Tart	Flan-base cake tin, black	3	&	190-210	-	25-40
Tart	Flan-base cake tin, black	3	<u></u>	200-220	1	30-40
Bundt yeast cake	Ring cake tin	2	ک	150-160	-	50-70
Bundt yeast cake	Ring cake tin	2	ک	150-160	1	60-70
Yeast cake	Springform cake tin, Ø 28 cm	2	ک	150-160	-	20-30
Yeast cake	Springform cake tin, Ø 28 cm	2	ک	150-160	2	25-35
Sponge base, 2 eggs	Flan base tin	3	ک	160-180*	-	20-30
Sponge base, 2 eggs	Flan base tin	2	ک	150-160	1	20-35
Sponge flan, 3 eggs	Springform cake tin, Ø 26 cm	2	_	160-170*	-	25-35
Sponge flan, 3 eggs	Springform cake tin, Ø 26 cm	2	ک	150-160	1	10
					-	20-30
Sponge flan, 6 eggs	Springform cake tin, Ø 28 cm	2	ک	150-170*	-	30-50
Sponge flan, 6 eggs	Springform cake tin, Ø 28 cm	2	ک	150-160	1 -	10 25-35
Cakes on baking trays						
Sponge cake with topping	Baking tray	3	S	150-170	-	25-40
Sponge cake with topping	Baking tray	3	L	160-170	1	30-40
Sponge cake, 2 levels	Universal pan + baking tray	3+1	L	140-160	-	30-50
Shortcrust tart with dry topping	Baking tray	3	=	170-190	-	25-35
Shortcrust tart with dry topping, 2 levels	Universal pan + baking tray	3+1	L	160-170	-	35-45
Shortcrust tart with moist topping	Universal pan	3	=	160-180	-	55-65
Shortcrust tart with moist topping	Universal pan	3	S	150-170	-	55-85
Swiss flan	Universal pan	3	Ξ	200-210	-	40-50
Swiss flan	Universal pan	3	<u>\$</u>	170-190	-	45-55
Yeast cake with dry topping	Universal pan	3	L	150-170	-	25-35
Yeast cake with dry topping	Baking tray	3	L	150-160	1	20-30
Yeast cake with dry topping, 2 levels	Universal pan + baking tray	3+1	S	150-170	-	20-30
Yeast cake with moist topping	Universal pan	3	=	180-200	-	30-40
Yeast cake with moist topping * Preheat ** Preheat for 5 mins., do not use quick h	Universal pan	3	L	160-170	-	40-50

Dish	Accessories/cookware	Shelf posi- tion	Heating function	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Yeast cake with moist topping, 2 levels	Universal pan + baking tray	3+1	ک	150-170	-	45-60
Plaited loaf, savarin	Baking tray	2	ک	150-160	-	30-40
Plaited loaf, savarin	Baking tray	2	ک	150-160	2	25-35
Swiss roll	Baking tray	3	ک	180-200*	-	8-15
Swiss roll	Baking tray	3	ک	180-200*	1	10-15
Stollen with 500 g flour	Baking tray	3	ک	150-170	-	55-65
Stollen with 500 g flour	Universal pan	3	ک	140-150	2	80-90
Strudel, sweet	Universal pan	2	ک	170-180	-	50-60
Strudel, sweet	Universal pan	3	ک	180-190	2	50-60
Strudel, frozen	Universal pan	3	<u></u>	200-220	-	35-45
Strudel, frozen	Universal pan	3	L	180-200	1	35-45
Small baked items						
Small cakes	Baking tray	3	=	160**	-	20-30
Small cakes	Baking tray	3	ک	150**	-	25-35
Small cakes, 2 levels	Universal pan + baking tray	3+1	ک	150**	-	25-35
Small cakes, 3 levels	Baking trays + universal pan	4+3+1	ک	140**	-	35-45
Muffins	Muffin tray	3	ک	160-180*	-	15-25
Muffins	Muffin tray	3	ک	150-160	1	25-35
Muffins, 2 levels	Muffin trays	3+1	ک	160-180*	-	15-30
Small yeast cakes	Baking tray	3	ک	150-170	-	25-35
Small yeast cakes	Baking tray	3	ک	160-180	2	25-35
Small yeast cakes, 2 levels	Universal pan + baking tray	3+1	ک	150-170	-	25-40
Puff pastry	Baking tray	3	ک	170-190*	-	20-35
Puff pastry	Baking tray	3		200-220*	1	15-25
Puff pastry, 2 levels	Universal pan + baking tray	3+1	ک	170-190*	-	20-45
Puff pastry, 3 levels	Baking trays + universal pan	4+3+1	ک	170-190*	-	20-45
Puff pastry, flat, 4 levels	4 wire racks	4+3+2+1	ک	180-200*	-	20-35
Choux pastry	Baking tray	3		190-210	-	30-40
Choux pastry	Baking tray	3	<u></u>	200-220*	1	25-35
Choux pastry, 2 levels	Universal pan + baking tray	3+1	ک	190-210	-	35-45
Danish pastry	Baking tray	3	ک	160-180	-	20-30
Danish pastry	Baking tray	3	L	160-180	1	25-35
Biscuits						
Viennese whirls	Baking tray	3	Ξ	140-150**	-	25-40
Viennese whirls	Baking tray	3	ک	140-150**	-	25-40
Whirls, 2 levels	Universal pan + baking tray	3+1	ک	140-150**	-	30-40
Whirls, 3 levels	Baking trays + universal pan	4+3+1	ک	130-140**	-	35-55
Biscuits	Baking tray	3	ک	140-160	-	15-30
Biscuits, 2 levels	Universal pan + baking tray	3+1	L	140-160	-	15-30
Biscuits, 3 levels	Baking trays + universal pan	4+3+1	L	140-160	-	15-30
Meringue	Baking tray	3	L	80-90*	-	120-150
Meringue, 2 levels	Universal pan + baking tray	3+1	L	80-90*	-	120-180
Macaroons	Baking tray	3	ک	90-110	-	20-40
* Preheat						
** Preheat for 5 mins., do not use quick	heat function					

Dish	Accessories/cookware	Shelf posi- tion	Heating function	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.	
Macaroons, 2 levels	Universal pan + baking tray	3+1	ک	90-110	-	25-45	
Macaroons, 3 levels	Baking trays + universal pan	4+3+1	ک	90-110	-	30-50	
* Preheat							
** Preheat for 5 mins., do not use quick heat function							

Tips on baking

You want to find out whether the cake is completely cooked in the middle.	Push a cocktail stick into the highest point on the cake. If the cocktail stick comes out clean with no dough residue, the cake is ready.
The cake collapses.	Next time, use less liquid. Alternatively, set the temperature to be 10 °C lower and extend the baking time. Adhere to the specified ingredients and preparation instructions in the recipe.
The cake has risen in the middle but is lower around the edge.	Only grease the base of the springform cake tin. After baking, loosen the cake carefully with a knife.
The fruit juice overflows.	Next time, use the universal pan.
Small baked items stick to one another during baking.	There should be a gap of approx. 2 cm around each item. This gives enough space for the baked items to expand well and brown on all sides.
The cake is too dry.	Set the temperature 10 °C higher and shorten the baking time.
The cake is generally too light in colour.	If the shelf position and the cookware are correct, then you should increase the temperature if necessary or extend the baking time.
The cake is too light on top, and too dark underneath.	Bake the cake one level higher in the oven the next time.
The cake is too dark on top, and too light underneath.	Bake the cake one level lower in the oven the next time. Select a lower temperature and extend the baking time.
Cakes baked in a tray or tin are too brown at the back.	Place the baking tray in the middle of the accessories, not directly against the back wall.
The whole cake is too dark.	Select a lower temperature next time and extend the baking time if necessary.
The cake is unevenly browned.	Select a slightly lower temperature. Protruding greaseproof paper can affect the air circulation. Always cut greaseproof paper to size. Ensure that the baking tin does not stand directly in front of the openings in the cooking compartment back wall. When baking small items, you should use similar sizes and thicknesses wherever possible.
You were baking on several levels. The items on the top baking tray are darker than those on the lower baking tray.	Always use CircoTherm when baking on several levels. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.
The cake looks good, but is not cooked properly in the middle.	Use a lower temperature and bake slightly longer; if necessary, add slightly less liquid. For cakes with a moist topping, bake the base first. Sprinkle it with almonds or breadcrumbs and then place the topping on top.
The cake cannot be turned out of the dish when it is turned upside down.	Allow the cake to cool down for 5 to 10 minutes after baking. If it still sticks, carefully loosen the cake around the edges again using a knife. Turn the cake tin upside down again and cover it several times with a cold, wet cloth. Next time, grease the baking tin/dish and sprinkle with breadcrumbs.

Bread and rolls

Your appliance offers you a range of heating types for baking bread and rolls. You can find the ideal settings for many dishes in the settings tables.

Also refer to the notes in the section on allowing dough to rise.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

Steam- assisted baking

Bread and bread rolls get a more crispy crust and a more glossy surface if baked with the steam assist mode. The baked item does not dry out so much.

Steam-assisted baking is only possible on one level.

Shelf positions

Use the indicated shelf positions.

Baking on one level

When baking on one level, use the following shelf positions:

Tall baked items: Level 2Flat baked items: Level 3

If you are using CircoTherm Hot air as the type of heating, you can choose between levels 1, 2, 3 and 4.

Baking on two levels

Use CircoTherm. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

Universal pan: Level 3 Baking tray: Level 1

Baking tins/dishes on the wire rack

First wire rack: Level 3 Second wire rack: Level 1

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another or offset and vertically stacked in the cooking compartment.

Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

Baking tins

Dark- coloured metal baking tins are most suitable.

Tinplate baking tins, ceramic dishes and glass dishes extend baking time and mean that the baked item will not brown evenly. If you wish to bake using these baking tins/dishes and using top/bottom heating, slide in the tin/dish at level 1.

The baking tins must be resistant to heat and steam for use in steam-assisted baking.

Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

Frozen products

Do not use frozen products that are heavily frosted. Remove any ice on the food.

Some frozen products may be unevenly pre-baked. Uneven browning may remain even after baking.

Recommended setting values

The table lists the optimal heating type for various kinds of bread and bread roll. The temperature and baking

time depend on the amount and consistency of the dough/mixture. For this reason, the table specifies setting ranges. Try using the lower values to start with. A lower temperature will result in more even browning. You can use a higher setting next time if necessary.

Note: Baking times cannot be reduced by using higher temperatures. The bread or bread rolls would only be cooked on the outside, but would not be fully baked in the middle.

The setting values apply to food that is placed into a cold cooking compartment; by doing this, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated baking times by several minutes.

Preheating is necessary for selected food, and this is indicated in the table. Do not place your food or accessories into the cooking compartment until it has finished preheating. Some food turns out best if it is baked in several stages. These foods are indicated in the table.

The setting values for bread dough apply to both dough placed on a baking tray and dough placed in a loaf tin.

If you wish to follow one of your own recipes when baking, you should use the setting values listed for similar baked items in the table as reference.

Remove unused accessories from the cooking compartment. This will ensure that you achieve the best possible cooking results and energy savings of up to 20 per cent.

Caution!

Never pour water into the hot cooking compartment or place cookware containing water onto the bottom of the cooking compartment. The change in temperature can cause damage to the enamel.

Types of heating used:

- Top/bottom heating Circo-roasting

- Bread baking
- Full-surface grill

- 1 = 1 ow
- 2 = Medium
- 3 = Hiah

Dish	Accessories	Shelf position	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Bread						
White bread, 750 g	Universal pan or cake tin	2	<u></u>	210-220*	-	10-15
				180-190*	-	25-35
* Preheat						

Dish	Accessories	Shelf position	Type of heating	Tempera- ture in °C	Steam in- tensity	time in
White bread, 750 g	Universal pan or cake tin	2	<u> </u>	210-220	3	mins. 10-15
Willia Broad, 700 g	offivoroal part of barko till	_	_	180-190	-	25-35
Multigrain bread, 1.5 kg	Universal pan or cake tin	2	<u></u>	210-220*	-	10-15
. 3				180-190*	-	40-50
Multigrain bread, 1.5 kg	Universal pan or cake tin	2	<u></u>	210-220	3	10-15
g , g	·			180-190	-	45-55
Wholemeal bread, 1 kg	Universal pan	2	<u></u>	210-220*	-	10-15
, 6	·			180-190*	-	40-50
Wholemeal bread, 1 kg	Universal pan	2	<u></u>	210-220	3	10-15
	·			180-190	-	40-50
Flatbread	Universal pan	3	<u></u>	220-240	-	25-35
Flatbread	Universal pan	3	=	220-230	3	20-30
Bread rolls						
Part-cooked rolls or baguette, pre-baked	Universal pan	3	<u>&</u>	180-200	-	10-15
Part-cooked rolls or baguette, pre-baked	Baking tray	3	=	200-220	2	10-20
Bread rolls, sweet, fresh	Baking tray	3	_ _ &	150-170*	_	15-25
Bread rolls, sweet, fresh	Baking tray	3	_	150-170	3	25-35
Bread rolls, sweet, fresh, 2 levels	Universal pan + baking tray	3+1	_ _ &	150-170*	-	20-30
Bread rolls, fresh	Baking tray	3	≈ J	170-190	-	20-30
Bread rolls, fresh	Baking tray	3	⊗	200-220	2	20-30
Baguette, pre-baked, chilled	Universal pan	3	<u>\$</u>	180-200	-	20-30
Baguette, pre-baked, chilled	Baking tray	3	_	200-220	1	10-20
Regenerate bread rolls, baguettes	Wire rack	2	<u> </u>	150-160*	-	10-20
	VIIIOTAGIK		<u> </u>	100 100		10 20
Bread rolls, frozen			0	400000		10.15
Part-cooked rolls or baguette, pre-baked	·	3	<u>&</u> =	180-200	-	10-15
Part-cooked rolls or baguette, pre-baked	,	3	_	180-200	1	15-25
Lye bread, pieces of dough	Universal pan	3	<u>&</u>	180-200	-	20-25
Lye bread, pieces of dough	Baking tray	3	_	210-230	1	18-25
Croissant, pieces of dough	Universal pan	3	٨	170-190	-	30-35
Croissant, pieces of dough	Baking tray	3	٨	180-200	1	20-25
Regenerate bread rolls, baguettes	Wire rack	2		160-170	-	10-20
Toast						
Toast with topping, 4 slices	Wire rack	3	Ĭ.	190-210	-	10-15
Toast with topping, 12 slices	Wire rack	3	Ĭ.	230-250	-	10-15
Toasting bread (do not preheat)	Wire rack	4	***	290	-	4-6
* Preheat						

Pizza, quiche and savoury cakes

Your appliance offers you a range of heating types for preparing pizza, quiche and savoury cakes. You can find the ideal settings for many dishes in the settings tables.

Also refer to the notes in the section on allowing dough to rise.

Only use original accessories supplied with your appliance. These have been tailored to the cooking

compartment and the operating modes of your appliance.

Steam- assisted baking

Certain types of baked item (e.g. yeast-risen pastries) get a more crispy crust and a more glossy surface if baked with the steam assist mode. The baked item does not dry out as much.

Steam-assisted baking is only possible on one level.

Shelf positions

Use the indicated shelf positions.

Baking on one level

When baking on one level, use the following shelf positions:

Tall baked items: Level 2 Flat baked items: Level 3

If you are using CircoTherm Hot air as the type of heating, you can choose between levels 1, 2, 3 and 4.

Baking on several levels

Use CircoTherm. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time. Baking on two levels:

Universal pan: Level 3 Baking tray: Level 1

Baking tins/dishes on the wire rack

First wire rack: Level 3 Second wire rack: Level 1

Baking on four levels:

4 wire racks with greaseproof paper

First wire rack: Level 4 Second wire rack: Level 3 Third wire rack: Level 2 Fourth wire rack: Level 1

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another or offset and vertically stacked in the cooking compartment.

Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

Use the universal pan for pizzas with many toppings.

Baking tins

Dark- coloured metal baking tins are most suitable.

Tinplate baking tins, ceramic dishes and glass dishes extend baking time and mean that the baked item will not brown evenly. If you wish to bake using these baking tins/dishes and using top/bottom heating, slide in the tin/dish at level 1.

The baking tins must be resistant to heat and steam for use in steam-assisted baking.

Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

Frozen products

Do not use frozen products that are heavily frosted. Remove any ice on the food.

Some frozen products may be unevenly pre-baked. Uneven browning may remain even after baking.

Recommended setting values

The table lists the optimal heating type for various types of food. The temperature and baking time depend on the amount and consistency of the dough/mixture. For this reason, the table specifies setting ranges. Try using the lower values to start with. A lower temperature will result in more even browning. You can use a higher setting next time if necessary.

Note: Baking times cannot be reduced by using higher temperatures. The food would only be cooked on the outside, but would not be fully baked in the middle.

The setting values apply to food that is placed into a cold cooking compartment; by doing this, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated baking times by several minutes.

Preheating is necessary for selected food, and this is indicated in the table. Do not place your food or accessories into the cooking compartment until it has finished preheating.

If you wish to follow one of your own recipes when baking, you should use the setting values listed for similar baked items in the table as reference.

Remove unused accessories from the cooking compartment. This will ensure that you achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- Top/bottom heating
 Circotherm intensive
- Bread baking

- 1 = 1 ow
- 2 = Medium
- 3 = High

Dish	Accessories	Shelf position	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Pizza						
Pizza, fresh	Baking tray	3	<u>&</u>	200-220	-	25-35
Pizza, fresh, 2 levels	Universal pan + baking tray	3+1	ک	180-200	-	35-45
* Preheat						

Dish	Accessories	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Pizza, fresh, thin base	Pizza tray	2	<u>&</u>	220-230	-	20-30
Pizza, chilled	Wire rack	3	<u>&</u>	190-210	-	10-15
Pizza, frozen						
Pizza with thin base x 1	Wire rack	3	<u>&</u>	190-210	-	15-20
Pizza with thin base x 2	Universal pan + wire rack	3+1	<u></u>	190-210	-	20-25
Pizza, deep-pan, x 1	Wire rack	3	<u>&</u>	180-200	-	20-25
Pizza, deep-pan, x 2	Universal pan + wire rack	3+1	<u></u>	190-210	-	20-30
Pizza baguette	Wire rack	3	<u></u>	200-220	-	15-20
Mini pizzas	Universal pan	3	<u></u>	180-200	-	15-20
Mini pizzas, diameter 7 cm, 4 levels	4 wire racks	4+3+2+1	L	180-200*	-	20-30
Savoury cakes and quiches						
Savoury cakes in a tin	Springform cake tin, diameter 28 cm	2	<u>&</u>	170-190	-	55-65
Savoury cakes in a tin	Springform cake tin, diameter 28 cm	2	L	170-190	1	60-70
Quiche	Flan-base cake tin, black	3	<u>&</u>	190-210	-	30-40
Tarte flambée	Universal pan	3	Ξ	260-280*	-	10-15
Tarte flambée	Universal pan	2	<u></u>	200-220*	2	15-25
Pierogi	Ovenproof dish	2	Ξ	190-200	-	30-45
Pierogi	Ovenproof dish	2	ک	170-190	-	50-70
Empanada	Universal pan	3	ک	180-190	-	30-45
Empanada	Universal pan	2	ک	170-190	2	30-40
Börek	Universal pan	2	Ξ	180-200	-	35-45
Börek	Universal pan	1	<u></u>	200-220*	-	20-30
* Preheat						

Bakes and soufflés

Your appliance offers a range of heating types for preparing bakes and soufflés. You can find the ideal settings for many dishes in the settings tables.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

Shelf positions

Use the indicated shelf positions.

You can prepare dishes on one level using a baking tin/dish or the universal pan.

- Baking tins/dishes on the wire rack: Level 2
- Universal pan: Level 3

Use the steam assist function for soufflés. You do not require a water bath.

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another in the cooking compartment.

Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

Universal pan

Slide in the universal pan carefully as far as the limit stop, with the bevelled edge facing the appliance door.

Cookware

Use wide, shallow cookware for bakes and gratins. In deep, narrow cookware, food requires more time to cook, and the top will be darker.

The baking tins/dishes must be resistant to heat and steam for use in steam-assisted cooking.

Recommended setting values

In the table, you can find the ideal heating type for various bakes and soufflés. The temperature and cooking time are dependent on the quantity of food and the recipe. How well cooked a bake is will depend on the size of the cookware and the depth of the bake. Settings ranges are indicated for this reason. Try using the lower values at first. A lower temperature results in more even browning. You can increase the temperature next time if necessary.

Note: Cooking times cannot be reduced by using higher temperatures. Bakes or soufflés would only be cooked on the outside, but would be raw in the middle.

The setting values apply to dishes placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, the indicated cooking times will be reduced by several minutes.

If you wish to follow one of your own recipes when cooking, you can use similar dishes in the table as a reference.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- Top/bottom heating Circo-roasting

- Bread baking

The levels of steam intensity are indicated as numbers in the table:

- 1 = Low
- 2 = Medium
- 3 = High

Bakas 8 soufflés	A cocception/occlewere	Chalf nasi	Typo of	Tomporo	Stoom in	Cooking
Bakes & soufflés	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in
						mins.
Bake, savoury, cooked ingredients	Ovenproof dish	2	L	170-190	-	35-50
Bake, savoury, cooked ingredients	Ovenproof dish	2	Ĭ	150-170	2	40-50
Bake, sweet	Ovenproof dish	2	ک	160-180	-	40-50
Bake, sweet	Ovenproof dish	2	=	170-190	-	40-60
Lasagne, fresh, 1 kg	Ovenproof dish	2	ک	160-180	-	50-60
Lasagne, fresh, 1 kg	Ovenproof dish	2	ک	170-180	2	35-45
Lasagne, frozen, 400 g	Wire rack	2	<u></u>	190-210	-	30-35
Lasagne, frozen, 400 g	Cookware, uncovered	2	ک	180-190	2	40-50
Potato gratin, raw ingredients, 4 cm deep	Ovenproof dish	2	<u>&</u>	160-190	-	50-70
Potato gratin, raw ingredients, 4 cm deep	Ovenproof dish	2	Ž	160-170	3	50-60
Potato gratin, raw ingredients, 4 cm deep, 2 levels	Ovenproof dish	3+1	٨	150-170	-	60-80
Soufflé	Ovenproof dish	2	ک	160-180*	-	35-45
Soufflé	Ovenproof dish	2	L	170-180	2	30-40
Soufflé	Individual moulds	2	_	170-190	-	65-75

Poultry

Your appliance offers you a range of heating types for preparing poultry. You can find the ideal settings for certain dishes in the settings tables.

Roasting on the wire rack

Roasting on the wire rack is particularly well suited for larger poultry or for multiple pieces at the same time.

Slide the universal pan into the oven at the indicated shelf position with the wire rack attached. Ensure that the wire rack is correctly positioned on the universal pan. → "Accessories" on page 12

Depending on the size and type of the poultry, pour up to ½ litres of water into the universal pan. Any dripping fat will be caught. You can make a sauce from these iuices. This will also result in less smoke and ensure that the cooking compartment stays cleaner.

Roasting in cookware

Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The poultry cooks slower and does not brown so well. Use a higher temperature and/ or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

Uncovered cookware

It is best to use a deep roasting tin/dish for roasting poultry. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

Covered cookware

When cooking with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

Poultry can also become crispy in a covered roasting dish. To do so, use a roasting dish with a glass lid and set a higher temperature.

Steam- assisted roasting

Certain foodstuffs will become crispier during steamassisted cooking. Their surface becomes glossier and they dry out less.

Use uncovered cookware. Cookware must be heat- and steam-resistant.

Use steam-assisted cooking if it is indicated in the settings table. Some dishes turn out best if they are cooked in several stages. These are indicated in the table.

Grilling

Keep the appliance door closed when using the grill. Never grill with the appliance door open.

Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. Any dripping fat will be caught.

When grilling, try wherever possible to use pieces of food which are of a similar thickness and weight. This will allow them to brown evenly and remain succulent and juicy. Place the food to be grilled directly onto the wire rack.

Use tongs to turn the pieces of food you are grilling. If you pierce the meat with a fork, the juices will run out and it will become dry.

Notes

- The grill element switches itself continuously on and off; this is normal. The set temperature determines how frequently this occurs.
- Smoke may be produced when grilling.

Meat thermometer

You can cook accurately using a meat thermometer. Read important notes on using the meat thermometer in the corresponding chapter. There, you can find notes on inserting the meat thermometer, the possible heating types and additional information. → "Meat thermometer" on page 26

Recommended setting values

In the table, you can find the ideal heating type for the kind of poultry you are cooking. The temperature and

cooking time depend on the amount, composition and temperature of the food. Setting ranges are indicated for this reason. Try using the lower values at first. You can increase the temperature next time if necessary.

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry is placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, the indicated cooking times will be reduced by several minutes.

In the table, you can find specifications for poultry with default values for the weight. If you wish to cook heavier poultry, use the lower temperature in every case. If cooking multiple pieces, use the weight of the heaviest piece as a reference for determining the cooking time. The individual pieces should be approximately equal in

A general rule: the larger the poultry is, the lower the cooking temperature and the longer the cooking time.

Turn the poultry after approx. ½ to ¾ of the indicated time.

Note: Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

- For duck or goose, pierce the skin on the underside of the wings. This allows the fat to run out.
- If using duck breast, score the skin. Do not turn duck breasts.
- When you turn poultry, ensure that the breast side or the skin side is underneath at first.
- Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water or orange juice.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per

Types of heating used:

- & CircoTherm
- Top/bottom heating
- Circo-roasting
- Circotherm intensive Full-surface grill

- 1 = 1 ow
- 2 = Medium
- 3 = High

Dish	Accessories/cookware	Shelf posi- tion		Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Chicken						
Chicken, 1 kg	Wire rack	2	Ĭ	200-220	-	60-70
Chicken, 1 kg	Wire rack	2	Ĭ.	190-210	2	50-60
* Preheat for 5 mins						

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Chicken breast fillet, 150 g each (grilling)	Wire rack	4	****	275*	-	15-20
Small chicken portions, 250 g each	Wire rack	3	Ĭ	220-230	-	30-35
Small chicken portions, 250 g each	Wire rack	3	Ĭ	200-220	2	30-45
Chicken goujons, nuggets, frozen	Universal pan	3	<u></u>	190-210	-	20-25
Poulard, 1.5 kg	Wire rack	2	Ĭ	200-220	-	70-90
Poulard, 1.5 kg	Wire rack	2	Ž	180-200	2	65-75
Duck and goose						
Duck, 2 kg	Wire rack	1	~~~	180-200	-	90-110
Duck, 2 kg	Wire rack	2	L	150-160	2	70-90
			Ž.	180-190	-	30-40
Duck breast, 300 g each	Wire rack	3	Ĭ.	230-250	-	25-30
Duck breast, 300 g each	Wire rack	3	~~~	220-240	2	25-30
Goose, 3 kg	Wire rack	2	~~~	160-180	-	120-150
Goose, 3 kg	Wire rack	2	ک	130-140	2	110-120
			2	150-160	2	20-30
			Ĭ.	170-180	-	30-40
Goose legs, 350 g each	Wire rack	2	Ĭ	210-230	-	40-50
Goose legs, 350 g each	Wire rack	3	Ž	190-200	2	45-55
Turkey						
Small turkey, 2.5 kg	Wire rack	2	~~~	180-200	-	70-90
Small turkey, 2.5 kg	Wire rack	2	L	140-150	2	70-80
			Ž.	170-180	-	20-30
Turkey breast, boned, 1 kg	Cookware, covered	2	Ξ	240-260	-	80-100
Turkey thigh, with bone, 1 kg	Wire rack	2	Ĭ	180-200	-	80-100
Turkey thigh, with bone, 1 kg	Wire rack	2	Ĭ	170-180	2	80-100
* Preheat for 5 mins						

Meat

Your appliance offers you many heating types for preparing meat. You can find the ideal settings for many dishes in the settings tables.

Roasting and braising

Baste lean meat with fat as required or cover it with strips of bacon.

Score the rind crosswise. If you turn the joint when cooking, ensure that the rind is underneath at first.

When the joint is ready, turn off the oven and allow it to rest for another 10 minutes in the cooking compartment. This allows the meat juices to be better distributed. Wrap the joint in aluminium foil if necessary. The recommended standing time is not included in the cooking time specified.

Roasting on the wire rack

On the wire rack, meat will become very crispy on all sides.

Pour up to ½ litres of water into the universal pan, depending on the size and type of the meat. Dripping fat and meat juices will be caught. You can make a sauce using these juices. This will also result in less smoke and ensure that the cooking compartment stays cleaner.

Slide the universal pan into the oven at the indicated shelf position with the wire rack attached. Ensure that the wire rack is correctly positioned on the universal pan.

"Accessories" on page 12

Roasting and braising in cookware

It is more convenient to roast and braise meat in cookware. You can take the joint out of the cooking compartment more easily in the cookware, and prepare the sauce in the cookware itself.

Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Add in a little liquid for roasting if the meat is lean. A covering of approx. ½ cm depth should be applied to the base of any glass cookware.

The amount of liquid is dependent on the type of meat, the cookware material and also on whether or not a lid is used. If preparing meat in an enamelled or dark metal roasting dish, it will need a little more liquid than if cooked in glass cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The meat cooks more slowly and will not brown so much. Use a higher temperature and/or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

Uncovered cookware

Use a deep roasting tin/dish for roasting meat. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

Covered cookware

When cooking with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

The distance between the meat and the lid must be at least 3 cm. The meat may rise.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

If necessary, braise the meat first by searing it. Add water, wine, vinegar or a similar liquid to the braising liquid. A covering approx. 1-2 cm deep should be applied to the base of the cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Meat can also become crispy in a covered roasting dish. To do so, use a roasting dish with a glass lid and set a higher temperature.

Steam- assisted roasting and braising

Certain dishes become crispier if cooked using steam, and do not dry out as much.

Use uncovered cookware. Cookware must be heat- and steam-resistant.

The joints do not have to be turned.

Use steam-assisted cooking if it is indicated in the settings table. Some dishes turn out best if they are cooked in several stages. These are indicated in the table.

Grilling

Keep the appliance door closed when using the grill. Never grill with the appliance door open.

Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. Any dripping fat will be caught.

When grilling, try wherever possible to use pieces of food which are of a similar thickness and weight. This will allow them to brown evenly and remain succulent and juicy. Place the food to be grilled directly onto the

Use tongs to turn the pieces of food you are grilling. If you pierce the meat with a fork, the juices will run out and it will become dry.

Do not add salt until after the meat has been grilled. Salt draws water from the meat.

Notes

- The grill element switches itself continuously on and off; this is normal. The set temperature determines how frequently this occurs.
- Smoke may be produced when grilling.

Meat thermometer

You can cook accurately using a meat thermometer. Read important notes on using the meat thermometer in the corresponding chapter. There, you can find notes on inserting the meat thermometer, the possible heating types and additional information. → "Meat thermometer" on page 26

Recommended setting values

You can find the ideal heating type for many meat dishes in the table. Temperature and cooking time depend on the amount, composition and temperature of the food. Settings ranges are indicated for this reason. Try using the lower values at first. You can increase the temperature next time if necessary.

The setting values apply to chilled meat placed into the cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated cooking times by several minutes.

You can find information on roasts and default values for weights in the table. If you wish to roast a heavy joint of meat, you should definitely use a lower temperature. If roasting several joints, use the weight of the heaviest piece as a basis for determining the cooking time. The individual pieces should be approximately equal in size.

As a general rule: the larger a roasting joint is, the lower the cooking temperature and the longer the cooking

Turn roasting joints and grilled items after approx. ½ to 2/3 of the indicated time.

If you wish to follow one of your own recipes, you should use similar dishes as a reference. You can find additional information in the tips on roasting, braising and grilling attached to the settings table.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- Top/bottom heating
- Circo-roasting
- Full-surface grill

- 1 = Low 2 = Medium 3 = High

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Pork						
Joint of pork without rind, e.g. neck, 1.5 kg	Cookware, uncovered	2	Ž	180-190	-	110-130
Joint of pork without rind, e.g. neck, 1.5 kg	Cookware, uncovered	2	ک	180-190	1	110-130
Joint of pork with rind, e.g. shoulder, 2 kg	Wire rack	2	Ž	190-200	-	130-140
Joint of pork with rind, e.g. shoulder,	Cookware, uncovered	2	L	100	3	25-30
2 kg			L	170-180	1	70-90
			Ž	200-210	-	20-25
Pork tenderloin steak, 1.5 kg	Cookware, uncovered	2	ž	220-230	-	70-80
Pork tenderloin steak, 1.5 kg	Cookware, uncovered	2	L	170-180	1	80-90
Fillet of pork, 400 g	Wire rack	3	ž	220-230	-	20-25
Fillet of pork, 400 g	Cookware, uncovered	3	ž	210-220*	1	25-30
Smoked pork on the bone, 1 kg (with a little added water)	Cookware, covered	2	2	210-230	-	70-90
Smoked pork on the bone, 1 kg	Cookware, uncovered	2	L	160-170	1	70-80
Pork steaks, 2 cm thick	Wire rack	4	****	275	-	16-20
Pork medallions, 3 cm thick	Wire rack	4	****	290*	-	10-14
Beef						
Fillet of beef, medium, 1 kg	Wire rack	2	ž	210-220	-	40-50
Fillet of beef, medium, 1 kg	Cookware, uncovered	2	L	190-200	1	50-60
Pot-roasted beef, 1.5 kg	Cookware, covered	2	Ĭ.	200-220	-	130-160
Sirloin, medium, 1.5 kg	Wire rack	2	Ĭ.	220-230	-	60-70
Sirloin, medium, 1.5 kg	Cookware, uncovered	2	L	190-200	1	65-80
Steak, 3 cm thick, medium	Wire rack	4	****	290	-	15-20
Burger, 3-4 cm thick	Wire rack	4	***	290	-	25-30
Veal						
Joint of veal, 1.5 kg	Cookware, uncovered	2	Ĭ.	160-170	-	100-120
Joint of veal, 1.5 kg	Cookware, uncovered	2	L	170-180	1	90-110
Knuckle of veal, 1.5 kg	Cookware, uncovered	2	=	200-210	-	100-120
Knuckle of veal, 1.5 kg	Cookware, uncovered	2	L	170-180	1	100-120
Lamb						
Leg of lamb, boned, medium, 1.5 kg	Cookware, uncovered	2	ž	170-190	-	50-80
Leg of lamb, boned, medium, 1.5 kg	Cookware, uncovered	2	ž	170-180	1	80-90
Saddle of lamb on the bone***	Wire rack	2	ž	180-190	-	40-50
Saddle of lamb on the bone***	Cookware, uncovered	3	Ĭ.	200-210*	1	25-30
Lamb cutlet**	Wire rack	4	****	290	-	14-18
* Preheat ** Slide the universal pan in underneath *** Do not turn	at shelf position 2					

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Sausages						
Grilled sausages	Wire rack	4	****	290	-	10-15
Meat dishes						
Meat loaf, 1 kg	Cookware, uncovered	2	Ž	170-180	-	60-70
Meat loaf, 1 kg	Cookware, uncovered	2	L	190-200	1	70-80
* Preheat						
** Slide the universal pan in	underneath at shelf position 2					
*** Do not turn						

Tips on roasting and braising

The cooking compartment becomes very dirty.	Prepare your food in an enclosed roasting dish with higher temperature or use the grill tray. You will achieve the best roasting results if you use the grill tray. The grill tray can be bought later as a special accessory.
The roast is too dark and the crackling is burned in places, and/or the roast is too dry.	Check the shelf position and temperature. Select a lower temperature the next time and reduce the roasting time if necessary.
The crackling is too thin.	Increase the temperature or switch on the grill briefly at the end of the roasting time.
The roast looks good but the juices are burnt.	Next time, use a smaller roasting dish and add more liquid if necessary.
The roast looks good but the juices are too clear and watery.	Next time, use a larger roasting dish and add less liquid if necessary.
The meat gets burned during braising.	The roasting dish and lid must fit together well and close properly. Reduce the temperature and add more liquid when braising if necessary.

Fish

Your appliance offers you a range of heating types for preparing fish. You can find the ideal settings for many dishes in the settings tables.

The whole fish does not have to be turned. Place the whole fish into the cooking compartment in swimming position with the dorsal fin facing upwards. Placing half a potato or a small oven-proof container in the stomach cavity of the fish will provide stability.

You can tell when the fish is cooked because the dorsal fin can be removed easily.

Roasting and grilling on the wire rack

Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door.

Pour up to ½ litres of water into the universal pan, depending on the size and type of the fish. Any dripping liquid will be caught. Less smoke is generated and the cooking compartment stays cleaner.

Keep the appliance door closed when using the grill. Never grill with the appliance door open.

When grilling, try wherever possible to use pieces of food which are of a similar thickness and weight. This will allow them to brown evenly and remain succulent and juicy. Place the food to be grilled directly onto the wire rack.

Use tongs to turn the pieces of food you are grilling. If you pierce the fish with a fork, the juices will run out and it will become dry.

Notes

- The grill element switches itself continuously on and off; this is normal. The set temperature determines how frequently this occurs.
- Smoke may be produced when grilling.

Roasting and stewing in cookware

Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The fish cooks more slowly and browns less. Use a higher temperature and/or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

Uncovered cookware

To cook a whole fish, it is best to use a deep roasting tin/dish. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

Covered cookware

When cooking with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

When stewing, add two to three tablespoons of liquid and a little lemon juice or vinegar into the cookware.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

Fish can also become crispy in a covered roasting dish. Here, use a roasting dish with a glass lid and set a higher temperature.

Steam- assisted roasting

Certain dishes become crispier if cooked using steam, and do not dry out as much.

Use uncovered cookware. Cookware must be heat- and steam-resistant.

The fish does not have to be turned.

Use steam-assisted cooking if it is indicated in the settings table. Some dishes turn out best if they are cooked in several stages. These are indicated in the table.

Meat thermometer

You can cook accurately using a meat thermometer. Read important notes on using the meat thermometer in the corresponding chapter. There, you can find notes on inserting the meat thermometer, the possible heating types and additional information. → "Meat thermometer" on page 26

Recommended setting values

You can find the ideal heating type for your fish dishes in the table. The temperature and cooking time depend on the amount, composition and temperature of the food. Settings ranges are indicated for this reason. Try

using lower setting values first. You can use a higher setting next time if necessary.

The setting values are based on the assumption that chilled fish is placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated cooking times by several minutes.

In the table, you can find information for fish with default values for the weight. If you want to cook a heavier fish, you should definitely use the lower temperature. If cooking several fish, you should use the weight of the heaviest fish as a reference for determining the cooking time. The individual fish should be approximately the same size.

As a general rule: the larger a fish, the lower the cooking temperature and the longer the cooking time.

Turn any fish which is not in swimming position after approx. ½ to ¾ of the indicated time.

Note: Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- ∆ CircoTherm
- Top/bottom heating
- Circo-roasting
 Full-surface grill

- 1 = Low
- 2 = Medium
- 3 = High

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Fish						
Fish, grilled, whole 300 g, e.g. trout	Wire rack	2	Ž.	170-190	-	20-30
Fish, fried, whole 300 g, e.g. trout	Universal pan	2	ک	170-180	1	15-20
			160-170	-	5-10	
Fish, grilled, whole 1.5 kg, e.g. salmon	Wire rack	2	Ĭ	170-190	-	30-40
Fish fillets						
Fish fillet, plain, grilled	Wire rack	4	***	220*	-	15-25
Fish steaks						
Fish steak, 3 cm thick**	Wire rack	4	****	290	-	10-20
Fish, frozen						
Fish fillet, plain	Cookware, covered	2	Ξ	210-230	-	20-30
Fish fillet, au gratin	Wire rack	2	Ž.	200-220	-	45-60
* Preheat ** Slide the universal pan in underneath	at shelf position 2					

Dish	Accessories/cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.	
Fish fillet, au gratin	Cookware, uncovered	2	Ĭ.	200-220	1	35-45	
Fish fingers (turn during cooking)	Universal pan	3	_	200-220	-	20-30	
* Preheat							
** Slide the universal pan in underneath at shelf position 2							

Vegetables and side dishes

Here, you can find information for preparing grilled vegetables, potatoes and frozen potato products.

Remove unused accessories from the cooking compartment. This will allow you to achieve ideal cooking results and save energy.

Shelf positions

Use the indicated shelf positions.

Cooking on one level

Adhere to the specifications in the table.

Cooking on two levels

Use CircoTherm. Food on baking trays that are placed in the oven at the same time will not necessarily be ready at the same time.

- Universal pan: Level 3
- Baking tray: Level 1

Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

Recommended setting values

In the table, you can find the ideal heating types for various dishes. The temperature and cooking time depend on the amount and composition of the food. Setting ranges are indicated for this reason. Try using the lower values at first. A lower temperature results in more even browning. You can use a higher setting next time if necessary.

The setting values apply to dishes placed into a cold cooking compartment. If you preheat the oven, the indicated cooking times will be reduced by several minutes.

If you wish to follow one of your own recipes when cooking, you can use similar dishes in the table as a reference.

Types of heating used:

- 👃 CircoTherm
- <u>& Circotherm intensive</u>
- Bread baking
- Full-surface grill

- 1 = Low
- 2 = Medium
- 3 = High

Dish	Accessories	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Vegetable dishes						
Grilled vegetables	Universal pan	4	****	290	-	10-15
Potatoes						
Baked potatoes, halved	Universal pan	3	ک	160-180	-	45-60
Baked potatoes, halved	Universal pan	3	L	180-190	1	40-50
Potato products, frozen						
Potato rösti	Universal pan	3	<u>&</u>	200-220	-	25-35
Potato pockets, filled	Universal pan	3	<u>&</u>	190-210	-	20-30
Croquettes	Universal pan	3	<u>&</u>	200-220	-	25-35
Chips	Universal pan	3	<u>&</u>	190-210	-	25-35
Chips, 2 levels	Universal pan + baking tray	3+1	<u></u>	190-210	-	30-40

Yogurt

You can make your own yogurt using your appliance.

Making yoghurt

Remove accessories and shelf supports from the cooking compartment. The cooking compartment must be empty. Do not open the appliance door while the appliance is in operation.

- 1. Heat 1 litre of milk (3.5% fat) to 90 $^{\circ}$ C on the hob and then leave it to cool down to 40 °C. It is sufficient to heat UHT milk to 40 °C.
- 2. Stir in 150 g (chilled) yoghurt.
- 3. Pour into cups or small jars and cover with cling film.
- 4. Place the cups or jars onto the cooking compartment floor and use the settings indicated in the table.
- 5. After making the yoghurt, leave it to cool in the refrigerator.

Type of heating used:

■ ⊖ Dough proving

D	ish	Accessories	Shelf position	Type of heating		Dough proving	Cooking time in hours
Y	ogurt	Individual moulds	Cooking compart- ment floor		-	1	5-6

Eco heating functions

CircoTherm eco and Top/bottom heating eco are intelligent heating functions that allow you to gently cook meat, fish and baked items. The appliance optimally controls the supply of energy to the cooking compartment. The food is cooked in phases using residual heat. This means that it remains more succulent and browns less. Depending on the method of preparation and the type of food, it is possible to save energy. If you open the appliance door before the food has finished cooking or if you preheat the appliance, you may not be able to achieve this result.

Only use genuine accessories for your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance. Remove any accessories that are not being used from the cooking compartment.

Place the food into the empty cooking compartment before the oven is heated up. For CircoTherm eco, select a temperature of between 125 and 200 °C, and for Top/bottom heating eco, select a temperature of between 150 and 250 °C. Always keep the appliance door closed when cooking. Only cook on one level when using this function.

The CircoTherm eco heating function is used to measure both the energy consumption in air recirculation mode and the energy efficiency class. The Top/bottom heating eco heating function is used to measure the energy consumption in the conventional mode.

The CircoTherm eco heating type is used to determine the energy efficiency class.

Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

Universal pan or baking trav

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

Baking tins and cookware

Dark- coloured metal baking tins are most suitable. These allow you to make energy savings of up to 35

Cookware made from stainless steel or aluminium reflects heat like a mirror. Non-reflective cookware made from enamel, heat-resistant glass or coated, diecast aluminium is more suitable.

Tinplate baking tins, ceramic dishes or glass dishes prolong baking time, and the cake will not brown so evenly.

Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to

Recommended setting values

Here, you can find specifications for the various dishes with CircoTherm Eco and Top/bottom heating Eco. The temperature and baking time depend on the consistency and amount of the dough. Settings ranges are indicated for this reason. Try with the lower values first. A lower temperature results in more even browning. You can increase the temperature next time if necessary.

Note: Baking times can not be reduced by using higher temperatures. Cakes or baked items would only be cooked on the outside, but would not be fully cooked in the middle.

Types of heating used:

- ☼ CircoTherm eco≅ Top/bottom heating Eco

Cakes in tins Sponge Cake in a tin Sponge Cake in	Dish	Accessories/cookware	Shelf posi-	Type of	Tempera-	Cooking
Sponge cake in a tin	5.5.1	Accessories/cookmare				time in
Sponge flan base Flan base tin 2	Cakes in tins					
Sponge base, 2 eggs Flan base fin 2 X 150-170 20-30 Sponge flan, 3 eggs Springform cake tin, diameter 26 cm 2 X 160-170 30-45 Bundt yeast cake Ring cake tin 2 X 150-160 50-60 Bundt yeast cake Ring cake tin 2 X 150-170 50-60 Cakes on baking trays 3 X 150-170 25-40 Shortcrust tart with dry topping Baking tray 3 X 170-180 25-35 Swiss roll Baking tray 3 X 180-190 15-20 Platied loaf, savarin Baking tray 3 X 160-180 15-20 Small baked items Wuffin Tray 2 X 160-180 15-25 Small cakes Baking tray 3 X 170-190 25-35 Small cakes Baking tray 3 X 170-190 25-35 Small cakes Baking tray 3 X 190-200 45-50 <td>Sponge cake in a tin</td> <td>Ring tin/cake tin</td> <td>2</td> <td>eco</td> <td>140-160</td> <td>60-80</td>	Sponge cake in a tin	Ring tin/cake tin	2	eco	140-160	60-80
Sponge flan, 3 eggs Springform cake tin, diameter 26 cm 2 第 160-170 30-45 Sponge flan, 6 eggs Springform cake tin, diameter 28 cm 2 第 150-160 50-60 Bundt yeast cake Ring cake tin 2 第 150-170 50-70 Cakes on baking trays Springform cake with dry topping Baking tray 3 第 150-170 25-40 Shortcrust tart with dry topping Baking tray 3 第 170-180 25-35 Swiss roll Baking tray 3 第 180-190 15-20 Plated loaf, savarin Baking tray 3 2 160-170 25-35 Yeast cake with dry topping Baking tray 3 2 160-180 15-20 Small baked items Wuffin Wuffin Year 2 2 160-180 15-25 Small baked items Muffin Year 2 2 160-180 15-20 Small cakes Baking tray 3 2 150-160 25-35 <	Sponge flan base	Flan base tin	2	eco &	150-170	20-30
Sponge flan, 6 eggs Springform cake tin, diameter 28 cm 2 第 150-160 50-60 Bundt yeast cake Ring cake tin 2 第 150-170 50-70 Cakes on baking trays Sponge cake with dry topping Baking tray 3 第 150-170 25-40 Shows sor III Baking tray 3 第 170-180 25-35 Swiss roll Baking tray 3 第 180-190 15-20 Shell take with dry topping Baking tray 3 第 160-180 15-20 Small baked items Muffin tray 2 第 160-180 15-25 Small cakes Baking tray 3 第 150-160 25-35 Small cakes Baking tray 3 第 170-190 20-35 Purif pastry Baking tray 3 第 140-160 15-30 Biscuits Baking tray 3 第 140-160 25-35 Small yeast cakes Baking tray 3 第 140-160 25-35 <td>Sponge base, 2 eggs</td> <td>Flan base tin</td> <td>2</td> <td>eco</td> <td>150-170</td> <td>20-30</td>	Sponge base, 2 eggs	Flan base tin	2	eco	150-170	20-30
Second	Sponge flan, 3 eggs	Springform cake tin, diameter 26 cm	2	eco	160-170	30-45
Cakes on baking trays Sponge cake with dry topping Baking tray 3 \$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$	Sponge flan, 6 eggs	Springform cake tin, diameter 28 cm	2	eco	150-160	50-60
Sponge cake with dry topping Baking tray 3 \$ 150-170 25-40 Shortcrust tart with dry topping Baking tray 3 \$ 170-180 25-35 Swiss roll Baking tray 3 \$ 180-190 15-20 Platited loaf, savarin Baking tray 3 \$ 160-170 25-35 Yeast cake with dry topping Baking tray 3 \$ 160-180 15-20 Small baked items Mutifins Muffin tray 2 \$ 160-180 15-25 Small cakes Baking tray 3 \$ 150-160 25-35 Small cakes Baking tray 3 \$ 150-160 25-35 Puff pastry Baking tray 3 \$ 170-190 20-35 Choux pastry Baking tray 3 \$ 170-190 20-35 Small yeast cakes Baking tray 3 \$ 140-160 15-30 Whirits Baking tray 3 \$	Bundt yeast cake	Ring cake tin	2	eco	150-170	50-70
Shortcrust tart with dry topping Baking tray 3 \$\$\$\$ 170-180 25-35 Swiss roll Baking tray 3 \$\$\$\$\$ 180-190 15-20 Plaited loaf, savarin Baking tray 3 \$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$	Cakes on baking trays					
Swiss roll Baking tray 3 \$ 180-190 15-20 Plaited loaf, savarin Baking tray 3 \$ 160-170 25-35 Yeast cake with dry topping Baking tray 3 \$ 160-180 15-20 Small baked items Muffins Muffin tray 2 \$ 160-180 15-25 Small cakes Baking tray 3 \$ 150-160 25-35 Small pastry 3 \$ 170-190 20-35 Choux pastry Baking tray 3 \$ 190-200 40-50 Biscuits Baking tray 3 \$ 140-160 15-30 Whiris Baking tray 3 \$ 140-150 25-35 Small yeast cakes Baking tray 3 \$ 140-150 25-35 Small yeast cakes Baking tray 3 \$ 140-150 25-35 Bread and bread rolls Whittigrain bread, 1.5 kg Cake tin 2 \$ 200-210 35-45 Flatbread Universal pan 3 \$ 170-190 15-20 Bread rolls, fresh Baking tray 3 \$ 170-190 15-20	Sponge cake with dry topping	Baking tray	3	eco	150-170	25-40
Plaited loaf, savarin Baking tray 3	Shortcrust tart with dry topping	Baking tray	3	eco &	170-180	25-35
Samil baked items	Swiss roll	Baking tray	3	eco	180-190	15-20
Small baked items Muffins Muffin tray 2 \$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$	Plaited loaf, savarin	Baking tray	3	eco	160-170	25-35
Muffins Muffin tray 2 \$ 160-180 15-25 Small cakes Baking tray 3 \$ 150-160 25-35 Puff pastry Baking tray 3 \$ 170-190 20-35 Choux pastry Baking tray 3 \$ 190-200 40-50 Biscuits Baking tray 3 \$ 140-160 15-30 Whirls Baking tray 3 \$ 140-150 25-35 Small yeast cakes Baking tray 3 \$ 140-160 25-35 Bread and bread rolls Whitigrain bread, 1.5 kg Cake tin 2 \$ 200-210 35-45 Flatbread Universal pan 3 \$ 170-190 15-20 Bread rolls, sweet, fresh Baking tray 3 \$ 170-190 15-20 Bread rolls, fresh Baking tray 3 \$ 170-190 15-20 Bread rolls, fresh Baking tray 3 \$ 170-190 15-20 Bread rolls, fresh Baking tray 3 \$ 170-190 15-20 Bread rolls, fresh Baking tray 3 \$ 170-190 15-20 Bread rolls, fresh	Yeast cake with dry topping	Baking tray	3	eco	160-180	15-20
Small cakes Baking tray 3 \$ 150-160 25-35 Puff pastry Baking tray 3 \$ 170-190 20-35 Choux pastry Baking tray 3 \$ 190-200 40-50 Biscuits Baking tray 3 \$ 140-160 15-30 Whiris Baking tray 3 \$ 140-150 25-35 Small yeast cakes Baking tray 3 \$ 140-150 25-35 Bread and bread rolls Wultigrain bread, 1.5 kg Cake tin 2 \$ 200-210 35-45 Flatbread Universal pan 3 \$ 250-275 15-20 Bread rolls, sweet, fresh Baking tray 3 \$ 170-190 15-20 Bread rolls, fresh Baking tray 3 \$ 180-200 20-30 Meat Joint of pork without rind, e.g. neck, 1.5 kg Cookware, uncovered 2 \$ 180-190 120-140 Pot-roasted beef, 1.5 kg Cookware, covered 2 \$ 200-220 140-160 Joint of veal, 1.5 kg Cookware, uncovered 2 \$ 200-220 140-160 Joint of veal, 1.5 kg Cookware, covered 2 <td>Small baked items</td> <td></td> <td></td> <td></td> <td></td> <td></td>	Small baked items					
Puff pastry Baking tray 3	Muffins	Muffin tray	2	eco &	160-180	15-25
Choux pastry Baking tray 3 \$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$\$	Small cakes	Baking tray	3	eco &	150-160	25-35
Baking tray Baki	Puff pastry	Baking tray	3	eco	170-190	20-35
Whirls Baking tray 3 \$ 140-150 25-35 Small yeast cakes Baking tray 3 \$ 160-180 25-35 Bread and bread rolls Multigrain bread, 1.5 kg Cake tin 2 \$ 200-210 35-45 Flatbread Universal pan 3 \$ 250-275 15-20 Bread rolls, sweet, fresh Baking tray 3 \$ 170-190 15-20 Bread rolls, fresh Baking tray 3 \$ 180-200 20-30 Meat Joint of pork without rind, e.g. neck, 1.5 kg Cookware, uncovered 2 \$ 180-190 120-140 Pot-roasted beef, 1.5 kg Cookware, covered 2 \$ 200-220 140-160 Joint of veal, 1.5 kg Cookware, uncovered 2 \$ 170-180 110-130 Fish Fish Fish, braised, whole 300 g, e.g. trout Cookware, covered 2 \$ 190-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 \$ 190-210 45-55	Choux pastry	Baking tray	3	eco	190-200	40-50
Bread and bread rolls Baking tray 3 ■ 160-180 25-35 Multigrain bread, 1.5 kg Cake tin 2 ● 200-210 35-45 Flatbread Universal pan 3 ● 250-275 15-20 Bread rolls, sweet, fresh Baking tray 3 ● 170-190 15-20 Bread rolls, fresh Baking tray 3 ● 180-200 20-30 Meat Joint of pork without rind, e.g. neck, 1.5 kg Cookware, uncovered 2 ● 180-190 120-140 Pot-roasted beef, 1.5 kg Cookware, covered 2 ● 180-190 120-140 Joint of veal, 1.5 kg Cookware, uncovered 2 ● 170-180 110-130 Fish Fish Fish, braised, whole 300 g, e.g. trout Cookware, covered 2 ● 190-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 ● 190-210 45-55	Biscuits	Baking tray	3	eco	140-160	15-30
Bread and bread rolls Multigrain bread, 1.5 kg Cake tin 2 00-210 35-45 Flatbread Universal pan 3 00-275 15-20 Bread rolls, sweet, fresh Baking tray 3 00-200 20-30 Meat Joint of pork without rind, e.g. neck, 1.5 kg Cookware, uncovered 2 00-220 140-160 Pot-roasted beef, 1.5 kg Cookware, covered 2 00-220 140-160 Joint of veal, 1.5 kg Cookware, uncovered 2 00-220 140-160 Fish Fish, braised, whole 300 g, e.g. trout Cookware, covered 2 00-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 00-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 00-210 25-35	Whirls	Baking tray	3	eco	140-150	25-35
Multigrain bread, 1.5 kg Cake tin 2	Small yeast cakes	Baking tray	3	eco	160-180	25-35
Flatbread Universal pan 3 5 250-275 15-20 Bread rolls, sweet, fresh Baking tray 3 5 170-190 15-20 Bread rolls, fresh Baking tray 3 5 180-200 20-30 Meat Joint of pork without rind, e.g. neck, 1.5 kg Cookware, uncovered 2 5 180-190 120-140 Pot-roasted beef, 1.5 kg Cookware, covered 2 5 200-220 140-160 Joint of veal, 1.5 kg Cookware, uncovered 2 5 170-180 110-130 Fish Fish, braised, whole 300 g, e.g. trout Cookware, covered 2 5 190-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 5 190-210 45-55	Bread and bread rolls					
Bread rolls, sweet, fresh Baking tray 3 ■ 170-190 15-20 Bread rolls, fresh Baking tray 3 ■ 180-200 20-30 Meat Joint of pork without rind, e.g. neck, 1.5 kg Cookware, uncovered 2 ■ 180-190 120-140 Pot-roasted beef, 1.5 kg Cookware, covered 2 ■ 200-220 140-160 Joint of veal, 1.5 kg Cookware, uncovered 2 ■ 170-180 110-130 Fish Fish, braised, whole 300 g, e.g. trout Cookware, covered 2 ■ 190-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 ■ 190-210 45-55	Multigrain bread, 1.5 kg	Cake tin	2	eco	200-210	35-45
Bread rolls, fresh Baking tray 3	Flatbread	Universal pan	3	eco	250-275	15-20
Meat Joint of pork without rind, e.g. neck, 1.5 kg Cookware, uncovered 2 5 180-190 120-140 Pot-roasted beef, 1.5 kg Cookware, covered 2 5 200-220 140-160 Joint of veal, 1.5 kg Cookware, uncovered 2 5 170-180 110-130 Fish Fish, braised, whole 300 g, e.g. trout Cookware, covered 2 5 190-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 5 190-210 45-55	Bread rolls, sweet, fresh	Baking tray	3	eco	170-190	15-20
Joint of pork without rind, e.g. neck, 1.5 kg Cookware, uncovered 2 2 200-220 140-160 Joint of veal, 1.5 kg Cookware, uncovered 2 170-180 110-130 Fish Fish, braised, whole 300 g, e.g. trout Cookware, covered Cookware, covered 2 190-210 25-35 190-210 45-55	Bread rolls, fresh	Baking tray	3	eco	180-200	20-30
Pot-roasted beef, 1.5 kg Cookware, covered 2	Meat					
Pot-roasted beef, 1.5 kg Cookware, covered 2 200-220 140-160 Joint of veal, 1.5 kg Cookware, uncovered 2 170-180 110-130 Fish Fish, braised, whole 300 g, e.g. trout Cookware, covered 2 190-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 190-210 45-55	Joint of pork without rind, e.g. neck, 1.5 kg	Cookware, uncovered	2	eco	180-190	120-140
Fish, braised, whole 300 g, e.g. trout Cookware, covered 2 190-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 190-210 45-55	Pot-roasted beef, 1.5 kg	Cookware, covered	2		200-220	140-160
Fish, braised, whole 300 g, e.g. trout Cookware, covered 2 = 190-210 25-35 Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 = 190-210 45-55	Joint of veal, 1.5 kg	Cookware, uncovered	2		170-180	110-130
Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 😇 190-210 45-55	Fish					
Fish, braised, whole 1.5 kg, e.g. salmon Cookware, covered 2 😇 190-210 45-55	Fish, braised, whole 300 g, e.g. trout	Cookware, covered	2	eco	190-210	25-35
	Fish, braised, whole 1.5 kg, e.g. salmon	Cookware, covered	2		190-210	
	Fish fillet, plain, braised	Cookware, covered	2		190-210	15-25

Acrylamide in foodstuffs

Acrylamide is mainly produced in grain and potato products prepared at high temperatures, such as potato

crisps, chips, sliced bread, bread rolls, bread or fine baked goods (biscuits, gingerbread, spiced biscuit).

Tips for keeping acrylam	de to a minimum	
General	 Keep cooking times as short as possible. Cook food until it is golden brown, but not too dark. Large, thick pieces of food contain less acrylamide. 	
Baking	With top/bottom heating at max. 200° C. With hot air at max. 180° C.	

Tips for keeping acrylamic	de to a minimum
Biscuits	With top/bottom heating at max. 190 °C.
	With hot air at max. 170 °C.
	Egg or egg yolk reduces the production of acrylamide.
Oven chips	Spread out a single layer evenly on the baking tray. Cook at least 400 g at once on a baking tray so that the chips do not dry out.

Slow cook

Slow cooking is a technique for cooking food over a long period at low temperatures. For this reason, it is also called "low-temperature cooking".

Slow cooking is ideal for all prime cuts (e.g. tender portions of beef, veal, pork, lamb or poultry) which are to be cooked "à point". The meat will remain succulent and tender.

The benefit of this cooking method is that it allows lots of scope for menu planning because slow-cooked meat is easy to keep warm. You do not have to turn the meat when cooking. Keep the appliance door closed in order to maintain an even cooking climate.

Only use fresh, clean and hygienic meat without bones. Carefully remove sinews and fat from around the edge. Fat develops a strong, distinct flavour during slow cooking. You can also use seasoned or marinated meat. Do not use defrosted meat.

Meat can be carved immediately following slow cooking. No standing time is required. Due to the special cooking method, the meat looks pink, but is not raw or undercooked.

Note: Delayed-start operation with an end time is not possible for the slow cooking heating type.

Cookware

Use shallow cookware, e.g. a glass/porcelain serving dish. Place the cookware into the cooking compartment to preheat it.

Always place the uncovered cookware onto the wire rack at level 2.

You can find additional information in the tips on slow cooking attached to the settings table.

Your appliance features the heating type "Slow cook". Only start operation when the cooking compartment has fully cooled down. Allow the cooking compartment to warm up for approx. 15 minutes with the cookware inside.

Sear the meat on the hotplate at a very high heat and for a sufficiently long time on all sides, even on the ends. Place into the preheated cookware right away. Place the cookware containing the meat into the cooking compartment once again and cook slowly.

Recommended setting values

The slow cooking temperature and cooking time are dependent on the size, thickness and quality of the meat. Different settings ranges are indicated for this reason.

Type of heating used:

■ Solution Low temperature cooking

Di I		01 14 1				0 11
Dish	Cookware	Shelf posi- tion	Heating function	Searing time in mins	Tempera- ture in °C	Cooking time in mins
Poultry						
Duck breast, medium rare, 300 g each	Cookware, uncovered	2	8	6-8	90*	45-60
Chicken breast fillet, 200 g each, well done	Cookware, uncovered	2	<u>S</u>	4	120*	45-60
Turkey breast, boned, 1 kg, well done	Cookware, uncovered	2	8	6-8	120*	110-130
Pork						
Pork tenderloin steak, 5-6 cm thick, 1.5 kg	Cookware, uncovered	2	<u>©</u>	6-8	80*	130-180
Fillet of pork, whole	Cookware, uncovered	2	8	4-6	80*	45-70
Beef						
Joint of beef (rump), 6-7 cm thick, 1.5 kg	Cookware, uncovered	2	<u>S</u>	6-8	100*	150-180
Fillet of beef, 1 kg	Cookware, uncovered	2	8	4-6	80*	90-120
Sirloin, 5-6 cm thick	Cookware, uncovered	2	<u>S</u>	6-8	80*	120-180
Beef medallions/rump steak, 4 cm thick	Cookware, uncovered	2	<u>S</u>	4	80*	30-60
* Preheat						

Dish	Cookware	Shelf position	Heating function	Searing time in mins	Tempera- ture in °C	Cooking time in mins
Veal						
Joint of veal, 4-5 cm thick, 1.5 kg	Cookware, uncovered	2	8	6-8	80*	80-140
Joint of veal, 7-10 cm thick, 1.5 kg	Cookware, uncovered	2	8	6-8	80*	140-200
Fillet of veal, whole, 800 g	Cookware, uncovered	2	8	4-6	80*	70-120
Veal medallions, 4 cm thick	Cookware, uncovered	2	8	4	80*	30-50
Lamb						
Saddle of lamb, boneless, 200 g each	Cookware, uncovered	2	<u>8</u>	4	80*	30-45
Leg of lamb, boned, medium, 1 kg, tied	Cookware, uncovered	2	8	6-8	95*	120-180
* Preheat						

Tips for slow cooking

Slow-cooking duck breast.	Place the cold duck breast into a pan and fry the skin side first. After slow cooking, grill for 3 to 5 minutes until crispy.
The slow-cooked meat is not as hot as conventionally roasted meat.	So that the roasted meat does not cool so quickly, warm the plates and serve the sauces very hot.

Drying

You can achieve outstanding drying results with CircoTherm. With this type of preserving, flavourings are concentrated by the dehydration.

Only use unblemished fruit, vegetables and herbs and wash them thoroughly. Line the wire rack with greaseproof paper or parchment paper. Drain the excess water from the fruit and dry it.

If necessary, cut it into equal chunks or thin slices. Place unpeeled fruit onto the dish with the sliced surfaces facing upwards. Ensure that neither fruit nor mushrooms overlap on the wire rack.

Grate vegetables and then blanch them. Allow the blanched vegetables to drain off and distribute them evenly on the wire rack.

Dry herbs on the stem. Position the herbs evenly and slightly heaped on the wire rack.

Use the following shelf positions for drying:

- 1 wire rack: Level 3
- 2 wire racks: Level 3+1

Turn very juicy fruit and vegetables several times. After drying, remove the dried products from the paper immediately.

Recommended setting values

In the table, you can find settings for drying various foodstuffs. The temperature and cooking time are dependent on the type, moisture, ripeness and thickness of the food to be dried. The longer you leave the food to be dried, the better it will be preserved. The thinner the slices are, the quicker the drying process will be and the more aromatic the dried food will remain. Setting ranges are indicated for this reason.

If you wish to dry additional foodstuffs, you should use similar foodstuffs in the table as a reference.

Type of heating used:

Fruit, vegetables and herbs	Accessories	Type of heating	Tempera- ture in °C	Cooking time in hours
Pomes (apple rings, 3 mm thick, 200 g per wire rack)	1-2 wire racks	L	80	5-9
Stone fruit (plums)	1-2 wire racks	L	80	8-10
Root vegetables (carrots), grated, blanched	1-2 wire racks	L	80	5-8
Sliced mushrooms	1-2 wire racks	L	60	6-9
Herbs, washed	1-2 wire racks	L	60	2-6

Preserving

You can preserve fruit and vegetables using your appliance.

Warning – Risk of injury!

If the food is preserved incorrectly, the preserving jars may burst. Follow the instructions for preserving.

Use only clean and undamaged preserving jars. Only use heat-resistant, clean and undamaged rubber rings. Check clips and clamps in advance.

For each preserving process, only use preserving jars that are the same size and contain the same food. In the cooking compartment, you can preserve the contents of a maximum of six 1/2, 1 or 11/2-litre preserving jars at the same time. Do not use jars that are larger or taller than this. The lids could rupture.

Preserving jars must not touch one another in the cooking compartment during the preserving process.

Preparing fruit and vegetables

Only use fruit and vegetables that are in good condition. Wash them thoroughly.

Peel, core and chop fruit and vegetables appropriate to their type and fill the preserving jars with them up to approx. 2 cm below the rim.

Fill the preserving jars with the fruit along with a hot, skimmed sugar solution (approx. 400 ml for a 1-litre jar). For one litre of water:

- Approx. 250 g sugar for sweet fruit
- Approx. 500 g sugar for sour fruit

Vegetables

Fill the jars with the vegetables along with hot, boiled water.

Wipe the rims of the jars, as they must be clean. Place a damp rubber ring and a lid on each jar. Seal the jars with clamps. Place the jars into the universal pan so that they do not touch each other. Pour 500 ml hot water (approx. 80 °C) into the universal pan. Use the settings indicated in the table.

Ending the preserving process

After a short while, small bubbles will form at short intervals. Switch off the appliance once all preserving jars are bubbling. Remove the jars from the cooking compartment after the indicated cooling time.

Vegetables

After a short while, small bubbles will form at short intervals. As soon as all preserving jars are bubbling, reduce the temperature to 120 °C and allow the jars to continue to bubble in the closed cooking compartment as indicated in the table. After this time has elapsed, switch off the appliance and make use of the residual heat for several minutes as indicated in the table.

After preserving, remove the jars from the cooking compartment and place them onto a clean cloth. Do not place these hot jars onto a cold or damp surface, as they may crack. Cover the preserving jars to protect them from draughts. Only remove the clamps once the iars are cold.

Recommended setting values

The indicated times in the settings table are average values for preserving fruit and vegetables. They may be influenced by room temperature, the number of jars, quantity, heat and quality of the jar contents. The specifications are based on 1-litre round jars. Before you switch off the appliance or change the cooking mode, check whether the contents of the jars are bubbling as they should. The bubbling process starts after approx. 30-60 minutes.

Type of heating used:

■ & CircoTherm

Preserving	Cookware	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Vegetables, e.g. carrots	1-litre preserving jars	1	ک	160-170	Before it starts bubbling:30-40
				120	When it starts to bubble: 30-40
				-	Residual heat: 30
Vegetables, e.g. cucumbers	egetables, e.g. cucumbers 1-litre preserving jars 1 👃	٨	160-170	Before it starts bubbling: 30-40	
			-	Residual heat: 30	
Stone fruit, e.g. cherries, damsons	1-litre preserving jars	1	L	160-170	Before it starts bubbling:30-40
			-	Residual heat:35	
Pomes, e.g. apples, strawberries 1-litre p	1-litre preserving jars	1	L	160-170	Before it starts bubbling:30-40
				-	Residual heat: 25

Allowing the dough to prove at dough proving setting

Yeast dough will prove considerably more quickly using the "Dough proving" heating type than at room temperature and does not dry out. Only start operation when the cooking compartment has fully cooled down. Always allow yeast dough to prove twice. Observe the specifications in the settings tables for the 1st and 2nd proving processes (dough fermentation and final fermentation).

Dough fermentation

Position the dough bowl on the wire rack for the dough fermentation. Use the settings indicated in the table.

Do not open the appliance door during the proving process, as moisture will escape. Do not cover the dough.

Final fermentation

Place your baked item into the oven at the shelf position indicated in the table.

Wipe moisture from the cooking compartment before baking.

Recommended setting values

The temperature and proving time are dependent on the type and quantity of the ingredients. The values in the table are therefore only meant to be average values.

Type of heating used:

■ ⊖ Dough proving

Dish	Accessories/cookware	Shelf posi-	Type of	Step	Dough	Cooking
3	7100000011007.0001111110	tion	heating		proving	time in mins.
Yeast dough, sweet						
E.g. small baked items	Bowl	2		Dough fer- mentation	1	30-45
	Universal pan	2		Final fermen- tation	1	10-20
Rich dough, e.g. panettone	Bowl	2		Dough fer- mentation	2	40-90
	Tin on wire rack	2		Final fermen- tation	2	30-60
Yeast dough, savoury						
E.g. pizza	Bowl	2		Dough fer- mentation	1	20-30
	Universal pan	2		Final fermen- tation	1	10-15
Bread dough						
White bread	Bowl	2		Dough fer- mentation	1	30-40
	Universal pan	2		Final fermen- tation	1	15-25
Multigrain bread	Bowl	2		Dough fer- mentation	1	25-40
	Universal pan	2		Final fermen- tation	1	10-20
Bread rolls	Bowl	2		Dough fer- mentation	1	30-40
	Universal pan	2	\Box	Final fermen- tation	1	15-25

Defrosting

The defrost setting is suitable for defrosting frozen fruit, vegetables and baked items. Poultry, meat and fish should ideally be defrosted in the refrigerator.

Use the following shelf positions when defrosting:

1 wire rack: Level 22 wire racks: Level 3+1

Recommended setting values

The times in the table are average values. They are dependent on the quality, freezing temperature (-18 °C) and composition of the food. Time ranges are indicated. Set the shortest time first and then extend the time if necessary.

Tip: Items which were frozen flat or portioned defrost faster than those frozen in a block.

Remove frozen food from the packaging and place it in suitable cookware onto the wire rack.

Stir the food or turn it once or twice in between. Large pieces of food should be turned several times. Occasionally split the food or remove items which have already defrosted from the cooking compartment.

Leave the defrosted food to rest for another 10 to 30 minutes in the appliance whilst it is switched off, so that the temperature balances out.

Type of heating used:

Defrost setting

Dish	Accessories	Shelf posi- tion	Type of heating	Tempera- ture in °C	Cooking time in mins.
Bread, bread rolls					
Bread & bread rolls general	Baking tray	2	8	50	40-70
Cake					
Cake, moist	Baking tray	2	*	50	70-90
Cake, dry	Baking tray	2	8	60	60-75

Reheating

Using heating type "Reheating", food is reheated gently using steam. It tastes and looks as though it has been freshly prepared. Even baked items from the day before can be re-crisped.

Use containers which are as flat, wide and heatresistant as possible. Cold containers prolong the reheating process.

Where possible, only reheat dishes of the same size and type at the same time. If this is not possible, the time required for the component with the longest reheating time should be used as a basis.

Do not cover food while it is being reheated.

Place the food in the cookware onto the wire rack or place it directly onto the wire rack at level 2.

Do not open the appliance door during operation, as a lot of steam will escape.

Recommended setting values

In the table, you can find the ideal settings for various dishes. The times specified are only average values. They are dependent on the cookware used, the quality, temperature and consistency of the food. Time ranges are indicated. Set the shortest time first and then extend the time if necessary.

The values in the table apply to dishes placed into a cold cooking compartment. Preheating is necessary for selected dishes, and this is indicated in the table.

Remove unused accessories from the cooking compartment. This will allow you to achieve ideal cooking results and save energy.

Type of heating used:

■ ② Reheat

Dish	Accessories/cookware	Shelf posi-	Type of heating	Tempera- ture in °C	Cooking time in
					mins.
Vegetables, chilled					
1 kg	Cookware, uncovered	2	<u></u>	120-130	15-25
250 g	Cookware, uncovered	2	<u></u>	120-130	5-15
Dishes, chilled					
Plated meal, 1 portion	Cookware, uncovered	2	<u></u>	120-130	15-25
Soup, stew, 400 ml	Cookware, uncovered	2	<u></u>	120-130	10-25
Side dishes, e.g. pasta, dumplings, potatoes, rice	Cookware, uncovered	2	<u></u>	120-130	8-25
Bakes, e.g. lasagne, potato gratin	Cookware, uncovered	2	<u></u>	120-140	10-25
Pizza, cooked	Wire rack	2	<u></u>	170-180*	5-15
Baked goods					
Bread rolls, baguette, baked	Wire rack	2	<u></u>	150-160*	10-20
Pastries (vol-au-vents)	Wire rack	2	<u> </u>	180*	4-10
Baked goods, frozen					
Pizza, cooked	Wire rack	2	<u></u>	170-180*	5-15
Bread rolls, baguette, baked	Wire rack	2	<u></u>	160-170*	10-20
* Preheat					

Keeping warm

You can keep cooked dishes warm using the "Keeping warm" heating type. This will avoid condensation developing, and means you will not have to wipe out the cooking compartment.

Do not keep cooked dishes warm for longer than two hours. Be aware that some dishes may continue cooking whilst being kept warm. Cover the dishes if necessary.

Test dishes

These tables have been produced for test institutes to facilitate appliance testing.

As per EN 60350-1.

Baking

Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

Shelf positions for baking on two levels:

- Universal pan: Level 3 Baking tray: Level 1
- Baking tins/dishes on the wire rack First wire rack: Level 3 Second wire rack: Level 1

Shelf positions for baking on three levels:

Baking tray: Level 4 Universal pan: Level 3 Baking tray: Level 1

Apple pie

Apple pie on one level: place dark-coloured springform cake tins diagonally next to each other.

Apple pie on two levels: position dark-coloured springform cake tins above each other so that they are offset.

Cakes in tinplate springform cake tins: bake on one level with top/bottom heating. Place the springform cake tin onto the universal pan instead of onto the wire rack.

Fatless sponge cake

Fatless sponge cake on two levels: vertically stack springform cake tins in an offset manner on the wire racks.

Notes

- The setting values apply to dishes placed into a cold cooking compartment.
- Please note the information in the tables about preheating. The setting values are valid without rapid heating-up.
- For baking, use the lower of the indicated temperatures first.

Types of heating used:

- ∆ CircoTherm
- Top/bottom heating
- ∆ Circotherm intensive

- 1 = Low
- 2 = Medium
- \blacksquare 3 = High

Dish	Accessory	Shelf posi- tion	Type of heating	Tempera- ture in °C	Steam in- tensity	Cooking time in mins.
Baking						
Shortbread	Baking tray	3	Ξ	140-150*	-	25-40
Shortbread	Baking tray	3	ک	140-150*	-	25-40
Shortbread, 2 levels	Universal pan + baking tray	3+1	ک	140-150*	-	30-40
Shortbread, 3 levels	Baking trays + universal pan	4+3+1	ک	130-140*	-	35-55
Small cakes	Baking tray	3	Ξ	160*	-	20-30
Small cakes	Baking tray	3	ک	150*	-	25-35
Small cakes, 2 levels	Universal pan + baking tray	3+1	ک	150*	-	25-35
Small cakes, 3 levels	Baking trays + universal pan	4+3+1	ک	140*	-	35-45
Fatless sponge cake	Springform cake tin, diameter 26 cm	2	Ξ	160-170**	-	25-35
Fatless sponge cake	Springform cake tin, diameter 26 cm	2	ک	160-170**	-	30-40
Fatless sponge cake	Springform cake tin, diameter 26 cm	2	ک	150-160	1	10
					-	20-25
Fatless sponge cake, 2 levels	Springform cake tin, diameter 26 cm	3+1	ک	150-170**	-	30-50
Apple pie	2 x black plate tins, diameter 20 cm	2	$\underline{\&}$	170-180	-	60-80
Apple pie	2 x black plate tins, diameter 20 cm	2	Ξ	180-200	-	60-80
Apple pie, 2 levels	2 x black plate tins, diameter 20 cm	3+1	ک	170-190	-	70-90
* Preheat for 5 mins, do not use qui	ck heat function					

Grilling

Type of heating used:

Full-surface grill

Also slide in the universal pan. The liquid will be caught and the cooking compartment stays cleaner.

Dish	Accessories	Shelf pos tion	i- Type of heating	Tempera- ture in °C	Cooking time in mins.
Grilling					
Toasting bread*	Wire rack	4	***	290	4-6
Beefburger, 12 pieces**	Wire rack	4	***	290	25-30
* Do not preheat					
** Turn after 2/3 of the total time					











REGISTER YOUR PRODUCT ONLINE NEFF-HOME.COM



Constructa NEFF Vertriebs-GmbH | Carl-Wery-Straße 34 | 81739 Munich | Germany 9001149181 980726 en