Instruction manual

Additional information can be found in the detailed instruction manual for the hob in chapter "Cooking Assist Functions". Read it through carefully.



COOKING PASSION SINCE 1877

QUICK AND FASY

COOKING ASSIST FUNCTIONS

The Cooking Assist Functions allow you to select the best way to prepare every food as you wish. The sensors measure the temperature of the pot or pan continuously. This allows the power to be controlled with great precision to maintain an adequate temperature and provide perfect cooking results.



(

cooking functions

These functions allow you to heat food, cook at low heat, boil, cook with a pressure cooker and fry with plenty of oil in the pot, all at a controlled temperature.

The wireless temperature sensor is required in order for you to use the coooking functions. If your hob does not have a sensor, you can obtain one as an accessory in specialised shops or from our Technical Assistance Service, using the reference number Z31PX10X0.

- Place the wireless temperature sensor on the pot.
- II) Place the pot with an adequate amount of liquid on the cooking zone and cover it with a lid.
- **III)** Select the cooking zone on which you have placed the saucepan with the temperature sensor.
- IV) Select the cooking class ♀ "Cooking functions".
- **V)** Press the symbol ♀ of the wireless temperature sensor.
- VI) Select the temperature level of the desired cooking function.
- VII) Wait until the water or oil has reached the appropriate temperature. The heating process is shown on the display. Then a signal sounds.
- VIII) Remove the lid and add the food. Cook with the lid on. Please note: If you use the Frying function in a pot with a lot of oil, keep the lid off whilst frying.

Cooking in a

pressure cooker,

e.g. chicken, stew

Instruction manual

Additional information can be found in the detailed instruction manual for the hob in chapter "Cooking Assist Functions". Read it through carefully.



COOKING PASSION SINCE 1877

QUICK AND FASY

COOKING ASSIST FUNCTIONS

The Cooking Assist Functions allow you to select the best way to prepare every food as you wish. The sensors measure the temperature of the pot or pan continuously. This allows the power to be controlled with great precision to maintain an adequate temperature and provide perfect cooking results.

FRYING SENSOR

This function can be used to fry food while maintaining the suitable frying pan temperature.

- I) Place the empty frying pan on the cooking zone.
- II) Select the cooking zone on the display.
- III) Select the cooking mode ₹ "Frying sensor".
- **IV)** Select the desired frying setting.
- **V)** Wait until the frying temperature is reached. The heating process is shown on the display. Then a signal sounds.
- VI) Put the fat in the frying pan and start frying.















Heating,

keeping warm,

e.g. soups, punch



Simmering,

e.g. rice, milk

90°C



e.g. pasta, vegetables

Boiling.

100°C



120°C



Deep frying with a lot

of oil, e.g. doughnuts,

meatballs

170 °C

Preparing and reducing sauces, sautéed vegetables and frying food in extra virgin olive oil, butter or margarine.

Frying food using extra virgin olive oil, butter or

margarine, e.g.

omelettes.

Frying fish and thick food, e.g. meatballs and sausages.

Medium - low

Medium - high

Frying steaks, medium or well-done, frozen. breaded and fine foods. e.g. escalope, fresh ragout and vegetables.

Frying food at high temperatures, e.g. steaks rare, potato fritters and frozen French fries.



Very low

9001160862

2

Low

en

High

NF FSCS TFT 9001160862 EN.indd 1

70°C



The following chart shows a selection of dishes for food categories. The temperature and duration of the cooking time can vary based on the amount, the condition and the quality of the food.

ੈ Cooking Functions

))(u	Frying	Sens

	Cooking Assist Functions	Q ≡	min.		Cooking Assist Functions	Q ≡	() min.
Meat				Egg dishes			
Frying with little amount of oil							
Escalope, plain ¹) (A)	4	6-10	Frying with little amount of oil			
Escalope, breaded ¹) (A	4	6-10	Fried eggs in butter ⁷)¢	2	2-6
Fillet ²	K	4	6-10	Fried eggs in oil ²	P.	4	2-6
Chops 1) (A	3	10-15	Scrambled eggs ³) (i	2	4-9
Cordon bleu ¹)¢	4	10-15	Omelettes ⁸) (i	2	3-6
Viennese schnitzel ¹	₩	4	10-15	Pancakes ⁸)	5	1.5-2.5
Steak, rare (3 cm thick) ²	₩	5	6-8	French toast ⁸)	3	4-8
Steak, medium (3 cm thick) ²	16	5	8-12	Shredded raisin pancake ⁸	T S	3	10-15
Steak, well done (3 cm thick) 1	16	4	8-12	Boiling function			
Poultry breast (2 cm thick) 1	16	3	10-20	Boiled eggs ⁵	\$	3/100°C	5-10
Stripes of meat ³)(i)	4	7-12	مالا			
Gyros ³	Dig.	4	7-12	Vegetables and legumes			
Bacon ¹)	2	5-8	vegetables and regumes			
Minced meat ³)	4	6-10	Frying with little amount of oil			
Hamburgers (1,5 cm thick) 1) (A)	3	6-15	Garlic ³	P	2	2-10
Meatballs (2 cm thick) 1) (A)	3	10-20	Glazed onion ³	P.	2	2-10
Rissoles ¹)(i)	3	10-20	Onion rings ³		3	5-10
Pre-boiled sausages ¹) (A)	3	8-20	Courgette ¹		3	4-12
Raw sausages ¹)(i)	3	8-20	Aubergine ¹		3	4-12
Simmering function				Pepper ³		3	4-15
Sausages ⁴	ੜ੍ਹੇ	2/90°C	10-20	Green asparagus ¹	P	3	4-15
Boiling function				Mushrooms ³		4	10-15
Meatballs ⁴	ੜ੍ਹੇ	3 / 100 °C	20-30	Sautéing vegetables in oil ³		1	10-20
Chicken 4	ੜ੍ਹੇ	3 / 100 °C	60-90	Glazed vegetables ³		3	6-10
Beef ⁴	\$	3 / 100 °C	60-90	Boiling function	-		
Cooking in pressure cooker function				Broccoli ⁴	\$	3 / 100 °C	10-20
Chicken in pressure cooker 5	÷	4 / 120 °C	15-25	Cauliflower ⁴	<u> </u>	3/100°C	10-20
Beef in pressure cooker 5	÷	4 / 120 °C	15-25	Brussels sprouts ⁴		3/100°C	30-40
Deep-frying function				Green beans ⁴	<u> </u>	3/100°C	15-30
Chicken portions ⁶	₽ P	5 / 170 °C	10-15	Chickpeas ⁵	÷	3/100°C	60-90
Meatballs ⁶		5 / 170 °C	10-15	Peas ⁴	± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ±	3/100°C	15-20
~				Lentils ⁵	<u> </u>	3/100°C	45-60
Fish				Cooking in pressure cooker function	~	37 100 C	15 00
Frying with little amount of oil				Vegetables in pressure cooker ⁵	± ±	4 / 120 °C	3-6
Fish fillet, plain ¹	P.	4	10-20	Chickpeas in pressure cooker ⁵	Ť.	4 / 120 °C	25-35
Fish fillet, breaded ¹	P.	3	10-20	Beans in pressure cooker ⁵	± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ±	4 / 120 °C	25-35
Prawns ¹	16	4	4-8	Lentils in pressure cooker ⁵	± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ±	4 / 120 °C	10-20
Scampi ¹) (A)	4	4-8		×	4/120 C	10-20
Frying fish, whole 1		3	10-20	Deep-frying function	<u> </u>	F /17000	
Simmering function	-	-		Deep-frying breaded vegetables 6	ਵੈ	5 / 170 °C	4-8
Stewed fish ⁴	1	2/90°C	15-20	Deep-frying vegetables in beer batter ⁶	\$	5 / 170 °C	4-8
Deep-frying function	-		.5 20	Deep-frying breaded mushrooms ⁶	Ť.	5 / 170 °C	4-8
Deep-frying fish in beer-batter ⁶	₩	5 / 170 °C	10-15	Deep-frying mushrooms in beer batter ⁶	÷	5 / 170 °C	4-8
Deep-frying breaded fish ⁶		5 / 170 °C	10-15				
Deep if ying breaded fish	~	3/1/0 C	10-13				

¹ Turn several times. / ² Add the oil and food to the frying pan after the signal sounds. / ³ Stir regularly. / ⁴ Heat and cook with the lid on. Add the food after the signal sounds.
⁵ Add the food right at the beginning. / ⁶ Heat the oil with the lid on. Fry in portions with the lid off.

	Cooking Assist Functions	® ≡	min.		Cooking Assist Functions	∬ ≡	min.
Potatoes				Desserts			
Frying with little amount of oil				Simmering function			
Potatoes boiled in their skin ³	100	5	6-12	Rice pudding ³	₽ D	2/90°C	40-50
Fried potatoes made from raw potatoes ³	P	4	15-25	Porridge oats ³	± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ±	2/90°C	10-15
Potato pancakes ⁸	J@	5	2.5-3.5	Chocolate pudding ³	₽	2/90°C	3-5
Swiss rösti ⁷	J@	2	50-55	Boiling function	1,2,	2,30 0	3 3
Glazed potatoes ³	J@	3	15-20	Compote ⁵	Ů.	3/100°C	15-25
Simmering function				Deep-frying function			
Potato dumplings ⁴	호	2/90°C	30-40	Deep-frying Berliners ⁶	₽ P	5 / 170 °C	5-10
Boling function				Deep-frying Doughnuts ⁶		5 / 170 °C	5-10
Boiling potatoes ⁵	호	3/100°C	30-45	Deep-frying Buñuelos ⁶	<u>ф</u>	5 / 170 °C	5-10
Cooking in pressure cooker function							
Potatoes in pressure cooker ⁵	호	4 / 120 °C	10-20	Frozen products			
							
Pasta and cereals				Frying with little amount of oil			
				Escalope ¹	*	4	15-20
Simmering function				Cordon bleu ¹	*	4	10-30
Rice ⁴	호	2/90°C	25 - 35	Poultry breast ¹	P.	4	10-30
Polenta ³	호	2/90°C	3-8	Chicken nuggets ¹	No.	4	10-15
Semolina puree ³	호	2/90°C	5 - 10	Gyros ³	T N	4	10-15
Boiling function				Kebab ³	*	4	10-15
Pasta ³	₽ P	3/100°C	7 - 10	Fish fillet, plain ¹	Die .	3	10-20
Stuffed pasta ³	₽ P	3/100°C	6 - 15	Fish fillet, breaded ¹	No.	3	10-20
Cooking in pressure cooker function				Fish fingers ¹) (i	4	8-12
Rice in pressure cooker ⁵	₽ P	4 / 120 °C	6 - 8	French Fries ³	*	5	4-6
<i>!!!</i>				Stir-fries ³		3	6-10
Soups				Spring rolls ¹		4	10-30
<u> </u>				Camembert ¹	No.	3	10-15
Simmering function	Ů,	2 /00 06	10 15	Keeping warm, heating function			
Creamy soups ³	Ä	2/90°C	10 - 15	Vegetables with cream ³	\$	1/70°C	15-20
Boiling function	A	2 /100.00	60.00	Boiling function			
Homemade stock ⁵	\$\frac{1}{2}\cdots	3/100°C	60 - 90	Green beans 4	Ž.	3/100°C	15-30
Instant soups ³	<u> </u>	3/100°C	5 - 10	Deep-frying function			
Cooking in pressure cooker function	ਫ਼ੈ	/ /120.0C	20. 20	Deep-frying French Fries ⁶	\$	5 / 170 °C	4-8
Homemade stock in pressure cooker 5 Sauces](4 / 120 °C	20 - 30	Miscellaneous			
Frying with little amount of oil				Frying with little amount of oil			
Tomato sauce with vegetables ³) (in	1	25 - 35	Camembert ¹	100	3	7-10
Béchamel sauce ³		1	10 - 20	Croûtons ³		3	6-10
Cheese sauce ³		1	10 - 20	Dried ready meals ¹⁰	76	1	5-10
	© 100	1	25 - 35	Toasting almonds ⁹	\$ P\$	4	3-15
Reducing sauces 3	<u></u>	1	15 - 25	Toasting nuts ⁹	16 Te	4	3-15
Sweet sauces ³			15 - 25	Toasting nuts 9	- P(e)	4	3-15
				Keeping warm, heating function	. <u>s</u> .	-	5 15
				Heating goulash soup ⁵	₽	1/70°C	10-20
				Heating godiash soup Heating hot spiced wine ⁵	1700 1700	1/70°C	-
				Simmering function	~	1//0 C	
				Heating milk ⁵	1	2/90°C	3-10
				ricating milk.	≂	2/30 C	2-10

⁷ Add the butter and food to the frying pan after the signal sounds. / ⁸ Total cooking time per portion. Fry one after the other. / ⁹ Add the food after the signal sounds. ¹⁰ Add the water after the signal sounds. Add the food once the water has boiled.