

## **Table of contents**

S Intended use	 	4
Important safety information	 	4
Causes of damage	 	5
Environmental protection	 	6
Getting to know your appliance  Control panel	 	7 7 8 8
Accessories  Accessories included  Inserting accessories  Optional accessories	 	9 9
Before using for the first time.  Before using for the first time.  Initial use	 . 1	0
Operating the appliance  Switching the appliance on and off  Filling the water tank  Setting and starting the appliance operation  Changing or cancelling the appliance operation  After each use	 . 1 . 1 . 1	1 2 2 3
Time-setting options  Showing and hiding the time-setting options  Setting the timer  Setting the cooking time  Start delay – "Ready at"  Checking, changing or deleting settings	 . 1 . 1 . 1	4 4 4 4
Selecting a programme	 . 1 . 1	5 5
Childproof lock	 . 1	

Basic settings	.18
Cleaning Cleaning agents Descaling Detaching and refitting the appliance door. Removing and installing the door panels Cleaning the rails	.19 .20 .21 .21
Trouble shooting  Fault table.  Replacing the cooking compartment bulb  Replacing the glass cover or seals  Changing the door seal	.24 .25 .26
Customer service	
Settings table and tips  Accessories  Ovenware  Cooking time and quantity  Distributing food evenly  Pressure-sensitive food.  Cooking a menu  Vegetables  Side dishes and pulses  Poultry and meat  Fish  Soup vegetables, miscellaneous  Dessert, compote  Reheating food  Sous-vide  Defrosting  Dough proving  Extracting juice  Preserving  Frozen products  Test dishes	.27 .27 .27 .27 .27 .28 .29 .30 .31 .34 .34 .34

Additional information on products, accessories, replacement parts and services can be found at **www.neff-international.com** and in the online shop **www.neff-eshop.com** 

## Intended use

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 2000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 15 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment the right way round.

→ "Accessories" on page 9

## Important safety information

#### Marning – Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Hot steam may escape during operation.
   Do not touch the ventilation openings. Keep children away.

#### Marning − Risk of scalding!

- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- Water in a hot cooking compartment may create hot steam. Never pour water into the cooking compartment when the cooking compartment is hot.
- When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.
- The water in the evaporator dish is still hot even after the appliance has been switched off. Do not empty the evaporator dish immediately after switching off the appliance. Allow the appliance to cool down before cleaning it.
- Hot liquid may spill over the sides of the accessory when it is removed from the cooking compartment. Remove hot accessories with care and always wear oven gloves.

#### **⚠** Warning – Risk of injury!

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- Flammable liquids can catch fire in the cooking compartment when it is hot (explosion). Do not fill the water tank with any flammable fluids (e.g. alcoholic drinks). Only fill the water tank with water or with the descaling solution that is recommended by us.

#### **∧** Warning – Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers. If the appliance is faulty, unplug the mains plug or switch off the fuse in the fuse box. Contact the after-sales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

## ➤ Causes of damage

#### Caution!

- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: Do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. The cooking compartment floor and the evaporator dish must always be kept clear. A build-up of heat may damage the appliance. Always place ovenware in a perforated cooking container or on a wire rack.
- Aluminium foil in the cooking compartment must not come into contact with the door panel. This could cause permanent discolouration of the door panel.
- Ovenware: Ovenware must be heat and steam resistant.
- Ovenware with areas of rust: Do not use any ovenware which displays areas of rust. Even the smallest spots of rust can lead to corrosion in the cooking compartment.
- Dripping liquids: When steaming with a perforated cooking container, always insert the baking tray, the universal pan or the solid cooking container underneath. Dripping liquid is caught.
- Moisture in the cooking compartment: Over an extended period of time, moisture in the cooking compartment may lead to corrosion. Allow the cooking compartment to dry after use. Do not keep moist food in the closed cooking compartment for extended periods of time. Do not store food in the cooking compartment.
- Extremely dirty seal: If the seal is very dirty, the appliance door will no longer close properly during operation. The fronts of adjacent units could be damaged. Always keep the seal clean. Never operate the appliance if the seal is damaged or missing. → "Cleaning" on page 19
- Appliance door as a seat, shelf or worktop: Do not sit on the appliance door, or place or hang anything on it. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.
- Looking after the appliance: The cooking compartment on your appliance is made of high-quality stainless steel. Improper care may lead to corrosion in the cooking compartment. Refer to the care and cleaning instructions in the instruction manual. Remove food residues from the cooking compartment as soon as the appliance has cooled.
- Hot water in the water tank: Hot water may damage the steam system. Only fill the water tank with cold water.
- Descaling solution: Do not allow any descaling solution to come into contact with the control panel or other surfaces on the appliance. This damages the surfaces. If this does happen, remove the descaling solution immediately with water.
- Cleaning the water tank: Do not clean the water tank in the dishwasher. Otherwise, the water tank will be damaged. Clean the water tank with a soft cloth and standard washing-up liquid.

## **Environmental protection**

Your new appliance is particularly energy-efficient. Here you can find tips on how to save even more energy when using the appliance, and how to dispose of your appliance properly.

#### Tips for saving energy

- Only preheat the appliance if this is specified in the recipe or in the operating instructions table.
- Open the appliance door as infrequently as possible while the food is cooking.
- When steaming, you can cook on several levels at the same time. When preparing foods with different cooking times, those with the longest cooking time should be placed in the oven first.

#### **Environmentally-friendly disposal**

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

# Getting to know your appliance

In this section, we will explain the indicators and controls. You will also find out about the various functions of your appliance.

**Note:** Depending on the appliance model, individual details and colours may differ.

#### **Control panel**

You can set your appliance's various functions on the control panel. The current settings are shown in the display.



- Display
- 2 Touch buttons
- 3 ShiftControl control element

#### **Controls**

Use the controls to set your appliance simply and directly.

#### **Touch buttons**

There are sensors under the touch buttons. Touch the corresponding touch button to select a function.

Touch button		Use	
1	On/off	Switches the appliance on or off → "Switching the appliance on and off" on page 11	
	Main menu	Selects operating modes and settings  → "Setting and starting the appliance operation" on page 12	
$\Theta$	Time-setting options	Sets the timer, cooking time or "Finished at" start delay → "Time-setting options" on page 14	
	Childproof lock	Activating and deactivating the child- proof lock → "Childproof lock" on page 17	
í	Information	Displays additional information Displays the current temperature  → "Setting and starting the appliance operation" on page 12	
DII	Start/stop	Start or pause the appliance  → "Setting and starting the appliance operation" on page 12	

#### ShiftControl control element

Use the ShiftControl control element to navigate through the lines on the display and select the settings. Settings that you can change have left and right arrows  $\langle \ \rangle$ .

Butto	n	Use
<	Left	Navigates to the left on the display
>	Right	Navigates to the right on the display
^	Up	Navigates upwards on the display
~	Down	Navigates downwards on the display

**Note:** You can also scroll through the settings values quickly by pressing and holding a button. As soon as you release the button, you stop scrolling through the values quickly.

#### Main menu

Touch the \(\begin{aligned} \text{touch button to access the main menu.} \end{aligned}\)

Menu	Use
<b>€</b> €€	Steaming Setting and starting the appropriate type of steam heating. → "Operating the appliance" on page 11
PE.	Steam programmes  Prepare dishes with steam. → "Programmes" on page 15
<b>⊕</b>	Basic settings Individually adjusting the appliance settings→ "Basic settings" on page 18
<b>*</b>	Descale  → "Cleaning" on page 19

#### Steaming menu

Your appliance has different types of heating. After switching on the appliance, you are taken directly to the Steaming menu, in which you can find the types of heating.

Heating	function	Temperature	Use
<b>≋</b>	Steam	30-100 °C	For vegetables, fish, side dishes, for extracting juice from fruit and for blanching
	Reheat	80-100 °C	For plated meals Cooked food is gently reheated. The steam ensures that the food does not dry out
	Dough proving	30-50 °C	For yeast dough Dough will rise considerably more quickly than at room temperature. The surface of the dough does not dry out
0	Sous-vide	50-95 °C	Cooking under a vacuum at low temperatures between 50 and 95 °C and 100% steam: Suitable for meat, fish, vegetables and desserts.  A vacuum-sealing machine is used to heat-seal the food in a special air-tight, heat-resistant cooking bag. The protective envelope retains the nutrients and flavours.
8	Defrost setting	30-60 °C	For fruit and vegetables The moisture gently transfers the heat to the food. The food does not dry out or lose its shape

#### Cooking compartment functions

The features of the cooking compartment make your appliance easier to use. This, for example, enables the cooking compartment to be well lit and a cooling fan to prevent the appliance from overheating.

#### Opening the appliance door

If you open the appliance door while the appliance is in operation, this pauses the programme. The operation continues to run when you close the door.

**Note:** For some types of heating, the operation continues to run even when the appliance door is open.

#### Interior lighting

When you open the appliance door, the interior lighting switches on. If the door remains open for longer than around 15 minutes, the lighting switches off again.

In most operating modes, the interior lighting will switch on as soon as the appliance is started. Once the program is complete, the lighting switches off. **Note:** You can set the interior lighting to not come on during the operation in the basic settings.  $\rightarrow$  "Basic settings" on page 18

#### Cooling fan

The cooling fan switches on and off as required. The hot air escapes above the door.

#### Caution!

Do not cover the ventilation slots. Otherwise, the appliance may overheat.

To cool the cooking compartment more quickly after operation, the cooling fan continues to run for a certain period afterwards.


**Note:** You can change how long the cooling fan continues to run in the basic settings. → "Basic settings" on page 18

## Accessories

Your appliance is accompanied by a range of accessories. Here, you can find an overview of the accessories included and information on how to use them correctly.

#### **Accessories included**

Your appliance is equipped with the following accessories:




Only use genuine accessories. They are specially adapted for your appliance.

You can buy accessories from the after-sales service, from specialist retailers or online.

#### Inserting accessories

The cooking compartment has four shelf positions. The shelf positions are counted from the bottom up.

In some appliances, the top shelf position in the cooking compartment features a grill symbol.



Evaporator dish

2 Water tank in the water tank recess

#### Caution!


- Do not place anything on the cooking compartment floor. Do not cover it with aluminium foil. A build-up of heat could damage the appliance. The cooking compartment floor and the evaporator dish must always be kept clear. Always place ovenware in a perforated cooking container or on a wire rack.
- Do not slide any accessories between the shelf positions, or they may tip.

#### **Locking function**


The accessories can be pulled out approximately halfway before they lock in place. The locking function prevents the accessories from tilting when they are pulled out.

- The accessories must be inserted into the cooking compartment the right way round for the tilt protection to work properly.
- Always insert the accessories fully into the cooking compartment so that they do not touch the appliance door.

When inserting the wire rack, ensure that the lug **b** is facing downwards and the **a** safety lug on the wire rack is at the rear and is facing upwards.



When inserting steam containers, make sure that the lug **c** is at the back and is facing downwards.



#### **Optional accessories**

You can purchase optional accessories from the aftersales service and specialist retailers, or on the Internet. You will find a comprehensive range of products for your appliance in our brochures and on the Internet.

Both availability and whether it is possible to order online differ between countries. Please see your sales documents for more details.

**Note:** Not all optional accessories are suitable for every appliance. When purchasing, please always quote the exact designation (E no.) of your appliance.

→ "Customer service" on page 26

# Steam container, perforated, size S Steam container, unperforated, size S Steam container, perforated, size S Steam container, perforated, size L Steam container, unperforated, size L Wire rack for steamer Porcelain cooking container, unperforated, size S Porcelain cooking container, unperforated, size L Decorative strip

# Before using for the first time

Before you can use your new appliance, you must make some settings. You must also clean the cooking compartment and accessories.

#### Before using for the first time

Before using the appliance for the first time, enquire about the water hardness of your tap water from your water supplier.

So that the appliance can reliably remind you to decalcify it when required, you must correctly set your water hardness range.

#### Caution!

The appliance may be damaged if unsuitable liquids are used.

Do not use distilled water, highly chlorinated tap water (>40 mg/l) or other liquids.

Only use cold, fresh tap water, softened water or uncarbonated mineral water.

#### **Notes**

- If your water is very hard, we recommend that you use softened water.
- If you only use softened water, you can set the water hardness range to "softened" in this case.
- If you use mineral water, set the water hardness range to "4 very hard".
- If you use mineral water, only use uncarbonated mineral water.

Water hardness range	Setting
0	0 softened
1 (up to 1.3 mmol/l)	1 soft
2 (1.3 - 2.5 mmol/l)	2 medium
3 (2.5 - 3.8 mmol/l)	3 hard
4 (above 3.8 mmol/l)	4 very hard

#### Initial use

As soon as the appliance is connected to the power supply, the first setting "Language" appears on the display.

#### Setting the language

- **1.** Use the  $\sim$  button to navigate to the bottom line.
- **2.** Use the 〈 or 〉 button to select the language.
- 3. Use the button to return to "Language".
- **4.** Use the button to select the next setting.

#### Setting the time

- **1.** Use the  $\sim$  button to navigate to the next line.
- **2.** Use the  $\langle$  or  $\rangle$  button to select the current time.
- **3.** Press the  $\sim$  button.
- **4.** Use the button to select the next setting.

#### Setting the date

- **1.** Use the  $\sim$  button to navigate to the next line.
- **2.** Use the  $\langle$  or  $\rangle$  button to select the current day.
- 3. Use the button to return to "Day".
- **4.** Use the button to select the next setting.
- **5.** Use the  $\sim$  button to navigate to the next line.
- **6.** Use the  $\langle$  or  $\rangle$  button to select the current month.
- 7. Use the button to return to "Month".
- 8. Use the button to select the next setting.
- **9.** Use the  $\sim$  button to navigate to the next line.
- **10.** Use the  $\langle$  or  $\rangle$  button to select the current year.
- **11.** Use the  $\frown$  button to return to "Year".
- **12.** Use the  $\rangle$  button to select the next setting.

#### Setting the water hardness

- **1.** Use the  $\sim$  button to navigate to the bottom line.
- 2. Use the 〈 or 〉 button to select the water hardness range.
- 3. Use the button to return to "Water hardness".
- **4.** Use the button to apply the settings. The initial use is complete.

#### Notes

- You can change these settings at any time in the basic settings. → "Basic settings" on page 18
- After connecting the appliance to the power or following a power cut, the settings for initial use are shown in the display.

## Calibrating the appliance and cleaning the cooking compartment

The boiling point of water depends on the air pressure. During calibration, the appliance sets itself to the pressure ratio at the installation location. This occurs automatically during the first steam operation. This results in a lot of steam.

#### Preparing the calibration

- 1. Remove the accessories from the cooking compartment.
- 2. Remove leftover packaging, such as polystyrene pellets, from the cooking compartment.
- 3. Before calibrating the appliance, wipe the smooth surfaces in the cooking compartment with a soft, wet cloth.

#### Calibrating the appliance and cleaning the cooking compartment

#### **Notes**

- The calibration can only be started once the cooking compartment is cold (room temperature).
- Do not open the appliance door during calibration. Calibration will otherwise be interrupted.
- **1.** Use the ① touch button to switch on the appliance.
- 2. Fill the water tank.  $\rightarrow$  "Filling the water tank" on page 12
- 3. Set the heating type, temperature and cooking time, then start the appliance operation. → "Setting and starting the appliance operation" on page 12

Settings		
Heating type	Steam <u></u> €	
Temperature	100 °C	
Cooking time	20 minutes	

- **4.** Use the ① touch button to switch off the appliance.
- 5. Wait until the cooking compartment has cooled
- 6. Clean the smooth surfaces with soapy water and a dish cloth.
- 7. Empty the water tank and dry the cooking compartment. → "After each use" on page 13

- So that the appliance adapts to a new installation location after moving house, reset the appliance to the factory settings. Repeat the initial use settings and the calibration.
- The appliance saves the calibration settings, even in the event of a power cut or disconnection from the mains.It must not be calibrated again.

#### Cleaning the accessories

Clean the accessories thoroughly using soapy water and a dish cloth or soft brush.

## Operating the appliance

You have already learnt about the controls and how they work. Now we will explain how to set your appliance. You will learn about what happens when you switch the appliance on and off, and how to select the operating mode.

#### Marning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.



#### Marning – Risk of scalding!

The water in the evaporator dish is still hot even after the appliance has been switched off. Do not empty the evaporator dish immediately after switching off the appliance. Allow the appliance to cool down before cleaning it.



#### ⚠ Warning – Risk of scalding!

When you open the appliance door, hot water may flow out of the appliance. When opening the door, do not stand too close to the appliance. Open the appliance door carefully. Keep children away from the appliance. If the evaporator dish overflows, do not pour more water into the water tank.

#### Switching the appliance on and off

Touch the ① touch button to switch the appliance on or

After switching off the appliance, on the display you can see how high the residual heat in the cooking compartment is.

Display	Meaning
-h-	Residual heat (between 60 °C and 100 °C)

#### **Notes**

- Certain displays and notes, such as the residual heat in the cooking compartment, remain visible on the display even when the appliance is switched off.
- After an appliance operation, the cooling fan runs on audibly until the cooking compartment has been cooled as far as possible.
- Switch off your device when you do not need to use it. If no settings are applied for a long time, the appliance switches itself off automatically.

#### Filling the water tank

When you open the appliance door, you will see the water tank on the right-hand side. Before starting the operation, fill the water tank with water.

Ensure that you have correctly set the water hardness range. → "Basic settings" on page 18

#### Caution!


The appliance may become damaged due to the use of unsuitable liquids.


Do not use distilled water, highly chlorinated tap water (> 40 mg/l) or other liquids.

Only use cold, fresh tap water, softened water or uncarbonated mineral water.


Fill the water tank before each use:


- 1. Open the appliance door.
- 2. Remove the water tank from the water tank recess (picture 1).
- 3. Fill the water tank with cold water up to the "max." mark. (Picture 2).





- Close the tank cover until you feel it engage.
- 5. Insert the filled water tank (picture 3).
- **6.** Check whether the water tank is pushed in flush with the water tank recess (picture 4).





Close the appliance door.

The water tank has been filled. You can now start the operation.

#### Refilling the water tank

If the water tank is empty, the prompt to fill the water tank appears on the display. The operation is stopped.

#### ⚠ Warning – Risk of scalding!

When you open the appliance door, hot water may flow out of the appliance. When opening the door, do not stand too close to the appliance. Open the appliance door carefully. Keep children away from the appliance. If the evaporator dish overflows, do not pour more water into the water tank.

- 1. Carefully open the appliance door.
- 2. Remove the water tank and fill it.
- Slide the water tank back in and close the appliance door.
- **4.** Start the operation. The operation continues.

#### Setting and starting the appliance operation

- 1. Touch the ① touch button to switch on the appliance.
  - This takes you directly to the steaming  $\approx$  menu.



- **2.** Use the  $\langle$  or  $\rangle$  button to select the heating function.
- 3. Use the  $\sim$  button to navigate to the next line.
- **4.** Use the  $\langle$  or  $\rangle$  button to select the temperature.



- **5.** Use the  $\sim$  button to navigate to the next line.
- **6.** Press the 〈 or 〉 button to change the cooking time. This takes you to the time-setting options menu.
- **7.** Use the  $\langle$  or  $\rangle$  button to select the cooking time.



- 8. Use the 🕒 button to exit the time-setting options menu.
- **9.** Touch the \| | touch button. The appliance starts.

#### "Fill water tank?" message

This message appears if you set a type of heating and the water tank is only half full.

If you think that the water in the water tank is sufficient for the cooking procedure, you can start the appliance.

If not, fill the water tank to the "max" mark, slide it back in and start the appliance.

#### Notes

- If you have started the steaming 

  the cooking time only begins to count down when the set temperature has been reached.
- If you open the appliance door during steaming, the appliance operation stops. After the appliance door has been closed again, the appliance must first heat up to the set temperature before the cooking time continues to count down.
- If you would like to go directly to the main menu after switching on the appliance, you can select the main menu under "Operation after switching on" in the basic settings chapter.

#### **Default values**

The appliance suggests a temperature or setting for each type of heating. You can accept this value or change it in the appropriate area.

#### **Heating bar**

As soon as a type of heating has started, the heating bar appears on the display. The heating bar shows the temperature increase in the cooking compartment.

**Note:** The temperature indicator is not displayed for the steaming  $\approx$  type of heating.

#### Displaying the current temperature

To show the current temperature on the display, press the  $\mathring{\mathbf{1}}$  touch button.

The current temperature is shown briefly only when heating up.

#### **Further information**

If the  $\mathring{\mbox{\it l}}$  touch button lights up, information can be displayed. Touch the  $\mathring{\mbox{\it l}}$  touch button to do this. The information is displayed for a few seconds.

## Changing or cancelling the appliance operation

#### Changing the appliance operation

- 1. Use the \| button to stop the operation.
- 2. Use the ✓ or button to navigate to the line for the setting that should be changed.
- **3.** Use the  $\langle$  or  $\rangle$  button to change the setting.
- Use the | | | | | touch button to start the changed operation.

**Note:** The cooling fan may continue to run while an operation is interrupted.

#### Cancelling the appliance operation

**Note:** The Descale function cannot be cancelled.

#### After each use

#### ⚠ Warning – Risk of scalding!

When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

Moisture and dirt remain in the cooking compartment after each operation. Therefore dry and clean the appliance after each use. Also empty the water tank after each use.

#### Drying the cooking compartment

#### ⚠ Warning – Risk of scalding!

The water in the evaporator dish may still be hot. Allow it to cool before wiping.

- 1. Leave the appliance door ajar until the appliance has cooled down.
- 2. Remove any dirt from the cooking compartment immediately.
- 3. Wipe out the cooled cooking compartment and evaporator dish with the cleaning sponge and dry with a soft cloth.
- Wipe the front of the units dry if condensation has formed.

#### **Emptying the water tank**

The water tank must be emptied and dried after each steam operation.

#### Caution!

- Do not dry the water tank in the hot cooking compartment. This will damage the water tank.
- Do not clean the water tank in the dishwasher. This will damage the water tank.
- **1.** Open the appliance door.
- 2. Remove the water tank and empty the residual
- **3.** Thoroughly dry the seal in the tank cover and the water tank recess in the appliance.
- 4. Insert the water tank into the water tank recess.
- 5. Close the appliance door.

## Time-setting options

Your appliance has different time-setting options.

Tim	e-setting option	Use
Ô	Timer	The timer functions like an egg timer. The appliance does not switch on and off automatically.
<b>→</b>	Cooking time	Once the set cooking time has elapsed, the appliance switches off automatically.
$\rightarrow$	Ready at	The appliance switches on automatically, and once the set cooking time has elapsed and the end time has passed, it switches off automatically.

**Note:** If you have set a time-setting option, the time interval increases if you set a higher value. Example: You can set a cooking time of up to one hour in one-minute increments; for cooking times over one hour, you can set a cooking time in five-minute increments.

#### Showing and hiding the time-setting options

To show or hide the time-setting options, touch the  $\odot$  touch button.

**Note:** After a particular length of time, the time-setting options that are shown are automatically hidden. If you have already set a cooking time, it will be applied.

#### Setting the timer

The timer can be set when the appliance is switched on or off.

- 1. Touch the ① touch button.

  The time-setting options are shown on the display.
- 2. Select the cooking time using the > button.
  Note: When the appliance is switched on, use the 
  button to navigate to the Timer ♀ line and then select the cooking time using the > button.
- Touch the ⊕ touch button to start the timer. The ⊕ symbol appears on the display. The timer counts down.

**Note:** As soon as the set time has elapsed, a signal sounds. To cancel the signal tone, touch the  $\bigcirc$  touch button.

#### Setting the cooking time

Once the set cooking time has elapsed, the appliance switches off automatically. The function can only be used in combination with a type of heating.

- 1. Touch the ① touch button.
- 2. Set the type of heating and temperature.
- 3. Touch the (b) touch button.

  The time-setting options are shown in the display.
- **4.** Use the  $\langle$  or  $\rangle$  button to set the cooking time.
  - Default value for the \( \) button = 10 minutes
  - Default value for the > button = 30 minutes
- 5. Touch the || touch button to start the set cooking time.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the ① touch button to end the audible signal.

#### Start delay - "Ready at"

The appliance switches on automatically and switches off at the preset end time. To do this, set the cooking time and determine the end time for the operation.

The start delay can only be used in combination with a type of heating.

#### **Notes**

- Ensure that food is not left in the cooking compartment for too long as it may spoil.
- It is not possible to start every type of heating with a start delay.
- 1. Slide food into the cooking compartment on a suitable accessory and close the appliance door.
- 2. Touch the ① touch button.
- 3. Set the type of heating and temperature.
- **4.** Touch the (b) touch button. The time-setting options are shown on the display.
- **5.** Select the cooking time using the > button.
- Use the 

  button to navigate to the "

  Ready at"
  line.
- 7. Select the end time using the > button.
- 8. Touch the || touch button.
  The appliance waits until the appropriate time to start the operation.

As soon as the end time has passed, a signal sounds and the appliance stops the operation automatically. To cancel the signal tone, touch the ① touch button.

#### Checking, changing or deleting settings

- Touch the touch button.
   The time-setting options are shown on the display.
- **2.** Use the  $\sim$  or  $\sim$  button to navigate through the lines.
- 3. If necessary, change the setting using the 〈 or 〉 button. Set "00:00" to delete a time function. The setting is applied automatically.

## Programmes

You can prepare food very easily using the various programmes. The programme then applies the most suitable settings.

#### Selecting a programme

#### ⚠ Warning – Risk of scalding!

Hot steam may escape when the appliance door is opened. Open the appliance door carefully during or after cooking. When opening the door, do not lean over it. Ensure that, depending on the temperature, steam is not visible.

Select the appropriate programme from the programme table. Follow the instructions for the programmes.

Note: Do not leave food which spoils easily in the cooking compartment for too long.

- **1.** Touch the  $\bigcirc$  touch button.
- 2. Use the ( or ) button to select "Steam programmes 8.".
- **3.** Use the  $\sim$  button to navigate to the next line. The food options are displayed.
- **4.** Use the  $\langle$  or  $\rangle$  button to select the required programme.
- **5.** Use the  $\sim$  button to navigate to the next line.
- 6. Touch the | touch button. The programme starts.

As soon as the cooking time has elapsed, an audible signal sounds and the appliance ends the operation automatically. Touch the (5) touch button to end the audible signal.

Some programmes offer you the opportunity to continue cooking your dish.

If you are happy with the cooking result, use the → button to select "Finish".

If you are not happy with the cooking result, you can continue cooking your dish.

#### Continue cooking

- 1. Use the  $\sim$  button to select "Continue cooking". A suggested cooking time appears on the display.
- 2. If necessary, use the \( \text{ or } \) button to adjust the suggested cooking time.
- 3. Touch the | touch button to start "Continue" cookina".

Wait until the appliance automatically applies your setting.

#### Switching off the appliance

Touch the ① touch button to switch off the appliance.

#### Cancelling

Press and hold the II touch button until the appliance operation is cancelled.

#### Information about the programmes

All programmes are designed for cooking on one level.

The cooking result may vary according to the size and quality of the food.

#### Cookware

Use the suggested cookware. All meals have been tested using this cookware. The cooking result may change if you use different cookware.

When cooking in the perforated steam container, also insert the solid steam container at level 1. Dripping liquid is caught.

#### Amount/weight

Do not fill the food more than 4 cm deep in the accessory.

The total weight must be within the specified weight range.

#### Cooking time

The displayed temperature may change during the first few minutes, as the heating-up time depends on the temperature of the food and the water, amongst other things.

#### **Preparing vegetables**

Do not season vegetables until after cooking.

#### Preparing cereal products/lentils

Weigh the food and add the correct ratio of water:

Basmati rice 1:1.5

Couscous 1:1

Brown rice 1:1.5

Lentils 1:2

Stir cereal products after cooking. The remaining water is quickly absorbed.

#### Steaming chicken breast

Do not place chicken breasts on top of each other in the cookware.

#### Steaming fish

When preparing fish, grease the perforated steam container.

Do not place whole fish or fish fillets on top of each other. Enter the weight of the heaviest fish and choose pieces as similar in size as possible.

#### **Preparing yoghurt**

Heat the milk to 90 °C on the hob. Then leave to cool to 40 °C. It is sufficient to heat UHT milk to 40 °C. Stir in 150 a (chilled) yogurt.

Pour into cups or small jars and cover with cling film. Place the cups or jars onto the steamer tray and position as indicated in the table. After preparation, leave the yogurt to cool in the refrigerator.

#### Making rice pudding

Weigh the rice and add 2.5 times the amount of milk. Ensure the level of rice and milk in the accessory is no higher than 2.5 cm. Stir after cooking. The remaining milk is quickly absorbed.

#### Making fruit compote

The programme is only suitable for fruits with stones and pips. Weigh the fruit and add approximately ½ of the water, and add sugar and spices according to taste.

#### Sterilising bottles

Always clean the bottles with a bottle brush immediately after use. Then clean them in the dishwasher.

Place the bottles in the perforated steam container so that they do not touch one another.

Dry the bottles with a clean cloth after sterilising. The process corresponds to normal sterilisation by boiling.

#### **Cooking eggs**

Pierce the eggs before cooking. Do not place eggs on top of each other.

#### **Table**

Follow the instructions for the programmes.

Programme	Notes	Accessories	Level
Steam cauliflower florets*	Florets of equal size	perforated + solid steam container	3 1
Steam broccoli florets*	Florets of equal size	perforated + solid steam container	3 1
Steam green beans*		perforated + solid steam container	3 1
Steam sliced carrots*	slices, approx. 3 mm thick	perforated + solid steam container	3 1
Steam frozen mixed vegetables	-	perforated + solid steam container	3 1
Unpeeled boiled potatoes*	medium-sized, dia. 4 - 5 cm	perforated + solid steam container	3 1
Basmati rice	max. 0.75 kg	solid steam container	2
Brown rice	max. 0.75 kg	solid steam container	2
Couscous	max. 0.75 kg	solid steam container	2
Lentils	max. 0.55 kg	solid steam container	2
Reheat cooked side dishes*		solid steam container	2
Steam fresh chicken breast	Total weight 0.2 - 1.5 kg	perforated + solid steam container	3 1
Steam fresh fish fillet	max. 2.5 cm thick	perforated + solid steam container	3 1
Steam whole fresh fish	0.3 - 2 kg	perforated + solid steam container	3 1
Yogurt in glass jars		jars + solid steam container	2
Rice pudding	-	solid steam container	2
Fruit compote*	-	solid steam container	2
Sterilising bottles*		solid steam container	2
Soft-boiled eggs*	Eggs, size M, max. 1 kg	perforated + solid steam container	3 1
Hard-boiled eggs*	Eggs, size M, max. 1.8 kg	perforated + solid steam container	3 1

## **Childproof lock**

Your appliance is equipped with a childproof lock so that children cannot switch it on accidentally or change any settings.

Your appliance has two different locks.

Lock	Activate/deactivate
Automatic childproof lock	Via the Settings menu → "Basic settings" on page 18
One-time childproof lock	Via the 🕒 touch button

**Note:** As soon as you activate the childproof lock, the control panel is locked. The ① and ① touch buttons are not included. You can deactivate the childproof lock at any time.

#### **Automatic childproof lock**

The control panel is locked so that the appliance cannot be switched on. To switch it on, the automatic childproof lock must be interrupted. After the appliance operation, the control panel is locked automatically.

#### **Activating**

- 1. Touch the ① touch button.
- 2. Touch the \(\begin{aligned}
  \text{ touch button.}
  \end{aligned}
- **3.** Use the  $\langle$  or  $\rangle$  button to select the "Settings".
- **4.** Use the  $\sim$  button to navigate to the next line.
- 5. Use the 〈 or 〉 button to select "Automatic childproof lock".
- **6.** Use the  $\sim$  button to navigate to the next line.
- 7. Use the  $\langle$  or  $\rangle$  button to select "Activated".
- **8.** Touch the  $\bigcirc$  touch button.
- Use the ✓ button to navigate to the next line to save the setting.
  - The "Automatic childproof lock" is activated. The symbol appears on the display after switching off the appliance.

#### Cancelling

- 1. Press and hold the (b) touch button until "Childproof lock deactivated" appears on the display.
- 2. Touch the ① touch button.
- 3. Switch on the required appliance operation.

#### **Deactivating**

- 1. Press and hold the (b) touch button until "Childproof lock deactivated" appears on the display.
- 2. Touch the ① touch button.
- 3. Touch the  $\bigcirc$  touch button.
- **4.** Use the  $\langle$  or  $\rangle$  button to select the "Settings".
- **5.** Use the  $\sim$  button to navigate to the next line.
- Use the 〈 or 〉 button to select "Automatic childproof lock".
- 7. Use the  $\sim$  button to navigate to the next line.
- 8. Use the ( or ) button to select "Deactivated".
- 9. Touch the \(\hat{\cap}\) touch button.
- **10.** Use the  $\sim$  button to navigate to the next line to save the setting.
  - The "Automatic childproof lock" is deactivated.
- 11. Touch the ① touch button.

#### One-time childproof lock

The control panel is locked so that the appliance cannot be switched on. To switch it on, the one-time childproof lock must be deactivated. After the appliance is switched off, the control panel is no longer locked.

#### Activating and deactivating

- Press and hold the touch button until "Childproof lock activated" appears on the display.
   The childproof lock is activated.
- 2. Press and hold the ① touch button until "Childproof lock deactivated" appears on the display. The childproof lock is deactivated.

## **Basic settings**

There are various settings available to you in order to help use your appliance effectively and simply. You can change these settings as required.

#### Changing the basic settings

- 1. Touch the ① touch button.
- 2. Touch the  $\bigcirc$  touch button.
- 3. Use the ⟨or⟩ button to select the "☺️ Settings".
- **4.** Use the  $\sim$  button to navigate to the next line.
- **5.** Use the  $\langle$  or  $\rangle$  button to select the setting.
- **6.** Use the  $\sim$  button to navigate to the next line.
- **7.** Use the  $\langle$  or  $\rangle$  button to select the setting.
- **8.** Touch the  $\bigcirc$  touch button.
- 9. To save the setting, use the  $\sim$  button to select "Save".

To discard the setting, use the  $\smallfrown$  button to select "Discard".

#### List of basic settings

Setting	Selection
Language	Select language
Time of day	Sets the current time
Date	Sets the current date
Water hardness	0 (softened)
	1 (soft)
	2 (medium)
	3 (hard)
	4 (very hard)
Audible signal duration	Short
	Medium
	Long
Button tone	Switched off (Exception: The button tone for the $\bigcirc$ touch button remains switched on)
	Switched on
Display brightness	Adjustable across 5 levels
Clock display	Digital
	Off
Lighting	On during operation
	Off during operation
Automatic childproof lock	Deactivated
	Activated
Operation after switching	Steaming
on	Main menu
	Steam programmes
Night-time dimming	Switched off
	Switched on (display dimmed between 10 p.m. and 5.59 a.m.)
Brand name logo	Display
	Do not display
Fan run-on time	Recommended
	Minimum
Factory settings	Load

## **Cleaning**

With good care and cleaning, your appliance will retain its appearance and remain fully functioning for a long time to come. We will explain here how you should correctly care for and clean your appliance.

#### ⚠ Warning. Risk of short circuit!

Do not use high-pressure cleaners or steam jet cleaners to clean your appliance.

#### Caution!

#### Risk of surface damage

Do not use

- harsh or abrasive cleaning agents
- oven cleaners
- corrosive or aggressive cleaners, or those containing chlorine
- cleaning agents with a high alcohol content If such an agent comes into contact with the front of the appliance, wash it off immediately with water.

#### Caution!

#### Risk of surface damage

If descaler comes into contact with the front of the appliance or any other sensitive surfaces, wash it off immediately with water.

Remove food residues from the cooking compartment as soon as the appliance has cooled.

Salts are very corrosive and can cause rust. Remove remains of acidic sauces (ketchup, mustard) or salted food from the cooking compartment immediately after cooling.

Do not use hard scouring pads or cleaning sponges.

#### Cleaning agents

Appliance exterior (with aluminium front)  Use soapy water and dry with a soft cloth.  Mild window cleaning agent - wipe over the aluminium front horizontally and without applying presure using a soft window cloth or a lint-free microfibre cloth.  Appliance exterior (with stainless steel front)  Use soapy water and dry with a soft cloth.  Always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Special stainless steel cleaning agents can be obtained from the after-sales service or from specialis	
Always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Spe	pliance exterior (with aluminium front)
retaillers.	pliance exterior (with stainless steel front)
Cooking compartment interior with evaporator dish  Hot, soapy water or a vinegar solution - use the enclosed cleaning sponge or a soft washing-up brush.  Caution! The cooking compartment could rust. Do not use steel pads or scourers.	
Water tank Soapy water - do not clean in the dishwasher.	ater tank
Tank recess Rub dry after every use	nk recess
Seal in the water tank lid Thoroughly dry after every use	al in the water tank lid
Rails See section: Cleaning the rails	ils
Door panels  See section: Cleaning the door panels  Caution!  Risk of surface damage  After cleaning, wipe the door panels with glass cleaner, then dry. Otherwise, stains will be cause that will not be able to be removed.	or panels
Door seal Hot soapy water	or seal
Accessories Soak in hot soapy water. Clean with a brush or washing-up sponge or in the dishwasher. If the ra are discoloured by starchy foods (e.g. rice), clean them with a vinegar solution.	cessories

#### Cleaning sponge

The enclosed cleaning sponge is very absorbent. Use the cleaning sponge only for cleaning the cooking compartment and for removing residual water from the evaporator dish.

Wash the cleaning sponge thoroughly before using for the first time. You can wash the cleaning sponge in the washing machine (hot wash).

#### Microfibre cloth

The honeycomb microfibre cloth is particularly suitable for cleaning sensitive surfaces such as glass, glass ceramic, stainless steel or aluminium (product no. 460 770, also available from our online eShop). It removes liquid and greasy deposits in one go.

#### **Descaling**

The appliance must be descaled regularly in order for it to continue operating correctly.

There are several steps in the descaling programme. For hygiene reasons, the descaling programme must be run through completely so that the appliance can be ready for operation again.

- Descale (approx. 30 minutes), then empty the evaporator dish and refill the water tank
- First rinsing cycle (20 seconds), then empty the evaporator dish
- Second rinsing cycle (20 seconds), then remove the remaining water

If descaling is interrupted (for example, due to a power failure or because the appliance is switched off), you are prompted to continue with the descaling programme after the appliance is switched back on.

The frequency with which the appliance must be descaled depends on the hardness of the water used. When only another five or fewer steam-assisted operations are possible, the appliance reminds you to descale it with a message on the display. The number of remaining operations is displayed after the appliance is switched on. You can therefore prepare for the descaling in good time.

#### Starting

#### Caution!

- Risk of damage to the appliance: Only use liquid descalers recommended by us for the descaling programme. The time the product needs to work during descaling depends on the type of descaler used. Other descalers may damage the appliance. Descaler order no. 311 680
- Descaling solution: Do not allow any descaling solution or descaler to come into contact with the control panel or other surfaces on the appliance. This damages the surfaces. If this does happen, remove the descaling solution immediately with water.
- 1. Mix 300 ml water with 60 ml liquid descaler to make a descaling solution.
- 2. Remove the water tank and fill it with descaling solution.
- 3. Once the water tank has been filled with descaling solution, push it back in again fully.
- **4.** Close the appliance door.
- 5. Touch the ① touch button.
- 6. Touch the \(\cap \) touch button.
- 7. Use the  $\langle$  or  $\rangle$  button to select "Descale  $\checkmark$ ".
- 8. Use the  $\sim$  button to navigate to the next line. The duration of the descaling programme is displayed. It cannot be changed.
- **9.** Use the  $\sim$  button to navigate to the next line.
- 10. Touch the | touch button.

The appliance is now descaled. The time counts down in the display. An audible signal sounds once descaling has finished.

#### First rinsing cycle

- **1.** Remove the descaling solution from the evaporator dish using the cleaning sponge.
- Remove the water tank, rinse thoroughly, fill with water and reinsert.
- 3. Close the appliance door.
- Touch the I touch button.
   The appliance rinses. The first rinsing cycle ends after around 20 seconds.
- 5. Open the appliance door.
- **6.** Thoroughly rinse out the cleaning sponge with water.
- **7.** Remove the remaining water in the evaporator dish using the cleaning sponge.
- 8. Proceed with the second rinsing cycle.

#### Second rinsing cycle

- 1. Remove the water tank, rinse thoroughly, fill with water and reinsert.
- **2.** Close the appliance door.
- 3. Touch the I touch button.
  The appliance rinses. The second rinsing cycle ends after around 20 seconds.
- **4.** Remove the remaining water in the evaporator dish using the cleaning sponge.
- **5.** Wipe out the cooking compartment using the cleaning sponge and then dry with a soft cloth.
- **6.** Switch off the appliance. Descaling is complete and the appliance is ready for use again.

#### Descaling the evaporator dish only

You can also use "Descale" if you do not wish to descale the whole appliance, but only the evaporator dish in the cooking compartment.

The only difference is as follows:

- 1. Mix 100 ml water with 20 ml liquid descaler to make a descaling solution.
- 2. Completely fill the evaporator dish with descaling solution.
- 3. Fill the water tank with water only.
- 4. Start "Descale" as described.


You can also descale the evaporator dish manually.


#### Detaching and refitting the appliance door

For cleaning purposes or to remove the door panels, you can detach the appliance door.

The appliance door hinges each have a locking lever. When the locking levers are closed (fig. 1), the appliance door is secured in place. It cannot be detached.

When the locking levers are open in order to detach the appliance door (fig. 2), the hinges are locked. They cannot snap shut.







## **⚠** Warning Risk of injury!

- If the hinges are not locked, they can snap shut with great force. Ensure that the locking levers are always fully closed or, when detaching the appliance door, fully open.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.

#### Detaching the appliance door

- 1. Open the appliance door fully.
- 2. Open the two locking levers on the left and right (fig. 1).
- **3.** Close the appliance door fully **a**. Take hold of the appliance door with both hands, one on the left and one on the right **b**, and pull it up and out (fig. **2**).







#### Refitting the appliance door

Follow the instructions in the reverse order to refit the appliance door.

- 1. When fitting the appliance door, ensure that both hinges are inserted straight into the opening (fig. ■). Slide the appliance door down as far as it will go.
- 2. Open the appliance door fully. Close the two locking levers (fig. 2).






3. Close the cooking compartment door.


#### Removing and installing the door panels

To facilitate cleaning, you can remove the glass panels from the appliance door.

#### Locking the appliance door


- 1. Open the appliance door fully.
- 2. Open the two locking levers on the left and right (fig. 1).
- **3.** Close the appliance door as far as it goes (fig. **2**).







#### Removing panels

- Press on the left- and right-hand sides of the cover (fig.° 1).
- **2.** Remove the cover (fig. **2**).







3. Lift out the inner panel (fig. 3) and set it down carefully on a flat surface.



- If necessary, you can remove the condensate trough for cleaning. To do this, open the appliance door fully (fig. 4).
- **5.** Tilt the condensate trough up and remove it (fig. **5**).





Clean the panels with glass cleaner and a soft cloth. Wipe the condensate trough with a cloth and some hot soapy water.


## **⚠** Warning

#### Risk of injury!

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.

#### Fitting panels


1. Open the appliance door fully and refit the condensate trough. To do this, insert the trough from above and rotate it at the bottom (fig. 1).




2. Push in the inner glass panel.

Before sliding the panel in, make sure that the glossy side of the panel is on the outside and the cut-outs on the left and right are at the top.


The panel must be sitting correctly at the bottom in the retainer (fig. 2).




**3.** Push the inner panel in at the top (fig. **3**).



- **4.** Put the cover back in place and press on it until you hear it click into place (fig. 4).
- 5. Open the appliance door again fully.
- Close the two locking levers on the left and right (fig. 5)





7. Close the appliance door.

#### Caution!

Do not use the cooking compartment again until the panels have been correctly fitted.

#### Cleaning the rails

The rails can be removed for cleaning.


## ⚠ Warning – Risk of burning due to hot components in the cooking compartment!


Wait until the cooking compartment has cooled down.

#### **Detaching the rails**

**Note:** Swing the front of the rail as far as possible (until you feel resistance), otherwise the appliance side panel may become bent.

- 1. Carefully press the front of the rail upwards until it becomes detached, and release it from the holder at the side (fig. 11).
- Detach the rail from the holder and remove it (fig.2).






Clean the rails with washing-up liquid and a sponge/ brush


or

Clean the rails in the dishwasher.

#### Attaching the rails

- **1.** Position the rail so that the indentations are facing upwards.
- 2. Hook the rail in at the back and push it towards the rear until it engages (fig. 3).
- 3. Hook the front of the rail onto the holder and press down until it engages and is fixed level in place in the appliance once more (fig. 4).





Each set of rails only fits on one side.

## ? Trouble shooting

If a fault occurs, there is often a simple explanation. Before calling the after-sales service, please refer to the fault table and attempt to correct the fault yourself.

Tip: If a meal does not turn out exactly as you wanted, refer to the "Tested for you in our cooking studio" section. Here, you will find plenty of cooking tips and

#### Marning – Risk of injury!

Incorrect repairs are dangerous. Do not attempt to repair the appliance yourself. Repairs must only be carried out by one of our trained after-sales engineers. If the appliance is defective, call the after-sales service.

⚠ Warning – Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

#### Fault table

⚠ Warning – Risk of electric shock!

- Work on the appliance electronics may only be performed by a specialist.
- Always disconnect the appliance from the power supply when work is carried out on the electronics. Switch off the circuit breaker or remove the fuse from your household fuse box.

Fault	Possible cause	Notes/remedy
The appliance does not work	The plug is not plugged into the mains	Connect the appliance to the power supply
	Power cut	Check whether other kitchen appliances are working
	The circuit breaker is faulty	Check in the fuse box to make sure that the fuse for the appliance is OK
The appliance cannot be switched on; the $\  \  \  \  \  \  \  \  \  \  \  $ symbol is shown on the display	The automatic childproof lock is activated	Press and hold the $\bigcirc$ touch button until the $\Longrightarrow$ symbol goes out
The appliance cannot be operated when it is switched on; the $\Longrightarrow$ symbol is shown on the display	The childproof lock is activated	Press and hold the $\bigcirc$ touch button until the $\Longrightarrow$ symbol goes out
The appliance does not heat up; □ is shown on the display	Demo mode is activated in the basic settings	Disconnect the appliance from the mains for approx. 10 seconds (switch off the circuit breaker in the fuse box) and then deactivate demo mode in the basic settings within 3 minutes  —> "Basic settings" on page 18
"D" or "E" appears on the display, e.g. D0111 or E0111	Technical problem	Switch the appliance off and on again If the message appears again, call the after-sales service. Quote the exact error message
The appliance cannot be started	The appliance door is not fully closed	Close the appliance door
	The appliance is not switched off	Switch the appliance off and back on again
The appliance is prompting you to wipe down the cooking compartment and fill the water tank	The power supply has been disconnected or the appliance has been switched off during the descaling process	Once the appliance is switched on again, rinse it twice
After switching on an operating mode, a message is shown on the display which indicates that the temperature is too high	The appliance has not cooled down sufficiently	Allow the appliance to cool down and switch the operating mode on again
The appliance prompts you to descale without the counter appearing beforehand	The set water hardness range is too low	Carry out descaling Check the set water hardness range and adjust it, if necessary
Buttons flash	Normal occurrence caused by condensation behind the control panel	As soon as the condensation has evaporated, the buttons no longer flash
Liquid in the evaporator dish has fully evaporated, even though the water	The water tank has not been inserted properly	Push in the water tank completely until you feel it engage
tank is full	The feed line to the water tank is blocked	Descale the appliance Check the set water hardness range and change it, if necessary

The water tank empties for no dis-	The water tank was not closed properly	Close the lid until you feel it lock into place
cernible reason. The evaporator dish overflows	The tank lid seal is dirty	Clean the seal
Overnows	The tank lid seal is faulty	Obtain a new water tank from the after-sales service
The appliance's display prompts you to fill up the water tank even though it	The water tank has not been inserted properly	Push in the water tank completely until you feel it engage
is full.	The detection system is not working	Call the after-sales service
The appliance's display prompts you to fill up the water tank even though it is not yet empty, or the water tank is empty but no corresponding message appears on the display	The water tank is dirty. The moving water level indicators are jammed	Shake and clean the water tank. If the jammed parts cannot be freed, obtain a new water tank from the after-sales service
The question "Fill the water tank?" appears in the display while the operation is running	Water tank half filled	No remedial action required, operation continues
"Appliance heating" appears on the display but the appliance is not reaching the selected temperature	Automatic calibration values not optimal	Restore the appliance's factory settings and repeat the steps required for first-time operation $\longrightarrow$ "Basic settings" on page 18 $\longrightarrow$ "Before using for the first time" on page 10
		The next time you use the steam function at 100 °C, calibration will run automatically and more steam will be produced
When you cook with steam, a lot of steam is produced	The appliance is being automatically calibrated	Normal procedure
When cooking with steam, a lot of steam is produced repeatedly	The appliance is unable to calibrate itself automatically if cooking times are too short	Reset the appliance to the factory settings and repeat the calibration process
Steam escapes from the ventilation slots during cooking	Normal procedure	Not possible

#### Replacing the cooking compartment bulb

Heat-resistant 230 V/25 W halogen bulbs with seals are available from the after-sales service. Please specify the E number and FD number of your appliance.

#### Marning − Risk of electric shock!

When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

#### ⚠ Warning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.


- Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- 2. Turn the cover anti-clockwise to remove it.
- **3.** Remove the bulb.

Insert the new bulb, making sure that the pins are in the correct position. Push the bulb in firmly.

#### Caution

Only operate the appliance with the glass cover and seals.

**4.** Slide the new seals and the clamping ring onto the glass cover in the right order.



- **5.** Screw the glass cover with the seals back on again.
- **6.** Connect the appliance to the power supply and carry out commissioning again.


#### Replacing the glass cover or seals

If the glass cover for the halogen bulb or the seals are damaged, they must be replaced. A new glass cover can be obtained from the after-sales service. Please specify the E number and FD number of your appliance.

#### Changing the door seal

If the seal around the outside of the cooking compartment is faulty, it must be replaced. Replacement seals for your appliance can be obtained from the after-sales service. Please specify the E number and FD number of your appliance.

- 1. Open the appliance door.
- 2. Pull off the old seal.
- 3. Push in the new door seal at one point and pull it in all the way round. The joint must be at the side.
- Check again that the seal is correctly fitted in the corners



## **Customer service**

Our after-sales service is there for you if your appliance needs to be repaired. We will always find an appropriate solution, also in order to avoid after-sales personnel having to make unnecessary visits.

#### E number and FD number

When calling us, please quote the full product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate bearing these numbers can be found when you open the appliance door.

On some appliances with a steam-assisted cooking function, you will find the rating plate behind the control panel.



To save time, you can make a note of the numbers for your appliance and the telephone number of the aftersales service in the space below in case you need them.

E no. FD no.

#### After-sales service 🕾

Please note that a visit from an after-sales service engineer is not free of charge in the event that the appliance has been misused, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

## To book an engineer visit and product advice GB 0344 892 8989

Calls charged at local or mobile rate.

**IE** 01450 2655

0.03 € per minute at peak. Off peak 0.0088 € per minute.

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

## Settings table and tips

Steaming is a particularly gentle way of cooking food. The steam surrounds the dish thereby preventing a loss of nutrients from the food. Cooking takes place without excess pressure. As a result, the shape, colour and typical aroma of the dishes are retained.

The tables contain a selection of dishes which are particularly suitable for your steam oven. You can find out which heating type, accessories, temperature and cooking time are best to select. Unless otherwise stated, the information given applies to inserting accessories when the appliance is cold.

#### **Accessories**

Use the accessories provided.

When steaming in the perforated steam container, always insert the solid steam container underneath. Dripping liquid is caught.

#### **Ovenware**

When using ovenware, always place it in the middle of the perforated steam container.

Ovenware must be heat and steam resistant. Cooking times are increased if thick-sided ovenware is used.

Food which would normally be prepared in a bain-marie should always be covered with foil (e.g. when melting chocolate).

#### Cooking time and quantity

The cooking times when steaming depend on the item size, but do not depend on the total quantity. The appliance can steam food to a maximum of 2 kg.

Follow the unit sizes given in the tables. The cooking time is reduced for smaller pieces and increased for larger ones. Cooking time is also influenced by the quality and ripeness of the food. The values quoted can therefore only serve as a guideline.

#### Distributing food evenly

Always distribute the food evenly in the ovenware. It will not cook evenly if the layers are of different depths.

#### Pressure-sensitive food

When layering delicate foods in the steam container, do not pile them too high. You should ideally use two steam containers.

#### Cooking a menu

With steam, you can cook a whole menu at once, without the different flavours mixing. Place the food with the longest cooking time in the appliance first and delay the rest until the appropriate time. This means that all the food will be ready at the same time.

The overall cooking time is extended with menu cooking, as a little steam escapes each time the appliance door is opened and has to be reheated.

#### **Vegetables**

Place the vegetables in the perforated steam container and insert at level 3. Always insert the solid steam container underneath at level 1. Any dripping liquid will be caught.

			- 41		
Food	Size	Accessories	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Artichokes	whole	perforated + solid	Steaming	100	30 - 35
Cauliflower	whole	perforated + solid	Steaming	100	25 - 35
Cauliflower	florets	perforated + solid	Steaming	100	10 - 15
Broccoli	florets	perforated + solid	Steaming	100	8 - 10
Peas	-	perforated + solid	Steaming	100	5 - 10
Fennel	sliced	perforated + solid	Steaming	100	10 - 14
Vegetable flan	-	1.5 I bain-marie dish + wire rack at level 2	Steaming	100	50 - 70
Green beans	-	perforated + solid	Steaming	100	20 - 25
Carrots	sliced	perforated + solid	Steaming	100	10 - 20
Kohlrabi	sliced	perforated + solid	Steaming	100	20 - 25
Leek	sliced	perforated + solid	Steaming	100	6 - 9
Sweetcorn	whole	perforated + solid	Steaming	100	25 - 35
Swiss chard*	shredded	perforated + solid	Steaming	100	8 - 10
Green asparagus*	whole	perforated + solid	Steaming	100	7 - 12
White asparagus*	whole	perforated + solid	Steaming	100	10 - 15
* Preheat the appliance					

Food	Size	Accessories	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Spinach*	-	perforated + solid	Steaming	100	2-3
Romanesco	florets	perforated + solid	Steaming	100	8 - 10
Brussels sprouts	florets	perforated + solid	Steaming	100	20 - 30
Beetroot	whole	perforated + solid	Steaming	100	40 - 50
Red cabbage	shredded	perforated + solid	Steaming	100	30 - 35
White cabbage	shredded	perforated + solid	Steaming	100	25 - 35
Courgette	sliced	perforated + solid	Steaming	100	3 - 4
Mangetout	-	perforated + solid	Steaming	100	8 - 12
* Preheat the appliance					

#### Side dishes and pulses

Add water or liquid in the proportion specified. For example: 1:1.5 = add 150 ml liquid for every 100 g rice.

You may select any shelf position you wish for the solid steam container.

Food	Ratio	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Unpeeled boiled potatoes (medium size)	-	perforated + solid	3 1	Steaming	100	35 - 45
Boiled potatoes (quartered)	-	perforated + solid	3 1	Steaming	100	20 - 25
Brown rice	1:1.5	solid	-	Steaming	100	35 - 45
Long grain rice	1:1.5	solid	-	Steaming	100	20 - 30
Basmati rice	1:1.5	solid	-	Steaming	100	20 - 30
Parboiled rice	1:1.5	solid	-	Steaming	100	15-20
Risotto	1:2	solid	-	Steaming	100	30 - 35
Lentils	1:2	solid	-	Steaming	100	35 - 50
Canellini beans, pre-softened	1:2	solid	-	Steaming	100	65 - 75
Couscous	1:1	solid	-	Steaming	100	6 - 10
Unripe spelt grain, coarse ground	1:2.5	solid	-	Steaming	100	15-20
Millet, whole	1:2.5	solid	-	Steaming	100	25 - 35
Wheat, whole	1:1	solid	-	Steaming	100	60 - 70
Dumplings	-	perforated + solid	3 1	Steaming	95	20 - 25

#### **Poultry and meat**

#### **Poultry**

Food	Amount	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Chicken breast	0.15 kg each	solid	2	Steam	100	15-25
Duck breast*	0.35 kg each	solid	2	Steam	100	12 - 18
* Sear first and wrap in foil						

#### Beef

Food	Amount	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Thin slice of sirloin, medium*	1 kg	solid	2	Steam	100	25 - 35
Thick piece of sirloin, medium*	1 kg	perforated + solid	3 1	Steam	100	30 - 40
* Sear first and wrap in foil						

#### **Pork**

Food	Amount	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Fillet of pork	0.5 kg	solid	2	Steaming	100	16 - 20
Pork medallions*	approx. 3 cm thick	solid	2	Steaming	100	10 - 12
Smoked pork ribs	sliced	solid	2	Steaming	100	15 - 20
* Sear first and wrap in foil						

#### Sausages

Food	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Wiener sausages	perforated + solid	3 1	Steaming	80 - 90	12 - 18
Bavarian veal sausages	perforated + solid	3 1	Steaming	80 - 90	20 - 25

#### Fish

Food	Amount	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Sea bream, whole	0.3 kg each	perforated + solid	3 1	Steam	80 - 90	15 - 25
Sea bream fillet	0.15 kg each	perforated + solid	3 1	Steam	80 - 90	10 - 20
Fish terrine	1.5 I bain- marie dish	solid	2	Steam	70 - 80	40 - 80
Trout, whole	0.2 kg each	perforated + solid	3 1	Steam	80 - 90	12 - 15
Cod fillet	0.15 kg each	perforated + solid	3 1	Steam	80 - 90	10 - 14
Salmon fillet	0.15 kg each	perforated + solid	3 1	Steam	100	8 - 10
Mussels	1.5 kg	solid	2	Steam	100	10 - 15
Ocean perch fillet	0.15 kg each	perforated + solid	3 1	Steam	80 - 90	10 - 20
Sole rolls, stuffed		perforated + solid	3 1	Steam	80 - 90	10 - 20

### Soup vegetables, miscellaneous

Food	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Royale (egg custard)	solid	2	Steam	90	15 - 20
Semolina dumplings	perforated + solid	3 1	Steam	90 - 95	7 - 10
Hard-boiled eggs (Size M, max. 1.8 kg)	perforated + solid	3 1	Steam	100	10 - 12
Soft-boiled eggs (Size M, max. 1 kg)	perforated + solid	3 1	Steam	100	6-8

#### Dessert, compote

#### Compote

Weigh the fruit and add approximately ½ of the water, then add sugar and spices according to taste.

#### Rice pudding

Weigh the rice and add 2.5 times the amount of milk. Ensure the level of rice and milk in the accessory is no higher than 2.5 cm. Stir after cooking. The remaining milk is quickly absorbed.

#### **Yogurt**

Heat the milk to 90 °C on the hob. Then leave to cool to 40 °C. It is sufficient to heat UHT milk to 40 °C.

Stir in 150 g (chilled) yogurt. Pour into cups or small jars and cover with cling film. Place the cups or glasses onto the steamer tray and set as indicated in the table.

After preparation, leave the yogurt to cool in the refrigerator.

Food	Accessories	Type of heating	Tempera- ture in °C	Cooking time in min.			
Yeast dumplings	solid	Steaming	100	20 - 25			
Crème caramel	small moulds + perforated	Steaming	80	15-20			
Rice pudding*	solid	Steaming	100	25 - 35			
Yoghurt*	Portion-sized glasses + perforated	Steaming	40	300 - 360			
Apple compote	solid	Steaming	100	10 - 15			
Pear compote	solid	Steaming	100	10 - 15			
Cherry compote	solid	Steaming	100	10 - 15			
Rhubarb compote	solid	Steaming	100	10-15			
Plum compote	solid	Steaming	100	15-20			
* You can also use the appropriate programme (see section: Automatic programmes)							

#### Reheating food

Using Reheat, dishes can be gently reheated. They taste and look like they have been freshly prepared.

Food	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Vegetables	solid steam container	3	Reheating	100	12 - 15
Pasta, potatoes, rice	solid steam container	3	Reheating	100	5 - 25

#### Sous-vide

Sous-vide cooking is a method of cooking under a vacuum at low temperatures from 50-95 C and in 100% steam.

Sous-vide cooking is a gentle method of preparing meat, fish, vegetables and desserts. A chamber vacuum-sealing machine is used to heat-seal the food in a special air-tight, heat-resistant vacuum-sealing bag.

The protective envelope of the vacuum-sealing bag retains the nutrients and flavours. The low temperatures and the direct transfer of heat allow precisely controlled cooking in order to achieve the desired cooking results. It is almost impossible to overcook the food.

#### **Portions**

Take into consideration the specified quantities and sizes for the food listed in the settings table. For relatively large quantities and items, the cooking time must be adjusted accordingly. The appliance can cook up to 2 kg of food sous-vide.

The quantities given for fish, meat and poultry correspond to one to two portions. A portion size sufficient for four people has been selected for vegetables and desserts.

#### Rack levels

You can cook on up to two levels. For this purpose, always slide in the unperforated cooking container at level 1 to catch any drops of condensate. Insert the perforated cooking container above accordingly.

#### Hygiene

#### ⚠ Warning – Health risk!

Sous-vide cooking is a method of cooking at low temperatures. As a result, it is important that you always follow the application and hygiene instructions below:

- Only use high-quality, perfectly fresh food.
- Wash and disinfect your hands. Use disposable gloves or cooking/grill tongs.
- Take extra care when preparing hygienically critical food, such as poultry, eggs and fish.
- Always thoroughly rinse and/or peel fruit and vegetables.
- Always keep work surfaces and chopping boards clean. Use different chopping boards for different types of food.
- Maintain the cold chain. Make sure that you only interrupt it briefly to prepare the food, and then return the food in its vacuum-sealed bag to the refrigerator for storage before you cook it. Store the prepared food for a maximum of 24 hours.
- Food is suitable for immediate consumption only.
   Once the food is cooked, consume it immediately.
   Do not store it after cooking not even in the refrigerator. It is not suitable for reheating.

**Tip:** Since germs can be found on the surface of almost all food, the best way to kill these germs is to put the vacuum-sealed, uncooked food in boiling water for a maximum of 3 seconds. This is the best way to prepare your ingredients for sous-vide cooking so that they are free from germs and hygienic. Then place the vacuum-sealing bag in the cooking compartment to sous-vide cook the food.

#### Vacuum-sealing bags

When using the sous-vide cooking method, only use heat-resistant vacuum-sealing bags designed for this purpose.

The vacuum-sealing bag must only be used once. Do not use these bags more than once.

Do not cook the food in the bag you bought it in (e.g. portions of fish). These bags are not suitable for sous-vide cooking.

#### Vacuum-sealing

Use a chamber vacuum-sealing machine that can create a 99% vacuum to vacuum-seal the food. This is the only way to achieve even heat transfer and therefore a perfect cooking result.

**Note:** To fill the vacuum-sealing bag, fold the edge of the bag down by 3-4 cm and place it into a container, e.g. into a measuring jug.

Before cooking the food, check whether the vacuum in the vacuum-sealing bag is intact. Make sure that:

- There is no/hardly any air in the vacuum-sealing bag.
- The heat-sealed seam is perfectly sealed.
- There are no holes in the vacuum-sealing bag. You do not use the core temperature probe.
- You do not pile pieces of meat or fish on top of one another.
- As far as possible, you avoid piling up vegetables and desserts when vacuum-sealing them.
- To ensure that the seam is perfect, the seam area on the edge of the vacuum-sealing bag does not become wet with food residue.

If in doubt, place the food into a new vacuum-sealing bag and vacuum-seal it again.

Food should be vacuum-sealed at most one day before it is cooked. This is the only way to prevent the escape of gases from the food (e.g. from vegetables) that inhibit the transfer of heat, or to prevent the texture of the food from changing, and thus altering how it cooks, as a result of the vacuum pressure.

#### Quality of the food

The quality of the cooking result is 100% influenced by the quality of the ingredients you use. Use only fresh, top-quality food. This is the only way to guarantee a consistent cooking result that delivers impeccable flavour.

#### **Preparation**

Cooking under a vacuum means that the flavours cannot escape. In using this method, please note that the usual quantities of seasoning and condiments, such as herbs, spices and garlic, can have a much greater effect on the flavour and can intensify the flavour. You should therefore start off by halving the quantities you usually use.

If the ingredients are of high quality, it is often sufficient to enclose them in the vacuum-sealing bag with just a small knob of butter and a little salt. Generally, the fact that the food's natural flavours intensify during cooking is sufficient on its own to produce a flavourful cooking result.

The following ingredients influence how the food is prepared:

- Salt and sugar reduce the cooking time
- Acidic food, such as lemon or vinegar, help the food to firm up
- Alcohol or garlic give the food an unpleasant aftertaste

Do not place the vacuum-sealed food items on top of one another or too close together in the perforated cooking containers. In order to ensure that the heat is distributed evenly, the food items should not be touching. Always slide in the unperforated cooking container at level 1 to catch any drops of condensate.

#### ⚠ Warning. Risk of scalding!

Hot water collects on the vacuum-sealing bag during cooking. Use an oven cloth to carefully lift the vacuum-sealing bag, so that the hot water runs off into the universal pan or the cooking container. Then use the oven cloth to carefully remove the vacuum-sealing bag.

Once the food is cooked, allow the cooking compartment to cool and then use a sponge to wipe away the water from the evaporator dish.

Dry the outside of the vacuum-sealing bag, place it in a clean container and use scissors to open it. Place all of the food, along with its juices, into the container. You can use the stock or marinade to make a sauce.

#### The food can be finished off as follows once the sousvide cooking stage is complete:

**Meat:** Flash fry in a frying pan at a very high temperature for only a few seconds on each side. This gives it a nice crust and the flavours you would expect from frying, without overcooking it.

Important: Dab the meat with a paper towel before placing it into hot oil, in order to avoid fat spitting out of the pan.

**Vegetables:** Flash fry in a frying pan to give them the flavours you would expect from frying. When frying vegetables like this, it is easy to season them or mix them with other ingredients.

Fish: Season and coat with hot butter.

Fry the food for longer if has not been sufficiently well cooked during the sous-vide cooking stage.

Serve the food on pre-heated plates and, if possible, with a hot sauce or butter as sous-vide cooking takes place at relatively low temperatures.

over cloth to carefully remove	tilo vacaaiii	Joanny Day.			
Food	Cooking container	Heating function	Tempera- ture in °C	Cooking time in min	Tip/note
Meat					
Veal steak, medium, 2 cm thick	Perforated + unperforated	Sous-vide	60	80	Vacuum-seal along with some butter and rosemary.
Beef steak (topside, saddle, etc.), rare, 2 - 3 cm thick	Perforated + unperforated	Sous-vide	58	90	
Beef steak (topside, saddle, etc.), medium, 2 - 3 cm thick	Perforated + unperforated	Sous-vide	62	80	
Fillet steak, whole piece, rare, 3 - 4 cm thick	Perforated + unperforated	Sous-vide	58	100	
Fillet steak, whole piece, medium, 3 - 4 cm thick	Perforated + unperforated	Sous-vide	62	90	
Pork medallions (80 g each)	Perforated + unperforated	Sous-vide	63	75	Vacuum-seal along with some butter and fresh basil.
Saddle of lamb, boned	Perforated + unperforated	Sous-vide	58	50	Vacuum-seal along with some salt, butter and thyme.
Pork belly, 700 g	Perforated + unperforated	Sous-vide	65	24 hours	Vacuum-seal along with some butter, rosemary, thyme and a little mustard.
Viennese boiled veal, 1 kg	Perforated + unperforated	Sous-vide	62	18 hours	Vacuum-seal along with some butter, thyme, a bay leaf, peppercorns and some root vegetables.
Pulled pork, 1.5 kg	Perforated + unperforated	Sous-vide	64	48 hours	Vacuum-seal along with some butter, soy sauce, liquid smoke, pepper, paprika powder and ground caraway.

Food	Cooking container	Heating function	Tempera- ture in °C	Cooking time in min	Tip/note
Poultry					
Duck breast (350 g each)	Perforated + unperforated	Sous-vide	62	70	Cut into the layer of fat, season the meat side with a little salt and pepper, and vacuum-seal it along with a small piece of orange peel.
Chicken breast (250 g each)	Perforated + unperforated	Sous-vide	65	60	Vacuum-seal along with some butter, a little salt and some thyme.
Fish					
Cod (140 g each)	Perforated + unperforated	Sous-vide	58	25	Vacuum-seal along with some butter and a little salt.
Halibut/turbot (150 g each)	Perforated + unperforated	Sous-vide	58	30	
Pike-perch (140 g each)	Perforated + unperforated	Sous-vide	60	20	
Vegetables					
Cauliflower (500 g)	Perforated + unperforated	Sous-vide	85	40 - 50	Vacuum-seal along with a little water, butter, salt and nutmeg.
Mushrooms, quartered (500 g)	Perforated + unperforated	Sous-vide	85	20 - 25	Vacuum-seal along with some butter, rosemary, a little garlic and some salt.
Chicory, halved (x 4 - 6)	Perforated + unperforated	Sous-vide	85	40 - 45	Vacuum-seal along with some orange juice, sugar, salt, butter and thyme.
Green asparagus, whole (600 g)	Perforated + unperforated	Sous-vide	85	20-30	Blanch before vacuum-sealing to retain the colour.  Vacuum-seal along with some butter, salt, a little sugar and some pepper.
Carrots, in 0.5 cm slices (600 g)	Perforated + unperforated	Sous-vide	90	70 - 80	Vacuum-seal along with some orange juice, curry powder/paste and butter.
Potatoes, peeled and quartered (800 g)	Perforated + unperforated	Sous-vide	95	35 - 45	Vacuum-seal along with some butter and salt. Can easily be used for making dishes such as salad.
Cherry tomatoes, whole or halved (500 g)	Perforated + unperforated	Sous-vide	58	25 - 35	Mix together red and yellow cherry tomatoes. Vacuum-seal along with some olive oil, salt and sugar.
Squash, in 2 x 2 cm cubes (600 g)	Perforated + unperforated	Sous-vide	90	25 - 35	The cooking time may vary depending on the type of squash.
Courgettes, in 1 cm slices (600 g)	Perforated + unperforated	Sous-vide	85	25 - 30	Vacuum-seal along with some olive oil, salt and thyme.
Mangetout, whole (500 g)	Perforated + unperforated	Sous-vide	85	5 - 10	Vacuum-seal along with some butter and salt.
Dessert					
Pineapple in 1.5 cm slices (400 g)	Perforated + unperforated	Sous-vide	85	70 - 80	Vacuum-seal along with some butter, honey and vanilla.
Apple, peeled, in 0.5 cm slices (x 2 - 4)	Perforated + unperforated	Sous-vide	85	15 - 25	Vacuum-seal along with some caramel sauce. The cooking time may vary depending on the type of apple.
Bananas, whole (x 2 - 4)	Perforated + unperforated	Sous-vide	65	20 - 25	Vacuum-seal along with some butter, honey and a vanilla pod.
Pear, peeled, sliced (x 2 - 4)	Perforated + unperforated	Sous-vide	85	25 - 35	Add honey or sugar to sweeten.
Kumquats, halved (x 12 - 16)	Perforated + unperforated	Sous-vide	85	75 - 80	Rinse under warm water, cut in half and deseed.  Vacuum-seal along with some butter, a vanilla pod, honey and apricot jam.
Vanilla sauce (0.5 l)	Perforated + unperforated	Sous-vide	80	15-25	Mix 0.5 I milk, 1 egg, 3 egg yolks, 80 g sugar, pulp of a vanilla pod, and vacuum-seal.

#### **Defrosting**

The steam function "Defrost" is suitable for defrosting frozen fruit and vegetables. It is best to allow poultry, meat and fish to defrost in the refrigerator. To defrost the frozen food, remove it from its packaging. Place frozen fruit and vegetables into the steaming pan with the perforated base, and place the steaming pan with the unperforated base underneath. This keeps the food away from the water that forms as it defrosts, and allows this water to be collected as it drips down. For frozen food that needs to retain liquid when it is cooked, e.g. creamed spinach, use the steaming pan with the

unperforated base or cookware placed on the wire rack.

The times specified in the table are intended as a guide. They are dependent on the quality, freezing temperature (-18 °C) and composition of the food. Time ranges are specified. Set the shortest time initially, and then extend the time if necessary.

**Tip:** Food that has been frozen in thinner pieces or in portions defrosts more quickly than food items frozen in a block.

Food	Amount	Accessories	Level	Tempera- ture in °C	Cooking time in min.
Berries	0.5 kg	perforated + solid	3 1	50 - 55	15-20
Vegetables	0.5 kg	perforated + solid	3 1	40 - 50	15 - 50

#### Dough proving

Dough will prove considerably more quickly using the dough proving setting than at room temperature.

You may select any shelf position you wish for the wire rack or place the wire rack carefully on the cooking

compartment floor.

Caution: Do not scratch the cooking compartment floor.

Place the dough bowl on the wire rack. Do not cover the dough.

Food	Amount	Accessories	Tempera- ture in °C	Cooking time in min
Yeast dough	1 kg	Bowl + wire rack	35	20 - 30

#### **Extracting juice**

Before juicing, place the berries in a bowl and sprinkle with sugar. Leave to stand for at least one hour to draw out the juice.

Pour the berries into the perforated steam container and insert at level 3. Insert the solid steam container at level 1 to catch the juice.

Finally, place the berries in a cloth and squeeze out the rest of the juice.

Food	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Raspberries	perforated + solid	3 1	Steam	100	30 - 45
Redcurrants	perforated + solid	3 1	Steam	100	40 - 50

#### **Preserving**

Preserve food which is as fresh as possible. When foods are stored for a relatively long period, their vitamin content is reduced and they ferment and spoil more easily.

Only use fruit and vegetables which are in perfect condition.

The following foods cannot be preserved with your appliance:

Contents of tins, meat, fish or pastry dough.

Check preserving jars, rubber rings, clips and springs.

Clean rubber rings and jars thoroughly with hot water. The "Sterilise bottles" programme is also suitable for cleaning jars.

Place the jars into the perforated steam container. They must not touch each other.

After the specified cooking time, open the appliance door.

Do not remove the preserving jars from the appliance until they have completely cooled down.

Food	Accessories	Height	Heating type	Tempera- ture in °C	Cooking time in min.
Vegetables	1-litre preserving jars	2	Steam	100	30 - 120
Stone fruits	1-litre preserving jars	2	Steam	100	25 - 30
Pip fruits	1-litre preserving jars	2	Steam	100	25 - 30

#### **Frozen products**

Observe the manufacturer's instructions on the packaging.

The cooking times indicated apply to dishes placed in a cold cooking compartment.

Food	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Pasta, fresh, refrigerated*	solid	2	Steaming	100	5 - 10
Trout	perforated + solid	3 1	Steaming	80 - 100	20 - 25
Salmon fillet	perforated + solid	3 1	Steaming	80 - 100	20 - 25
Broccoli	perforated + solid	3 1	Steaming	100	6 - 10
Cauliflower	perforated + solid	3 1	Steaming	100	5-8
Beans	perforated + solid	3 1	Steaming	100	6 - 10
Peas	perforated + solid	3 1	Steaming	100	5 - 12
Carrots	perforated + solid	3 1	Steaming	100	4 - 6
Mixed vegetables	perforated + solid	3 1	Steaming	100	6 - 10
Brussels sprouts	perforated + solid	3 1	Steaming	100	5 - 10
* Add a little liquid					

#### **Test dishes**

These tables have been produced for test institutes to facilitate the inspection and testing of the various appliances.

Test dishes in accordance with EN 60350-1.

Food	Accessories	Level	Type of heat- ing	Tempera- ture in °C	Cooking time in min.
Broccoli (Steam distribution)	perforated + solid	3 1	Steaming	100	7 - 9
Broccoli (Steam supply)	perforated + solid	3 1	Steaming	100	7 - 9
Peas* (Maximum load)	perforated + solid	3 1	Steaming	100	5 - 12
* Spread out 2.0 kg peas evenly in the container.					







REGISTER YOUR PRODUCT ONLINE NEFF-HOME.COM



Constructa NEFF Vertriebs-GmbH | Carl-Wery-Straße 34 | 81739 Munich | Germany 9001430005 990322 en