

Table of contents

USER MANUAL

1	Safety 2
2	Preventing material damage 4
3	Environmental protection and saving energy 5
4	Familiarising yourself with your appliance 6
5	Accessories 8
6	Before using for the first time 9
7	Basic operation 10
8	Rapid heating 10
9	Time-setting options11
10	Childproof lock12
11	Basic settings 13
12	Cleaning and servicing14
13	Cleaning function15
14	Shelf supports17
15	Appliance door 18
16	Troubleshooting
17	Disposal23
18	Customer Service24
19	How it works24
20	INSTALLATION INSTRUCTIONS 28
20.1	General installation instructions 28



1 Safety

Observe the following safety instructions.

1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

This appliance is designed only to be built into kitchen units. Read the special installation instructions.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under the warrantv.

Only use this appliance:

- To prepare meals and drinks.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance. Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

1.4 Safe use

Always place accessories in the cooking compartment the right way round.

→ "Accessories", Page 8

⚠ WARNING – Risk of fire!

Combustible objects that are left in the cooking compartment may catch fire.

- ► Never store combustible objects in the cooking compartment.
- ▶ If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire.

▶ Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Opening the appliance door creates a draught. Greaseproof paper may come into contact with the heating element and catch fire.

- Never place greaseproof paper loosely over accessories when preheating the appliance and while cooking.
- ► Always cut greaseproof paper to size and use a plate or baking tin to hold it down.

The appliance and its parts that can be touched become hot during use.

- ► Caution should be exercised here in order to avoid touching heating elements.
- ► Young children under 8 years of age must be kept away from the appliance.

Accessories and cookware get very hot.

Always use oven gloves to remove accessories or cookware from the cooking compartment.

When the cooking compartment is hot, any alcoholic vapours inside may catch fire.

- Only use small quantities of drinks with a high alcohol content in food.
- ► Open the appliance door carefully.

⚠ WARNING – Risk of scalding!

The accessible parts of the appliance become hot during operation.

- ► Never touch these hot parts.
- ► Keep children at a safe distance.

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- Open the appliance door carefully.
- ► Keep children at a safe distance.

If there is water in the cooking compartment when it is hot, this may create hot steam.

Never pour water into the cooking compartment when the cooking compartment is hot.

⚠ WARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

▶ Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

Keep your hands away from the hinges.

Components inside the appliance door may have sharp edges.

► Wear protective gloves.

⚠ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- ► If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- Never kink, crush or modify the power cord

An ingress of moisture can cause an electric shock.

▶ Do not use steam- or high-pressure cleaners to clean the appliance.

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never operate an appliance with a cracked or fractured surface.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ► If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 24

⚠ WARNING – Danger: Magnetism!

Permanent magnets are used in the control panel or in the controls. These may affect electronic implants, e.g. heart pacemakers or insulin pumps.

► Wearers of electronic implants must stay at least 10 cm away from the control panel.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- Keep packaging material away from children.
- Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- Keep small parts away from children.
- ▶ Do not let children play with small parts.

1.5 Halogen bulb

MARNING – Risk of burns!

The bulbs in the cooking compartment get very hot. There is still a risk of burning for some time after they have been switched off.

- ▶ Do not touch the glass cover.
- Avoid contact with your skin when cleaning.

⚠ WARNING – Risk of electric shock!

When changing the bulb, the bulb socket contacts are live.

- ▶ Before replacing the bulb, ensure that the appliance is switched off in order to prevent a potential electric shock.
- ► Also unplug the appliance from the mains or switch off the circuit breaker in the fuse

1.6 Cleaning function

⚠ WARNING – Risk of fire!

Loose food remnants, fat and meat juices may catch fire when the cleaning function is in progress.

- ▶ Before you start the cleaning function, always remove coarse dirt from the cooking compartment.
- Never clean accessories at the same time. The outside of the appliance gets very hot when the cleaning function is in progress.
- ▶ Never hang combustible objects, e.g. tea towels, on the door handle.
- ► Leave the front of the appliance clear.
- Keep children at a safe distance.

If the door seal is damaged, a large amount of heat is generated around the door.

- Do not scrub or remove the seal.
- ► Never operate the appliance if the seal is damaged or missing.

WARNING – Risk of serious harm to health!

The appliance gets very hot when the cleaning function is in progress. The non-stick coating on baking trays and tins is destroyed and noxious gases are released.

- ► Never clean non-stick baking trays or baking tins using the cleaning function.
- Never clean accessories at the same time.

WARNING – Risk of harm to health!

The cleaning function heats up the cooking compartment to a very high temperature so that food left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate mucous membranes.

- Keep the kitchen well ventilated while the cleaning function is running.
- ▶ Do not remain in the room for long periods.
- Keep children and pets away.

⚠ WARNING – Risk of burns!

The cooking compartment gets very hot when the cleaning function is in progress.

- ► Never open the appliance door.
- ► Allow the appliance to cool down.
- Keep children at a safe distance.

The outside of the appliance gets very hot when the cleaning function is in progress.

- ▶ Never touch the appliance door.
- Allow the appliance to cool down.
- Keep children at a safe distance.

Preventing material damage

2.1 General

ATTENTION!

Objects on the cooking compartment floor at over 50 °C will cause heat to build up. The baking and roasting times will no longer be correct and the enamel will be damaged.

- Do not place any accessories, greaseproof paper or foil of any kind on the cooking compartment floor.
- Only place cookware on the cooking compartment floor if a temperature above 50 °C has been set.

When the cooking compartment is hot, any water inside it will create steam. The change in temperature may cause damage.

- Never pour water into the cooking compartment when it is still hot.
- ► Never place cookware containing water on the cooking compartment floor.

The prolonged presence of moisture in the cooking compartment leads to corrosion.

- Allow the cooking compartment to dry after use.
- ► Do not keep moist food in the cooking compartment for a long time with the door closed.
- ► Do not store food in the cooking compartment.

Leaving the appliance to cool down with the door open will damage the front of neighbouring kitchen units over

- ► Always allow the cooking compartment to cool down with the door closed after cooking at high temperatures.
- Take care not to trap anything in the appliance
- Only leave the cooking compartment to dry with the door open if a lot of moisture was produced during operation.

Fruit juice dripping from the baking tray leaves stains that cannot be removed.

- When baking very juicy fruit flans, do not pack too much on the baking tray.
- If possible, use the deeper universal pan.

Using oven cleaner in a hot cooking compartment damages the enamel.

- Never use oven cleaner in the cooking compartment when it is still warm.
- Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

If the seal is very dirty, the appliance door will no longer close properly during operation. This may damage the front of adjacent kitchen units.

- Keep the seal clean at all times.
- Never operate the appliance if the seal is damaged

Sitting or placing objects on the appliance door may damage it.

- Do not place or hang objects on the appliance door.
- Do not place cookware or accessories on the appliance door.

With certain models, accessories may scratch the door pane when closing the appliance door.

Always push accessories fully into the cooking compartment.

Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Only preheat the appliance if the recipe or the recommended settings tell you to do so.

Not preheating the appliance can reduce the energy used by up to 20%.

Use dark-coloured, black-coated or enamelled baking

These types of baking tin absorb the heat particularly well.

Open the appliance door as little as possible during operation.

■ This will maintain the temperature in the cooking compartment and eliminate the need for the appliance to reheat.

When baking multiple dishes, do so in succession or in parallel.

 The cooking compartment is heated after baking the first dish. This reduces the baking time for the second cake.

If the cooking time is relatively long, you can switch the appliance off 10 minutes before the cooking time ends.

There will be enough residual heat to finish cooking the dish.

Remove any accessories that are not being used from the cooking compartment.

 Accessories that are not being used do not need to be heated.

Allow frozen food to defrost before cooking.


■ This will save the energy that would otherwise be required to defrost it.

Familiarising yourself with your appliance

4.1 Controls

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

On certain models, specific details such as colour and shape may differ from those pictured.



Buttons

→ "Buttons", Page 6

Function selector

You can turn the function selector clockwise or anti-clockwise from the zero setting. → "Types of heating", Page 6→ "Functions", Page 7

3 Display

→ "Display", Page 6

Temperature selector

Use the temperature selector to set the temperature for the type of heating or select the setting for other functions. You can turn the temperature selector clockwise and anti-clockwise.

→ "Temperature and setting levels", Page 7

Note: Depending on the appliance type, the control knobs can be pushed in. To click it in or out, push the control knob in when it is in the off position.

4.2 Buttons

The buttons are touch-sensitive surfaces. Press the corresponding button to select a function.

Symbol	Name	Use	
<u>(L)</u>	Time-setting options	Sets the time, timer, cooking time or end time → "Time-setting options", Page 11	
<	Left arrow	Decreases the adjustment values	
$\overline{}$	Right arrow	Increases the adjustment values	
î	Information	 ■ Displays the current cooking compartment temperature ■ Set basic settings → "Basic settings", Page 13 	

4.3 Display

The display shows the current settings, options or relevant information.

Symbol	Name	Use	
⇔	Childproof lock activated	The childproof lock is activated → "Childproof lock", Page 12	
Door lock Appliance door is locked → "Childproof lock", Page 12			
		→ "Pyrolytic self-cleaning ", Page 15	
B	Temperature display	Appliance is heating	

4.4 Types of heating

Here you can find an overview of the types of heating. You can find recommendations on using the types of heating. Use the function selector to set the types of heating.

Symbol	Type of heating	What it's used for/how it works	
L	CircoTherm hot air	Bake and roast on one or more levels. The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment.	
wall evenly around the cooking compartment. The food is cooked in ing residual heat. Select a temperature of between 120 °C and 230 °C. Always keep the appliance door closed when cooking. This type of heating is used to determine the energy consumption in		The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment. The food is cooked in phases using residual heat. Select a temperature of between 120 °C and 230 °C.	
<u>&</u>	Pizza setting	Cook pizza or dishes that require a lot of heat from below. The bottom heating element and the ring-shaped heating element in the back wall heat the cooking compartment.	
_	Bottom heating	Final baking or cooking food in a bain marie. Heat is emitted from below.	
****	Full-surface grill	Grill flat items such as steak and sausages, or make toast. Gratinate food. The entire area underneath the grill element becomes hot.	
Ž.	Circo-roasting	Roast poultry, whole fish and larger pieces of meat. The grill element and the fan switch on and off alternately. The fan circulates the hot air around the food.	
=	Top/bottom heating	Traditionally bake or roast on one level. This type of heating is ideal for cakes with moist toppings. The heat is emitted evenly from above and below. This type of heating is used to measure the energy consumption in the conventional mode.	

4.5 Functions

Here you can find an overview of the functions. Use the function selector to set the functions.

Symbol	Name	Use	
₿ŝ	Rapid heating	Rapidly preheat the cooking compartment without accessories. → "Rapid heating", Page 10	
<u> </u>	Oven light	Illuminate the cooking compartment without heating. → "Lighting", Page 8	
<u> </u>	EasyClean	EasyClean ^o removes light dirt from the cooking compartment. → "Cleaning aid EasyClean ", Page 16	
***	Pyrolytic self-cleaning	Set the cleaning function, which cleans the cooking compartment virtually independently. → "Pyrolytic self-cleaning", Page 15	

4.6 Temperature and setting levels

There are different settings for the types of heating and functions.

Note: For temperature settings above 275 °C for the Grill type of heating, the appliance reduces the temperature to approx. 250 °C after approx. 20 minutes.

Symbol	Function	Use	
•	Zero setting	The appliance is not heating up.	
50-275	Temperature range	Set the temperature in the cooking compartment in °C.	
<u> </u>	EasyClean	Set the cleaning aid.	
****	Grill, intensive	The maximum temperature that can be set for Full-surface grill and Grill, small area (depending on the appliance type).	
1, 2, 3 or I, II, III	Cleaning settings	Set the cleaning settings for Pyrolytic self-cleaning . 1 = light 2 = medium 3 = intensive	

Heat-up indicator

When you are preheating the appliance, the optimal time to place your food in the cooking compartment is when the symbol first goes out.

Notes

- The heat-up indicator only appears for types of heating for which a temperature is set. It does not appear for grill settings, for example.
- Due to thermal inertia, the temperature displayed may differ slightly from the actual temperature inside the cooking compartment.

4.7 Cooking compartment

The functions in the cooking compartment make your appliance easier to use.


Rails

The rails in the cooking compartment enable you to place accessories at different heights.

→ "Accessories", Page 8

Your appliance has four shelf positions. The shelf positions are numbered from bottom to top.

You can remove the rails, e. g. for cleaning. → "Shelf supports". Page 17



Lighting

The oven light lights up the cooking compartment. With most types of heating and functions, the lighting lights up during operation. When the function selector is turned to bring operation to an end, the lighting goes out.

The **Oven light** setting on the function selector can be used to switch on the light without heating.

Cooling fan

The cooling fan switches on and off depending on the appliance's temperature. The hot air escapes above the door.

ATTENTION!

Do not cover the ventilation slot above the appliance door. The appliance overheats.

Ensure that the ventilation slots are unobstructed.

To ensure that the appliance cools down more quickly after operation, the cooling fan continues to run for a certain period afterwards.

Appliance door

If you open the appliance door during operation, the operation continues.

5 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Accessories may become deformed if they get hot. Deformation has no effect on function. As the accessory cools down, it will regain its original shape.

The accessories supplied may differ depending on the appliance model.

Use **Accessories** Wire rack Cake tins Ovenproof dishes Cookware Meat, e.g. roasting joints or steak Frozen meals Universal pan Moist cakes Baked items Bread Large roasts Frozen meals Catching dripping liquids, e.g. fat when grilling food on the wire rack.

5.1 Locking function

The locking function prevents the accessories from tilting when they are pulled out.

You can pull out the accessories approximately halfway without them tipping. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.


5.2 Sliding accessories into the cooking compartment

Always slide accessories into the cooking compartment correctly. This is the only way to ensure that accessories can be pulled out approximately halfway without tip-

- 1. Turn the accessories so that the notch a is at the rear and is facing downwards.
- 2. Insert accessories between the two guide rods for the shelf position.


Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip - facing downwards.



Baking tray E.g. universal pan or baking tray

Slide the tray, e.g. the universal pan, in with the sloping edge b facing the appliance door.



3. Push the accessory all the way in, making sure that it does not touch the appliance door.


Note: Take any accessories that you will not be using out of the cooking compartment while the appliance is in operation.

Combining accessories

You can combine the wire rack with the universal pan to catch any liquid that drips down.

- 1. Place the wire rack on the universal pan so that both spacers a are on the rear edge of the universal pan.
- 2. Insert the universal pan between the two guide rods for a shelf position. In so doing, the wire rack is on top of the upper guide rod.

Wire rack on universal pan



5.3 Other accessories

You can purchase other accessories from our aftersales service, specialist retailers or online.

You will find a comprehensive range of products for your appliance in our brochures and online: www.neff-international.com

Accessories vary from one appliance to another. When purchasing accessories, always quote the exact product number (E no.) of your appliance.

You can find out which accessories are available for your appliance in our online shop or from our aftersales service.

Before using for the first time

Configure the settings for initial start-up. Clean the appliance and accessories.

6.1 Initial use

You need to make settings for initial use before you can use your appliance.

Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

Requirement: The function selector must be set to the "Off" position o.

- 1. Use the \langle or \rangle button to set the time.
- 2. Press the (button.
- The time that is set appears on the display.

Tip: You can go to the basic settings \rightarrow *Page 13* to specify whether or not the time should be shown on the display.

6.2 Cleaning the appliance before using it for the first time

Clean the cooking compartment and accessories before using the appliance to prepare food for the first

- 1. Remove any accessories and leftover packaging. such as polystyrene pellets, from the cooking compartment.
- 2. Before heating the appliance, wipe the smooth surfaces in the cooking compartment with a soft, damp cloth

- Keep the room ventilated while the appliance is heating.
- **4.** Set the type of heating and temperature.
 - → "Basic operation", Page 10

Type of heating	CircoTherm hot air &
Temperature	Maximum
Cooking time	1 hour

- Switch off the appliance after the specified cooking time.
- Wait until the cooking compartment has cooled down.
- Clean the smooth surfaces with soapy water and a dish cloth.
- 8. Clean the accessories using soapy water and a dish cloth or soft brush.

7 Basic operation

7.1 Switching on the appliance

- ► Turn the function selector to any position other than the "Off" position •.
- ▼ The appliance is switched on.

7.2 Switching off the appliance

- ► Turn the function selector to the "Off" position o.
- The appliance is switched off.

7.3 Setting the type of heating and temperature

- **1.** Use the function selector to set the type of heating.
- **2.** Use the temperature selector to set the temperature or grill setting.
- ▼ The appliance starts heating after a few seconds.

3. When your food is ready, switch off the appliance.

Tips

- The most suitable type of heating for your food can be found in the description of the type of heating.
 → "Types of heating", Page 6
- You can also set a cooking time and end time on the appliance.
 - → "Time-setting options", Page 11

Changing the type of heating

You can change the type of heating at any time.

► Use the function selector to set the required type of heating.

Changing the temperature

You can change the temperature at any time.

Use the temperature selector to set the required temperature.

8 Rapid heating

To save time, you can use rapid heating to shorten the preheat time.

Only use rapid heat-up when a temperature of over 100 °C has been set.

After rapid heating, it is best to use the following types of heating:

■ CircoTherm hot air &

8.1 Setting rapid heating

To ensure an even cooking result, do not place the food in the cooking compartment until rapid heating has come to an end.

- 1. Use the function selector to select rapid heating $\delta \hat{s}$.
- **2.** Use the temperature selector to set the required temperature.
- Rapid heating starts after a few seconds.
- When the rapid heating process ends, an audible signal sounds and the heating indicator goes out.
- **3.** Use the function selector to set a suitable type of heating.
- **4.** Place the food in the cooking compartment.

Time-setting options

Your appliance has different time-setting options, with which you can control its operation.

9.1 Overview of the time-setting options

With the (b) button, select the different time-setting options.

Time-setting option	Use
Timer △	The timer can be set independently of the appliance when it is in operation. It does not affect the appliance.
Cooking time I→I	If you set a cooking time, operation of the appliance stops automatically once this time has elapsed.
End time →I	For the cooking time, you can set the time at which operation ends. The appliance starts up automatically so that it finishes cooking at the required time.
Time ©	You can set the time.

9.2 Setting the timer

The timer runs independently of the appliance when it is in operation. The timer can be set when the appliance is switched on or off, up to 23 hours and 59 minutes. The timer has its own audible signal so that you can tell whether it is the timer or a cooking time which has elapsed.

- **1.** Press the \bigcirc button repeatedly until \triangle is highlighted in the display.
- **2.** Use the \langle or \rangle button to set the timer duration.

Button	Default value	
<	5 minutes	
$\overline{\rangle}$	10 minutes	

The timer duration can be set in 30-second increments up to 10 minutes. Above 10 minutes, the time increments become longer the higher the value.

- The timer starts and the timer duration begins to count down after a few seconds.
- An audible signal sounds and the timer duration is zero in the display when the timer duration has elapsed.
- 3. Once the timer duration has elapsed:
 - Press any button to switch off the timer.

Changing the timer

You can change the timer duration at any time.

Requirement: \triangle is highlighted on the display.

- Use the (or) button to change the timer duration.
- The appliance applies the change after a few seconds.

Cancelling the timer

You can cancel the timer duration at any time.

Requirement: \triangle is highlighted on the display.

- Use the \(\text{ button to reset the timer duration to zero.} \)
- After a few seconds, the appliance applies the change and \triangle goes out.

9.3 Setting the cooking time

You can set a cooking time for operation of up to 23 hours 59 minutes.

Requirement: The type of heating and temperature or setting are set.

- 1. Press the ⓑ button repeatedly until → is highlighted in the display.
- **2.** Use the \langle or \rangle button to set the cooking time.

Button	Default value
<	10 minutes
>	30 minutes

The cooking time can be set in 1-minute increments up to 1 hour, and then in 5-minute increments.

- ▼ The appliance starts heating and the cooking time counts down after a few seconds.
- ✓ If the cooking time has elapsed, an audible signal sounds and the display shows the cooking time as
- **3.** When the cooking time has elapsed:
 - Press any button to end the audible signal before
 - To set a cooking time again, press the > button.
 - When your food is ready, switch off the appli-

Changing the cooking time

You can change the cooking time at any time.

Requirement: \rightarrow is highlighted on the display.

- Change the cooking time using the \langle or \rangle button.
- The appliance applies the change after a few seconds.

Cancelling the cooking time

You can cancel the cooking time at any time.

Requirement: \rightarrow is highlighted on the display.

- Reset the cooking time to zero using the \(\) button.
- After a few seconds, the appliance applies the change and continues to heat without a cooking time.

9.4 Setting the end time

You can delay the time at which cooking is due to finish by up to 23 hours and 59 minutes.

Notes

- The end time cannot be set for types of heating with grill function.
- In order to achieve a good cooking result, do not delay the end time once the appliance is already in operation.
- Food will spoil if you leave it in the cooking compartment too long.

Requirements

- The type of heating and temperature or setting are
- A cooking time is set.
- **1.** Press the \bigcirc button repeatedly until \rightarrow is highlighted in the display.
- 2. Press the (or) button.
- The display shows the calculated end time.
- **3.** Use the \langle or \rangle button to delay the end time.
- ✓ After a few seconds, the appliance applies the setting and the display shows the set end time.
- Once the calculated start time has been reached, the appliance starts heating up and the cooking time starts counting down.
- Once the time has elapsed, an audible signal sounds and the display shows the cooking time as
- **4.** When the cooking time has elapsed:
 - Press any button to end the signal prematurely.
 - To set another cooking time, press the button.
 - When your food is ready, switch off the appli-

Changing the end time

In order to achieve a good cooking result, you can only change the set end time before operation starts and the cooking time starts counting down.

Requirement: \rightarrow is highlighted on the display.

- Use the (or) button to delay the end time.
- The appliance applies the change after a few seconds.

Cancelling the end time

You can delete the set end at any time.

Requirement: → I is highlighted on the display.

- Reset the end time to the current time plus the set cooking time using the \(\text{button.} \)
- After a few seconds, the appliance applies the change and starts heating up. The cooking time counts down.

9.5 Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

Requirement: The function selector must be set to the "Off" position o.

- 1. Use the \langle or \rangle button to set the time.
- 2. Press the (button.
- The time that is set appears on the display.

Tip: You can go to the basic settings \rightarrow *Page 13* to specify whether or not the time should be shown on the display.

Changing the time on the clock

You can change the time on the clock at any time.

Requirement: The function selector must be set to the "Off" position o.

- 1. Press the © button repeatedly until © is highlighted in the display.
- **2.** Use the \langle or \rangle button to change the time.
- ▼ The appliance applies the change after a few seconds.

10 Childproof lock

You can secure your appliance to prevent children from accidentally switching it on or changing the set-

Note: You can go to the basic settings → *Page 13* to specify whether you want the option to set the childproof lock.

You can only use the childproof lock to lock the control elements of the appliance. In addition, you can lock the appliance door.

→ "Basic settings", Page 13

10.1 Automatic childproof lock

When the appliance is switched off, it locks automatically. You need to pause the automatic childproof lock before you switch on the appliance.

You can activate and deactivate the automatic childproof lock in the basic settings.

→ "Basic settings", Page 13

Pausing the automatic childproof lock

Requirement: The automatic childproof lock is activated in the basic settings.

- → "Basic settings", Page 13
- ▶ Press and hold the ⓑ button until ⇔ goes out on the display.

10.2 Childproof lock

If you activate the childproof lock, the appliance is locked until you deactivate the childproof lock. If you switch off the appliance after the next operation, the childproof lock is not activated automatically.

Activating the childproof lock

► Press and hold the ① button until 🖘 appears on the display.

Deactivating the childproof lock

the display.

You can configure the appliance to meet your needs.

11.1 Overview of the basic settings

Here you can find an overview of the basic settings and factory settings. The basic settings depend on the features of your appliance.

Display	Basic setting	Selection		
- 0	Automatic childproof lock	☐ = no¹ I = yes		
<u>- 1</u>	Signal duration upon completion of a cooking time or timer period	I = 10 seconds ∃ = 30 seconds¹ ∃ = 2 minutes		
-2	Waiting time until a setting is adopted	I = 3 seconds¹ E = 6 seconds E = 10 seconds		
- 3	Button tone when pressing a button	$ \Box = \text{off} \\ I = \text{on}^1 $		
<u>-</u> 4	Brightness of the display illumination	I = dark ∃ = medium¹ ∃ = bright		
-5	Time display	☐ = hide the time I = display the time ¹		
c 6	Childproof lock can be adjusted	☐ = no I = yes¹ ⊇ = yes, with locked door		
<u>-</u> 7	Interior lighting during operation	☐ = no I = yes¹		
- 8	Cooling fan run-on time	I = short ∃ = medium¹ ∃ = long H = extra long		
c 9	Telescopic shelves retrofitted ²	= no ¹ (for rails and 1-level pull-out) I = yes (for 2- and 3-level pull-out)		
∟A	Reset all values to factory settings	☐ = no¹ I = yes		
 Factory Depend 	 Factory setting (may vary according to model) Depending on the appliance specifications 			

11.2 Changing basic settings

Requirement: The appliance is switched off.

- 1. Press and hold the \(\frac{1}{2}\) button for approximately four seconds.
- The first basic setting appears in the display, e.g. □ 1 l.
- **2.** Use the 〈 or 〉 button to change the setting.
- 3. Use the (1) button to switch to the next basic setting.

4. To save the changes, press and hold the \(\delta\) button for approx. four seconds.

Note: Your changes to the basic settings will be retained even after a power failure.

11.3 Discarding changes to the basic settings

- ► Turn the function selector.
- ✓ All changes are discarded and not saved.

Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

12.1 Cleaning products

In order to avoid damaging the various oven surfaces on the appliance, do not use unsuitable cleaning products.

⚠ WARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

Do not use steam- or high-pressure cleaners to clean the appliance.

ATTENTION!

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive cleaning products.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Do not use any special cleaners for cleaning the appliance while it is hot.

Using oven cleaner in a hot cooking compartment damages the enamel.

- Never use oven cleaner in the cooking compartment when it is still warm.
- ► Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

New sponge cloths contain residues from production.

Wash new sponge cloths thoroughly before use.

Suitable cleaning agents

Only use cleaning products that are suitable for the different surfaces on your appliance.

Follow the instructions on cleaning the appliance.

→ "Cleaning the appliance", Page 15

Appliance front

Surface	Suitable cleaning agents	Information
Stainless steel	 Hot soapy water Special stainless steel cleaning products suitable for hot surfaces 	To prevent corrosion, remove any patches of limescale, grease, starch or albumin (e.g. egg white) on stainless steel surfaces immediately. Apply a thin layer of the stainless steel cleaning product with a soft cloth.
Plastic or painted surfaces E.g. control panel	Hot soapy water	Do not use glass cleaner or a glass scraper.

Appliance door

Area	Suitable cleaning agents	Information
Door panels	Hot soapy water	Do not use a glass scraper or a stainless steel wool. Tip: Remove the door panels in order to clean them thoroughly. → "Appliance door", Page 18
Door cover	 Made of stainless steel: Stainless steel cleaner Made of plastic: Hot soapy water 	Do not use glass cleaner or a glass scraper. Tip: Remove the door cover for thorough cleaning. → "Appliance door", Page 18
Door handle	■ Hot soapy water	To avoid permanent stains, remove descaling agents from the door handle immediately.
Door seal	Hot soapy water	Do not remove or scrub.

Cooking compartment

Area	Suitable cleaning agent	s Information
Enamel surfaces	 Hot soapy water Vinegar water Oven cleaner 	Soak any heavily soiled areas and use a brush or steel wool. Leave the appliance door open to dry the cooking compartment after cleaning it. Tip: It is best to use the cleaning function. → "Pyrolytic self-cleaning", Page 15 Notes ■ Enamel burns at very high temperatures, causing minor discolouration. The functionality of your appliance is not affected by this. ■ The edges of thin trays cannot be completely enamelled and may be rough. This does not impair corrosion protection. ■ Food residues will leave a white coating on the enamel surfaces.
		The coating does not pose a health risk. The functionality of your appliance is not affected by this. You can remove residues with lemon juice.
Glass cover for the oven light	Hot soapy water	Use oven cleaner to remove very heavy soiling.
Rails	■ Hot soapy water	Soak any heavily soiled areas and use a brush or steel wool. Tip: Remove the shelf supports for cleaning. → "Shelf supports", Page 17
Accessorles	Hot soapy waterOven cleaner	Soak any heavily soiled areas and use a brush or steel wool. Enamelled accessories are dishwasher-safe.

12.2 Cleaning the appliance

In order to avoid damaging the appliance, you must clean your appliance only as specified, and with suitable cleaning products.

⚠ WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- Young children under 8 years of age must be kept away from the appliance.

⚠ WARNING – Risk of fire!

Loose food remnants, fat and meat juices may catch fire.

Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Requirement: Read the information on cleaning products.

- → "Cleaning products", Page 14
- 1. Clean the appliance using hot soapy water and a dish cloth.
 - For some surfaces, you can use alternative cleaning agents.
 - → "Suitable cleaning agents", Page 14
- 2. Dry with a soft cloth.

Cleaning function 13

You can use the cleaning function to clean the appliance.

13.1 Pyrolytic self-cleaning

The **Pyrolytic self-cleaning** cleaning function cleans the cooking compartment almost by itself. Use the cleaning function to clean the cooking compartment every two to three months. If required, you can use the cleaning function more frequently. The cleaning function requires approx. 2.5-4.8 kilowatt hours.

Preparing the appliance for the cleaning function

In order to achieve a good cleaning result, prepare the appliance carefully.

⚠ WARNING – Risk of fire!

Combustible objects that are left in the cooking compartment may catch fire.

- Never store combustible objects in the cooking compartment.
- If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire when the cleaning function is in progress.

- Before you start the cleaning function, always remove coarse dirt from the cooking compartment.
- Never clean accessories at the same time.

The outside of the appliance gets very hot when the cleaning function is in progress.

- Never hang combustible objects, e.g. tea towels, on the door handle.
- Leave the front of the appliance clear.
- Keep children at a safe distance.

If the door seal is damaged, a large amount of heat is generated around the door.

- Do not scrub or remove the seal.
- Never operate the appliance if the seal is damaged or missina.
- 1. Remove accessories and cookware from the cooking compartment.
- 2. Unhook the shelf supports and remove them from the cooking compartment.
 - → "Shelf supports", Page 17
- 3. Remove heavy soiling from the cooking compartment.
- **4.** Use a detergent solution and a soft cloth to clean the surfaces at the edges of the cooking compartment around the door seal.
 - Do not remove or scrub the door seal.
 - Use oven cleaner to remove stubborn dirt from the inner door pane.
- **5.** Remove any objects from the cooking compartment. The cooking compartment must be empty.

Setting the cleaning function

Ventilate the kitchen while the cleaning function is running.

WARNING – Risk of harm to health!

The cleaning function heats up the cooking compartment to a very high temperature so that food left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate mucous membranes.

- Keep the kitchen well ventilated while the cleaning function is running.
- Do not remain in the room for long periods.
- Keep children and pets away.

⚠ WARNING – Risk of burns!

The cooking compartment gets very hot when the cleaning function is in progress.

- Never open the appliance door.
- Allow the appliance to cool down.
- Keep children at a safe distance.

The outside of the appliance gets very hot when the cleaning function is in progress.

- Never touch the appliance door.
- Allow the appliance to cool down.
- Keep children at a safe distance.

Note: The oven light does not come on during the cleaning function.

Requirement: Prepare the appliance for the cleaning function. → Page 15

- 1. Use the function selector to set Pyrolytic self-
- 2. Use the temperature selector to set the cleaning setting.

Cleaning set- ting	Cleaning level	Duration in hours		
1	Lightly soiled	Approx. 1:15		
2	Medium	Approx. 1:30		
3	High	Approx. 2:00		

Select a higher cleaning setting for very heavy or older soiling.

The duration cannot be changed.

- The cleaning function starts after a few seconds and the time counts down.
- For safety reasons, the appliance door locks automatically once a certain temperature is reached in the cooking compartment.

 appears in the display.
- Once the cleaning function has ended, an audible signal sounds and the display shows the duration as zero.
- **3.** Switch off the appliance. Once the appliance has cooled down sufficiently, the appliance door unlocks and ⊕ goes out.
- **4.** Prepare the appliance for use. \rightarrow *Page 16*

Preparing the appliance for use following the cleaning function

- 1. Allow the appliance to cool down.
- 2. Wipe off any ash that has been left behind in the cooking compartment and around the appliance door with a damp cloth.
- 3. Remove white residues with lemon juice.

Note: White residues on the enamel surfaces may be caused by heavy soiling. These food residues are harmless. The deposits do not compromise the functionality of the appliance.

- Attach the shelf supports.
 - → "Shelf supports", Page 17

13.2 Cleaning aid EasyClean

Use the cleaning aid EasyClean for intermediate cleaning of the cooking compartment. The cleaning aid **EasyClean** softens dirt by vaporising the soapy water. The dirt can then be removed more easily.

Setting the cleaning aid EasyClean

MARNING – Risk of scalding!

If there is water in the cooking compartment when it is hot, this may create hot steam.

 Never pour water into the cooking compartment when the cooking compartment is hot.

Notes

- You cannot delay the end time.
- The length of time has been preset and cannot be changed.

Requirements

- Start the cleaning aid only when the cooking compartment has completely cooled down.
- To remove particularly stubborn dirt, leave the soapy water to work for some time before starting the cleaning aid.
- To remove particularly stubborn dirt, rub soapy water onto the dirt on smooth surfaces before starting the cleaning aid.
- 1. Remove the accessories from the cooking compartment.

2. ATTENTION!

Distilled water in the cooking compartment leads to

Do not use distilled water.

Mix 0.4 litres water with a drop of washing-up liquid and pour into the centre of the cooking compart-

- 3. Use the function selector and the temperature selector to set the cleaning aid .
- The length of time appears in the display.
- The cleaning aid starts after a few seconds. The duration counts down in the display.
- Once the cleaning aid has run through to the end, an audible signal sounds.

Note: If H flashes in the display when the cleaning aid is switched on, this indicates that the cooking compartment has not completely cooled down. Switch off the appliance. Wait until __ appears in the display and switch the cleaning aid back on.

Recleaning the cooking compartment **ATTENTION!**

The prolonged presence of moisture in the cooking compartment leads to corrosion.

After using the cleaning aid, wipe the cooking compartment clean and allow it to dry fully.

- 1. Open the appliance door and remove the remaining water with an absorbent sponge cloth.
- 2. Clean the smooth surfaces in the cooking compartment with a dish cloth or a soft brush. Stubborn residues can be removed using a stainless steel scouring pad.
- **3.** Remove limescale with a cloth soaked in vinegar. Then wipe with clean water and rub dry with a soft cloth (including under the door seal).
- 4. If you are unable to remove stubborn dirt, repeat the cleaning aid after the cooking compartment has cooled down.
- 5. To switch off, turn the function selector to the zero settina.
- 6. Lower the appliance door and leave it open for approx, one hour to allow the surfaces in the cooking compartment to dry thoroughly.
 - To dry the cooking compartment quickly, heat up the appliance for approx. five minutes at Circo-Therm hot air & and 50 °C while the door is open.

Shelf supports


To clean the rails and the cooking compartment, or to replace the rails, you can remove these.


14.1 Detaching the shelf supports

⚠ WARNING – Risk of burns!

The shelf supports get very hot

- Never touch the shelf supports when hot.
- Always allow the appliance to cool down.
- Keep children at a safe distance.
- **1.** Lift the rail forwards slightly ① and detach it ②.
- 2. Pull the whole rail to the front 3 and remove it.







- 3. Clean the rail.
 - → "Cleaning products", Page 14

14.2 Attaching the shelf supports

Notes

- The rails only fit on the right or left.
- For both rails, ensure that the curved rods are at the
- 1. First, push the rail into the middle of the rear socket 1 until the rail rests against the cooking compartment wall, and then push this back 2.
- 2. Push the rail into the front socket 3 until the rail also rests against the cooking compartment wall, and then press this downwards 4.





Appliance door

To ensure that your appliance retains its appearance and remains fully functioning for a long time, you can detach the appliance door and clean it.

⚠ WARNING – Risk of injury!


If the hinges are not secured due to an incomplete lock, they can snap shut with great force.


- To detach or attach the appliance door, always turn the two locks as far as they will go.
- If the hinge snaps closed when detaching or attaching the appliance door, do not reach into the hinge - call the after-sales service.


15.1 Detaching the appliance door

Requirements


- Have a torch ready.
- Have a screwdriver ready.
- Have a coin ready.
- 1. To make it easier to see the door lock, shine the torch into the gap beside the appliance door.
- 2. Hold the screwdriver horizontally ① and use it to push the door lock (black component) on each side of the door upwards as far as it will go 2.









3. Open the appliance door approx. 45° wide.



- 4. Insert the coin in the gap in the lock ① and rotate as far as it will go 2.
 - Turn the lock on the left-hand side in a clockwise direction.
 - Turn the lock on the right-hand side in an anticlockwise direction.






The lock audibly engages.

5. ATTENTION!

Opening and closing the appliance door when it is in the lock position damages the door hinges.

- Never force the appliance door open or closed.
- If the door hinge has been damaged, call the after-sales service.

Move the appliance door up and down until you hear a quiet click. You can still only move the appliance door slightly.



- The appliance door is in the lock position.
- **⚠** WARNING Risk of injury!


The appliance door has a weight of 7-10 kg and may fall if it is not handled carefully.

► Handle the appliance door carefully.

The door handle is not suitable for carrying the appliance door. The door handle may break off.

- Never carry the appliance door by the door handle.
- Grab hold of the appliance door with both hands on the left and right to carry it.


Firmly grip the appliance door with both hands at the left and right below the door handle, and pull it up and out.




7. Set the appliance door down on a flat, soft, clean surface.

15.2 Attaching the appliance door


1. **Tip:** Ensure that the appliance door is not wedged at an angle and that it is properly fitted in place. Attach the appliance door via the left- and right-hand guide rollers simultaneously a.



2. Ensure that the appliance door slides the short distance remaining to the bottom.



- 3. Use a coin to release both locks on the appliance door. Insert the coin in the gap in the lock 1 and rotate as far as it will go 2.
 - Turn the lock on the left-hand side in an anticlockwise direction.
 - Turn the lock on the right-hand side in a clockwise direction.




4. Open the appliance door slightly until you hear a quiet click, and then close the appliance door.

5. MARNING – Risk of injury!

If the door locks are unsecured, the appliance door may become detached.

► After attaching the appliance door, close the leftand right-hand door locks.

Hold the screwdriver horizontally 1 and use it to push the door lock (black component) on each side of the door downwards as far as it will go 2.



The door lock is closed.

15.3 Removing the door panes

To facilitate cleaning, you can remove the door pane.

⚠ WARNING – Risk of injury!

Components inside the appliance door may have sharp edges.

Wear protective gloves.


Requirement: The appliance door is detached.

- → "Detaching the appliance door", Page 18
- 1. Lay the appliance door with the front side facing down on a flat surface that is soft and clean.
- 2. Push on the left- and right-hand side of the appliance door from the outside ① until the inner pane is released on both sides.
- 3. Carefully lift the inner pane and remove it in the direction of the arrow 2.







4. Push down on the intermediate pane in the area of a, and carefully lift the retainer b until you are able to pull it out.



5. Lift the first and second intermediate panes from below 1 and remove them in the direction of the arrow



6. Remove the spacers a and seals for cleaning, if required.



Scratched glass in the appliance door may develop into a crack.

Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

Clean the door panes on both sides with glass cleaner and a soft cloth.

- 8. Dry the door panes and refit them.
 - → "Fitting the door panes", Page 21


15.4 Fitting the door panes

⚠ WARNING – Risk of injury!


If a door pane or appliance door has not been installed correctly, this is dangerous.

- ▶ Make sure that all of the door panes and the appliance door have been correctly fitted before you switch the appliance back on again.
- 1. Tip: When fitting the door panes, make sure that they are in the original order.


Insert the intermediate pane so that the a arrow on the right-hand side is pointing upwards.




- 2. Check the fit of the four spacers and two seals.
 - Place the spacers on the centre of the lines a ①.
 - Secure the seals at the corners 2.




- 3. Insert the intermediate pane with spacers and seals in the direction of the arrow 1.
 - The arrow on the intermediate pane must line up with the arrow on the frame a.
- 4. Insert the second intermediate pane without the spacers and seals, and slide it in the direction of the arrow until it is inserted in the frame 2.






The arrow on the intermediate pane must line up with the arrow on the frame b.


5. Push down on the intermediate pane around a. slide the retainer b in at an angle and push down until it clicks into place.



The retainer has been inserted.



- 6. Insert the inner pane into the fixing rail at an angle towards the back a 1.
- 7. Push the inner pane downwards until it locks into place 2.





16 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting aftersales service. This will avoid unnecessary costs.

MARNING – Risk of injury!

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ If the appliance is defective, call Customer Service.

⚠ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- ► If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

16.1 Malfunctions

Fault	Cause and troubleshooting
The appliance is not	The circuit breaker is faulty.
working.	► Check the circuit breaker in the fuse box.
	There has been a power cut.
	Check whether the lighting in your kitchen or other appliances are working.
Appliance is not heating; the colon flashes in the display.	Demo mode is activated.
The appliance door	The childproof lock locks the appliance door.
cannot be opened;	► Use the ⊕ button to deactivate the childproof lock.
⇔ lights up in the display.	→ "Childproof lock", Page 12
The appliance door	The cleaning function locks the appliance door.
cannot be opened;	► Allow the appliance to cool down until ⊕ goes out in the display.
lights up in the display.	→ "Pyrolytic self-cleaning ", Page 15
The time flashes in	There has been a power cut.
the display.	► Reset the time.
	→ "Setting the time on the clock", Page 12
The time does not appear in the display	S S
when the appliance is	 Change the basic setting for the time display. → "Basic settings", Page 13
switched off.	Basic settings , rage 15
⇔ lights up in the	Childproof lock is activated.
display and no set- tings can be made	► Use the ⑤ button to deactivate the childproof lock.
on the appliance.	→ "Childproof lock", Page 12
h flashes in the dis-	The cooking compartment is too hot for the selected operation.
play and the appli-	1. Switch off the appliance and allow it to cool down.
ance does not start.	2. Restart the operation.
F ∃ appears in the display.	The maximum cooking time has been reached. To prevent an unwanted permanent operation, the appliance automatically stops heating after several hours if the settings are unchanged.
	 Switch off the appliance. You can configure new settings if required.
	Tip: To prevent the appliance from switching off when you do not want it to, e.g. for an
	extremely long preparation time, set a cooking time.

Fault Cause and troubleshooting

A message with E appears in the display, e.g. E05-32.

Electronics fault

- 1. Press the © button.
 - If required, reset the time.
- ✓ If the fault was a one-off, the error message disappears.
- 2. If the error message appears again, call the after-sales service. Quote the exact error message and the E no. of your appliance.
 - → "Customer Service", Page 24

16.2 Replacing the oven light bulb

If the light in the cooking compartment fails, change the oven light bulb.

Note: Heat-resistant, 40-watt, 230 V halogen bulbs are available from the after-sales service or specialist retailers. Only use these bulbs. Hold the new halogen bulbs only with a clean, dry towel. This increases the service life of the bulb.

⚠ WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- Young children under 8 years of age must be kept away from the appliance.



When changing the bulb, the bulb socket contacts are live.


- Before replacing the bulb, ensure that the appliance is switched off in order to prevent a potential electric shock.
- Also unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

Requirements

- The appliance is disconnected from the power sup-
- The cooking compartment has cooled down.
- You have a new halogen bulb to replace the old one.

- 1. Place a tea towel in the cooking compartment to prevent damage.
- Turn the glass cover anti-clockwise to remove it ①.
- **3.** Pull out the halogen bulb without turning it ②.





- 4. Insert the new halogen lamp and press it firmly into the socket.
 - Make sure the pins are positioned correctly.
- **5.** Depending on the appliance model, the glass cover may have a sealing ring. Put the sealing ring in posi-
- **6.** Screw the glass cover on.
- **7.** Take the tea towel out of the cooking compartment.
- 8. Connect the appliance to the power supply.

Disposal

Find out here how to dispose of old appliances correctly.

17.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- **3.** Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE).

The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

18 **Customer Service**

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service. Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.


Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website. If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

18.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. The rating plate bearing these numbers can be found on the base of the appliance when you open the appliance door.



Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

19 How it works

Here, you can find the ideal settings for various types of food as well as the best accessories and cookware. We have perfectly tailored these recommendations to your appliance.

19.1 Cooking tips

Observe this information when preparing food.

- The temperature and cooking time depend on the amount of food and the recipe. Settings ranges are specified for this reason. Try using the lower values to start with.
- The setting values apply to food placed in the cooking compartment while the cooking compartment is still cold. Do not slide the accessory into the cooking compartment until it has finished preheating.
- Remove any accessories that are not being used from the cooking compartment.

19.2 Notes on baking

When baking, use the shelf positions indicated.

Baking on one level	Height
Deep baked goods or tin on wire rack	2
Flat baked goods or goods in a baking	3
tray	

Baking on two levels	Height
Universal pan Baking tray	3
Baking tins/dishes on the wire rack: First wire rack Second wire rack	Height 3 1

Baking on three levels	Height
Baking tray	4
Universal pan	3
Baking tray	1

Notes

- When baking on several layers, always use hot air. Baked goods that are placed in the oven at the same time will not necessarily be ready at the same
- Position baking tins/dishes either next to one another or offset on different shelves so that they are not directly one above the other in the cooking com-
- For best results, we recommend using dark-coloured metal bakeware.

19.3 Notes on roasting and grilling

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry, meat or fish is placed into a cold cooking compartment.

- The larger the poultry, meat or fish, the lower the cooking temperature and the longer the cooking time.
- Turn the poultry, meat or fish after approx. 1/2 to 2/3 of the time listed.
- Add a little liquid to the poultry in the cookware. Cover the bottom of the cookware with approx. 1-2 cm of liquid.
- When you turn poultry, ensure that the breast side or skin side is underneath to begin with.
- Cooking time calculation (e.g. 20 + 35): To calculate the cooking time, assume 20 minutes per 500 g of meat plus an extra 35 minutes. For 1.5 kg, the cooking time is then 95 minutes.
- Cooking time range (e.g. 10-15): Your food will be ready within the specified range of time.

Roasting and grilling on the wire rack

Roasting on the wire rack works particularly well for large poultry or for multiple pieces at the same time.

- Depending on the size and type of the food to be roasted, add up to 1/2 litre water to the universal pan.
 - You can make a sauce from the juices that are caught. This also means that less smoke is produced and the cooking compartment becomes less dirty.
- Keep the appliance door closed when using the grill.
 - Never grill with the appliance door open.
- Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. This means that any dripping fat is caught.

Roasting in cookware

When preparing food in cookware with a lid, the cooking compartment remains cleaner.

Follow the manufacturer's instructions for your roasting dishes. Glass cookware is best.

Cookware without lid

- Use a deep roasting dish.
- Place the cookware onto the wire rack.
- If you do not have any suitable cookware, use the universal pan.

Cookware with lid

- Place the cookware onto the wire rack.
- Meat, poultry and fish can also become crispy in a covered roasting dish. Use a roasting dish with a glass lid. Set a higher temperature.

⚠ WARNING – Risk of injury!

If hot glass cookware is placed on a wet or cold surface, the glass may shatter.

Place hot glass ovenware on a dry mat after cook-

WARNING – Risk of scalding!

Very hot steam may escape when the lid is opened after cooking. Steam may not be visible, depending on the temperature.

- Lift the lid in such a way that the hot steam can escape away from you.
- Keep children away from the appliance.

19.4 Food selection

Food	Accessories/cookware	Shelf pos- ition	Type of heating	Temperature in °C/grill setting	Cooking time in mins
Victoria sponge cake	2 pcs Ø 20 cm cake tin	2	S	150-170 ¹	15-25
Rich fruit cake	Deep 23 cm diameter tin	2	0	140-150	180-210
Fruit pie	20 cm diameter plate or pie tin	2	<u>&</u>	160–170	60-70
Quiche	Quiche tin (dark-coated)	3	00	180-200	40-55
(White) bread	Loaf tin (1 x 900 g or 2 x 450 g)	2	=	190-210 ¹	25-40
Scones	Baking sheet on wire rack	3	Ξ	190-200²	10-15
Biscuits	Baking sheet on wire rack	3	L	140-160 ¹	10-20
Small cakes	12-cup tin	3	Ξ	150 ³	25-35
Pavlova	Baking sheet on wire rack	3	L	100-110 ⁴	150-180
Yorkshire pudding	12-cup tin	3	<u>&</u>	200-220 ⁵	15-25
Pizza, home-made	Baking tray	3	S	190-210	20-30
Pizza, home-made, thin base	Round pizza tray	2	<u>&</u>	250-270	8–13

Preheat the appliance. Do not use the rapid heating function.

Preheat the appliance.

Preheat the appliance for five minutes. Do not use the rapid heating function.

Preheat the appliance to 150 °C using HotAir.

Preheat the appliance for 20 minutes.

Do not turn the food.

Slide the universal pan underneath the wire rack.

Add the food after approx. one hour.

Preheat the appliance for 5 minutes.

¹⁰ Preheat the appliance for three minutes.

¹¹ Turn the food occasionally.

Food	Accessories/cookware	Shelf pos- ition	Type of heating	Temperature in °C/grill setting	Cooking time in mins
Victoria sponge cake, 2 levels	4 pcs Ø 20 cm cake tin	3+1	S	150-160 ²	20-30
Biscuits, 2 or 3 levels	Baking sheet on wire rack	3+1 4+3+1	J	140–160²	15–25
Beef, top side/top rump	Cookware without lid	2	S	170	40+30
Lamb leg (on the bone)	Cookware without lid	2	J	160-170	25+15
Pork belly	Cookware without lid	2	1. 2. ****	1. 170–180 2. 250	1. 30+30 ⁶ 2. 3–5
Chicken, whole	Wire rack	2	S	170-180	25+15 ⁷
Turkey, crown	Wire rack	2	S	140-150	20+25
Turkey, whole, 4-8 kg	Wire rack	1	S	150-160	12+12 ⁸
Fish, braised, whole 300 g, e. g. trout	Cookware with lid	2	00	170-190	25-35
Diced meat (beef, pork, lamb), 500 g	Cookware with lid	2	00	140	120-140
Complete meal with chicken	Wire rack + Wire rack + Universal pan	4+1	چ ا	180, then 200 (York- shire pud- ding)	Chicken: (25+25) + 20 for York- shire pud- ding
Bacon rashers	Wire rack	3	****	lnL/ ^{~~9}	1 side 4–5 2 side 3–4
Sausages, thickness 2-4 cm	Wire rack	3	***	Int/***10	10-15 ¹¹
Pork, gammon joint	Cookware without lid	2	Ž	170-180	25+20 ⁶
Chicken, whole	Cookware without lid	2	Ž	170-180	20+20 ⁷

¹ Preheat the appliance. Do not use the rapid heating function.

19.5 Yoghurt

You can use your appliance to make your own yoghurt.

Preparing yoghurt

- 1. Remove the accessories and shelf supports from the cooking compartment.
- 2. Pour the previously prepared yoghurt mixture into small containers, e.g. into cups or small jars.
- **3.** Cover the containers with foil, e. g. with cling film.
- **4.** Place the containers on the cooking compartment floor.
- **5.** Set the appliance according to the recommended setting.
- **6.** After making the yoghurt, leave it to cool in the refrigerator.

Recommended settings for yoghurt

Food	Accessories/cookware	Shelf position	Type of heating	Temperature in °C	Cooking time in mins
Yoghurt	Individual moulds	Cooking compartment floor	_	40-45	8-9 hrs

² Preheat the appliance.

³ Preheat the appliance for five minutes. Do not use the rapid heating function.

⁴ Preheat the appliance to 150 °C using HotAir.

⁵ Preheat the appliance for 20 minutes.

⁶ Do not turn the food.

⁷ Slide the universal pan underneath the wire rack.

⁸ Add the food after approx. one hour.

⁹ Preheat the appliance for 5 minutes.

¹⁰ Preheat the appliance for three minutes.

¹¹ Turn the food occasionally.

19.6 Test dishes

These overviews have been produced for test institutes to facilitate appliance testing in accordance with EN 60350-1.

Baking

Observe this information when baking test dishes.

General information

- The settings apply to food that is placed into a cold cooking compartment.
- Observe the notes about preheating in the tables. These setting values apply without rapid heating.
- When baking, use the lower of the listed temperatures to begin with.

Shelf positions

Shelf positions for baking on two levels:

Note: Items that are placed in the oven on baking trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

Universal pan: Level 3 Baking tray: Level 1


Baking tins/dishes on the wire rack First wire rack: Level 3 Second wire rack: Level 1

Shelf positions for baking on three levels:

Baking tray: Level 4 Universal pan: Level 3 Baking tray: Level 1

Baking with two springform cake tins:

Position baking tins/dishes either next to one another or offset on different shelves so that they are not directly one above the other in the cooking compartment.



Recommended settings for baking

Food	Accessories/cookware	Shelf pos- ition	Type of heating	Temperature in °C	Cook- ing time in mins
Viennese whirls	Baking tray	3	=	140-150 ¹	25-35
Viennese whirls	Baking tray	3	S	140-150 ¹	20-30
Viennese whirls, 2 levels	Universal pan + Baking tray	3 + 1	ک	140-150 ¹	25-35
Viennese whirls, 3 levels	Universal pan + Baking tray	4 + 3 + 1	S	130–140¹	35-55
Small cakes	Baking tray	3	Ξ	150 ¹	25-35
Small cakes	Baking tray	3	L	140¹	25-35
Small cakes, 2 levels	Universal pan + Baking tray	3 + 1	٨	140 ¹	30-40
Small cakes, 3 levels	Universal pan + Baking tray	4 + 3 + 1	٨	140 ¹	30-40
Hot water sponge cake	Springform cake tin, diameter 26 cm	2	=	160-170 ²	25–35
Hot water sponge cake	Springform cake tin, diameter 26 cm	2	000	160–170	30-35
Hot water sponge cake, 2 levels	Springform cake tin, diameter 26 cm	3 + 1	L	150-160 ²	35–50

² Preheat the appliance. Do not use the rapid heating function.

Recommended settings for grilling

Food	Accessories/cookware	Shelf pos- ition	Type of heating	Temperature in °C/grill setting	Cook- ing time in mins
Toasting bread	Wire rack	4	***	InL/***1	5-6
¹ Do not preheat the appliance.				_	

Installation instructions 20

Observe this information when installing the appliance.






20.1 General installation instructions

Follow these instructions before you start with the installation of the appliance.

- The safe operation of this appliance can only be guaranteed if it has been installed to a professional standard in accordance with these installation instructions. The installer shall be liable for damages incurred as a result of incorrect installation.
- Do not use the door handle for the transport or installation.
- Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.
- Before starting up the appliance, remove any packaging material and adhesive film from the cooking compartment and the door.
- Proceed in accordance with the installation sheets for installing accessories.
- Fitted units must be heat-resistant up to 95 °C, and adjacent unit fronts up to 70 °C.
- Do not install the appliance behind a decorative door or the door of a kitchen unit. There is a risk of overheating.
- Cut-out work on the units should be carried out before installing the appliance. Remove any shavings. Otherwise, the correct operation of electrical components may be adversely affected.

The mains socket for the appliance must either be located in the hatched area @ or outside of the area where the appliance is installed.

Any unsecured units must be secured to the wall using a standard bracket b.



- Wear protective gloves so that you do not cut yourself. Parts that are accessible during installation may have sharp edges.
- Dimensions of the figures in mm.

MARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- Do not use multiple socket strips.
- Only use extension cables that are certified. have a minimum cross section of 1.5 mm² and comply with the applicable national safety requirements.
- ▶ If the power cord is too short, contact customer service.
- Only use adapters approved by the manufacturer.


ATTENTION!

Carrying the appliance by the door handle could break it. The door handle cannot support the weight of the appliance.

Do not carry or hold the appliance by the door handle.


20.2 Appliance dimensions

You will find the dimensions of the appliance here



20.3 Installation below a worktop


Observe the installation dimensions and the installation instructions when installing below a worktop.



- To ventilate the appliance, the intermediate floor must have a ventilation cut-out.
- In combination with induction hobs, the gap between the worktop and appliance must not be sealed using additional strips.
- The worktop must be secured to the built-in unit.
- Observe any available installation instructions for the hob.

20.4 Installing below a hob

If the appliance is installed below a hob, the following minimum dimensions must be adhered to (including substructure, if applicable).




The minimum worktop thickness b is based on the required minimum clearance a.

Hob type	a raised in mm	a flush in mm	b in mm
Induction hob	37	38	5
Full-surface induction hob	47	48	5
Gas hob	30	38	5
Electric hob	27	30	2

20.5 Installation in a tall unit


Observe the installation dimensions and the installation instructions when installing in a tall unit.



- To ventilate the appliance, the intermediate floors must have a ventilation cut-out.
- If the tall unit has another back panel in addition to the element back panels, this must be removed.
- Only fit the appliance up to a height which allows accessories to be easily removed.

20.6 Corner installation

Observe the installation dimensions and the installation instructions when installing in a corner.



To ensure that the appliance door can be opened, you must take the minimum dimensions into consideration when installing in a corner. The dimension a is dependent on the thickness of the unit front and the handle.

20.7 Electrical connection

In order to safely connect the appliance to the electrical system, follow these instructions.

- The appliance corresponds to protection class I and must only be operated with a protective earth connection.
- The fuse protection must correspond to the power rating specified on the appliance's rating plate and to local regulations.
- The appliance must be disconnected from the power supply whenever installation work is being carried out.
- The appliance must only be connected using the power cable provided.

- The power cable must be plugged in at the rear of the appliance until you hear a clicking sound. A 3 m power cable can be obtained from the after-sales service.
- The power cable must only be replaced with a cable from the original manufacturer. This is available from after-sales service.
- Contact protection must be ensured during the installation.

Electrically connect the appliance with the protective contact plug

Note: The appliance must only be connected to a protective contact socket that has been correctly installed.

Insert the plug into the protective contact socket. When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access to the mains plug is impossible, an all-pole isolating switch must be integrated into the permanent electrical installation in accordance with the installation regulations.

Electrically connecting an appliance without a protective contact plug

Note: Only a licensed professional may connect the appliance. Damage caused by incorrect connection is not covered under the warranty.


An all-pole isolating switch must be integrated into the permanent electrical installation according to the installation regulations.

- Identify the phase and neutral conductors in the socket.
 - The appliance may be damaged if it is not connected correctly.
- 2. Connect the hob in accordance with the connection diagram.
 - See the rating plate for the voltage.
- **3.** Connect the wires of the mains power cable according to the colour coding:
 - Green/yellow = Protective conductor ⊕
 - Blue = Neutral conductor
 - Brown = Phase (external conductor)

20.8 Installing the appliance


Note: Do not use a cordless screwdriver to secure the panels. This may damage the panels.

1. If required, you can adjust the gap between the appliance door and the panels using the adjustment screws on the left and right.




Turning the screws clockwise makes the gap larger Turning the screws anti-clockwise makes the gap smaller

- **2.** Push the appliance in fully. Do not kink or trap the connection cable, or route it over sharp edges.
- 3. Centre the appliance.




There must be an air gap of at least 4 mm between the appliance and adjacent unit fronts.

Open the appliance door slightly and unscrew panels on the left and right.



5. Close the appliance door.


6. If required, you can adjust the height of the appliance door using the adjustment screws on the left and right.




Turning the screws clockwise makes the gap smal-

Turning the screws anti-clockwise makes the gap larger


7. Screw the appliance into place.



- 8. For handleless kitchens with vertical bar handle strips:
 - Attach a suitable filling piece ① in order to cover any sharp edges and to guarantee a safe installation.
 - Pre-drill aluminium profiles to establish a screw connection 2.
 - Secure the appliance using a suitable screw 3.



9. Open the appliance door slightly, then refit the panels and screw them in place, first at the top and then at the bottom.



Note: The gap between the worktop and the appliance must not be closed by additional battens. Thermal insulation strips must not be fitted to the side panels of the surround unit.

20.9 Removing the appliance

- 1. Disconnect the appliance from the power supply.
- 2. Undo the fastening screws.
- 3. Lift the appliance slightly and pull it out completely.













REGISTER YOUR PRODUCT ONLINE NEFF-HOME.COM

Constructa-Neff Vertriebs-GmbH Carl-Wery-Straße 34 81739 München GERMANY Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom



9001580261 010806 en