





#### You can find additional information and explanations online. Scan the QR code on the title page.



## Table of contents

INF	ORMATION FOR USE		17	Basic settings	22
1	Safety	2	18	Home Connect	24
2	Preventing material damage	6	19	Cleaning and servicing	25
3	Environmental protection and saving energy	7	20	"Pyrolytic self-cleaning" cleaning function	27
4	Familiarising yourself with your appliance	8	21	"Easy Clean" cleaning aid	28
5	Functions	9	22	Drying	29
6	Accessories	12	23	Rails	30
7	Before using for the first time	13	24	Appliance door	30
8	Basic operation	13	25	Troubleshooting	32
9	Microwave	15	26	Disposal	34
10	Ventilation function "Crisp Finish"	16	27	Customer Service	34
11	Time-setting options	16	28	Information regarding Free and Open Source	
12	Meat probe	18		Software	
13	Dishes	19	29	Declaration of Conformity	
14	Favourites	21	30	How it works	36
15	Childproof lock	21	31	INSTALLATION INSTRUCTIONS	47
16	Bapid heating	22	31.1	General installation instructions	47

## ▲ 1 Safety

Observe the following safety instructions.

#### 1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

#### 1.2 Intended use

This appliance is designed only to be built into kitchen units. Read the special installation in-

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under the warranty.

Only use this appliance:

■ To prepare meals and drinks.

- For household use and similar applications, such as: In kitchens for employees in shops, offices and other commercial sectors; in agriculture; by customers in hotels and other residential facilities; in bed and breakfasts.
- Up to an altitude of 4000 m above sea level. This appliance complies with the standards EN 55011 and CISPR 11. It is a group 2, class B product. Group 2 means that microwaves are produced for the purpose of heating food. Class B means that the appliance is suitable for private households.

#### 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance

safely and have understood the resulting dangers.

Do not let children play with the appliance. Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

#### 1.4 Safe use

Always place accessories in the cooking compartment the right way round.

→ "Accessories", Page 12

## 

Combustible objects that are left in the cooking compartment may catch fire.

- ► Never store combustible objects in the cooking compartment.
- ► If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire.

► Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Opening the appliance door creates a draught. Greaseproof paper may come into contact with the heating element and catch fire.

- Never place greaseproof paper loosely over accessories when preheating the appliance and while cooking.
- Always cut greaseproof paper to size and use a plate or baking tin to hold it down.

#### 

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- ► Young children under 8 years of age must be kept away from the appliance.

Accessories and cookware get very hot.

Always use oven gloves to remove accessories or cookware from the cooking compartment.

When the cooking compartment is hot, any alcoholic vapours inside may catch fire. The appliance door may spring open. Hot steam and jets of flame may escape.

Only use small quantities of drinks with a high alcohol content in food.

- Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).
- ▶ Open the appliance door carefully.

## 

The accessible parts of the appliance become hot during operation.

- ► Never touch these hot parts.
- ► Keep children at a safe distance.

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- ► Open the appliance door carefully.
- ► Keep children at a safe distance.

If there is water in the cooking compartment when it is hot, this may create hot steam.

► Never pour water into the cooking compartment when the cooking compartment is hot.

## **△ WARNING – Risk of injury!**

Scratched glass in the appliance door may develop into a crack.

► Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

The appliance and its parts that can be touched may have sharp edges.

- ► Take care when handling and cleaning them.
- ▶ If possible, wear protective gloves.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- ► Keep your hands away from the hinges. Components inside the appliance door may have sharp edges.
- Wear protective gloves.

Alcoholic vapours may catch fire in the hot cooking compartment, and the appliance door may spring open and may fall off. The door panels may shatter and fragment.

- → "Preventing material damage", Page 6
- ► Only use small quantities of drinks with a high alcohol content in food.
- Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).
- Open the appliance door carefully.

### ⚠ WARNING – Risk of electric shock!

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.

- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.
- ► If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord. An ingress of moisture can cause an electric shock.
- ► Do not use steam- or high-pressure cleaners to clean the appliance.

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ► If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer service. → Page 34
  Once the appliance has been installed, the openings in the back panel of the appliance must not be accessible to children.
- ▶ Read the special installation instructions.

## **⚠ WARNING – Danger: Magnetism!**

Caution: Magnetism

Caution for people with pacemakers Permanent magnets are used in the control panel. These may impair the functionality of electronic implants, e.g. pacemakers or insulin pumps.

► Persons with electronic implants must stand at least 10 cm away from the control panel.

## **⚠ WARNING – Risk of suffocation!**

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

Keep packaging material away from children.

 Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

#### 1.5 Microwave

CAREFULLY READ THE IMPORTANT SAFETY INSTRUCTIONS AND KEEP THEM SAFE FOR FUTURE USE

### ⚠ WARNING – Risk of fire!

Using the appliance for anything other than its intended purpose is dangerous and may cause damage. For example, heated slippers and pillows filled with grain or cereal may catch fire, even several hours later.

- Never dry food or clothing with the appliance.
- Never heat up slippers, pillows filled with grain or cereal, sponges, damp cleaning cloths or similar with the appliance.
- ► The appliance must only be used to prepare food and drink.

Food and its packaging and containers may catch fire.

- ► Never heat food in heat-retaining packaging.
- Do not leave food unattended while it is heating in containers made of plastic, paper or other combustible materials.
- Never set the microwave power too high or the cooking time too long. Follow the instructions provided in this user manual.
- ► Never use the microwave to dry food.
- Never defrost or heat food with a low water content, such as bread, at too high a microwave power or for too long.

Cooking oil may catch fire.

► Never use the microwave to heat cooking oil on its own.

## 

Liquids and other food may easily explode when in containers that have been tightly sealed.

► Never heat liquids or other food in containers that have been tightly sealed.

## **⚠ WARNING – Risk of burns!**

Foods with peel or skin may burst or explode during heating, or even afterwards.

- Never cook eggs in their shell or heat hardboiled eggs in their shell.
- Never cook shellfish or crustaceans.

- ► Always prick the yolk of eggs before microwaving.
- ► The skin of foods that have a peel or skin, such as apples, tomatoes, potatoes and sausages, may burst. Before heating, prick the peel or skin.

Heat is not distributed evenly through baby food

- ▶ Never heat baby food in closed containers.
- ► Always remove the lid or teat.
- ► Stir or shake well after heating.
- Check the temperature before giving the food or drink to a child.

Heated food gives off heat. The cookware may become hot.

Always use oven gloves to remove cookware or accessories from the cooking compartment.

Airtight packaging may burst when food is heated.

- Always follow the instructions on the packaging.
- Always use oven gloves to remove the dishes from the cooking compartment.

The accessible parts of the appliance become hot during operation.

- ► Never touch these hot parts.
- Keep children at a safe distance.

At the highest settings in microwave only mode, the drying function will automatically switch on an additional heating element to heat the cooking compartment.


- Never touch the inside surfaces of the cooking compartment or the heating elements while they are hot.
- Keep children at a safe distance.

## 

There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches the boiling temperature without the usual steam bubbles rising to the surface. Exercise caution even when only gently shaking the container. The hot liquid may suddenly boil over and splatter.

► Always place a spoon in the container when heating liquids. This prevents delayed boil-

#### ing.



## **⚠ WARNING – Risk of injury!**

Unsuitable cookware may crack. Porcelain or ceramic cookware can have small perforations in the handles and lid. These perforations conceal a cavity below. If moisture penetrates this cavity, it could cause the cookware to crack.

- ► Only use microwave-safe cookware. Cookware and containers made from metal or cookware with metal edging may lead to sparks being formed during simple microwave operation. The appliance is damaged.
- Never use metal containers during microwave-only operation.
- ► Only use microwave-safe cookware or use the microwave in combination with a type of heating.

#### ⚠ WARNING – Risk of electric shock!

The appliance uses a high voltage.

Never remove the casing.

# **⚠ WARNING** – Risk of serious harm to health!

Inadequate cleaning may destroy the surface of the appliance, reduce its service life, and lead to dangerous situations, such as escaping microwave energy.

- ► Clean the appliance on a regular basis, and remove any food residue immediately.
- ► Always keep the cooking compartment, door seal, door and hinge clean.
- → "Cleaning and servicing", Page 25
  Never operate the appliance if the cooking compartment door or the door seal is damaged. Microwave energy may escape.
- Never use the appliance if the cooking compartment door, the door seal or the plastic door frame is damaged.
- ► Any repair work must only be carried out by customer service.

Microwave energy will escape from appliances that do not have any casing.

- ▶ Never remove the casing.
- ► For any maintenance or repair work, contact the customer service.

### 1.6 Meat probe

#### WARNING – Risk of electric shock!

Using the wrong meat probe could damage the insulation.

▶ Only use the meat probe for this specific appliance.

## ⚠ WARNING – Risk of injury!

The meat probe is sharp.

► Handle the meat probe with care.

## 1.7 Cleaning function

#### 

Loose food remnants, fat and meat juices may catch fire when the cleaning function is in progress.

- ▶ Before you start the cleaning function, always remove coarse dirt from the cooking compartment.
- ▶ Never clean accessories at the same time. The outside of the appliance gets very hot when the cleaning function is in progress.
- ▶ Never hang combustible objects, e.g. tea towels, on the door handle.
- ► Leave the front of the appliance clear.
- ► Keep children at a safe distance.

If the door seal is damaged, a large amount of heat is generated around the door.

- ▶ Do not scrub or remove the seal.
- ▶ Never operate the appliance if the seal is damaged or missing.

## ⚠ WARNING – Risk of serious harm to health!

The appliance gets very hot when the cleaning function is in progress. The non-stick coating on baking trays and tins is destroyed and noxious gases are released.

- Never clean non-stick baking trays or baking tins using the cleaning function.
- Never clean accessories at the same time.

## 

The cleaning function heats up the cooking compartment to a very high temperature so that food left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate mucous membranes.

- Keep the kitchen well ventilated while the cleaning function is running.
- ▶ Do not remain in the room for long periods.
- Keep children and pets away.

### 

The cooking compartment gets very hot when the cleaning function is in progress.

- Never open the appliance door.
- ► Allow the appliance to cool down.
- ► Keep children at a safe distance.

The outside of the appliance gets very hot when the cleaning function is in progress.

- ▶ Never touch the appliance door.
- ► Allow the appliance to cool down.
- Keep children at a safe distance.

## 2 Preventing material damage

#### 2.1 General

#### **ATTENTION**

Alcoholic vapours may catch fire in the hot cooking compartment and cause permanent damage to the appliance. The appliance door may spring open due to an explosion and it may fall off. The door panels may shatter and fragment. Due to the resulting negative pressure, the cooking compartment may become considerably deformed inwards.

Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120 °C, this will damage the enamel.

- ▶ Do not use the appliance if there is water on the cooking compartment floor.
- Wipe away any water on the cooking compartment floor before operation.

Objects on the cooking compartment floor at over 50 °C will cause heat to build up. The baking and roasting times will no longer be correct and the enamel will be damaged.

- ► Do not place any accessories, greaseproof paper or foil of any kind on the cooking compartment floor.
- Only place cookware on the cooking compartment floor if a temperature under 50 °C has been set. When the cooking compartment is hot, any water inside it will create steam. The change in temperature may cause damage.
- Never pour water into the cooking compartment when it is still hot.
- Never place cookware containing water on the cooking compartment floor.

The prolonged presence of moisture in the cooking compartment leads to corrosion.

- ► Allow the cooking compartment to dry after use.
- Do not keep moist food in the cooking compartment for a long time with the door closed.
- Do not store food in the cooking compartment.
- Take care not to trap anything in the appliance door.

Fruit juice dripping from the baking tray leaves stains that cannot be removed.

- When baking very juicy fruit flans, do not pack too much on the baking tray.
- ► If possible, use the deeper universal pan.

Using oven cleaner in a hot cooking compartment damages the enamel.

- ► Never use oven cleaner in the cooking compartment when it is still warm.
- ► Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

If the seal is very dirty, the appliance door will no longer close properly during operation. This may damage the front of adjacent kitchen units.

- Keep the seal clean at all times.
- ► Never operate the appliance if the seal is damaged or

Sitting or placing objects on the appliance door may damage it.

- ► Do not place, hang or support objects on the appliance door.
- ► Do not place cookware or accessories on the appliance door.

With certain models, accessories may scratch the door pane when closing the appliance door.

 Always push accessories fully into the cooking compartment.

If aluminium foil comes into contact with the door pane, it could cause permanent discolouration.

▶ Do not allow aluminium foil in the cooking compartment to come into contact with the door pane.

#### 2.2 Microwave

Follow these instructions when using the microwave.

#### **ATTENTION**

Metal touching the wall of the cooking compartment will cause sparks, which may damage the appliance or the inner door pane.


► Metal (e.g. a spoon in a glass) must be kept at least 2 cm from the cooking compartment walls and the inside of the door.

Using accessories directly on top of one another causes sparks.

- ▶ Do not combine the wire rack with the universal pan.
- ► Always place accessories on different levels.

The universal pan and baking tray are not suitable for use with microwave-only mode. Using either of these may create sparks, which will damage the cooking com-

- Place accessories on the wire rack supplied. Placing aluminium containers in the appliance may cause sparks, which will damage the appliance.
- ▶ Do not use aluminium containers in the appliance. Operating the appliance without food in the cooking compartment may lead to overloading.
- ▶ Do not switch on the microwave unless there is food inside. The only exception to this rule is when performing a short cookware test.



If you prepare microwave popcorn at a microwave power level that is too high, the door pane may crack due to overloading.

- Never set a microwave power level that is too high.
- Use a maximum microwave output of 600 watts.
- ► Always place the popcorn bag on a glass plate.

## 3 Environmental protection and saving energy

## 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

## 3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Only preheat the appliance if the recipe or the recommended settings tell you to do so.

- → "How it works", Page 36
- ✓ Not preheating the appliance can reduce the energy used by up to 20%.

Use dark-coloured, black-coated or enamelled baking

▼ These types of baking tin absorb the heat particularly well.

Open the appliance door as little as possible during operation.

▼ This maintains the temperature in the cooking compartment and eliminates the need for the appliance to reheat.

When baking multiple dishes, do so in succession or in parallel.

The cooking compartment is heated after baking the first dish. This reduces the baking time for the subsequent cakes.

For longer cooking times, you can switch the appliance off 10 minutes before the cooking time ends.

▼ There is sufficient residual heat to finish cooking the dish.

Remove any accessories that are not being used from the cooking compartment.

Accessories that are not being used do not need to be heated.

Allow frozen food to defrost before cooking.

▼ This saves the energy that would otherwise be required to defrost it.

Switch off the display in the basic settings.

- → "Basic settings", Page 22
- ✓ Energy is saved when the display is switched off.

Heat two glasses or cups of liquid at the same time.

✓ Heating several dishes at the same time requires less energy than heating dishes one after the other.

**Note:** In accordance with the EU Ecodesign Directive 2023/826, this appliance is in a different state when

switched off. This is referred to below as low power mode.

Even when the main function is not active, the appliance needs energy for:

- Detecting operation of the touch keys
- Monitoring door opening
- Editing the time (without display)


By definition, therefore, there is neither an "off" nor a "standby" mode, which is why the term low power mode is used. EN IEC 60350-1:2023 must be used to measure low power mode.


## 4 Familiarising yourself with your appliance

## 4.1 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

On certain models, specific details such as colour and shape may differ from those pictured.





## 4.2 Display

You can configure all the functions on your appliance via the display.

The main menu provides an overview of your appliance's functions.

→ "Functions", Page 9

## **Navigating**

Direction	Use
Navigate to the left	Swipe right on the display with your finger

Direction	Use
Navigate to the right	Swipe left on the display with your finger

### **Setting values**

To adjust a setting, touch the appropriate place on the display with your finger. The settings area appears on the display. Swipe left or right over this settings area on the display with your finger until the required setting is magnified.

Values	Use
Increase	Swipe right on the display with your fin-
	ger
Decrease	Swipe left on the display with your fin-
	ger

To set values precisely, keep your finger close to the required value on the scale until a more precise scale appears.

#### 4.3 Buttons

The buttons are touch-sensitive areas. To select a function, press the corresponding button.

Symbol	Name	Use	
(1)	On/Off	Switch the appliance on or off	
<u>्</u>	Home Connect	Display for Home Connect. The field has no further function. When the symbol lights up, the appliance is connected.	
$\overline{ }$	Start/stop	Start or pause the appliance	
\$\$\$ \$\$\$	Microwave	Setting the microwave	

## 4.4 Cooking compartment

Various functions in the cooking compartment provide support when operating your appliance.


### **Shelf supports**

The shelf supports in the cooking compartment enable you to place accessories at different heights.

→ "Accessories", Page 12

Your appliance has 3 shelf positions. The shelf positions are numbered from bottom to top.

You can remove the shelf supports, e.g. for cleaning. → "Rails", Page 30



#### Lighting

One or more oven lights illuminate the cooking compartment.

When you open the appliance door, the light in the cooking compartment switches on. If the appliance door remains open for longer than 15 minutes, the light switches off again.

For most functions, the lighting is switched on during operation. The lighting switches off again when the operation ends.

#### Cooling fan

The cooling fan switches on and off depending on the appliance's temperature. The hot air escapes above the door.

#### **ATTENTION**

Covering the ventilation slots will cause the appliance to overheat.

Do not cover the ventilation slots.

To cool down the appliance and remove residual moisture from the cooking compartment, the cooling fan runs for a certain time after operation.

Note: You can change the run-on time in the basic settings. If you frequently prepare very moist food or keep it warm in the cooking compartment, set a longer run-on

→ "Basic settings", Page 22

#### **Appliance door**

If you open the appliance door during operation, the operation stops. If you close the appliance door, operation resumes automatically.

In microwave mode, if you close the appliance door, you must continue the operation.

## 5 Functions

The main menu provides an overview of your appliance's functions.

Tip: Depending on the appliance type, additional or more comprehensive functions are available to you with the Home Connect app. You can find more information about this in the app.

Function	Name	Use
	Types of heating	Select the required type of heating and temperature for your food
*** ***	Microwave	Use the microwave to cook, heat up or defrost food quickly  → "Microwave", Page 15
$\bigcirc$	Favourites	Select saved favourites  → "Favourites", Page 21

#### en Functions

Function	Name	Use
	Dishes	Use programmes or recommended settings for various types of food  → "Dishes", Page 19
	Cleaning	<ul> <li>Pyrolytic self-cleaning ﷺ cleans the cooking compartment almost by itself         → "Pyrolytic self-cleaning cleaning function", Page 27</li> <li>Easy Clean  removes light dirt from the cooking compartment         → "Easy Clean cleaning aid", Page 28</li> <li>Drying function  function of the cooking compartment         → "Drying", Page 29</li> </ul>
<b>⊕</b>	Basic settings	Individually adjust the appliance settings  → "Basic settings", Page 22

## 5.1 Heating functions

This is where you will find an overview of the types of heating. You will find recommendations for using the types of heating.

For temperatures above 275 °C, the appliance reduces the temperature to approx. 275 °C after around 40 minutes.

Symbol	Heating function	Temperature	Use
J	Circo Therm hot air	30 - 230 °C	Bake or roast on one or more levels.  The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment.
=	Top/bottom heat	30 - 275 °C	Traditionally bake or roast on one level. This type of heating is especially good for cakes with moist toppings.  The heat is emitted evenly from above and below.
C ()	Circo Therm gentle	125 - 230 °C	For gently cooking selected types of food on one level without preheating.  The fan distributes the heat from the ring-shaped heating element in the back wall around the cooking compartment.  The food is cooked in phases using residual heat. Always keep the appliance door closed when cooking. If you open the appliance door even briefly, the appliance will continue to heat without utilising any residual heat.  This type of heating is used to determine the energy consumption in circulating-air mode and the energy efficiency class.
<del></del>	Top/bottom heat gentle	150 - 250 °C	For gently cooking selected types of food without preheating. Heat is emitted from above and below.  This type of heating is used to determine the energy consumption in the conventional mode.
T T	Circo-roasting	30 - 275 °C	Roast poultry, whole fish or larger pieces of meat. The grill element and the fan switch on and off alternately. The fan circulates the hot air around the food.
<u>&amp;</u>	Circotherm intensive	30 - 275 °C	Cook pizza or food that requires a lot of heat from below.  The bottom heating element and the ring-shaped heating element in the back wall heat the cooking compartment.
	Bread baking setting	180 - 275 °C	For baking bread, bread rolls and baked goods that require high temperatures.
****	Full-surface grill	50 - 290 °C	For grilling flat items such as steaks, sausages or bread, and for cooking au gratin.  The entire area below the grill element becomes hot.
····	Centre-area grill	50 - 290 °C	For grilling small amounts of steaks, sausages or bread, and for cooking au gratin.  The central area below the grill element becomes hot.
_	Bottom heat	30 - 250 °C	For cooking in a bain marie and for baking food for extra time. The heat is emitted from below.
9	Low-temperature cooking	70 - 120 °C	For gentle, slow cooking of seared, tender pieces of meat in cookware without a lid.  The heat is emitted evenly from above and below at a low temperature.
$\Box$	Dough proving	30 - 50 °C	For proving dough and culturing yoghurt.

Symbol	Heating function	Temperature	Use
			Dough will prove more quickly than at room temperature. The surface of the dough does not dry out.
<u></u>	Plate warming	30 - 90 C	For heating cookware.
$\bigoplus$	Keep warm	50 - 100 °C	For keeping cooked food warm.

## 5.2 Microwave power settings

This is where you can find an overview of the different microwave output settings and recommendations on when to use them.

Microwave output in watts	Maximum cooking time in hours	Use
90 W	1:30	Defrost delicate foods.
180 W	1:30	Defrost food and continue cooking.
360 W	1:30	Cook fish and meat. Heat up delicate foods.
600 W	1:30	Heat and cook food.
900 W"Boost"	00:30	Heat liquids.

#### **Notes**

■ To protect the appliance, the maximum microwave output "Boost" is gradually reduced to 600 watts during the first few minutes. Maximum output is made

- available again after a cooling period. Full output is made available again after a cooling period.
- The microwave output settings do not correspond with the real power consumption of the appliance.

## 5.3 Additional options

You can find an overview of other options here. To display the options, press:

Symbol	Name	Use
- <u>\</u> -	Lighting	Switch the lighting in the cooking compartment on or off
Ô	Timer	Set the timer
$\overline{\sim}$	Childproof lock	Activate the childproof lock
	Remote start	Activate remote start  → "Home Connect ", Page 24

## 5.4 Symbols

You can find an overview of other symbols on the display here.

Symbol	Name	Use
<u> </u>	Save setting	Save the setting
	Back	Navigate back
X	Close	Close the message
9	Reset	Reset the cooking time
$\widehat{}$	Reset	Reset the values
<b>√</b> ∱	Change	Change the selection
i	Information	Display information
Jậ	Rapid heating	Activate or deactivate the rapid heating function
<u></u>	Home Connect	<ul> <li>Home network and Home Connect server connected</li> <li>The number of lines shows the signal strength of the home network</li> <li>→ "Home Connect ", Page 24</li> </ul>
Ž.	Home network	Home network not connected  → "Home Connect ", Page 24
( x	Home Connect server	Home Connect server not connected  → "Home Connect ", Page 24
F.Y	Remote diagnostics	Remote diagnostics activated  → "Home Connect ", Page 24

## 6 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Accessories may become deformed if they get hot. Deformation has no effect on function. As the accessory cools down, it will regain its original shape.

The accessories supplied may differ depending on the appliance model.

Accessories	Use
Wire rack	<ul> <li>Cake tins</li> <li>Ovenproof dishes</li> <li>Cookware</li> <li>Meat, e.g. roasting joints or steak</li> <li>Frozen meals</li> </ul>
Universal pan	<ul> <li>Moist cakes</li> <li>Baked items</li> <li>Bread</li> <li>Large roasts</li> <li>Frozen meals</li> <li>Catch dripping liquids, e.g. fat when grilling food on the wire rack.</li> </ul>
Meat thermometer	High-precision roasting or cooking.  → "Meat probe", Page 18

#### 6.1 Information on accessories

Some accessories are only suitable for certain functions.

#### Microwave accessories

The wire rack that is supplied is only suitable for operation solely using the microwave.

Baking trays, e.g. the universal pan or the baking tray, may create sparks and are not suitable.

Observe the information about the microwave.

→ "Cookware and accessories with microwave", Page 15

## 6.2 Locking function

The locking function prevents the accessories from tilting when they are pulled out.


You can pull out the accessories approximately halfway without them tipping. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

## 6.3 Sliding accessories into the cooking compartment

Always slide the accessory into the cooking compartment the right way round. This is the only way to ensure that accessories can be pulled out approximately halfway without tipping.


- 1. Turn the accessories so that the notch a is at the rear and is facing downwards.
- 2. Insert the accessory between the two guide rods for a shelf position.

Wire rack Insert the wire rack with the open side facing the appliance door.



Tray E.g. universal pan or baking tray

Slide the tray in with the sloping edge **b** towards the appliance door.



3. Push the accessory all the way in, making sure that it does not touch the appliance door.

Note: Take any accessories that you will not be using out of the cooking compartment while the appliance is in operation.

#### 6.4 Other accessories

You can purchase other accessories from our customer service, specialist retailers or online.

You will find a comprehensive range of products for your appliance in our brochures and online: www.neff-home.com

Accessories are appliance-specific. When purchasing accessories, always quote the exact product number (E no.) of your appliance.

You can find out which accessories are available for your appliance in our online shop or from our customer service.

## 7 Before using for the first time

Configure the settings for initial start-up. Clean the appliance and accessories.

#### 7.1 Initial use

After connecting the appliance to the power supply, you must configure the settings for its initial start-up. It may take a few minutes for the settings to appear on the display.

#### **Notes**

- You can adjust the settings at any time in the basic settings.
  - → "Basic settings", Page 22
- You can also use Home Connect to configure the settings. When your appliance is connected, follow the instructions in the app.
  - → "Home Connect ", Page 24

### Setting the language

**Requirement:** The appliance is connected to the power

- **1.** Press ① to switch the appliance on.
- 2. Swipe left or right to select the required language.
- **3.** Press the required language.
- **4.** Press  $\rightarrow$  to confirm the language.

#### Setting up Home Connect

Note: You can skip Home Connect set-up by pressing "Later". Next, set the clock.

- 1. Press "Connect" to set up Home Connect.
- 2. Make all other settings for initial start-up in the Home Connect app.

#### Setting the time

- 1. Swipe left or right to select the hours.
- 2. Press the minutes.
- **3.** Swipe left or right to select the minutes.
- **4.** Press ✓ to confirm the time.

#### Setting the date

1. Swipe left or right to select the correct year.

- 2. Press the month.
- **3.** Swipe left or right to select the correct month.
- **4.** Press the day.
- **5.** Swipe left or right to select the correct day.
- **6.** Press  $\checkmark$  to confirm the date.
- 7. Press "OK" to end the initial start-up.
- 8. Open and close the appliance door once.
- ▼ The appliance will perform a self-test, after which it will be ready to use.
- ▼ The initial start-up is now complete.

## 7.2 Cleaning the appliance

Before using the appliance to cook food for the first time, you must clean the cooking compartment and accessories.

- 1. Remove the product information, accessories and any leftover packaging (e.g. polystyrene pellets) from the cooking compartment.
- 2. Wipe the smooth surfaces in the cooking compartment with a soft, damp cloth.
- 3. Press (1) to switch the appliance on.
  - → "Switching on the appliance", Page 13
- 4. Set the required type of heating and temperature for the heat-up process and press III to start.
  - → "Setting the type of heating and temperature", Page 14

Heating up	
Type of heating	Circo Therm hot air ⊀
Temperature	Maximum
Cooking time	1 hour

- **5.** Ventilate the kitchen while the appliance is heating.
- 6. Press ① to switch off the appliance after 1 hour. → "Switching off the appliance", Page 14
- 7. Allow the appliance to cool down.
- 8. Clean the smooth surfaces with soapy water and a dish cloth.
- 9. Thoroughly clean any accessories you used with soapy water and a dish cloth.

## 8 Basic operation

## 8.1 Switching on the appliance

### **ATTENTION**

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120 °C, this will damage the enamel.

- ▶ Do not use the appliance if there is water on the cooking compartment floor.
- Wipe away any water on the cooking compartment floor before operation.

▶ Press ① to switch the appliance on.

- In the basic settings, you can specify whether the display shows the main menu or another function when the appliance is switched on.
  - → "Basic settings", Page 22
- If you do not perform any actions on the appliance for an extended period, it will automatically switch itself off.

## 8.2 Switching off the appliance

▶ Press (1) to switch the appliance off.

#### **Notes**

- The residual heat indicator will appear on the display while the cooking compartment is still hot.
  - → "Residual heat indicator", Page 14
- The cooling fan will continue to run until the cooking compartment has cooled down.
  - → "Cooling fan", Page 9

#### 8.3 Residual heat indicator

After you have switched off the appliance, the residual heat indicator will appear on the display.

Display	Temperature
Residual heat high	Over 120 °C
Residual heat low	Between 60 and 120 °C

# 8.4 Setting the type of heating and temperature

- **1.** Press ① to switch the appliance on.
- 2. Press "Types of heating".
- **3.** Swipe left or right until the required type of heating appears.
- **4.** Press the type of heating.
- 5. Press "Temperature".
- **6.** Swipe left or right to select a temperature.
- **7.** Press  $\checkmark$  to confirm the setting.

Also available to select:

- Rapid heating → Page 22
- Cooking time → Page 17
- Ready at → Page 17
- Microwave → Page 16
- → "Meat probe", Page 18
- Information → Page 14
- **8.** Press III to start the operation.
- ▼ The cooking time appears on the display.
- ✓ For some types of heating, the heat-up indicator can be viewed in the preheating phase. The optimal time to place your food in the cooking compartment is as soon as the heat-up indicator is filled.
- **9.** When the food is ready, use  $\bigcirc$  to switch the appliance off.

## 8.5 Changing the temperature

You can also change the temperature once you have started the operation.

- 1. Press ^.
- 2. Press "Temperature".
- **3.** Swipe left or right until the changed temperature appears.
- **4.** Press  $\checkmark$  to confirm the setting.
- ✓ The temperature is changed.

## 8.6 Changing the type of heating

If you switch to a different type of heating, the appliance will reset all the settings.

- 1. Press II to pause operation.
- **2.** Press to switch to the types of heating.

- **3.** Swipe left or right until the required type of heating appears.
- 4. Press the type of heating that you want to use.
- 5. Adjust the temperature or level, if required.
- **6.** Press III to start the operation.

## 8.7 Pausing operation

- 1. Press III.
- 2. Press III again to resume operation.

## 8.8 Displaying information

**Note:** In most cases, you can call up information about the function that you have just started.

- 1. Press "Information".
- ▼ The information will be displayed for a few seconds.
- **2.** Press  $\times$  to close the information.

## 8.9 Keeping warm over an extended period

You can use your appliance to keep meals warm for up to 24 hours without changing the behaviour of the appliance. Use the time functions and change the basic settings.

**Note:** If you open the appliance door during operation, the appliance stops heating. When you close the appliance door, the appliance continues to heat again. To ensure that the behaviour of the appliance is not changed during operation, only open the appliance door once the set time has elapsed.

- 1. Change the basic settings.
  - → "Basic settings", Page 22
  - ► Change the "Lighting" basic setting to "Always off".
  - ► Change the "Standby screen" basic setting to "On".
  - ► Change the "Signal tone" basic setting to "Very short duration".
- ✓ This will ensure that the light in the cooking compartment is always off while the appliance is in operation and when you open the appliance door. The clock display does not change. The duration of the signal tone is reduced at the end of the operation.
- 2. Set the required operating mode.
  - → "Heating functions", Page 10
- **3.** Set the required cooking time depending on the operating mode.
  - → "Setting the cooking time", Page 17
  - → "Time-setting options", Page 16
- **4.** Use "End" to set the time at which the operation should end.
  - $\rightarrow$  "Setting the "Ready at" time for delayed starts", Page 17
  - → "Time-setting options", Page 16
- **5.** Place the food in the cooking compartment before the appliance starts to heat.
- **6.** Press III to start the operation.
- ▼ The display shows the time remaining until the operation starts. The appliance is in standby mode.
- Once the start time has been reached, the appliance starts heating and the cooking time starts counting down.
- 7. When the operation has ended, remove the food from the cooking compartment. The appliance automatically switches off completely after approximately 15 to 20 minutes.

Note: If required, change the different basic settings again.

## 9 Microwave

You can use the microwave to cook, heat up, bake or defrost food very quickly.

The microwave can be used on its own, or in combination with a different function.

### 9.1 Cookware and accessories with microwave

To heat food evenly and avoid damaging your appliance, it is important to only use the right cookware and accessories.

Follow the cookware manufacturer's instructions. Unless otherwise specified, place the cookware and accessory on level 1.

#### Microwave-safe cookware

Cookware made from heat-resistant, microwave-safe material:

- Glass
- Glass ceramic
- Porcelain
- Temperature-resistant plastic
- Fully glazed ceramic without cracks
- Serving dishes

Only use cookware with decorative gold or silver trim if the manufacturer quarantees its suitability for microwave use.

 Supplied wire rack In microwave-only operation, sheets and trays, e.g. the universal pan or the baking tray, may create sparks and are not suitable.

These materials allow microwaves to pass through and are not damaged.

#### Cookware that is not microwave-safe

**Note:** Observe the specifications for preventing material damage.

- → "Microwave", Page 7
- Metal cookware and bakeware

Microwaves cannot pass through metal. The food is barely heated or not heated at all. Metal may create sparks in microwave-only operation.

#### Cookware when adding microwave to an operating mode

If you switch on the microwave for another operating mode, metal is also an option, in addition to microwavesafe cookware and accessories:

- Metal cookware and bakeware Metal must be kept at least 2 cm from the cooking compartment walls and the inside of the door. Always place metal cookware or bakeware in the centre of the supplied wire rack.
- Accessories supplied: Wire rack Universal pan Baking tray


### Testing cookware for microwave suitability

If you are unsure whether your cookware is suitable for use in the microwave, carry out a cookware test.

#### **ATTENTION**

Operating the appliance without food in the cooking compartment may lead to overloading.

► Do not switch on the microwave unless there is food inside. The only exception to this rule is when performing a short cookware test.



## ⚠ WARNING – Risk of burns!

The accessible parts of the appliance become hot during operation.

- ► Never touch these hot parts.
- ► Keep children at a safe distance.
- 1. Place the empty cookware in the cooking compartment
- 2. Set the appliance to run for 30 seconds to 1 minute at maximum power.
- 3. Start the operation.
- 4. Check the cookware several times:
  - ▶ If the cookware remains cold or warm to the touch, it is suitable for microwave use.
  - If the cookware becomes hot or sparks are created, stop the cookware test. The cookware is not microwave-safe.

## 9.2 Microwave-only operation

The electromagnetic waves of the microwave alone generate energy and this is converted into heat in food, for example.

To prevent condensation, when the microwave output is "600 W" and "Boost", the appliance automatically switches on a heating element. The cooking compartment and the accessories become hot. The cooking result is not affected by this.

You can switch off this automatic drying function in the basic settings.

→ "Basic settings", Page 22

#### ⚠ WARNING – Risk of burns!

At the highest settings in microwave only mode, the drying function will automatically switch on an additional heating element to heat the cooking compartment.

- ► Never touch the inside surfaces of the cooking compartment or the heating elements while they are hot.
- ► Keep children at a safe distance.

#### 9.3 Added microwave

Adding the microwave to a type of heating or function reduces the cooking time.

### Types of heating and functions for added microwave

You can switch on added microwave for the following types of heating and functions:

- "Circo Therm hot air" &
- "Circo-roasting" 🖫
- "Bread baking setting"
- "Full-surface grill" \*\*\*\*
- "Centre-area grill" <sup>™</sup>
- → "Dishes", Page 19
- → "Meat probe", Page 18
- → "Ventilation function Crisp Finish", Page 16

Possible microwave output settings combined with a type of heating or function include:

- "90 W"
- "180 W"
- "360 W"

## Setting added microwave

Note the correct way to operate the microwave:

- → "Safety", Page 2
- → "Preventing material damage", Page 6
- → "Microwave power settings", Page 11

→ "Cookware and accessories with microwave", Page 15

Requirement: Observe the information about the respective type of heating or function.

- 1. Set a suitable type of heating or function.
  - → "Types of heating and functions for added microwave", Page 16
- 2. Set the required temperature.
- 3. Press "Microwave".
- **4.** Press the required microwave output setting:
  - "90 W"
  - "180 W"
  - "360 W"
- **5.** Press  $\checkmark$  to confirm the setting.
- 6. Press "Cooking time".
- 7. Swipe left or right to select the duration.
- **8.** Press  $\checkmark$  to confirm the setting.
- 9. Press III to start operation with added microwave.
- ▼ The appliance starts to heat and the cooking time counts down.
- ✓ When the time has elapsed, a signal tone sounds. A notification appears on the display confirming that the operation has finished.
- 10. Press any button to end the signal tone.

### Cancelling added microwave

- 1. Press ^.
- 2. Press "Microwave".
- 3. Press "Off".
- **4.** Press  $\checkmark$  to confirm the setting.
- The operation continues without added microwave.

## 10 Ventilation function "Crisp Finish"

The ventilation function "Crisp Finish" extracts moisture from the cooking compartment so that your meal will be more crispy.

Hot steam that may escape when the appliance door is opened is reduced.

### 10.1 Types of heating for the ventilation function

Only certain types of heating are suitable for the ventilation function.

You can activate the ventilation function for the following types of heating:

- "Circo Therm hot air" &
- "Circo-roasting" 🖫
- "Circotherm intensive" &
- "Bread baking setting" #

## 10.2 Activating the ventilation function

You can activate the ventilation function at any time, even once the operation has started.

- **1.** Press ① to switch the appliance on.
- 2. Set a suitable type of heating.
  - → "Types of heating for the ventilation function", Page 16
- 3. Set the required temperature.
- 4. Press "Crisp Finish" =>.
- **5.** Press III to start operation with the ventilation function.
- 6. When the food is ready, use ① to switch the appli-

Note: Amplified fan noises can be heard while the appliance is in operation.

## 10.3 Cancelling the ventilation function

- **1.** Press ^.
- 2. Press "Crisp Finish" = 3.
- The operation continues without the ventilation func-

## 11 Time-setting options

Your appliance has different time-setting options, with which you can control its operation.

Time-setting option	Use
Timer 🗘	You can set the timer to run independently of the appliance during operation. The timer does not affect the appliance.
Cooking time  →	Once the set duration has elapsed, the appliance stops heating automatically.
Ready at →	Along with the duration, you can set the time at which you want the opera- tion to end. The appliance starts up automatically so that the operation fin- ishes at the required time.

#### **11.1 Timer**

You can set the timer regardless of whether the appliance is on or off.

### Setting the timer

- 1. Press :.
- 2. Press Q.
- 3. Press Hours, Minutes or Seconds.
- 4. Swipe left or right to select the required timer dura-
- **5.** Press ▷ to confirm the setting.
- Once the timer duration has elapsed, an audible signal sounds.
- 6. Press any button to end the audible signal.

## Changing the timer

- 1. Press :
- 2. Press ⊕.
- 3. Press II.
- 4. Press Hours, Minutes or Seconds.
- 5. Swipe left or right to change the timer duration.
- **6.** Press ▷ to confirm the setting.

### Cancelling the timer

- 1. Press :
- **2.** Press  $\circ$ .
- **3.** Press 9 to reset the timer duration.

## 11.2 Cooking time

Once the set duration has elapsed, the appliance stops heating automatically. You can only use the cooking time in conjunction with a type of heating.

## Setting the cooking time

- 1. Set a type of heating and a temperature.
- 2. Press "Cooking time".
- 3. Swipe left or right to select the duration.
- **4.** Press ▷ to confirm the setting.
- **5.** Press III to start operation with a cooking time.
- ▼ The cooking time appears on the display. The cooking time counts down.
- ✓ When the time has elapsed, a signal sounds.
- 6. Press any button to end the audible signal.

## Changing the cooking time

- 1. Press ^.
- 2. Press "Cooking time".
- 3. Swipe left or right to change the duration.
- **4.** Press ▷ to confirm the setting.

## Cancelling the cooking time

- 1. Press ^.
- 2. Press "Cooking time".
- **3.** Reset the cooking time using 9.
- **4.** Press  $\checkmark$  to confirm the setting.

## 11.3 Delayed start/"Ready at" time

With this function, the appliance automatically switches itself on, and then switches itself off at the preselected end time. To enable it to do this, you set the cooking time (duration) and specify when you want your food to be ready. You can only use the delayed start function in conjunction with a heating function.

## Setting the "Ready at" time for delayed starts **Notes**

- Do not leave food that spoils easily in the cooking compartment for too long.
- You cannot use the delayed start function with every type of heating.
- 1. Place the food into the cooking compartment and close the appliance door.
- 2. Set a type of heating and a temperature.
- 3. Press "Cooking time".
- 4. Press Hours or Minutes.
- **5.** Swipe left or right to select the duration.
- **6.** Press  $\checkmark$  to confirm the setting.
- 7. Press "Ready at".
- ▼ The time at which your food will be ready will appear. on the display.
- 8. Swipe left or right to select the end time.
- **9.** Press  $\checkmark$  to confirm the setting.
- **10.**Press III to confirm the delayed start.
- ✓ Once the start time has been reached, the appliance starts heating and the cooking time starts counting down.
- ✓ When the time has elapsed, a signal tone sounds.
- 11. Press any button to end the audible signal.

### Changing the "Ready at" time for delayed starts

- 1. Press III.
- 2. Press "Ready at".
- **3.** Swipe left or right to change the end time.
- **4.** Press  $\checkmark$  to confirm the setting.
- 5. Press III to confirm the delayed start.

### Cancelling the "Ready at" time for delayed starts

- 1. Press III.
- 2. Press "Ready at".
- **3.** Use 9 to reset the end time.
- **4.** Press  $\checkmark$  to confirm the setting.
- ▼ The end time corresponds to the current time plus the set cooking time.
- ✓ Press III to start operation with a cooking time.

**Note:** If you want to continue the operation without a cooking time, cancel the cooking time.

→ "Cancelling the cooking time", Page 17

## 12 Meat probe

Cook with precision by inserting the meat probe  $\mathscr{I}$  into the food and setting a core temperature on the appliance. The meat probe measures the core temperature inside the food. Once the set core temperature has been reached in the food, the appliance automatically stops heating.

# 12.1 Suitable types of heating with the meat probe

Only certain types of heating are suitable for use with the meat probe.

- "Circo Therm hot air" &
- "Circo Therm gentle" &
- "Top/bottom heat gentle"
- "Circo-roasting" 🖫
- "Circotherm intensive" &
- "Bread baking setting" @
- "Bottom heat" =
- "Low-temperature cooking"

## 12.2 Inserting the meat probe

Use the meat probe supplied or order a suitable meat probe from our customer service.

## 

Using the wrong meat probe could damage the insulation.

▶ Only use the meat probe for this specific appliance.

#### **ATTENTION**

Otherwise the meat probe may be damaged.

- ▶ Do not trap the cable of the meat probe.
- ▶ Do not use cookware with a lid.
- ► To prevent the meat probe from being damaged by excessive heat, there must be a gap of a few centimetres between the grill element and the meat probe. The meat may expand during the cooking process.

If, during operation with the microwave, the tip of the meat probe is not fully inside the food, sparks will be created.

► Insert the meat probe fully into the food.

## 

The meat probe is sharp.

- ► Handle the meat probe with care.
- Insert the meat probe into the food.
   The meat probe has three measuring points. Ensure that at least the middle measuring point is inserted in the food.

Thin Insert the meat probe into the thickest part pieces of of the meat from the side.

meat

Thick pieces of meat


Insert the meat probe diagonally into the meat from above, pushing it in as far as possible.



**Note:** If you want to turn the food, insert the meat probe into the side of the food so that it does not need to be removed when turning.

Poultry


Insert the meat probe into the thickest part of the breast, pushing it in as far as possible. The meat probe can be inserted horizontally or vertically depending on the size and shape of the poultry.



Turn the poultry and place it on the wire rack breast-side down.

Fish

When cooking whole fish, insert the meat probe behind the fish's head in the direction of the spine, pushing it in as far as possible.



Place the fish on the wire rack in the swimming position without turning it, e.g. using half a potato as a support.

- 2. Place the food with the meat probe into the cooking compartment.
- **3.** Plug the meat probe into the socket on the left-hand side of the cooking compartment.

**Note:** Do not remove the meat probe when turning the food. Once you have turned the food, check that the meat probe is correctly positioned in the food.

## 12.3 Core temperatures of different foods

This is where you can find the suggested core temperatures for different foods.

These suggestions depend on the quality and the size/shape of the food. Do not use frozen food.

shape of the food. Do not use fr	rozen food.
Poultry	Core temperature in °C
Chicken	80 - 85
Chicken breast	75 - 80
Duck	80 - 85
Duck breast, medium rare	55 - 60
Turkey	80 - 85
Turkey breast	80 - 85
Goose	80 - 90
Pork	Core temperature in °C
Shoulder of pork	85 - 90
Fillet of pork, medium rare	62 - 70
Pork loin, well done	72 - 80
Beef	Core temperature in °C
Tenderloin or sirloin, rare	45 - 52

Torradriori or orriori, well dorre		
Veal	Core temperature in °C	
Joint of veal or hock, lean	75 - 80	
Joint of veal, shoulder	75 - 80	
Veal knuckle	85 - 90	

55 - 62

65 - 75

Cara tamparatura

Tenderloin or sirloin, medium rare

Tenderloin or sirloin well done

Lamb	Core temperature in °C
Leg of lamb, medium rare	60 - 65
Leg of lamb, well done	70 - 80
Saddle of lamb, medium rare	55 - 60
	'

risii	in °C
Fish, whole	65 - 70
Fish fillet	60 - 65
Other	Core temperature in °C
Other  Meat loaf, all kinds of meat	<u>-</u>

# 12.4 Setting the oven temperature and core temperature

You can set a core temperature of between 30  $^{\circ}\text{C}$  and 99  $^{\circ}\text{C}.$ 

#### Requirements

- The food with the meat probe is in the cooking compartment.
- The meat probe is inserted in the cooking compartment.
- 1. Press "Types of heating".
- **2.** Select a suitable type of heating and cooking compartment temperature.

Set the cooking compartment temperature at least 10 °C higher than the core temperature.

Do not set the cooking compartment temperature to higher than 250 °C.

- 3. Press "Meat probe".
- **4.** Swipe left or right to select the core temperature.
- **5.** Press  $\checkmark$  to confirm the settings.
- **6.** Press III to start cooking using the meat probe.
- Once the required core temperature has been reached, an audible signal sounds and the appliance stops heating. With the "Low-temperature cooking" type of heating, the appliance continues to heat.
- 7. Press ① to switch the appliance off.

## 8. MARNING – Risk of burns!

The cooking compartment, accessories and meat probe become very hot.

Always use oven gloves to remove hot accessories and the meat probe from the cooking compartment.

Pull the meat probe out of the socket in the cooking compartment.

#### Tip

You can also combine the meat probe with a different operating mode, e.g.:

- → "Microwave", Page 15
- → "Dishes", Page 19

**Note:** You can use the meat probe even if no core temperature is set. You can read off the core temperature of the food on the display and manually end the operation, if required.

# 12.5 Changing the cooking compartment temperature or core temperature

- 1. Press ^.
- 2. Press the appropriate temperature.
- 3. Swipe left or right to change the temperature.

## 13 Dishes

Eich

"Dishes" helps you to use your appliance to prepare different dishes by selecting the optimum settings automatically.

#### 13.1 Cookware for dishes

The cooking result depends on the composition of the meat and the size of cookware.

You should therefore use heat-resistant cookware that is suitable for temperatures up to 300 °C. Glass or glass

ceramic cookware is best. The joint should cover approx. 2/3 of the cookware base.

Cookware made from the following material is not suitable:

- Bright, shiny aluminium
- Unglazed clay
- Plastic or plastic handles

**Note:** For some dishes, the appliance switches on the microwave. A notification appears in the display stating that you should use cookware that is suitable for microwave use.

→ "Cookware and accessories with microwave", Page 15

## 13.2 Setting options for the dishes

To cook the dishes perfectly, the appliance uses different settings depending on the dish.

The display shows you the settings that are used. You can adjust certain settings. Follow the instructions on the display.

**Note:** The cooking result depends on the quality and composition of the food. Use fresh and, ideally, chilled food. Use frozen food straight from the freezer.

#### Tips and information about the settings

If you set a dish, the display shows relevant information for this dish, e.g.:

- Suitable shelf position
- Suitable accessory or cookware
- Added liquid
- Time for turning or stirring
   When this time is reached, a signal sounds.

To call up the information, press "Information". Some notifications are displayed automatically.

#### **Programmes**

The optimum type of heating, temperature and cooking time are preset for programmes.

To achieve an optimal cooking result, you must also set the weight, thickness or the cooking level. You can set the weight only in the intended range.

Unless otherwise indicated, set the total weight for your dish.

### Recommended settings

For the recommended settings, the optimum type of heating is preset as a fixed value. You can adjust the set temperature and the cooking time.

#### Dishes with meat probe

You can use the meat probe  $\ensuremath{\mathscr{P}}$  for some dishes. You can adjust the temperature and the core temperature.

→ "Meat probe", Page 18

## Remaining time forecast for the operation

If your appliance is connected to Home Connect, the appliance can forecast the expected remaining time for the cooking process.

The initial remaining time appears on the display after approx. 1 minute. The remaining time is continually recalculated and updated.

**Note:** The remaining time forecast is not available for all dishes.

#### Dishes with microwave

For some dishes, you can select a cooking method with microwave . The cooking time is reduced.

Observe the information on operating with microwave.

→ "Microwave", Page 15

#### 13.3 Overview of the dishes

You can see which individual dishes are available to you on the appliance. The dishes depend on the features of your appliance.

The dishes are sorted by category and food.

**Note:** In the basic settings, you can regionally specialise the displayed dishes.

→ "Basic settings", Page 22

→ "Basic settings", Page 22		
Category	Food	
Cakes	Cakes in tins Cakes on a baking tray Small baked items Biscuits	
Bread, bread rolls	Bread Bread rolls	
Pizza, sa- voury cakes, quiche	Pizza Savoury cakes, quiche	
Bakes, soufflés	Bake, savoury, fresh, cooked ingredients Potato gratin, raw ingredients, 4 cm deep Lasagne, fresh Lasagne, chilled Bake, sweet, fresh Fruit crumble Soufflés in individual moulds Yorkshire pudding	
Poultry	Chicken Duck, goose Turkey	
Meat	Pork Beef Veal Lamb Game Meat dishes	
Fish.	Fish, whole Fish fillets	
Frozen products	Pizza Bakes Potato products Poultry, fish Bread rolls	
Side dishes, vegetables	Potatoes Rice Cereals Vegetables	
Defrosting food	Cakes Bread, bread rolls Meat, poultry Fish.	

## 13.4 Setting a dish

- 1. Press "Dishes".
- 2. Press the required category.
- 3. Press the required food.
- 4. Press the required dish.

**Note:** The setting options vary depending on the dish. → "Setting options for the dishes", Page 20

- The settings for the dish appear on the display.
- **5.** Adjust the settings if required.

The setting options vary depending on the dish.

- → "Setting options for the dishes", Page 20
- **6.** For information about the accessory and shelf position, for example, press "Information".
- 7. Press III to start the operation.
- The appliance starts to heat and the cooking time counts down.
- ✓ When using a roasting sensor, no cooking time is displayed. The setting values and how long the appliance has already been in operation are shown on the display. If the appliance is connected to Home Connect, the forecast time remaining is displayed.
  - → "Remaining time forecast for the operation", Page 20
- Once the dish is ready, a signal sounds. The appliance stops heating.

8. Decide how you want to continue:

Finish	Dish is ready
Add extra cooking time	→ "Extending the cooking time", Page 21
Keep warm	→ "Keeping a dish warm", Page 21
Dry the cooking compartment	→ "Drying", Page 29

## 13.5 Extending the cooking time

- To extend the cooking time, press "Add extra cooking time".
- 2. Swipe left or right to adjust the settings.
- **3.** Press  $\checkmark$  to confirm the settings.

## 13.6 Keeping a dish warm

- 1. To keep the dish warm, press "Keep warm".
- 2. Swipe left or right to change the settings.
- **3.** Press  $\checkmark$  to confirm the settings.
- 4. Press III to start the keep warm function.

## 14 Favourites

In the "Favourites", you can save your settings and use these again.

**Note:** Depending on the appliance type/software status, you must first download this function to your appliance. You can find more information in the Home Connect app

## 14.1 Saving favourites

You can save up to 30 different functions as your favourites.

- **1.** If you set a function, press ♥ "Favourites".
- 2. If required, change the title of the favourite using the keyboard on the display.
- 3. Press "Save".

## 14.2 Selecting favourites

If you have saved favourites, you can use these to set the operation.

- 1. Press "Favourites".
- 2. Press the required favourites.
- 3. If required, you can change the settings.
- **4.** Press I to start the operation.

#### Note

Observe the instructions for the various functions:

■ → "Microwave", Page 15

- → "Ventilation function Crisp Finish", Page 16
- → "Meat probe", Page 18

## 14.3 Changing favourites

You can change, sort or rename your saved favourites at any time.

- 1. Press "Favourites".
- 2. Press the required favourites.
- **3.** Press \_∅.
- **4.** Change the settings or the title of the favourite.
- 5. Press "Apply" to confirm the change.

## 14.4 Deleting favourites

- 1. Press "Favourites".
- 2. Press the required favourites.
- 3. Press ♥.
- 4. Press "Delete" to confirm.

## 14.5 Sorting favourites

- 1. Press "Favourites".
- **2.** Press \_∅.
- **3.** Press and hold the required favourite and drag it to a different position.

## 15 Childproof lock

You can secure your appliance to prevent children from accidentally switching it on or changing the settings.

## 15.1 Activating the childproof lock

The childproof lock disables the control panel to prevent children from accidentally switching on the appliance. To switch on the appliance, deactivate the childproof lock.

#### **Notes**

 When you activate the childproof lock, the appliance will immediately disable the control panel. The ① button is the exception and will not be disabled.

- You can also activate the appliance door lock.
   → "Basic settings", Page 22
- 1. Press :.
- 2. Press ⇔.
- ▼ "Childproof lock activated" appears on the display.

## 15.2 Deactivating the childproof lock

Press and hold "Unlock" until "Childproof lock deactivated" appears.

## 16 Rapid heating

With the rapid heating function, you can shorten the heat-up time.

From 200 °C, the rapid heating function is activated automatically.

**Note:** You can deactivate automatic rapid heating from 200 °C in the basic settings.

→ "Basic settings", Page 22

Rapid heating is possible for the following types of heating:

- "Circo Therm hot air" &
- "Top/bottom heat" =
- "Bread baking setting" 

  —

**Note:** Do not set a cooking time until rapid heating has come to an end.

- **1.** Set a suitable type of heating and a temperature of at least 100 °C.
  - Rapid heating automatically switches on at temperatures of 200 °C and above.
- **2.** Press 8€.
- **3.** Press III to start the operation.
- Once rapid heating has ended, "Rapid heating" switches off automatically and a signal sounds. goes out on the display.
- **4.** Place the food in the cooking compartment.

## 16.1 Activating rapid heat-up

To ensure an even cooking result, do not place the food in the cooking compartment until rapid heating has come to an end.

# 16.2 Deactivating the "Rapid heat-up" function

- 1. Press ^.
- **2.** Press 8€.

## 17 Basic settings

You can configure the basic settings for your appliance to meet your needs.

### 17.1 Overview of the basic settings

Here you can find an overview of the basic settings and factory settings. The basic settings depend on the features of your appliance.

You can find more information about the individual basic settings on the display using "Information".

Basic settings	Selection
Language	See selection on appliance
Home Connect	Connect the oven to a mobile end device and remotely control it
Clock	Time in 24-hour format
Date	Date in the format DD.MM.YYYY
Display	Selection
Brightness	<ul> <li>1</li> <li>2</li> <li>3</li> <li>4</li> <li>5<sup>1</sup></li> </ul>

Display	Selection
Standby screen	<ul> <li>On for a limited time</li> <li>On (this setting increases energy consumption)</li> <li>Off <sup>1</sup></li> </ul>
Clock	<ul> <li>Digital + date <sup>1</sup></li> <li>Digital</li> <li>Analogue + date</li> <li>Analogue</li> </ul>
Alignment	Align the display horizontally and vertically
Tone	Selection
Button tone	■ On¹ ■ Off
Volume	<ul> <li>1</li> <li>2</li> <li>3</li> <li>4</li> <li>5<sup>1</sup></li> </ul>

<sup>&</sup>lt;sup>1</sup> Factory setting (may vary according to model)

	Onlandar.
Tone	Selection
Signal tone	<ul> <li>Very short duration</li> </ul>
	<ul> <li>Short duration</li> <li>Medium duration <sup>1</sup></li> </ul>
	<ul><li>Long duration</li></ul>
	- Long duration
Appliance set- tings	Selection
Fan run-on time	■ Minimum
	<ul> <li>Recommended <sup>1</sup></li> </ul>
	■ Long
1.1.1.12	• Very long
Lighting	<ul> <li>On when cooking and opening the</li> </ul>
	door 1  Only when the door is opened
	<ul><li>Only when the door is opened</li><li>Always off</li></ul>
Microwave out-	■ 90 W
put presetting	■ 180 W
par processing	■ 360 W
	■ 600 W
	■ Boost <sup>1</sup>
Continue to mi-	■ On_
crowave	■ Off <sup>1</sup>
Dry microwave	■ On <sup>1</sup>
	■ Off
Personalisa-	Selection
tion	
Brand logo	■ Display <sup>1</sup>
	<ul><li>Do not display</li></ul>
Operation after	■ Main menu <sup>1</sup>
switch-on	<ul><li>Types of heating</li></ul>
	<ul><li>Microwave</li></ul>
	<ul><li>Dishes</li><li>Favourites</li></ul>
Flancod socia	
Elapsed cook- ing time	<ul> <li>Display <sup>1</sup></li> <li>Do not display</li> </ul>
Microwave bak- ing tray	<ul><li>On '</li><li>Off</li></ul>
	A II 1
Regional dishes	<ul><li>All '</li><li>European dishes</li></ul>
GIOTICO	<ul><li>British dishes</li></ul>
Dishes	■ All ¹
2101100	No pork
	<ul><li>Kosher only</li></ul>
Childproof lock	<ul> <li>Keylock only<sup>1</sup></li> </ul>
- 1	<ul><li>Door lock + keylock</li></ul>
	<ul><li>Deactivated</li></ul>
Automatic	■ On¹
rapid heating	■ Off
Factory set-	Selection
tings	

Appliance information	Display
Appliance information	Display technical information about the appliance

## 17.2 Changing basic settings

- **1.** Press ① to switch the appliance on.
- 2. Press "Basic settings".
- 3. Swipe left or right until the required basic setting or category appears.
- 4. Press the required basic setting or category.
  - ► Press the required basic setting in a category.
- **5.** Swipe left or right to select the required setting.
- **6.** Press the required setting.
- **7.** Press  $\checkmark$  to confirm the change. If  $\checkmark$  does not appear, the change is applied immediately.
- 8. To change other basic settings, use to return to the basic settings.

Cancel

Restore

Factory set-

tings

<sup>&</sup>lt;sup>1</sup> Factory setting (may vary according to model)

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

**Tip:** Please also follow the instructions in the Home Connect app.

#### **Notes**

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app.
  - → "Safety", Page 2
- Operating the appliance on the appliance itself always takes priority. During this time it is not possible to operate the appliance using the Home Connect app.
- In networked standby mode, the appliance requires a maximum of 2 W.

## 18.1 Setting up Home Connect

#### Requirements

- The appliance is connected to the power supply and is switched on.
- You have a mobile device with a current version of the iOS or Android operating system, e.g. a smartphone.
- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- The mobile device and the appliance are within range of your home network's Wi-Fi signal.
- 1. Scan the following QR code.



You can install the Home Connect app and connect your appliance via the QR code.

**2.** Follow the instructions in the Home Connect app.

## 18.2 Home Connect settings

You can adjust the Home Connect settings and network settings in your appliance's basic settings. Which settings the display shows will depend on whether Home Connect has been set up and whether the appliance is connected to your home network.

Basic setting	Possible settings	Explanation
Home Connect assistant	Start the assistant Disconnect	You can connect your appliance to the Home Connect app via the Home Connect assistant.
		<b>Note:</b> If you are using the Home Connect assistant for the first time, only the "Start assistant" setting is available.
Wi-Fi	On Off	You can use the Wi-Fi to switch off the network connection for your appliance. When you have connected successfully once, you can deactivate the Wi-Fi and not lose your detailed data. As soon as you activate Wi-Fi again, the appliance connects automatically.
		<b>Note:</b> In networked standby mode, the appliance requires a maximum of 2 W.
Remote control status	Monitoring Manual remote start Permanent remote start	During monitoring, you can only view the operating status of the appliance in the app.  If you convert from monitoring or permanent remote start to manual remote start, you must activate the remote start each time. You can open the appliance door within 15 minutes of having activated remote start. Remote start will not be deactivated by this. Once 15 minutes have elapsed, opening the appliance door will deactivate manual remote start.  For permanent remote start, you can start and operate the appliance remotely at any time. If you often operate the appliance remotely, it is helpful to set the remote start to "Permanent".

## 18.3 Operating the appliance with the **Home Connect app**

You can use the Home Connect app to set and start the appliance remotely.

#### ⚠ WARNING – Risk of fire!

Combustible objects that are left in the cooking compartment may catch fire.

- Never store combustible objects in the cooking compartment.
- ▶ If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

#### Requirements

- The appliance is switched off.
- The appliance is connected to the home network and to the Home Connect app.
- In order to be able to set the appliance via the app. the manual or permanent remote start must be selected in the "Remote control status" basic setting.
- 1. To activate manual remote start, press a. You only have to confirm on the oven if you are switching from monitoring or permanent remote start to manual remote start.
  - With permanent remote start, you do not need to confirm on the oven.
- 2. Configure a setting in the Home Connect app and send it to the appliance.

#### **Notes**

- When you start the oven using the controls on the appliance itself, the remote start function is activated automatically. You can use the Home Connect app to adjust the settings or start a new pro-
- You can open the appliance door within 15 minutes of having activated remote start. Remote start will not be deactivated by this. Once 15 minutes have elapsed, opening the appliance door will deactivate manual remote start.

## 18.4 Software update

Your appliance's software can be updated using the software update function, e.g. for the purposes of optimisation, troubleshooting or security updates. This may lead to minor changes of visualizations and operation in the display.

To do this, you must be a registered Home Connect user, have installed the app on your mobile device and be connected to the Home Connect server. As soon as a software update is available, you will be informed via the Home Connect app and will be able to start the software update via the app. Once the update has been successfully downloaded, you can start installing it via the Home Connect app if you are in your home network (Wi-Fi). The Home Connect app informs you once installation is successful.

#### **Notes**

- The software update consists of two steps.
  - The first step is the download.
  - The second step is the installation on your appliance.
- You can continue to use your appliance as normal while updates are downloading. Depending on your personal settings in the app, software updates can also be set to download automatically.
- Installation takes a few minutes. You cannot use your appliance during installation.
- We recommend that you install security updates as soon as possible.

## 18.5 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

Tip: For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of your local website: www.home-connect.com.

## 18.6 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed Wi-Fi communication module).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

## 19 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

## 19.1 Cleaning products

In order to avoid damaging the various oven surfaces on the appliance, do not use unsuitable cleaning products.

## **⚠** WARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners to clean the appliance.

#### **ATTENTION**

Unsuitable cleaning agents damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive cleaning products.
- Do not use cleaning products with a high alcohol content.
- ▶ Do not use hard scouring pads or cleaning sponges.
- ► Do not use any special cleaners for cleaning the appliance while it is hot.

Using oven cleaner in a hot cooking compartment damages the enamel.

- ► Never use oven cleaner in the cooking compartment when it is still warm.
- Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

If different cleaning agents are mixed together, there may be a chemical reaction between these.

- ► Do not mix cleaning agents.
- ► Completely remove any cleaning agent residue. Salt contained in new sponge cloths may damage surfaces.
- Wash new sponge cloths thoroughly before use.

### Suitable cleaning agents

Only use cleaning agents that are suitable for the different surfaces on your appliance. Follow the instructions on cleaning the appliance.

→ "Cleaning the appliance", Page 27

## Appliance front

Surface	Suitable cleaning agents	Information
Stainless steel	<ul> <li>Hot soapy water</li> <li>Special stainless steel cleaning products suitable for hot surfaces</li> </ul>	To prevent corrosion, remove any patches of limescale, grease, starch or albumin (e.g. egg white) from stainless steel surfaces immediately.  Apply a thin layer of the stainless steel cleaning product.
Plastic or painted surfaces	<ul><li>Hot soapy water</li></ul>	Do not use glass cleaner or a glass scraper.  To avoid permanent stains, immediately remove any descaling agent that gets onto the surface.
Glass	<ul> <li>Hot soapy water</li> </ul>	Do not use glass cleaner or a glass scraper.

#### **Appliance door**

Range	Suitable cleaning agents	Information
Door panels  - Hot soapy water  - Oven cleaner  - Steel wool	Do not use a glass scraper.	
	<b>Tip:</b> Remove the door panels in order to clean them thoroughly. → "Appliance door", Page 30	
Door cover	<ul><li>Made of stainless steel:</li></ul>	Do not use glass cleaner or a glass scraper. Do not use stainless steel care products.
	Stainless steel cleaner  Made from plastic: Hot soapy water	<b>Tip:</b> Remove the door cover for thorough cleaning.  → "Appliance door", Page 30
Stainless steel interior door frame	Stainless steel cleaner	Discolouration can be removed using stainless steel cleaner.  Do not use stainless steel care products.
Door handle	<ul> <li>Hot soapy water</li> </ul>	To avoid permanent stains, immediately remove any descaling agent that gets onto the surface.

#### **Cooking compartment**

Range	Suitable cleaning agents	Information
Enamel surfaces	<ul><li>Hot soapy water</li><li>Vinegar solution</li><li>Oven cleaner</li><li>Steel wool</li></ul>	Soak any heavily soiled areas and use a brush or steel wool. Leave the appliance door open to dry the cooking compartment after cleaning it.

Range	Suitable cleaning agents	Information
		<ul> <li>Notes</li> <li>It is best to use the cleaning function.         → "Pyrolytic self-cleaning cleaning function", Page 27     </li> <li>Enamel burns at very high temperatures, causing minor discolouration. The functionality of your appliance is not affected by this.</li> <li>The edges of thin trays cannot be completely enamelled and may be rough. This does not impair the corrosion protection.</li> <li>Food residues leave a white coating on the enamel surfaces. The coating does not pose a health risk. The functionality of your appliance is not affected by this. You can remove residues with lemon juice.</li> </ul>
Shelf supports	<ul><li>Hot soapy water</li><li>Steel wool</li></ul>	Soak any heavily soiled areas and use a brush or steel wool.  Note: To clean thoroughly, detach the shelf supports.  → "Rails", Page 30
Accessories	<ul><li>Hot soapy water</li><li>Oven cleaner</li><li>Steel wool</li></ul>	Soak any heavily soiled areas and use a brush or steel wool. Enamelled accessories are dishwasher-safe.
Meat probe	<ul><li>Hot soapy water</li></ul>	Use a brush to remove heavy soiling.  Do not clean in the dishwasher.

## 19.2 Cleaning the appliance

In order to avoid damaging the appliance, you must clean your appliance only as specified, and with suitable cleaning products.

## ⚠ WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- Young children under 8 years of age must be kept away from the appliance.

## 

Loose food remnants, fat and meat juices may catch

▶ Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

**Requirement:** Read the information on cleaning products.

- → "Cleaning products", Page 25
- 1. Clean the appliance using hot soapy water and a dish
  - ► For some surfaces, you can use alternative cleaning agents.
    - → "Suitable cleaning agents", Page 26
- 2. Dry with a soft cloth.

## 20 "Pyrolytic self-cleaning" cleaning function

With the "Pyrolytic self-cleaning" \*\*\*\* cleaning function, the cooking compartment is cleaned virtually automatically. The cleaning function requires approx. 3.1 - 4.0 kilowatt

## 20.1 Preparing the appliance for the cleaning **function**

To achieve a good cleaning result and prevent damage, prepare the appliance carefully.

### ⚠ WARNING – Risk of fire!

Combustible objects that are left in the cooking compartment may catch fire.

- ► Never store combustible objects in the cooking compartment.
- ► If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire when the cleaning function is in progress.

- ► Before you start the cleaning function, always remove coarse dirt from the cooking compartment.
- Never clean accessories at the same time.

The outside of the appliance gets very hot when the cleaning function is in progress.

- ► Never hang combustible objects, e.g. tea towels, on the door handle.
- ► Leave the front of the appliance clear.
- Keep children at a safe distance.

If the door seal is damaged, a large amount of heat is generated around the door.

- ▶ Do not scrub or remove the seal.
- ▶ Never operate the appliance if the seal is damaged or missing.
- 1. Remove accessories and cookware from the cooking compartment.

You can also clean the shelf supports.

**Tip:** Also remove the shelf supports to save energy and achieve a better cleaning result in the cooking compartment.

- → "Rails", Page 30
- 2. Remove coarse dirt from the cooking compartment and from the shelf supports.
  - Coarse dirt may burn on, making it difficult to remove.
- 3. Use a detergent solution and a soft cloth to clean the surfaces at the edges of the cooking compartment around the door seal.
  - Do not remove or scrub the door seal.
  - Use oven cleaner to remove stubborn dirt from the inner door pane.
- **4.** Remove any objects from the cooking compartment. The cooking compartment must be empty except for the shelf supports.

## 20.2 Setting the "Pyrolytic self-cleaning" cleaning function

#### ⚠ WARNING – Risk of harm to health!

The cleaning function heats up the cooking compartment to a very high temperature so that food left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate mucous membranes.

- Keep the kitchen well ventilated while the cleaning function is running.
- Do not remain in the room for long periods.
- Keep children and pets away.

#### 

The cooking compartment gets very hot when the cleaning function is in progress.

- Never open the appliance door.
- Allow the appliance to cool down.
- Keep children at a safe distance.

igtriangle The outside of the appliance gets very hot when the cleaning function is in progress.

- Never touch the appliance door.
- Allow the appliance to cool down.
- Keep children at a safe distance.

Note: The oven light does not light up while the cleaning function is running.

#### Requirement:

- → "Preparing the appliance for the cleaning function", Page 27
- 1. Press "Cleaning".
- 2. Press "Pyrolytic self-cleaning" 👯.
- 3. Press "Level" to set the cleaning setting.

Cleaning set- ting	Cleaning level	Duration in hours
1	Low	Approx. 2:15

Cleaning set- ting	Cleaning level	Duration in hours
2	High	Approx. 2:30

Select the higher cleaning setting if the cooking compartment is particularly dirty or has not been cleaned for a while.

You cannot change the duration of the cleaning func-

Once the cleaning function is in progress, you cannot change the cleaning setting.

- The duration of the cleaning setting will appear on the display.
- **4.** Press II to start the cleaning function.
- A notification stating that you should carry out the necessary preparatory work for the cleaning function appears on the display.
- 5. Press "OK" to confirm the notification.
- ▼ The cleaning function starts. The duration counts down on the display.
- ✓ For your safety, the appliance door locks the cooking compartment. d appears on the display.
- ✓ Once the cleaning function has run through to the end, an audible signal sounds.
- 6. After using the cleaning function, prepare the appliance for operation.
  - → "Preparing the appliance after the cleaning function", Page 28

The appliance door will remain locked until the appliance has cooled down sufficiently and final has gone out.

## 20.3 Cancelling the cleaning function

Note: You can no longer stop or change the cleaning function once it has started.

► To cancel the cleaning function, press ① to switch the appliance off.

## 20.4 Preparing the appliance after the cleaning function

- 1. Allow the appliance to cool down.
- 2. Wipe off any ash that has been left behind in the cooking compartment, on the shelf supports and around the appliance door.
  - → "Cleaning and servicing", Page 25
- 3. Remove white residues with lemon juice.

Note: White residues on the enamel surfaces may be caused by heavy soiling. These food residues are harmless. The deposits do not compromise the functionality of the appliance.

**Note:** While the cleaning function is running, the frame on the inside of the appliance door or other parts of the door that are made of stainless steel become discoloured. This discolouration does not compromise the functionality of the appliance. The discolouration can be removed using a stainless steel cleaner.

## 21 "Easy Clean" cleaning aid

Use the "Easy Clean" cleaning aid for intermediate cleaning of the cooking compartment. The "Easy Clean" cleaning aid softens dirt by vaporising the soapy water. It is then easier to remove the dirt.

## 21.1 Setting the "Easy Clean" cleaning aid

## 

If there is water in the cooking compartment when it is hot, this may create hot steam.

► Never pour water into the cooking compartment when the cooking compartment is hot.

#### **Notes**

- The oven light does not light up while the cleaning aid is running.
- Do not open the appliance door while the appliance is in operation.

#### Requirements

- You can only start the cleaning aid once the cooking compartment is cold (room temperature) and the appliance door is closed.
- To remove particularly stubborn dirt, rub washing-up liquid onto dirty areas on the smooth surfaces before starting the cleaning aid.
- Remove any accessories from the cooking compartment
- ATTENTION Distilled water in the cooking compartment leads to corrosion.
  - ▶ Do not use distilled water.

Mix 0.4 litres water with a drop of washing-up liquid and pour into the centre of the cooking compartment floor.

- 3. Press "Cleaning".
- 4. Press "Easy Clean".
- 5. Press III to start the cleaning aid.
- ✓ A notification stating that you should carry out the necessary preparatory work for the cleaning aid appears on the display.

- 6. Press "OK" to confirm the notification.
- The cleaning aid starts. The duration counts down on the display.
- Once the cleaning aid has run through to the end, an audible signal sounds.
- 7. Press any button to end the audible signal.
- **8.** After using the cleaning aid, finish cleaning the cooking compartment.
  - → "Wiping down the cooking compartment", Page 29

# 21.2 Wiping down the cooking compartment ATTENTION

The prolonged presence of moisture in the cooking compartment leads to corrosion.

► After using the cleaning aid, wipe the cooking compartment clean and allow it to dry fully.

**Requirement:** The cooking compartment must have cooled down.

- **1.** Open the appliance door and remove the remaining water with an absorbent sponge cloth.
- Clean the smooth surfaces in the cooking compartment with a dish cloth or a soft brush. Remove stubborn food remnants using a stainless steel scouring pad.
- **3.** Remove limescale with a cloth soaked in vinegar. Then wipe with clean water and rub dry with a soft cloth (including under the door seal).
- **4.** If there is any stubborn dirt that you are unable to remove, run the cleaning aid again once the cooking compartment has cooled down.
- In order to dry the cooking compartment, leave the appliance door open in the detent position (approx. 30°) for around 1 hour or use the drying function.
   "Drying", Page 29

## 22 Drying

To prevent residual moisture, dry the cooking compartment following microwave-only operation.

## 22.1 Drying the cooking compartment

## **⚠ WARNING – Risk of burns!**

The appliance becomes hot during operation.

▶ Allow the appliance to cool down before cleaning.

#### **ATTENTION**

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120 °C, this will damage the enamel.

- Do not use the appliance if there is water on the cooking compartment floor.
- Wipe away any water on the cooking compartment floor before operation.

**Requirement:** The cooking compartment has cooled down.

- Remove any food remnants from the cooking compartment.
- **2.** Dry the cooking compartment with a sponge.

- **3.** Remove limescale marks with a cloth soaked in vinegar, then wipe with clean water and dry with a soft cloth.
- **4.** Leave the cooking compartment to dry with the appliance door open for 1 hour or use "Drying function".
  - → "Setting Drying function", Page 29

## 22.2 Setting "Drying function"

#### Requirement:

- → "Drying the cooking compartment", Page 29
- 1. Press "Cleaning".
- 2. Press "Drying function".
- ▼ The duration appears on the display. You cannot change the duration of the drying function.
- 3. Start the drying function using III.
- A notification stating that you should carry out the necessary preparatory work for the drying function appears on the display.
- 4. Press "OK" to confirm the notification.
- ▼ The drying function starts. The duration counts down on the display.
- Once the drying function has run through to the end, an audible signal sounds.

**5.** Leave the appliance door open for 1-2 minutes so that the cooking compartment dries completely.

## 23 Rails


To thoroughly clean the rails and the cooking compartment, or to replace the rails, you can remove the rails.

## 23.1 Detaching the rails

## 

The shelf supports get very hot


- ► Never touch the shelf supports when hot.
- Always allow the appliance to cool down.
- Keep children at a safe distance.
- 1. Lift the rail forwards ① and detach it ②.
- Swivel the entire rail outwards 3 and unhook it at the rear 4.



3. Clean the rail.


## 23.2 Fitting the retainers

The retainers may fall out when you detach the rails. **Note:** The retainers at the front differ from those at the rear.




**1.** Hook the front retainers with the hook into the round hole at the top and set them at a slight angle ①.

**2.** Hook the front retainers in at the bottom and straighten them ②.




**3.** Hook the rear retainers with the hook into the top hole ① and push them into the bottom hole ②.



## 23.3 Attaching the rails

- **1.** Set the rear rail at an angle, hooking it into the retainers at the top and bottom ①.
- 2. Pull the rail forwards 2.
- 3. Hook in the rail at the front 3 and press it down 4.




## 24 Appliance door

To clean the appliance door thoroughly, you can disassemble the appliance door.

## 24.1 Removing the door cover

The stainless steel inlay in the door cover may discolour. Remove the door cover in order to clean it and the stainless steel inlay, or to remove the door panes.

- 1. Open the appliance door slightly.
- 2. Press down on the left- and right-hand sides of the door cover ①.
- 3. Remove the door cover 2 and carefully close the appliance door.



## 24.2 Removing the door panes

## ⚠ WARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

► Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


Keep your hands away from the hinges.

Components inside the appliance door may have sharp edges.

Wear protective gloves.


Requirement: The door cover has been removed.

- → "Removing the door cover", Page 31
- 1. Undo and remove the screws 1 on the left and right of the appliance door.
- 2. Place a folded-up tea towel in the appliance door.
- **3.** Close the appliance door.
- 4. Pull the front pane up and out 2.




5. Place the front pane down on a flat surface with the door handle facing down.

**6.** Press the intermediate pane against the appliance with one hand while pushing the left- and right-hand retainers a upwards. Do not detach the retainers a.



- 7. Remove the intermediate pane.
- 8. MARNING Risk of serious harm to health! If the screws are undone, the safety of the appliance can no longer be guaranteed. Microwave energy may escape.
  - Never undo the screws.

Never unscrew the four black screws on the frame.



#### 24.3 Fitting the door panes


#### ⚠ WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

Keep your hands away from the hinges.


Components inside the appliance door may have sharp edaes.

- Wear protective gloves.
- 1. Turn the intermediate pane until the arrow a is in the top right.




2. Insert the intermediate pane into the retainer a at the bottom 1 and push it in firmly at the top.


**3.** Push the left- and right-hand retainer a downwards until the intermediate pane is clamped ②.



- **4.** Attach the front pane downwards into the left- and right-hand retainers **a** ①.
- 5. Push the front pane to the appliance until the left- and right-hand hook a is opposite the support b 2.



- **6.** Push the front pane in at the bottom ① until you hear it click into place.
- Open the appliance door slightly and remove the tea towel.
- 8. Screw both screws back in on the left and right of the appliance door.
- **9.** Put the door cover in position and push down on it ② until you hear it click into place.



10. Close the appliance door.

**Note:** Do not use the cooking compartment again until the door panes have been correctly fitted.

## 25 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting aftersales service. This will avoid unnecessary costs.

### **⚠** WARNING – Risk of injury!

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ If the appliance is defective, call Customer Service.
  - → "Customer Service", Page 34

#### ⚠ WARNING – Risk of electric shock!

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.
- ▶ If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

#### 25.1 Malfunctions

Fault	Cause and troubleshooting	
The appliance is not working.	The circuit breaker in the fuse box has tripped.  • Check the circuit breaker in the fuse box.	
	There has been a power cut.  ► Check whether the lighting in your room or other appliances are working.	

Fault	Cause and troubleshooting
The appliance is not working.	<ul> <li>Electronics fault</li> <li>1. Disconnect the appliance from the power supply for at least 30 seconds by switching off the fuse.</li> <li>2. Reset the basic settings to the factory settings.  → "Basic settings", Page 22</li> </ul>
"Sprache Deutsch" appears in the display.	There has been a power cut.  ► Configure the initial configuration settings.  → "Initial use", Page 13
The operation does not start or is interrupted.	Different causes are possible.  ► Check the notifications that appear on the display.  → "Displaying information", Page 14
	Malfunction  ► Call .  → "Customer Service", Page 34
Appliance does not heat up.	<ul> <li>Demo mode is switched on.</li> <li>1. Disconnect the appliance from the power supply for at least 30 seconds by switching off the fuse.</li> <li>2. Switch off demo mode in the basic settings within approx. 5 minutes. → "Changing basic settings", Page 23</li> </ul>
	There has been a power cut.  ► Open and close the appliance door once after a power failure.  ✓ The appliance is checked and is ready to use.
The time is not displayed when the appliance is switched off.	Display switches itself off after a short time.  No action required.
Appliance door cannot be opened.	The cleaning function locks the appliance door; ⊕ lights up in the display.  ► Allow the appliance to cool down until ⊕ goes out in the display.  → "Pyrolytic self-cleaning cleaning function", Page 27
	The childproof lock locks the appliance door.  ► Deactivate the childproof lock using "Unlock".  → "Childproof lock", Page 21  You can switch off the lock in the basic settings.  → "Basic settings", Page 22
Home Connect is not working properly.	Different causes are possible.  • Go to www.home-connect.com.
During simple microwave operation, the cooking compartment becomes hot.	The drying function is switched on.  ➤ You can change the basic setting for the drying function during microwave operation.  → "Basic settings", Page 22  ➤ Observe the information on operating with microwave.  → "Microwave", Page 15
The interior lighting does not work.	Basic setting has been changed.  ► Change the basic setting for the lighting.  → "Basic settings", Page 22
	The LED light is defective.  ► Call .  → "Customer Service", Page 34
	<ul> <li>The maximum operating time has been reached. The appliance stops heating.</li> <li>1. Press "OK" to confirm the notification about the maximum operating time.</li> <li>2. Check whether you still need the appliance.</li> <li>▶ Set a cooking time so that the operation does not stop.</li> <li>→ "Time-setting options", Page 16</li> </ul>
The operation stops.	<ul> <li>The maximum operating time has been reached. The appliance stops heating.</li> <li>1. Press ① to switch off the appliance.</li> <li>2. If necessary, press ① to switch the appliance back on and then restart the operation.</li> <li>▶ Set a cooking time so that the operation does not stop.</li> <li>→ "Time-setting options", Page 16</li> </ul>

Fault	Cause and troubleshooting	
Error code made up of letters and numbers appears on the display, e.g. E0111.	<ul> <li>The electronics have detected a fault.</li> <li>is- <ol> <li>Switch the appliance off and on again.</li> <li>If the fault was a one-off, the message disappears.</li> <li>If the message appears again, call the after-sales service. Please specify exact error message when calling.</li> <li>"Customer Service", Page 34</li> </ol> </li> </ul>	
The cooking result is not satisfactory.	Settings were unsuitable.  Adjustment values, e.g. temperature or cooking time, depend on the recipe, quantity and food.  Next time, set lower or higher values.  Tip: A lot of other information about the preparation, corresponding adjustment values and recipes can be found in the Home Connect app or on our website www.neff-home.com.	
The result of the cleaning function is not satisfactory.	<ul> <li>The cooking compartment was too dirty.</li> <li>▶ Remove coarse dirt from the cooking compartment before using the cleaning function.</li> <li>▶ Take the shelf supports out of the cooking compartment to save energy and achieve a better cleaning result in the cooking compartment.</li> <li>▶ Pay attention to the cleaning and care of your appliance.</li> <li>→ "Cleaning and servicing", Page 25</li> </ul>	

## 26 Disposal

## 26.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are avail-

able from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

## 27 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

**Note:** Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website. This product contains light sources from energy efficiency class G. These light sources are available as a spare part and should only be replaced by trained specialist staff.

You can find the information required as per Regulation (EU) 2023/826 online at *www.neff-home.com* on the product and service pages for your appliance, in the area of user manuals and additional documents.

# 27.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) on the appliance's rating plate.

You will see the rating plate with these numbers if you open the appliance door.



Make a note of your appliance's details and the Customer Service telephone number to find them again auickly.

You can also display the appliance information in the basic settings.

→ "Basic settings", Page 22

## 28 Information regarding Free and Open Source Software

This product includes software components that are licensed by the copyright holders as free or open source software.

The applicable licence information is stored on your home appliance. You can also access the applicable licence information via your Home Connect app: "Profile -> Legal information -> Licence Information". 1 You can download the licence information on the brand product website. (Please search on the product website for your appliance model and additional documents). Alternatively, you can request the relevant information from ossrequest@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str. 34, 81739 Munich, Germany.

The source code will be made available to you on request.

Please send your request to ossrequest@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str.34, 81739 Munich, Germany.

Subject: "OSSREQUEST"

The cost of performing your request will be charged to you. This offer is valid for three years from the date of purchase or at least as long as we offer support and spare parts for the relevant appliance.

## 29 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at www.neff-home.com among the additional documents on the product page for your appliance.



Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements.<sup>2</sup>

A detailed Declaration of Conformity can be found online at www.neff-home.com/uk among the additional documents on the product page for your appliance.<sup>2</sup>

2.4 GHz band (2400-2483.5 MHz): Max. 100 mW

5 GHz band (5150-5350 MHz + 5470-5725 MHz): max. 200 mW

<b>#</b> / E	BE	BG	CZ	DK	DE	EE	IE	EL	ES
Ī	FR	HR	IT	CY	LI	LV	LT	LU	HU
1	MT	NL	AT	PL	PT	RO	SI	SK	FI
-	SE	NO	CH	TR	IS	UK (NI)			
5 GHz WLAN (Wi-Fi): For indoor use only.									
AL	BA	MD		ME	MK	RS	UK		 JA

## 29.1 Statement of Compliance for Great **Britain**

#### **Product type**

This statement of compliance covers the products described in this information for use whose model identifier group is seen on the title page. The full model identifier is made up of the characters before the slash in the product number (E no.) which can be found on the rating plate. Alternatively, you can also find the model identifier in the first line of the UK Energy Label.

<sup>2</sup> Only applies to Great Britain

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

#### Name and address of manufacturer

BSH Hausgeräte GmbH, Carl-Wery-Strasse 34, 81739 München, Germany

This statement of compliance is prepared by the manufacturer.

The manufacturer, BSH Hausgeräte GmbH deems that it has complied with

 provision 5.1-1 of ETSI EN 303 645 v2.1.1 and, where relevant, provision 5.1-2 of ETSI EN 303 645 v2.1.1;

- provision 5.2-1 of ETSI EN 303 645 v2.1.1;
- provision 5.3-13 of ETSI EN 303 645 v2.1.1.

#### Support period

BSH Hausgeräte GmbH will provide security updates that are necessary to maintain the main functions free of charge until at least 28/02/2034.

## 30 How it works

Here, you can find the ideal settings for various types of food as well as the best accessories and cookware. We have perfectly tailored these recommendations to your appliance.

**Tip:** A lot of other information about the preparation, corresponding adjustment values and recipes can be found in the Home Connect app or on our website *www.neff-home.com*.

## 30.1 General cooking tips

Take note of the following information when cooking all types of food.

- The temperature and cooking time depend on the amount of food and the recipe. Settings ranges are specified for this reason. Try using the lower values to start with.
- The setting values apply to food placed in the cooking compartment while the cooking compartment is still cold. If you want to preheat anyway, do not place accessories into the cooking compartment until it has finished preheating.
- Remove any accessories that are not being used from the cooking compartment.

#### **ATTENTION**

Acidic food may damage the wire rack

► Do not place acidic food, such as fruit or food with an acidic marinade directly on the wire rack.

#### Information for those allergic to nickel

In rare cases, small amounts of nickel may pass into the food.

You can buy suitable accessories from customer service, from specialist retailers or online.

→ "Other accessories", Page 12

**Tip:** For some food, you can use the ventilation function "Crisp Finish". For some food, you can use the ventilation function . The ventilation function "Crisp Finish" extracts moisture from the cooking compartment with increased intensity. This method is recommended for food with lots of moisture, e. g.

- for cooking on several levels
- for baked items with a moist toppings
- for meringue pastry
- when increased crispiness is required

For crispier food, we recommend switching this on in the second half of the cooking time.

→ "Ventilation function Crisp Finish", Page 16

### 30.2 Baking tips

- Dark-coloured metal baking tins are most suitable for baking cakes, bread and other baked goods.
- Use wide, shallow cookware for bakes and gratins.
   Food takes longer to cook in deep, narrow cookware and it browns more on top.
- Silicone moulds are not suitable.
- If you are cooking bakes directly in the universal pan, place the universal pan into the cooking compartment at level 1.
- The setting values for bread dough apply to both dough placed on a baking tray and dough placed in a loaf tin.
- The recommended settings for baking in combination with the microwave mode are for metal baking tins.

#### **ATTENTION**

When the cooking compartment is hot, any water inside it will create steam. The change in temperature may cause damage.

- Never pour water into the cooking compartment when it is still hot.
- Never place cookware containing water on the cooking compartment floor.

#### Shelf positions

You will obtain the best results if you use the following shelf positions.

If you are baking on one level, use shelf position 1.

Baking on 2 levels	Height
Universal pan	3
Baking tray	1
Baking tins/dishes on two wire racks	3
	1

Use the hot air heating function.

#### **Notes**

- Items that are placed in the appliance on baking trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.
- If you opt for cooking in combination with the microwave mode, you can only cook on one level.

## 30.3 Roasting, braising and grilling tips

- The recommended settings are for fridge-temperature food and unstuffed, oven-ready poultry.
- Place the poultry onto the cookware breast-side or skin-side down.

 Turn roasting joints, grilled items or whole fish after approx. ½ to ¾ of the specified time.

# Roasting on the wire rack

Food roasted on the wire rack will become very crispy on all sides. You can roast large poultry, for example, or multiple individual pieces at the same time.

- Roast pieces of a similar weight and thickness. The grilled food will brown evenly and will remain succulent and juicy.
- Place the food to be roasted directly on the wire rack.
- To catch any liquids that drip down, place the universal pan into the cooking compartment one level below the wire rack.
- Add up to ½ litre of water to the universal pan, depending on the size and type of food that you want to

You can make a sauce from the juices that are collected. This also means that less smoke is produced and the cooking compartment does not become as dirty.

# Roasting in cookware

If you cover the cookware when you cook your food, this will keep the cooking compartment cleaner.

#### General information about roasting in cookware

- Use heat-resistant, ovenproof cookware.
- Place the cookware on the wire rack.
- Glass cookware is best.
- Follow the manufacturer's instructions for your roastina dishes.

#### Roasting in uncovered cookware

- Use a deep roasting dish.
- If you do not have any suitable cookware, you can use the universal pan.

#### Roasting in covered cookware

- Use a suitable lid that seals well.
- When roasting meat, there should be at least 3 cm between the food and the lid. The meat may expand.

# 

Very hot steam may escape when the lid is opened after cooking. Steam may not be visible, depending on the temperature.

- ► Lift the lid in such a way that the hot steam can escape away from you.
- Keep children away from the appliance.

#### Grilling

Grill food if you want it to be crispy.

The "Grill" type of heating is good for cooking thinner pieces of poultry, meat and fish such as steaks, drumsticks and burgers. It is also excellent for toasting

Circo-roasting is very well suited to cooking whole poultry and fish, as well as meat, e.g. roast pork with crackling.

- When grilling several food items, choose pieces that are of a similar weight and thickness. The grilled food will brown evenly and will remain succulent and juicy.
- Place the food to be grilled directly onto the wire rack.

 To catch any liquids that drip down, place the universal pan into the cooking compartment at least one level below the wire rack.

#### **Notes**

- The grill element switches on and off continuously. This is normal. The temperature that you set determines how frequently this occurs.
- Smoke may be produced when grilling.

# 30.4 Microwave cooking

If you cook food using the microwave mode, you can reduce the cooking time considerably.

#### **General information**

- When using the microwave mode, the cooking time is determined based on the total weight. If you want to cook a quantity that differs from the specified quantity, the general rule is **Double the** quantity requires just under double the cooking time.
- The food transfers heat to the cookware. The cookware may become very hot.
- The main part of the instruction manual contains information on how to configure the microwave and microwave boost oven settings.
  - → "Microwave", Page 15

#### Tip

You can find more microwave recipes here:

- → "Defrosting", Page 42
- → "Warming up food using the microwave mode", Page 42

# Cooking, braising or steaming using the microwave mode

- Use microwave-safe cookware with a lid. Alternatively. you can use a plate or special microwaveable film to cover the dish.
- For cereal products, e.g. rice, use deep cookware with a lid. Cereal products foam a lot during cooking. Add liquid in accordance with the instructions and information provided in the recommended settings tables
- Do not wash or dry food. Add 1-3 tablespoons of water or lemon juice to the food.
- Spread the food out so that as much of it as possible is in contact with the bottom of the cookware. Food that is in contact with the bottom will cook more quickly than food that is piled up.
- Use salt and seasoning sparingly. When cooking food using the microwave mode, most of the food's natural flavour will be retained.
- Turn or stir the food 2-3 times during cooking.
- After cooking, leave the food to rest for 2-3 minutes.

# 30.5 Cooking instructions for ready meals

- The cooking result greatly depends on the quality of the food. Pre-browning and irregularities may already be present in the food before cooking.
- Do not use frozen products that are covered with a thick layer of ice. Remove any ice on the food.
- Take ready meals out of the packaging.

- If you are warming or cooking the ready meal in cookware, make sure that the cookware is heat-resistant.
- Distribute foods that are in the form of separate pieces, such as bread rolls and potato products, so that they are spread out flat and evenly on the accessory. Leave a little space between the individual pieces.
- Follow the manufacturer's instructions on the packaging.
- To achieve best results, we recommend that you reheat food or ready meals at 600 watts. If the packaging specifies a higher microwave output setting, extend the time.

# 30.6 List of foods

Recommended settings for a variety of foods, sorted into food categories.

# Recommended settings for various types of food

Food	Accessories/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Sponge cake, simple	Ring-shaped tin or Loaf tin	1	L	160-180	90	30-40
Sponge cake, delicate	Ring-shaped tin or Loaf tin	1	=	150-170	-	60-80
Fruit tart or cheesecake with shortcrust pastry base	Springform cake tin, diameter 26 cm	1	L	160-170	-	65-85
Fruit tart or cheesecake with shortcrust pastry base	Springform cake tin, diameter 26 cm	1	L	<b>1.</b> 160-180 <b>2.</b> 100	<b>1.</b> 180 <b>2.</b> -	<b>1.</b> 30-40 <b>2.</b> 20
Sponge flan, 6 eggs	Springform cake tin Ø 28 cm	1	ک	150-170 <sup>1</sup>	-	30-50
Sponge flan, 6 eggs	Springform cake tin Ø 28 cm	1	n 60	150-160	-	50-60
Shortcrust tart with moist topping	Universal pan	1	=	160-180 <sup>2</sup>	-	60-80
Yeast cake with moist topping	Universal pan	1	=	180-190 <sup>2</sup>	-	30-45
Swiss roll	Baking tray	1	=	180-190 <sup>1</sup>	-	10-20
Muffins	Muffin tray	1	_	170-190	_	15-30
Small yeast cakes	Baking tray	1	=	160-170	-	30-40
Biscuits	Baking tray	2	L	140-160	-	15-30
Biscuits, 2 levels	Universal pan + Baking tray	3+1	گ ا	130-150	-	20-35
Meringues	Baking tray	2	L	80-90 <sup>1,2</sup>	-	120-150
Bread, 750 g	Universal pan or Loaf tin	1	<u></u>	<b>1.</b> 210-220 <b>2.</b> 180-190 <sup>1,2</sup>	-	<b>1.</b> 10-15 <b>2.</b> 25-35
Bread, 1500 g	Universal pan or Loaf tin	1		<b>1.</b> 210-220 <b>2.</b> 180-190 <sup>1,2</sup>	-	<b>1.</b> 10-15 <b>2.</b> 40-50
Bread, 1500 g	Universal pan or Loaf tin	1		200-210	-	35-45
Flatbread	Universal pan	1	Ξ	250-270	_	20-30
Bread rolls, fresh	Baking tray	1	=	180-190	-	25-35
Pizza, fresh	Baking tray	1	<u>&amp;</u>	180-200 <sup>2</sup>	-	20-30

<sup>&</sup>lt;sup>1</sup> Preheat the appliance.

<sup>&</sup>lt;sup>2</sup> Switch on the Crisp Fresh ventilation function.

Food	Accessories/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Pizza, fresh, 2 levels	Universal pan + Baking tray	3+1	&	180-190 <sup>1</sup>	-	35-45
Pizza, fresh, thin-crust, on a pizza tray		1	<u>&amp;</u>	210-230	-	20-30
Börek	Universal pan	1	=	180-190	-	35-45
Quiche	Dark coated quiche tin	1	<u>&amp;</u>	190-210	-	25-40
Tarte flambée	Universal pan	1	=	260-270 <sup>2</sup>	-	10-20
Bake, savoury, cooked ingredients	Ovenproof dish	1	=	200-220	-	35-55
Bake, savoury, cooked ingredients	Ovenproof dish	1	Ĭ	140-160	360	20-30
Lasagne, frozen, 350-450 g, 3 cm deep	Uncovered cook- ware	1	=	200-210	180	20-25
Lasagne, frozen, 600-1000 g, 4-5 cm deep	Uncovered cook- ware	1	= =	200-210	180	35-45
Potato gratin, raw ingredients, 4 cm deep	Ovenproof dish	1	<u>&amp;</u>	170-180	-	50-65
Potato gratin, raw ingredients, 4 cm deep	Ovenproof dish	1	Ä	170-190	360	20-25
Chicken, halved	Uncovered cook- ware	1	Ä	180-200	360	25-35
Chicken, 1.3 kg, un- stuffed	Wire rack	1	Ï	200-220 1	-	60-70
Chicken, 1.3 kg, un- stuffed	Covered cookware	1	Z.	230-250	360	25-35
Small chicken portions, 250 g each	Wire rack	2	Ĭ.	220-230	-	30-35
Small chicken portions, 250 g each	Uncovered cook- ware	1	Ĩ	190-210	360	20-30
Goose, unstuffed, 3 kg	Uncovered cook- ware	1	Ĩ	160-170	-	120-150
Joint of pork without rind, e.g. neck, 1.5 kg	Uncovered cook- ware	1	Ž	180-200	-	120-130
Joint of pork without rind, e.g. neck, 1.5 kg	Covered cookware	1	Ĩ	180-200	180	55-65
Joint of pork without rind, e.g. neck, 1.5 kg	Uncovered cook- ware	1		180-190	-	120-140
Fillet of beef, medium, 1 kg	Uncovered cook- ware	1	Ĭ	210-220	-	40-50
Pot-roasted beef, 1.5 kg	Covered cookware	1	Ĩ	200-220	-	130-140
Pot-roasted beef, 1.5 kg	Covered cookware	1	<del></del>	200-220	_	140-160
Sirloin, medium, 1.5 kg	Uncovered cook- ware	1	Ä	220-230	-	60-70
Sirloin, medium, 1.5 kg	Uncovered cook- ware	1	=	240-260	180	30-40
Burger, 3-4 cm thick	Wire rack	2	<u></u>	290	_	20-30 <sup>3</sup>

<sup>&</sup>lt;sup>1</sup> Switch on the Crisp Fresh ventilation function.
<sup>2</sup> Preheat the appliance.
<sup>3</sup> Turn the dish 2/3 of the way through the cooking time.

Food	Accessories/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Leg of lamb, boned, medium, 1.5 kg	Uncovered cook- ware	1	Ä	170-190	-	50-70
Leg of lamb, boned, medium, 1.5 kg	Covered cookware	1	ک	240-260	<b>1.</b> 360 <b>2.</b> 180	<b>1.</b> 30 <b>2.</b> 35-40
Meat loaf, 1 kg + 50 ml water	Uncovered cook- ware	1	W.	170-190	360	30-40
Fish, grilled, whole, 300 g, e.g. trout	Uncovered cook- ware	1	Ä	170-190	-	20-30
Fish, grilled, whole, 300 g, e.g. trout	Wire rack	2	<u>—</u>	250	90	15-20
Vegetables, fresh, 250 g	Covered cookware	1	***	=	600	8-12 1
Mixed vegetables, 250 g, + 25 ml water	Covered cookware	1	***	-	600	10-14 1
Baked potatoes, halved, 1 kg	Universal pan	2	Ä	200-220	360	15-20
Peeled boiled potatoes, quartered, 500 g	Covered cookware	1	**** ****	_	600	12-15 <sup>1</sup>
Long-grain rice, 250 g + 500 ml water	Covered cookware	1	***	_	<b>1.</b> 600 <b>2.</b> 180	<b>1.</b> 7-9 <b>2.</b> 13-16
Millet, whole, 250 g, + 600 ml water	Covered cookware	1	***	-	<b>1.</b> 600 <b>2.</b> 180	<b>1.</b> 8-10 <b>2.</b> 10-15
Polenta or maize semolina, 125 g + 500 ml water	Covered cookware	1	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	-	600	6-8 1

#### **Desserts**

### **Making yoghurt**

- **1.** Remove the accessories and shelves from the cooking compartment.
- 2. Heat 1 litre of whole milk (3.5% fat) to 90 °C on the hob and then leave it to cool down to 40 °C. It is sufficient to heat UHT milk to 40 °C.
- 3. Mix 150 g of chilled yoghurt into the milk.
- Pour the mixture into small containers, e.g. cups or small iars
- 5. Cover the containers with film, e.g. cling film.
- **6.** Place the containers on the cooking compartment floor.
- 7. Use the recommended settings when configuring the appliance settings.
- **8.** After making the yoghurt, leave it to cool in the refrigerator for at least 12 hours.

#### Making blancmange from blancmange powder

- 1. Use a deep, microwave-safe receptacle.
- 2. Pour the blancmange powder and all of the milk and sugar into the receptacle and mix.
- **3.** Place the receptacle onto the wire rack and slide the rack into the cooking compartment.
- **4.** Use the recommended settings when configuring the appliance settings.

- **5.** As soon as the milk starts to rise, stir thoroughly.
- **6.** Repeat the process until the required consistency is achieved.

#### Using the microwave mode to make popcorn

### 

Airtight packaging may burst when food is heated.

- ► Always follow the instructions on the packaging.
- Always use oven gloves to remove the dishes from the cooking compartment.
- **1.** Use a microwave-safe, shallow ovenproof dish. Do not use porcelain or deep plates.
- **2.** Place the popcorn bag onto the cookware in accordance with the instructions on the packaging.
- **3.** Use the recommended settings when configuring the appliance settings.
- **4.** The time may need to be adjusted, depending on the product and quantity in question.
- **5.** Remove the popcorn bag after 1½ minutes and shake it to ensure that the popcorn does not burn.
- **6.** Place the popcorn bag back into the oven and leave it to continue popping.
- 7. Once you can only hear popping noises once every 2-3 seconds, switch off the appliance and take the popcorn bag out of the oven.
- **8.** Wipe the cooking compartment clean afterwards.

<sup>&</sup>lt;sup>1</sup> Stir the food one or two times during cooking.

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Blancmange made from blancmange powder	Covered cookware	1	****	-	600	5-8 1
Yoghurt	Individual moulds	Cooking compart- ment floor		40-45	-	8-9 hrs
Microwave popcorn, 1 x 100 g bag <sup>2</sup>	Uncovered cook- ware	1	****	-	600	4-6

# 30.7 Special cooking methods and other applications

Information and recommended settings for special cooking methods and other applications, e.g. low-temperature cooking.

# Low-temperature cooking

For all prime cuts which are to be cooked rare or "à point". When slow cooking at low temperatures, meat and poultry remain juicy and tender.

# Low-temperature cooking poultry or meat

**Note:** When using the low-temperature cooking type of heating, you cannot delay the start of the programme by setting an end time.

**Requirement:** The cooking compartment is cold.

- **1.** Use fresh, hygienically perfect meat. Pieces without bones and without a lot of connective tissue are most suitable.
- **2.** Place the cookware onto the wire rack at level 1 in the cooking compartment.
- **3.** Preheat the cooking compartment and cookware for approx. 15 minutes.
- Sear the meat on all sides on the hob at a very high heat.

5. Immediately place the meat into the pre-warmed cookware in the cooking compartment.
To ensure that the temperature in the cooking compartment remains constant, keep the cooking compartment remains constant.

partment remains constant, keep the cooking compartment door closed during low-temperature cooking.

# Tips for low-temperature cooking

Here you will find tips for achieving good results when low-temperature cooking food.

Issue	Tip
You want to cook a duck breast at a low temperature.	<ul> <li>Place the cold duck breast into a pan.</li> <li>Sear the skin side first.</li> <li>Cook the duck breast at low temperature.</li> <li>After low-temperature cooking, grill the duck breast for 3 to 5 minutes until crispy.</li> </ul>
You want to serve your low-temperature cooked meat as hot as possible.	<ul> <li>Preheat the serving plate.</li> <li>Make sure that the accompanying sauces are very hot when you serve them.</li> </ul>

#### Recommended settings for low-temperature cooking

Food	Accessory/ cookware	Height	Searing time in mins	Type of heating	Temperat- ure in °C	Mi- crowave power setting in W	Cooking time in mins
Duck breast, medium rare, 300 g each	Uncovered cookware	1	6-8	8	95 <sup>3</sup>	-	45-60
Fillet of pork, whole	Uncovered cookware	1	4-6	<u></u>	85 <sup>3</sup>	-	45-70
Fillet of beef, 1 kg	Uncovered cookware	1	4-6	<u> </u>	85 <sup>3</sup>	-	90-120
Veal medallions, 4 cm thick	Uncovered cookware	1	4	8	80 <sup>3</sup>	-	40-60
Saddle of lamb, boned, 200 g each	Uncovered cookware	1	4	8	85 <sup>3</sup>	-	30-45

<sup>3</sup> Preheat the appliance.

<sup>&</sup>lt;sup>1</sup> Stir the food one or two times during cooking.

<sup>&</sup>lt;sup>2</sup> Place the sealed bag on the cookware.

You can defrost frozen food in your appliance.

### Tips for defrosting food

- You can use the "microwave" mode to defrost frozen fruit, vegetables, poultry, meat, fish or baked goods.
- Remove frozen food from its packaging before you defrost it.
- Use heat-resistant, microwave-safe cookware.
- The recommended settings are for freezer-temperature food (-18 °C).
- Defrosting works best if you divide it into more than one step. The steps are listed one after the other in the recommended settings tables.
- Stir or turn the food 1-2 times during defrosting.
   Turn large items several times. Split the food into smaller pieces as it defrosts.
  - Remove pieces that have already defrosted from the cooking compartment.
- Once the food has defrosted, switch off the appliance and leave the food in the appliance for another 10 to 30 minutes to allow the temperature to equalise.

# Recommended settings for defrosting food

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Bread, 500 g	Uncovered cook- ware	1	**** ****	_	<b>1.</b> 180 <b>2.</b> 90	<b>1.</b> 3 <b>2.</b> 10-15
Bread rolls	Wire rack	1	S	140-160	90	2-4
Cake, moist, 500 g	Uncovered cook- ware	1	**** ****	_	<b>1.</b> 180 <b>2.</b> 90	<b>1.</b> 2 <b>2.</b> 10-15
Cake, dry, 750 g	Uncovered cook- ware	1	***	_	90	10-15
Chicken, whole, 1.3 kg	Uncovered cook- ware	1	***	_	<b>1.</b> 180 <b>2.</b> 90	<b>1.</b> 10 <b>2.</b> 10-20 <sup>1</sup>
Meat, whole, e.g. joint, raw meat, 1 kg	Uncovered cook- ware	1	***	_	<b>1.</b> 180 <b>2.</b> 90	<b>1.</b> 15 <b>2.</b> 20-30 <sup>1</sup>
Minced meat, mixed, 500 g	Uncovered cook- ware	1	***	_	<b>1.</b> 180 <b>2.</b> 90	<b>1.</b> 5 <b>2.</b> 10-15 <sup>1</sup>
Fish, whole, 300 g	Uncovered cook- ware	1	***	_	<b>1.</b> 180 <b>2.</b> 90	<b>1.</b> 3 <b>2.</b> 10-15 <sup>1</sup>
Berries, 300 g	Uncovered cook- ware	1	***	-	180	5-10
Butter, defrosting, 125 g	Uncovered cook- ware	1	***	-	90	7-9

#### Warming up food using the microwave mode

You can use the microwave mode to warm up food or to defrost and warm up food in a single step.

# Tips for warming up food using the microwave mode


- Use microwave-safe cookware with a lid.
- Turn or stir the food 2-3 times during warming.
- After warming up the food, leave it to rest for 1-2 minutes.
- The food transfers heat to the cookware. The cookware can become very hot.
- Make sure that you do the following when you are warming up baby food:
  - Place bottles on the wire rack without the teat or lid.
  - Shake or stir the baby food well after warming it up.
  - Always check the temperature of the baby food.
- Wipe the cooking compartment dry after using it to warm up food.

# 

There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches the boiling

temperature without the usual steam bubbles rising to the surface. Exercise caution even when only gently shaking the container. The hot liquid may suddenly boil over and splatter.

Always place a spoon in the container when heating liquids. This prevents delayed boiling.



#### **ATTENTION**

Metal touching the wall of the cooking compartment will cause sparks, which may damage the appliance or the inner door pane.

Metal (e.g. a spoon in a glass) must be kept at least 2 cm from the cooking compartment walls and the inside of the door.

<sup>&</sup>lt;sup>1</sup> Turn the dish halfway through the cooking time.

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Drinks, warming up, 200 ml	Uncovered cook- ware	1	****	-	Max.	1-3 1
Baby food, heating up, e.g. baby bottle, 150 ml	Uncovered cook- ware	1	****	-	360	1-3 1
Vegetables, chilled, 250 g	Covered cookware	1	****	-	600	3-8
Vegetables, frozen, loose, 250 g	Covered cookware	1	****	-	600	8-12
Plated meal, chilled, 1 portion	Covered cookware	1	****	-	600	4-8
Soup, stew, chilled, 400 ml	Covered cookware	1	****	-	600	5-7
Side dishes, e.g. pasta, dumplings, potatoes, rice, chilled	Covered cookware	1	****	_	600	5-10
Plated meal, frozen, 1 portion	Covered cookware	1	****	-	600	11-15
Soup, stew, frozen, 200 ml	Covered cookware	1	****	-	600	4-6 <sup>1</sup>
Side dishes, 500 g, e.g. pasta, dumplings, potatoes, rice, frozen	Covered cookware	1	****	-	600	7-10 <sup>1</sup>
Bakes, 400 g, e.g. lasagne, potato gratin, frozen	Uncovered cook- ware	1	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	180-200	180	20-25

# Keeping food warm

# Tips for keeping food warm

- Using the "Keep warm" heating function prevents condensation from forming. You will not have to wipe down the cooking compartment.
- To prevent the food from drying out, you can cover it.
- Do not keep food warming for longer than 2 hours.
- Be aware that some types of food will actually continue cooking when you are keeping them warm in the oven.

# 30.8 Meals and tips for cooking for Great Britain

Recommended settings for meals with British cooking habits.

Also follow the instructions in the individual sections. This section contains only special additional information relating to British meals and cooking habits.

# **Baking**

# Recommended settings for baking on one level

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Victoria sponge cake	x 2 20 cm diameter cake tin	1	L	160-170 <sup>2</sup>	-	20-30
Rich fruit cake	Deep, 23 cm dia- meter tin	1	L	130-150	_	150-180
Rich fruit cake	Deep, 23 cm dia- meter tin	1	L	130-140	90	80-90
Rich fruit cake	Deep, 23 cm dia- meter tin	1	000	140-160	-	120-180

<sup>&</sup>lt;sup>1</sup> Stir the food well.

<sup>&</sup>lt;sup>2</sup> Preheat the appliance.

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Fruit pie	20 cm diameter plate or Pie tin	1	<u>&amp;</u>	180-190	_	45-50
Fruit pie	20 cm diameter plate or Pie tin	1	C C	170-190	-	60-75
Bread or white bread	Loaf tin, 1 x 900 g or 2 x 450 g	1	<u></u>	200-210 <sup>1</sup>	-	20-30
Bread or white bread	Loaf tin, 1 x 900 g or 2 x 450 g	1	000	190-200	-	45-55
Scones	Baking sheet on wire rack	1	L	180-190 ¹	-	10-14
Biscuits	Baking sheet on wire rack	2	٨	140-160 <sup>1</sup>	-	10-25
Small cakes	12-cup-tin	1	Ξ	150-170	-	20-30
Pavlova	Baking tray	2	L	90-100 <sup>1, 2</sup>	-	120-180
Yorkshire pudding	12-cup-tin	1	L	200-220 <sup>1</sup>	_	15-25

# Recommended settings for baking on several levels

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Biscuits, 2 levels	x 2 Baking tray	3+1	L	140-160 <sup>1</sup>	-	15-30

# Grilling

# Recommended settings for meat

Food	Accessories/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Pork, Bacon rashers	Wire rack	2	****	290 <sup>3</sup>	-	<b>1.</b> 4-5 <b>2.</b> 3-4 <sup>4</sup>
Pork, Sausages, thickness 2-4 cm	Wire rack	2	****	290 5	-	10-15 <sup>6</sup>
Pork, Belly	Uncovered cook- ware	1	Ä	200-220	-	30+25
Pork, Gammon joint	Uncovered cook- ware	2	Ä	180-200	-	30+25

# **Recommended settings for poultry**

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Chicken, whole	Uncovered cook- ware	1	Ĭ.	200-220	_	25+15

<sup>&</sup>lt;sup>1</sup> Preheat the appliance. <sup>2</sup> Switch on the Crisp Fresh ventilation function. <sup>3</sup> Preheat the appliance for 5 minutes.

<sup>&</sup>lt;sup>4</sup> Turn the food occasionally.
<sup>5</sup> Preheat the appliance for 3 minutes.

<sup>&</sup>lt;sup>6</sup> Turn the food several times.

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Chicken, whole, 1 kg	Covered cookware	1	Ĩ.	230-250	360	25-35

# Roasting and braising

#### Cooking tips for roasting and braising

Follow this information when frying or braising poultry or meat.

Calculating the cooking time, e.g. 20+35:

■ To calculate the cooking time, assume 20 minutes per 500 g of meat. Then add an extra 35 minutes to that figure.

• For 1.5 kg, the cooking time would therefore be 95 minutes.

Cooking time range, e.g. 10-15:

 Your food will be ready within the specified range of time (in minutes).

#### Recommended settings for meat

Food	Accessories/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Beef, Top side, Top rump	Uncovered cook- ware	1	S	160-170	-	30+25
Lamb, Leg, bone-in	Uncovered cook- ware	1	S	160-170	-	25+25
Pork, Belly	Uncovered cook- ware	1	J	170-180	-	30+25

# Recommended settings for poultry

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Chicken, whole	Uncovered cook- ware	1	<u>گ</u>	170-180	-	25+15
Turkey, crown	Uncovered cook- ware	1	L	150-160	-	20+15 <sup>1</sup>
Turkey, whole, 4-8 kg	Universal pan	1	S	150-160	_	12+12 <sup>2</sup>

#### Recommended settings for meat dishes

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Meat loaf, 1 kg, + 50 ml water	Uncovered cook- ware	1	Ĭ.	170-190	360	30-40

# 30.9 Test dishes

The information in this section is provided for test institutes to facilitate testing of the appliance in accordance with EN 60350-1 or IEC 60350-1 and EN 60705 or IEC 60705.

#### Baking

- The setting values apply to food that is placed into a cold cooking compartment.
- Take note of the information on preheating in the recommended settings tables. These setting values apply without rapid heat-up.

- For baking, use the lower of the temperatures indicated first.
- Items that are placed in the appliance on baking trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.
- Shelf positions when baking on 2 levels:
  - Universal pan: Shelf position 3 Baking tray: Shelf position 1
- Hot water sponge cake
  - When baking on 2 levels, place the springform tins at diagonally opposite corners of the wire racks.
  - As an alternative to a pan support, you can also use the Air Fry baking tray offered by us.

<sup>&</sup>lt;sup>1</sup> Do not turn the food.

<sup>&</sup>lt;sup>2</sup> Turn the food after approx. one hour.

# Recommended settings for baking

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Shortbread	Baking tray	1	=	150-160 <sup>1</sup>	-	20-30
Shortbread	Baking tray	1	S	140-150 <sup>1</sup>	-	25-35
Small cakes	Baking tray	1	=	160 ¹	=	25-35
Small cakes	Baking tray	1	L	150 ¹	=	20-30
Small cakes, 2 levels	Universal pan + Baking tray	3+1	S	140 1	-	30-40
Hot water sponge cake	Springform cake tin, diameter 26 cm	1	Ξ	160-170 <sup>2</sup>	-	25-35
Hot water sponge cake	Springform cake tin, diameter 26 cm	1	L	160-170 <sup>2</sup>	-	30-45

# Grilling

# Recommended settings for grilling

Food	Accessories/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Toasting bread	Wire rack	3	***	290 <sup>3</sup>	=	3-6

# Microwave cooking

To test the microwave mode on its own, switch off the drying function in the basic settings. → Page 22

# Recommended settings for defrosting food using the microwave

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Meat	Uncovered cook- ware	1	<b>***</b>	-	<b>1.</b> 180 <b>2.</b> 90	<b>1.</b> 5 <b>2.</b> 10-15

# Recommended settings for cooking food using the microwave

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Custard	Uncovered cook- ware	1	***	-	<b>1.</b> 360 <b>2.</b> 180	<b>1.</b> 20 <b>2.</b> 20-25
Sponge	Uncovered cook- ware	1	***	_	600	7-9
Meat loaf	Uncovered cook- ware	1	**** ****	_	600	22-27

# Recommended settings for cooking in combination with the microwave

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Potato gratin	Uncovered cook- ware	1	Ĭ.	150-170	360	25-30

<sup>&</sup>lt;sup>1</sup> Preheat the appliance for five minutes. Do not use the rapid heating function.

46

<sup>&</sup>lt;sup>2</sup> Preheat the appliance. Do not use the rapid heating function.

<sup>&</sup>lt;sup>3</sup> Do not preheat the appliance.

Food	Accessory/cook- ware	Shelf po- sition	Type of heating	Temperature in °C	Microwave power set- ting in W	Cooking time in mins
Cakes	Uncovered cook- ware	1	L	190-210	180	12-18
Chicken, halved	Uncovered cook- ware	1	Ä	180-200	360	25-35

# 31 Installation instructions

Observe this information when installing the appliance.




# 31.1 General installation instructions

Follow these instructions before you start installing the appliance.

- There should be a gap of at least 35 mm between the wall and the cabinet base as well as the rear panel of the cabinet situated above.
- Ventilation slots and intake openings must not be covered.
- The safe operation of this appliance can only be guaranteed if it has been installed to a professional standard in accordance with these installation instructions. The installer shall be liable for damages incurred as a result of incorrect installation.
- Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.
- Before starting up the appliance, remove any packaging material and adhesive film from the cooking compartment and the door.
- Proceed in accordance with the installation sheets for installing accessories.
- Fitted units must be heat-resistant up to 95 °C, and adjacent unit fronts up to 70 °C.
- Do not install the appliance behind a decorative door or the door of a kitchen unit. There is a risk of overheating.
- Cut-out work on the units should be carried out before installing the appliance. Remove any shavings. Otherwise, the correct operation of electrical components may be adversely affected.
- Position the appliance on a horizontal surface.

- The mains socket for the appliance must either be located in the hatched area @ or outside of the area where the appliance is installed.
- 1 Any unsecured units must be secured to the 2.wall using a standard bracket D.



- Wear protective gloves so that you do not cut yourself. Parts that are accessible during installation may have sharp edges.
- Dimensions of the figures in mm.

# 

Once the appliance has been installed, the openings in the back panel of the appliance must not be accessible to children, not even through the drawers and kitchen cabinets underneath. This must be ensured through the installation. In the case of an island unit, a closed back panel is required.

# 



Caution: Magnetism

Caution for people with pacemakers Permanent magnets are used in the control panel. These may impair the functionality of electronic implants, e.g. pacemakers or insulin pumps.

▶ Persons with electronic implants must stand at least 10 cm away from the control panel.

### 

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ► Only use adapters and power cords approved by the manufacturer.
- ▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.


#### **ATTENTION**

Carrying the appliance by the door handle could break it. The door handle cannot support the weight of the appliance.

► Do not carry or hold the appliance by the door handle.


# 31.2 Appliance dimensions

You will find the dimensions of the appliance here



# 31.3 Installation below a worktop


Observe the installation dimensions and the installation instructions when installing below a worktop.



- To ventilate the appliance, the intermediate floor must have a ventilation cut-out.
- The worktop must be secured to the fitted unit.
- Observe any available installation instructions for the
- Observe different national installation instructions for the hob.
- Observe the worktop depth of min. 600 mm.
- When installing under a gas hob, ensure that the appliance does not come into contact with the gas connection of the gas hob.
- If necessary, call a qualified specialist for gas installa-

# 31.4 Installation underneath a hob

If the appliance is installed under a hob, the following minimum dimensions must be adhered to (including substructure, if applicable).




The minimum worktop thickness b a is based on the required minimum clearance a.

Hob type	a raised in mm	a flush in mm	b in mm	
Induction hob	42	43	5	
Full-surface induction hob	52	53	5	


Hob type	a raised in mm	a flush in mm	b in mm
Gas hob	32	43	5 <sup>1</sup>
Electric hob	32	35	2

# 31.5 Installation in a tall unit

Observe the installation dimensions and the installation instructions when installing in a tall unit.



- To ventilate the appliance, the intermediate floors must have a ventilation cut-out.
- In order to ensure sufficient ventilation of the appliance, there must be a ventilation opening of at least. 200 cm<sup>2</sup> in the base area. To do this, trim the base panel or fit a ventilation grille. Ensure that the air exchange is guaranteed in accordance with the diagram.




 Only fit the appliance up to a height which allows accessories to be easily removed.


# 31.6 Installing two appliances on top of each other

Your appliance can also be installed above or below another appliance. Observe the installation dimensions

and the installation instructions when installing appliances on top of each other.



- To ventilate the appliances, the intermediate floor must have a ventilation cut-out.
- To ensure sufficient ventilation of the two appliances, there must be a ventilation opening of at least 200 cm<sup>2</sup> in the base area. To do this, trim the base panel or fit a ventilation grille.
- Ensure that air exchange is guaranteed in accordance with the diagram.




 Only fit appliances up to a height that allows accessories to be easily removed.

<sup>&</sup>lt;sup>1</sup> Observe different national installation instructions for the hob.

#### 31.7 Corner installation

Observe the installation dimensions and the installation instructions when installing in a corner.




To ensure that the appliance door can be opened, you must take the minimum dimensions into consideration when installing in a corner. The dimension a is dependent on the thickness of the unit front and the handle.

#### 31.8 Electrical connection

In order to safely connect the appliance to the electrical system, follow these instructions.

- The appliance corresponds to protection class I and must only be operated with a protective earth connec-
- The fuse protection must correspond to the power rating specified on the appliance's rating plate and to the local regulations.
- The appliance must be disconnected from the power supply whenever installation work is being carried
- The appliance must only be connected using the power cable provided.
- The power cable must be plugged in at the rear of the appliance until you hear a clicking sound. A 3 m power cable can be obtained from customer service.



- The power cable must only be replaced with a cable from the original manufacturer. This is available from after-sales service.
- Contact protection must be guaranteed by the installation.
- If the display on the appliance remains dark, it has not been connected correctly. Disconnect the appliance from the mains and check the connection.

# Electrically connect the appliance with the protective contact plug

Note: The appliance must only be connected to a protective contact socket that has been correctly installed.

Insert the plug into the protective contact socket. When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.

# Electrically connecting an appliance without a protective contact plug

Note: Only licensed specialists may connect the appliance. Damage caused by incorrect connection is not covered under the warranty.


An isolating switch must be integrated into the permanent electrical installation according to the installation regulations.

- 1. Identify the phase and neutral conductors in the socket.
  - The appliance may be damaged if it is not connected
- 2. Connect the hob in accordance with the connection diagram.
  - See the rating plate for the voltage.
- 3. Connect the wires of the mains power cable according to the colour coding:
  - ► Green/yellow = Protective conductor ⊕
  - ► Blue = Neutral conductor
  - ► Brown = Phase (external conductor)

# 31.9 Installing the appliance


Note: Do not use a cordless screwdriver to secure the panels. This may damage the panels.

- 1. Push the appliance in fully. Do not kink or trap the connection cable, or route it over sharp edges.
- 2. Centre the appliance.




There must be an air gap of at least 4 mm between the appliance and adjacent unit fronts.


3. Open the appliance door and unscrew the left and right-hand panels.




- **4.** Close the appliance door.
- 5. Screw the appliance into place.



6. Refit the panels and screw them in place, first at the top and then at the bottom.



7. If required, the gap between the appliance door and the side panels can be adjusted using the screws at the top left and right.




**Note:** The gap between the worktop and the appliance must not be closed by additional battens.


Thermal insulation strips must not be fitted to the side panels of the surround unit.

# 31.10 For handleless kitchens with vertical bar handle strips:


1. Attach a suitable filling piece on both sides in order to cover any sharp edges and to guarantee safe installation.



- 2. Secure the filling piece to the unit.
- 3. Pre-drill the filling piece and the unit to establish a screw connection.



4. Secure the appliance using a suitable screw.



# 31.11 Removing the appliance

- 1. Disconnect the appliance from the power supply.
- 2. Open the appliance door and unscrew the left and right-hand panels.
- **3.** Undo the fastening screws.
- 4. Lift the appliance slightly and pull it out completely.

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom



Register your product online **neff-home.com** 

**BSH Hausgeräte GmbH** Carl-Wery-Straße 34 81739 München, GERMANY



**9001697004** (050507) REG25 en