



U1DCC0A.3B

#### You can find additional information and explanations online. Scan the QR code on the title page.



# Table of contents

| IN | FORMATION FOR USE                            | 10         | Childproof lock ≡  | 12       |
|----|--|------------|--|----------|
| 1  | Safety 2                                     | 11         | Cleaning and servicing                                     | 12       |
| 2  | Preventing material damage 4                 | 12         | Appliance door   | 14       |
| 3  | Environmental protection and saving energy 5 | 13         | Shelf supports   | 18       |
| 4  | Familiarising yourself with your appliance 5 | 14         | Troubleshooting  | 19       |
| 5  | Accessories9                                 | 15         | Disposal   | 21       |
| 6  | Before using for the first time 10           | 16         | Customer Service   | 21       |
| 7  | Basic operation 10                           | 17         | How it works   | 22       |
| 8  | Rapid heating 10                             |            |  |          |
| 9  | Time-setting options 11                      | 18<br>18.1 | INSTALLATION INSTRUCTIONSGeneral installation instructions | 26<br>26 |

# ▲ 1 Safety

Observe the following safety instructions.

#### 1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

#### 1.2 Intended use

This appliance is designed only to be built into kitchen units. Read the special installation instructions.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under the warranty.

Only use this appliance:

- To prepare meals and drinks.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level. Do not use the appliance:
- with an external timer or a remote control.

#### 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance. Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

#### 1.4 Safe use

Always place accessories in the cooking compartment the right way round.

→ "Accessories", Page 9

#### 

Combustible objects that are left in the cooking compartment may catch fire.

- ► Never store combustible objects in the cooking compartment.
- ▶ If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire.

▶ Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Opening the appliance door creates a draught. Greaseproof paper may come into contact with the heating element and catch fire.

- ► Never place greaseproof paper loosely over accessories when preheating the appliance and while cooking.
- Always cut greaseproof paper to size and use a plate or baking tin to hold it down.

#### ⚠ WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- ► Young children under 8 years of age must be kept away from the appliance.

Accessories and cookware get very hot.

► Always use oven gloves to remove accessories or cookware from the cooking compartment.

When the cooking compartment is hot, any alcoholic vapours inside may catch fire. The appliance door may spring open. Hot steam and jets of flame may escape.

- Only use small quantities of drinks with a high alcohol content in food.
- ▶ Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).
- ▶ Open the appliance door carefully.

#### ⚠ WARNING – Risk of scalding!

The accessible parts of the appliance become hot during operation.

- ► Never touch these hot parts.
- Keep children at a safe distance.

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- Open the appliance door carefully.
- Keep children at a safe distance.

If there is water in the cooking compartment when it is hot, this may create hot steam.

Never pour water into the cooking compartment when the cooking compartment is hot.

# 

Scratched glass in the appliance door may develop into a crack.

▶ Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

The appliance and its parts that can be touched may have sharp edges.

- ▶ Take care when handling and cleaning them.
- ▶ If possible, wear protective gloves.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- ► Keep your hands away from the hinges. Components inside the appliance door may have sharp edges.
- ▶ Wear protective gloves.

Alcoholic vapours may catch fire in the hot cooking compartment, and the appliance door may spring open and may fall off. The door panels may shatter and fragment.

- → "Preventing material damage", Page 4
- ► Only use small quantities of drinks with a high alcohol content in food.
- ▶ Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over
- ▶ Open the appliance door carefully.

# ⚠ WARNING – Risk of electric shock! Improper repairs are dangerous.

- ▶ Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.
- ▶ If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

If the insulation of the power cord is damaged, this is dangerous.

- ▶ Never let the power cord come into contact with hot appliance parts or heat sources.
- ▶ Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord. An ingress of moisture can cause an electric shock.
- ▶ Do not use steam- or high-pressure cleaners to clean the appliance.

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.

- ► If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer service. → Page 21 Once the appliance has been installed, the openings in the back panel of the appliance must not be accessible to children.
- ► Read the special installation instructions.

#### 

Children may put packaging material over their heads or wrap themselves up in it and suffocate

- Keep packaging material away from children.
- Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

► Keep small parts away from children.

▶ Do not let children play with small parts.

# 1.5 Halogen bulb

#### ⚠ WARNING – Risk of burns!

The bulbs in the cooking compartment get very hot. There is still a risk of burning for some time after they have been switched off.

- ▶ Do not touch the glass cover.
- ► Avoid contact with your skin when cleaning.

# 

When changing the bulb, the bulb socket contacts are live.

- ► Before replacing the bulb, ensure that the appliance is switched off in order to prevent a potential electric shock.
- ► Also unplug the appliance from the mains or switch off the fuse in the fuse box.

# 2 Preventing material damage

#### 2.1 General

#### **ATTENTION**

Alcoholic vapours may catch fire in the hot cooking compartment and cause permanent damage to the appliance. The appliance door may spring open due to an explosion and it may fall off. The door panels may shatter and fragment. Due to the resulting negative pressure, the cooking compartment may become considerably deformed inwards.

Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120 °C, this will damage the enamel.

- Do not use the appliance if there is water on the cooking compartment floor.
- Wipe away any water on the cooking compartment floor before operation.

Objects on the cooking compartment floor at over 50 °C will cause heat to build up. The baking and roasting times will no longer be correct and the enamel will be damaged.

- Do not place any accessories, greaseproof paper or foil of any kind on the cooking compartment floor.
- ► Only place cookware on the cooking compartment floor if a temperature under 50 °C has been set.

When the cooking compartment is hot, any water inside it will create steam. The change in temperature may cause damage.

- Never pour water into the cooking compartment when it is still hot.
- Never place cookware containing water on the cooking compartment floor.

The prolonged presence of moisture in the cooking compartment leads to corrosion.

Allow the cooking compartment to dry after use.

- ► Do not keep moist food in the cooking compartment for a long time with the door closed.
- Do not store food in the cooking compartment.
- ► Take care not to trap anything in the appliance door. Fruit juice dripping from the baking tray leaves stains that cannot be removed.
- When baking very juicy fruit flans, do not pack too much on the baking tray.
- ▶ If possible, use the deeper universal pan.

Using oven cleaner in a hot cooking compartment damages the enamel.

- Never use oven cleaner in the cooking compartment when it is still warm.
- ► Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

If the seal is very dirty, the appliance door will no longer close properly during operation. This may damage the front of adjacent kitchen units.

- ► Keep the seal clean at all times.
- Never operate the appliance if the seal is damaged or missing.

Sitting or placing objects on the appliance door may damage it.

- Do not place, hang or support objects on the appliance door.
- Do not place cookware or accessories on the appliance door.

With certain models, accessories may scratch the door pane when closing the appliance door.

Always push accessories fully into the cooking compartment.

If aluminium foil comes into contact with the door pane, it could cause permanent discolouration.

► Do not allow aluminium foil in the cooking compartment to come into contact with the door pane.

# 3 Environmental protection and saving energy

# 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

Sort the individual components by type and dispose of them separately.

### 3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Only preheat the appliance if the recipe or the recommended settings tell you to do so.

Not preheating the appliance can reduce the energy used by up to 20%.

Use dark-coloured, black-coated or enamelled baking

These types of baking tin absorb the heat particularly well.

Open the appliance door as little as possible during op-

▼ This maintains the temperature in the cooking compartment and eliminates the need for the appliance to

When baking multiple dishes, do so in succession or in parallel.

▼ The cooking compartment is heated after baking the first dish. This reduces the baking time for the subsequent cakes.

For longer cooking times, you can switch the appliance off 10 minutes before the cooking time ends.

▼ There is sufficient residual heat to finish cooking the dish.

Remove any accessories that are not being used from the cooking compartment.

✓ Accessories that are not being used do not need to be heated.

Allow frozen food to defrost before cooking.

▼ This saves the energy that would otherwise be required to defrost it.

**Note:** In accordance with the EU Ecodesign Directive 2023/826, this appliance is in a different state when switched off. This is referred to below as low power mode.

Even when the main function is not active, the appliance needs energy for:

- Detecting operation of the touch keys
- Monitoring door opening
- Editing the time (without display)

By definition, therefore, there is neither an "off" nor a "standby" mode, which is why the term low power mode is used. EN IEC 60350-1:2023 must be used to measure low power mode.

# 4 Familiarising yourself with your appliance

# 4.1 Difference between the top and bottom oven

The top oven and the bottom oven have different functions.


The symbol shows you which oven the information applies to.

| Main oven |
|-----------|
| Top oven  |

#### 4.2 Controls

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

Note: On certain models, specific details such as colour and shape may differ from those pictured.



#### Main oven ⊒

Controls for the main oven

# 🔣 Top oven 🖶

Controls for the top oven

#### **Buttons and display**

The buttons are touch-sensitive surfaces. To select a function, simply press lightly on the relevant field. The display shows symbols for active functions and the time-setting options.

→ "Buttons and display", Page 6

#### Function selector ■

Use the function selector to set the types of heating and other functions.

- You can turn the function selector clockwise or anti-clockwise from the zero setting o.

  Depending on the appliance, the function selector can be pushed in. Press on the function selector to click it into or out of the zero setting o.
  - → "Types of heating and functions", Page 7

#### Heating-up control

→ "Heating-up control", Page 8

#### Temperature selector

Use the temperature selector to set the temperature for the type of heating and select settings for other functions.

You can only turn the temperature selector clockwise from the zero setting o until it offers resistance. You cannot turn it any further than this. Depending on the appliance, the temperature selector can be pushed in. Press on the temperature selector to click it into or out of the zero setting o. → "Temperature and setting levels", Page 8

#### 4.3 Buttons and display

You can use the buttons to set various functions for your appliance. The display shows the settings.

#### Function selector

Use the function selector to set the types of heating and other functions.

You can turn the function selector clockwise or anti-clockwise from the zero setting o.

Depending on the appliance, the function selector can be pushed in. Press on the function selector to click it into or out of the zero setting o.

→ "Types of heating and functions", Page 7

# 👸 Heating-up control 🖶

→ "Heating-up control", Page 8

#### Temperature selector **=**

Use the temperature selector to set the temperature for the type of heating and select settings for other functions.

You can only turn the temperature selector clockwise from the zero setting o until it offers resistance. You cannot turn it any further than this. Depending on the appliance, the temperature selector can be pushed in. Press on the temperature selector to click it into or out of the zero setting o. → "Temperature and setting levels", Page 8

If a function is active, the corresponding symbol lights up on the display.

| Symbol    | Use   |
|-----------|---|
| (L)       | Sets the time, timer, cooking time or end time  → "Time-setting options", Page 11 |
| <         | Decreases the adjustment values   |
| $\rangle$ | Increases the adjustment values   |

| Symbol     | Use   |
|------------|---|
| <u>(L)</u> | Press and hold for approx. 3 seconds to activate or deactivate the childproof lock.  → "Childproof lock \\ \\ \\ \\ \''''', Page 12 |

# 4.4 Types of heating and functions

To ensure that you always find the right type of heating to cook your food, we explain the differences and applications below.

### 

| Symbol    | Type of heating     | What it's used for and how it works   |
|-----------|---------------------|---|
| J         | Circo Therm hot air | Bake or roast on one or more levels.  The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment.   |
| n<br>%    | Circo Therm gentle  | Cook selected dishes gently on one level without preheating. The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment. The food is cooked in phases using residual heat. Always keep the appliance door closed when cooking. If you open the appliance door even briefly, the appliance will continue to heat without utilising any residual heat. Select a temperature of between 120 °C and 230 °C. This type of heating is used to determine the energy consumption in air recirculation mode and the energy efficiency class. |
| ****      | Full-surface grill  | Grill flat items such as vegetables and sausages, or make toast. Gratinate food. The entire area below the grill element becomes hot.   |
| <u>~~</u> | Circo-roasting      | Roast poultry, whole fish or larger pieces of meat.  The grill element and the fan switch on and off alternately. The fan circulates the hot air around the food.   |
| =         | Top/bottom heating  | Traditionally bake or roast on one level. This type of heating is especially good for cakes with moist toppings.  The heat is emitted evenly from above and below.  This type of heating is used to measure the energy consumption in the conventional mode.  |

# Top oven **■**

| Symbol | Type of heating    | What it's used for and how it works   |  |
|--------|--------------------|---|--|
| ····   | Grill, small area  | Grill small quantities of vegetables, sausages or toast. Gratinate small quantities of food.  The central area below the grill element becomes hot. |  |
| ****   | Full-surface grill | Grill flat items such as vegetables and sausages, or make toast. Gratinate food. The entire area below the grill element becomes hot.               |  |
| = -    | Top/bottom heating |   |  |

### **Other functions**

This is where you can find an overview of other functions of your appliance.

### Main oven □

| Symbol   | Function      | Use   |  |
|----------|---------------|---|--|
| ₽ŝ       | Rapid heating | Rapidly preheat the cooking compartment without accessories.            |  |
| <u> </u> | Oven light    | Light up the cooking compartment without heating.  → "Lighting", Page 8 |  |

#### Top oven

| Symbol   | Function   | Use   |
|----------|------------|---|
| <u>ф</u> | Oven light | Light up the cooking compartment without heating.  → "Lighting", Page 8 |

# 4.5 Temperature and setting levels

There are different settings for the types of heating and functions.

Note: For temperature settings above 250 °C, the appliance reduces the temperature to approx. 240 °C after approx. 10 minutes. If your appliance has the top/bottom heating or bottom heating types, this temperature reduction does not take place there.

| Symbol   | Function          | Use   |  |
|----------|-------------------|---|--|
| 0        | Zero setting      | The appliance is not heating up.  |  |
| 50 - 275 | Temperature range | Set the temperature in the cooking compartment in °C.   |  |
| ***      | Grill, intensive  | The maximum temperature that can be set for <b>Full-surface grill</b> and <b>Grill</b> , <b>small area</b> (depending on the appliance type). |  |

#### **Heating-up control**

The heating-up indicator for the oven remains lit while the appliance is heating.

Note: Due to thermal inertia, the temperature displayed may differ slightly from the actual temperature inside the cooking compartment.

### Heating-up indicator ■

When the main oven 

heats up, the symbol 
 also lights up in the display. This symbol goes out when heating is paused.

#### 4.6 Cooking compartment

The functions in the cooking compartment make your appliance easier to use.

#### Rails

The shelf supports in the cooking compartment enable you to place accessories at different heights.


→ "Accessories", Page 9

The shelf positions are numbered from bottom to top. You can remove the shelf supports, e.g. for cleaning.

→ "Shelf supports", Page 18


#### Main cooking compartment □

The cooking compartment has four shelf positions.



#### Top cooking compartment

The cooking compartment has three shelf positions.



#### Lighting

The oven lamp lights up the cooking compartment. With most types of heating and functions, the lighting lights up during operation. The lighting goes off when operation ends.

The oven light setting A on the function selector can be used to switch on the light without heating.

The cooling fan also runs in the oven light A position.

### Cooling fan

The cooling fan switches on automatically during operation. The hot air escapes above the door.

#### **ATTENTION**

Covering the ventilation slots will cause the appliance to overheat.

Do not cover the ventilation slots.

To cool down the appliance and remove residual moisture from the cooking compartment, the cooling fan runs for a certain time after operation.

#### **Appliance door**

If you open the appliance door during operation, the operation continues.

# 5 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Accessories may become deformed if they get hot. Deformation has no effect on function. As the accessory cools down, it will regain its original shape.

The accessories supplied may differ depending on the appliance model.

| Accessories   | Use   |
|---------------|---|
| Wire rack     | <ul> <li>Cake tins</li> <li>Ovenproof dishes</li> <li>Tableware</li> <li>Meat, e.g. roasting joints or steak</li> <li>Frozen meals</li> </ul>   |
| Universal pan | <ul> <li>Moist cakes</li> <li>Baked items</li> <li>Bread</li> <li>Large roasts</li> <li>Frozen meals</li> <li>Catching dripping liquids, e.g. fat when grilling food on the wire rack.</li> </ul> |

# 5.1 Locking function

The locking function prevents the accessories from tilting when they are pulled out.


You can pull out the accessories approximately halfway without them tipping. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

# 5.2 Sliding accessories into the cooking compartment


Always slide the accessory into the cooking compartment the right way round. This is the only way to ensure that accessories can be pulled out approximately halfway without tipping.

- 1. Turn the accessories so that the notch a is at the rear and is facing downwards.
- 2. Insert the accessory between the two guide rods for a shelf position.

Pan support Insert the wire rack with the open side facing the appliance door and the curved lip - facing downwards.



Trav E.a. universal pan or baking tray Slide the tray in with the sloping edge **b** towards the appliance door.




3. Push the accessory all the way in, making sure that it does not touch the appliance door.

Note: Take any accessories that you will not be using out of the cooking compartment while the appliance is in operation.

#### **Combining accessories**

You can combine the wire rack with the universal pan to catch any liquid that drips down.

- **1.** Place the wire rack on the universal pan so that both spacers a are on the rear edge of the universal pan.
- 2. Insert the universal pan between the two guide rods for a shelf position. In so doing, the wire rack is on top of the upper guide rod.



#### 5.3 Other accessories

You can purchase other accessories from our customer service, specialist retailers or online.

You will find a comprehensive range of products for vour appliance in our brochures and online: www.neff-home.com

Accessories are appliance-specific. When purchasing accessories, always quote the exact product number (E no.) of your appliance.

You can find out which accessories are available for your appliance in our online shop or from our customer service.

# 6 Before using for the first time

Configure the settings for initial start-up. Clean the appliance and accessories.

#### 6.1 Initial use

You need to make settings for initial use before you can use your appliance.

#### Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

Requirement: The function selector must be set to the "Off" position o.

- **1.** Use the  $\langle$  or  $\rangle$  button to set the time.
- 2. Press the © button.
- The time that is set appears in the display.

# 6.2 Cleaning the appliance before using it for the first time

Before using the appliance to cook food for the first time, you must clean the cooking compartment and accessories.

- 1. Remove the product information and the accessories from the cooking compartment. Remove any leftover packaging, such as polystyrene pellets, and any adhesive tape that is in or on the appliance.
- 2. Wipe the smooth surfaces in the cooking compartment with a soft, damp cloth.
- **3.** Set the type of heating and the temperature. → "Basic operation", Page 10

|               | Main oven <b>⊒</b> | Top oven <b>=</b> |
|---------------|--------------------|-------------------|
| Heating func- | Circo Therm hot    | Top/bottom heat-  |
| tion          | air                | ing               |
| Temperature   | Maximum            | 240 °C            |
| Duration      | 1 hour             | 1 hour            |

- **4.** Ventilate the kitchen while the appliance is heating.
- 5. Switch off the appliance after the specified cooking
- 6. Once the appliance has cooled down, clean the smooth surfaces in the cooking compartment with a detergent solution and a dish cloth.
- 7. Clean the accessories with soapy water and a dish cloth or soft brush.

# 7 Basic operation

# 7.1 Switching on the appliance

- Turn the function selector to any position other than the "Off" position o.
- ▼ The appliance is switched on.

# 7.2 Setting the type of heating and temperature

- 1. Use the function selector to set the type of heating.
- **2.** Use the temperature selector to set the temperature or grill setting.
- ▼ The appliance starts heating after a few seconds.
- **3.** When your food is ready, switch off the appliance.

- The most suitable type of heating for your food can be found in the description of the type of heating.
  - → "Types of heating and functions", Page 7

- You can also set a cooking time and end time on the appliance.
  - → "Time-setting options", Page 11

## Changing the type of heating

You can change the type of heating at any time.

► Use the function selector to set the required type of heating.

# Changing the temperature

You can change the temperature at any time.

► Use the temperature selector to set the required temperature.

# 7.3 Switching off the appliance

- Turn the function selector to the "Off" position o.
- The appliance is switched off.

# 8 Rapid heating

To save time, you can use rapid heating to shorten the preheat time.

# 8.1 Setting rapid heating

To ensure an even cooking result, do not place the food in the cooking compartment until rapid heating has come to an end.

- 1. Use the function selector to select rapid heating &\hat{\omega}.
- 2. Use the temperature selector to set the required temperature.
  - Only use rapid heating when a temperature of over 100 °C has been set.
- Rapid heating starts after a few seconds.
- ✓ When the rapid heating process ends, an audible signal sounds and the heating indicator goes out.
- 3. After rapid heating, it is best to use heating type Circo Therm hot air &.
- **4.** Place the food in the cooking compartment.

# 9 Time-setting options

Your appliance has different time-setting options, with which you can control its operation.

# 9.1 Overview of the time-setting options

Use the © button to select the different time-setting op-

| Time-setting option | Use   |
|---------------------|---|
| Timer △             | You can set the timer to run independently of the operation. It does not affect the appliance.  |
| Cooking time I→I    | If you set a cooking time, the appliance stops heating automatically once this time has elapsed.  |
| End →I<br>⊒         | For the cooking time, you can set the time at which you want the operation to end. The appliance starts up automatically so that the operation finishes at the required time. |
| Clock               | You can set the time.   |

#### 9.2 Setting the timer

The timer runs independently during the operation. You can set the timer to times of up to 23 hours and 59 minutes, regardless of whether the appliance is on or off. The timer has its own signal so that you can tell whether it is the timer or a cooking time that has elapsed.

- **1.** Press the  $\odot$  button repeatedly until  $\triangle$  is highlighted on the display.
- **2.** Use the 〈 or 〉 button to set the timer duration.

| Button | Default value |
|--------|---------------|
| <      | 5 minutes     |
| >      | 10 minutes    |

The timer duration can be set in 30-second increments up to 10 minutes. The time increments then become bigger as the value increases.

- ▼ The timer starts and the timer duration begins to count down after a few seconds.
- An audible signal sounds and the timer duration is zero in the display when the timer duration has
- 3. Once the timer duration has elapsed:
  - Press any button to switch off the timer.

#### Changing the timer

You can change the timer duration at any time.

**Requirement:** △ is highlighted on the display.

- ▶ Use the ⟨or⟩ button to change the timer duration.
- ▼ The appliance applies the change after a few seconds.

# Cancelling the timer

You can cancel the timer duration at any time.

**Requirement:** △ is highlighted on the display.

- ► Use the \( \text{button to reset the timer duration to zero.} \)
- ✓ After a few seconds, the appliance applies the change and △ goes out.

# 9.3 Setting the cooking time

You can set the cooking time for operation of up to 23 hours 59 minutes.

**Requirement:** The type of heating and a temperature or setting have been set.

- 1. Press the <sup>⊕</sup> button repeatedly until I→I is highlighted on the display.
- 2. Use the ( or ) button to set the time.

| Button | Default value |  |
|--------|---------------|--|
| <      | 10 minutes    |  |
| >      | 30 minutes    |  |

The cooking time can be set in one-minute increments up to one hour, and then in five-minute increments.

- ✓ After a few seconds, the appliance starts heating and the cooking time counts down.
- ✓ When the cooking time has elapsed, a signal sounds and the duration is at zero on the display.
- 3. Once the cooking time has elapsed:
  - Press any button to end the signal prematurely.
  - ► To set another cooking time, press the > button.
  - ▶ When your food is ready, switch off the appliance.

### Changing the cooking time

You can change the cooking time at any time.

**Requirement:** I→I is highlighted in the display.

- ► Change the cooking time using the 〈 or 〉 button.
- ▼ The appliance applies the change after a few seconds.

#### Cancelling the cooking time

You can cancel the cooking time at any time.

**Requirement:** I→I is highlighted in the display.

- ► Reset the cooking time to zero using the 〈 button.
- ✓ After a few seconds, the appliance applies the change and continues to heat without a cooking time.

# 9.4 Setting the end time

You can delay the time at which cooking is due to finish by up to 23 hours and 59 minutes.

#### **Notes**

- The end time cannot be set for types of heating with grill function.
- In order to achieve good cooking results, do not delay the end time once the appliance is operating.
- Food will spoil if you leave it in the cooking compartment for too long.

#### Requirements

- The type of heating and a temperature or setting have been set.
- A cooking time is set.
- 1. Press the ⊕ button repeatedly until → I is highlighted on the display.

- **2.** Press the 〈 or 〉 button.
- ▼ The display shows the calculated end time.
- **3.** Use the 〈 or 〉 button to delay the end time.
- After a few seconds, the appliance applies the setting and the display shows the set end time.
- Once the calculated start time is reached, the appliance starts heating up and the cooking time counts down.
- ✓ When the cooking time has elapsed, a signal sounds and the duration is at zero on the display.
- **4.** Once the cooking time has elapsed:
  - ▶ Press any button to end the signal prematurely.
  - ► To set another cooking time, press the > button.
  - ► When your food is ready, switch off the appliance.

# Changing the end time

In order to achieve a good cooking result, you can only change the set end time before operation starts and the cooking time starts counting down.

**Requirement:** → I is highlighted in the display.

- ▶ Use the ⟨or⟩ button to delay the end time.
- The appliance applies the change after a few seconds.

# Cancelling the end time

You can delete the set end time at any time.

**Requirement:** →I is highlighted in the display.

- ► Reset the end time to the current time plus the set cooking time using the < button.
- After a few seconds, the appliance applies the change and starts heating up. The cooking time counts down.

# 9.5 Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

**Requirement:** The function selector must be set to the "Off" position o.

- **1.** Use the 〈 or 〉 button to set the time.
- 2. Press the © button.
- ▼ The time that is set appears in the display.

# Changing the time on the clock

You can change the time on the clock at any time.

**Requirement:** The function selector must be set to the "Off" position o.

- **1.** Press and hold the © button until the clock flashes on the display.
- 2. Use the ( or ) button to change the time.
- The appliance applies the change after a few seconds.

# 10 Childproof lock ■

You can secure your appliance to prevent children from accidentally switching it on or changing the settings.

**Note:** After a power cut, the childproof lock is deactivated.

You can use the childproof lock to lock the control elements of the appliance only.

# 10.1 Activating and deactivating the childproof lock

**Requirement:** The function selector must be set to the zero setting o.

- **1.** To activate the childproof lock, press and hold the © button until *SRFE* appears in the display.
- 2. To deactivate the childproof lock, press and hold the 

   button until *SRFE* goes out in the display.

# 11 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

# 11.1 Cleaning products

In order to avoid damaging the various oven surfaces on the appliance, do not use unsuitable cleaning products.

#### ⚠ WARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners to clean the appliance.

#### **ATTENTION**

Unsuitable cleaning products may damage the surfaces of the appliance.

► Do not use harsh or abrasive cleaning products.

- Do not use cleaning products with a high alcohol content.
- ► Do not use hard scouring pads or cleaning sponges.
- ► Do not use any special cleaners for cleaning the appliance while it is hot.

Using oven cleaner in a hot cooking compartment damages the enamel.

- Never use oven cleaner in the cooking compartment when it is still warm.
- Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

New sponge cloths contain residues from production.

Wash new sponge cloths thoroughly before use.

# 11.2 Suitable cleaning agents

Only use cleaning agents that are suitable for the different surfaces on your appliance. Follow the instructions on cleaning the appliance.

#### **Appliance front**

| Surface  | Suitable cleaning agents   | Information   |
|--|--|---|
| Stainless steel                                | <ul> <li>Hot soapy water</li> <li>Special stainless steel cleaning products suitable for hot surfaces</li> </ul> | To prevent corrosion, remove any patches of limescale, grease, starch or albumin (e.g. egg white) from stainless steel surfaces immediately.  Apply a thin layer of the stainless steel cleaning product. |
| Plastic or painted surfaces E.g. control panel | <ul><li>Hot soapy water</li></ul>  | Do not use glass cleaner or a glass scraper.  |

#### **Appliance door**

| Range       | Suitable cleaning agents   | Information  |
|-------------|--|--|
| Door panels | <ul><li>Hot soapy water</li><li>Steel wool</li></ul>   | Do not use a glass scraper. <b>Tip:</b> Remove the door panels in order to clean them thoroughly.  → "Appliance door", Page 14     |
| Door cover  | <ul> <li>Made of stainless<br/>steel:<br/>Stainless steel cleaner</li> <li>Made of plastic:<br/>Hot soapy water</li> </ul> | Do not use glass cleaner or a glass scraper. <b>Tip:</b> Remove the door cover for thorough cleaning.  → "Appliance door", Page 14 |
| Door handle | <ul> <li>Hot soapy water</li> </ul>  | To avoid permanent stains, remove descaling agents from the door handle immediately.   |
| Door seal   | <ul><li>Hot soapy water</li></ul>  | Do not remove or scrub.  |

### **Cooking compartment**

| Range                          | Suitable cleaning agents   | Information   |
|--------------------------------|--|---|
| Enamel surfaces                | <ul><li>Hot soapy water</li><li>Vinegar solution</li><li>Oven cleaner</li><li>Steel wool</li></ul> | Soak any heavily soiled areas and use a brush or steel wool. Leave the appliance door open to dry the cooking compartment after cleaning it.  |
|                                | - Steel Wool   | <ul> <li>Notes</li> <li>Enamel burns at very high temperatures, causing minor discolouration. The functionality of your appliance is not affected by this.</li> <li>The edges of thin trays cannot be completely enamelled and may be rough. This does not impair the corrosion protection.</li> <li>Food residues leave a white coating on the enamel surfaces. The coating does not pose a health risk. The functionality of your appliance is not affected by this. You can remove residues with lemon juice.</li> </ul> |
| Glass cover for the oven light | <ul> <li>Hot soapy water</li> </ul>  | Use oven cleaner to remove very heavy soiling.  |
| Shelf supports                 | <ul> <li>Hot soapy water</li> </ul>  | Soak any heavily soiled areas and use a brush or steel wool.  |
|                                | <ul><li>Steel wool</li></ul>   | <b>Tip:</b> Remove the shelf supports for cleaning.  → "Shelf supports", Page 18  |
| Accessories                    | <ul><li>Hot soapy water</li><li>Oven cleaner</li><li>Steel wool</li></ul>                          | Soak any heavily soiled areas and use a brush or steel wool. Enamelled accessories are dishwasher-safe.   |

# 11.3 Cleaning the appliance

In order to avoid damaging the appliance, you must clean your appliance only as specified, and with suitable cleaning products.

# **⚠** WARNING – Risk of burns!

The appliance becomes hot during operation.

► Allow the appliance to cool down before cleaning.

#### ⚠ WARNING – Risk of fire!

Loose food remnants, fat and meat juices may catch fire.

► Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

**Requirement:** Read the information on cleaning agents.

- → "Cleaning products", Page 12
- Clean the appliance using hot soapy water and a dish cloth.
  - ► For some surfaces, you can use alternative cleaning agents.
    - → "Suitable cleaning agents", Page 13
- 2. Dry with a soft cloth.

# 12 Appliance door

To clean the appliance door thoroughly, you can disassemble the appliance door.

#### 12.1 Main oven

#### Detaching the appliance door

# **⚠** WARNING – Risk of injury!

Components inside the appliance door may have sharp edges.

► Wear protective gloves.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- ► Keep your hands away from the hinges.
- 1. Open the appliance door fully.


# 2. MARNING – Risk of injury!

When the hinges are not secured, they can snap shut with great force.

Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open.


Open the locking levers on the left- and right-hand hinges.

Locking levers opened



The hinge is now secured and cannot snap shut.


Locking levers closed



The appliance door is secured and cannot be detached.

▼ The locking levers are open. The hinges are now secured and cannot snap shut.

3. Close the appliance door fully ①. Grab hold of the appliance door with both hands (on the left and right) and pull it upwards and out ②.



4. Carefully place the appliance door on a level surface.

# Attaching the appliance door


#### 

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

► Keep your hands away from the hinges.

When the hinges are not secured, they can snap shut with great force.

- Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open.
- 1. Slide the appliance door straight onto the two hinges ①. Slide the appliance door on as far as it will go.
- **2.** Open the appliance door fully.
- **3.** Close the locking levers on the left- and right-hand hinges ②.



- The locking levers are closed. The appliance door is secured and cannot be detached.
- **4.** Close the appliance door.

#### Removing the door panes

### 


The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

► Keep your hands away from the hinges.


Components inside the appliance door may have sharp edges.


- Wear protective gloves.
- 1. Open the appliance door fully.
- 2. Open the locking levers on the left- and right-hand hinges 1.
- ▼ The locking levers are open. The hinges are now secured and cannot snap shut.
- 3. Close the appliance door fully 2.






- 4. Push on the left- and right-hand side of the door cover from the outside 10 until it is released.
- 5. Remove the door cover 2.






6. Lift out the inner pane and set it down carefully on a flat surface.



- 7. If necessary, you can remove the condensate trough for cleaning.
  - Open the appliance door.

▶ Tilt the condensate trough upwards and remove it.



# 8. MARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

► Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

Clean the removed door panels on both sides with glass cleaner and a soft cloth.


- 9. Clean the condensate trough with a cloth and hot soapy water.
- **10.**Clean the appliance door.
  - → "Suitable cleaning agents", Page 13
- 11. Dry the door panels and refit them.
  - → "Fitting the door panes", Page 15

# Fitting the door panes


#### ⚠ WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


- ► Keep your hands away from the hinges. Components inside the appliance door may have sharp edges.
- Wear protective gloves.
- 1. Open the appliance door fully.
- 2. Place the condensate trough vertically into the retainer a and turn it downwards.




3. Slide the inner pane into the left- and right-hand retainers a.



**4.** Push the inner pane upwards until it is in the left- and right-hand retainers **a**.



- **5.** Put the door cover into position ① and push down on it until you hear it click into place.
- 6. Open the appliance door fully.
- 7. Close the locking levers on the left- and right-hand hinges ②.



- The locking levers are closed. The appliance door is secured and cannot be detached.
- 8. Close the appliance door.

**Note:** Do not use the cooking compartment again until the door panes have been correctly fitted.

# **12.2 Top oven ■**

#### Detaching the appliance door

#### **⚠** WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- ► Keep your hands away from the hinges.
- 1. Open the appliance door fully.


# 2. MARNING - Risk of injury!

When the hinges are not secured, they can snap shut with great force.

Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open.


Open the locking levers on the left- and right-hand hinges.

Locking levers opened




The hinge is now secured and cannot snap shut.

Locking levers closed



The appliance door is secured and cannot be detached.

- The locking levers are open. The hinges are now secured and cannot snap shut.
- **3.** Close the appliance door fully ①. Grab hold of the appliance door with both hands (on the left and right) and pull it upwards and out ②.



**4.** Carefully place the appliance door on a level surface.

### Attaching the appliance door


#### **⚠** WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


► Keep your hands away from the hinges.

When the hinges are not secured, they can snap shut with great force.

Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open. 1. Slide the appliance door straight onto the two hinges. Slide the appliance door on as far as it will go.



- 2. Open the appliance door fully.
- 3. Close the locking levers on the left- and right-hand hinges.



- The locking levers are closed. The appliance door is secured and cannot be detached.
- **4.** Close the appliance door.


# Removing the door panes

#### 


The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- Keep your hands away from the hinges.
- Components inside the appliance door may have sharp edges.
- Wear protective gloves.
- 1. Open the appliance door fully.
- 2. Open the locking levers on the left- and right-hand hinges 1.
- The locking levers are open. The hinges are now secured and cannot snap shut.


3. Close the appliance door fully 2. Grab hold of the appliance door with both hands (on the left and right) and pull it upwards and out 3.



- 4. Carefully place the appliance door on a level surface.
- 5. Push on the left- and right-hand side of the door cover from the outside 1 until it is released.
- 6. Remove the door cover 2.



7. Lift out the inner pane and set it down carefully on a flat surface.



#### 8. MARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

► Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

Clean the removed door panels on both sides with glass cleaner and a soft cloth.


- 9. Clean the appliance door.
  - → "Suitable cleaning agents", Page 13
- 10. Dry the door panels and refit them.
  - → "Fitting the door panes", Page 18

#### Fitting the door panes


# 

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


- ► Keep your hands away from the hinges.
- Components inside the appliance door may have sharp edges.
- Wear protective gloves.
- 1. Slide in the intermediate pane. When doing so, ensure that the number on the intermediate pane is at the bottom right 1.
- 2. Slide the intermediate pane until it is in the left- and right-hand retainers @ 2.
- 3. Push the intermediate pane upwards until it is in the retainer a.
- 4. Slide the inner pane in. In doing so, ensure that the inner pane is in the retainer a.




5. Push the inner pane upwards until it is in the left- and right-hand retainers a.




6. Put the door cover in position and push down on it until you hear it click into place.



7. Slide the appliance door straight onto the two hinges. Slide the appliance door on as far as it will go. When doing so, ensure that the hinges are inserted into the correct opening.



8. Close the locking levers on the left- and right-hand hinges.



- The locking levers are closed. The appliance door is secured and cannot be detached.
- 9. Close the appliance door.

Note: Do not use the cooking compartment again until the door panes have been correctly fitted.

# 13 Shelf supports

To clean the rails and the cooking compartment, or to replace the rails, you can remove these.

# 13.1 Main oven


#### **Detaching the shelf supports**

WARNING – Risk of burns!

The shelf supports get very hot

▶ Never touch the shelf supports when hot.

- ► Always allow the appliance to cool down.
- ► Keep children at a safe distance.
- 1. Lift the rail forwards slightly 1 and detach it 2.
- 2. Pull the whole rail to the front 3 and remove it.





- 3. Clean the rail.
  - → "Cleaning products", Page 12

# Attaching the shelf supports

#### **Notes**

- The rails only fit on the right or left.
- For both rails, ensure that the curved rods are at the front.
- 1. First, push the rail into the middle of the rear socket ① until the rail rests against the cooking compartment wall, and then push this back 2.
- 2. Push the rail into the front socket 3 until the rail also rests against the cooking compartment wall, and then press this downwards 4.






### 13.2 Top oven

# **Detaching the shelf supports**

#### ⚠ WARNING – Risk of burns!

The shelf supports get very hot

- ▶ Never touch the shelf supports when hot.
- Always allow the appliance to cool down.
- Keep children at a safe distance.
- 1. Lift the rail forwards slightly ① and detach it ②.
- 2. Pull the whole rail to the front 3 and remove it.







- 3. Clean the rail.
  - → "Cleaning products", Page 12

## Attaching the shelf supports **Notes**

- The rails only fit on the right or left.
- For both shelf supports, ensure that the hooks that are attached at the rear are pointing upwards.
- 1. First, push the rail into the middle of the rear socket ① until the rail rests against the cooking compartment wall, and then push this back 2.
- 2. Push the rail into the front socket 3 until the rail also rests against the cooking compartment wall, and then press this downwards 4.





# 14 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting aftersales service. This will avoid unnecessary costs.

# ⚠ WARNING – Risk of injury!

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- If the appliance is defective, call Customer Service.
  - → "Customer Service", Page 21

# 

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.
- ► If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

#### 14.1 Malfunctions

| Fault   | Cause and troubleshooting  |
|---|--|
| The appliance is not working.   | The circuit breaker in the fuse box has tripped.  • Check the circuit breaker in the fuse box.   |
|   | There has been a power cut.  ▶ Check whether the lighting in your room or other appliances are working.  |
| The appliance does not switch off fully at the end of a cooking time.         | At the end of a cooking time, the appliance stops heating up. The oven light and cooling fan do not switch off. For types of heating with recirculation, the fan continues to run in the back wall of the cooking compartment.  Turn the function selector to the off position.  The appliance is switched off.  The oven light and the fan in the back wall are switched off.  The cooling fan switches off automatically as soon as the appliance has cooled down. |
| The time flashes in the display.  | There has been a power cut.  Reset the time.   |
| 5 RF E lights up in the display and no settings can be made on the appliance. | Childproof lock is activated.  ► Deactivate the child safety lock.  → "Activating and deactivating the childproof lock", Page 12   |
| A message with E appears in the display, e.g. E05-32.                         | <ul> <li>Electronics fault</li> <li>1. Press the <sup>⑤</sup> button.</li> <li>If required, reset the time.</li> <li>✓ If the fault was a one-off, the error message disappears.</li> <li>2. If the error message appears again, call the after-sales service. Quote the exact error message and the E no. of your appliance.</li> <li>→ "Customer Service", Page 21</li> </ul>  |
| The cooking result is not satisfactory.                                       | Settings were unsuitable.  Adjustment values, e.g. temperature or cooking time, depend on the recipe, quantity and food.  Next time, set lower or higher values.   |

# 14.2 Replacing the oven light bulb

If the light in the cooking compartment fails, change the oven light bulb.

**Note:** Heat-resistant, 40 - 43-watt, 230 V halogen bulbs are available from the after-sales service or specialist retailers. Only use these bulbs. Hold the new halogen bulbs only with a clean, dry towel. This increases the service life of the bulb.

#### 

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- ► Young children under 8 years of age must be kept away from the appliance.

#### 

When changing the bulb, the bulb socket contacts are live.

- ► Before replacing the bulb, ensure that the appliance is switched off in order to prevent a potential electric shock.
- ► Also unplug the appliance from the mains or switch off the fuse in the fuse box.

#### **⚠** WARNING – Risk of injury!

The glass cover may already have broken due to external influences or it may break due to excessive pressure when being installed or removed.


- ► Exercise caution when installing or removing the glass cover.
- ▶ Use gloves or a tea towel.

#### Requirements

- The appliance is disconnected from the power sup-
- The cooking compartment has cooled down.
- You must have a new halogen lamp to replace the old one.
- 1. Place a tea towel in the cooking compartment to prevent damage.
- 2. Turn the glass cover anti-clockwise to remove it ①.

3. Pull out the halogen bulb without turning it ②.





- 4. Insert the new halogen bulb and press it firmly into the socket.
  - Make sure that the pins are positioned correctly.
- 5. Depending on the appliance model, the glass cover may have a sealing ring. Attach the sealing ring.
- **6.** Screw in the glass cover.
- 7. Remove the tea towel from the cooking compartment.
- 8. Connect the appliance to the power supply.

# 15 Disposal

# 15.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

# 16 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

**Note:** Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.


If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website. This product contains light sources from energy efficiency class G.

You can find the information required as per Regulations (EU) 65/2014, (EU) 66/2014 and (EU) 2023/826 online at www.neff-home.com on the product and service pages for your appliance, in the area of user manuals and additional documents.

# 16.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. You will see the rating plate with these numbers if you open the appliance door.



Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

# 17 How it works

Here, you can find the ideal settings for various types of food as well as the best accessories and cookware. We have perfectly tailored these recommendations to your appliance.

# 17.1 Cooking tips

Observe this information when preparing food.

- The temperature and cooking time depend on the amount of food and the recipe. Settings ranges are specified for this reason. Try using the lower values to start with.
- The setting values apply to food placed in the cooking compartment while the cooking compartment is still cold. Do not slide the accessory into the cooking compartment until it has finished preheating.
- Remove any accessories that are not being used from the cooking compartment.

# 17.2 Notes on baking

When baking, use the shelf positions indicated.

| Baking on one level                        | Height |
|--|--------|
| Deep baked goods or tin on wire rack       | 2      |
| Flat baked goods or goods in a baking tray | 3      |

| Baking on two levels                 | Height |
|--------------------------------------|--------|
| Universal pan                        | 3      |
| Baking tray                          | 1      |
| Baking tins/dishes on the wire rack: | Height |
| First wire rack                      | 3      |
| Second wire rack                     | 1      |

#### **Notes**

- When baking on several layers, always use hot air. Baked goods that are placed in the oven at the same time will not necessarily be ready at the same time.
- Position baking tins/dishes either next to one another or offset on different shelves so that they are not directly one above the other in the cooking compartment.
- For best results, we recommend using dark-coloured metal bakeware.

# 17.3 Notes on roasting and grilling

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry, meat or fish is placed into a cold cooking compartment.

#### **ATTENTION**

Acidic food may damage the wire rack

- ▶ Do not place acidic food, such as fruit or food with an acidic marinade directly on the wire rack.
- The larger the poultry, meat or fish, the lower the cooking temperature and the longer the cooking time.
- Turn the poultry, meat or fish after approx. 1/2 to 2/3 of the time listed.

- Add a little liquid to the poultry in the cookware. Cover the bottom of the cookware with approx. 1-2 cm of liquid.
- When you turn poultry, ensure that the breast side or skin side is underneath to begin with.
- Cooking time calculation (e.g. 20 + 35): To calculate the cooking time, assume 20 minutes per 500 g of meat plus an extra 35 minutes. For 1.5 kg, the cooking time is then 95 minutes.
- Cooking time range (e.g. 10-15): Your food will be ready within the specified range of time.

## Information for those allergic to nickel

In rare cases, small amounts of nickel may pass into the food.

#### Roasting and grilling on the wire rack

Roasting on the wire rack works particularly well for large poultry or for multiple pieces at the same time.

- Depending on the size and type of the food to be roasted, add up to 1/2 litre water to the universal pan. You can make a sauce from the juices that are collected. This also means that less smoke is produced and the cooking compartment does not become as dirtv.
- Keep the appliance door closed when using the grill. Never grill with the appliance door open.
- Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. This means that any dripping fat is caught.

#### Roasting in cookware

When preparing food in cookware with a lid, the cooking compartment remains cleaner.

Follow the manufacturer's instructions for your roasting dishes. Glass cookware is best.

#### Cookware without lid

- Use a deep roasting dish.
- Place the cookware onto the wire rack.
- If you do not have any suitable cookware, use the universal pan.

#### Cookware with lid

- Place the cookware onto the wire rack.
- Meat, poultry and fish can also become crispy in a covered roasting dish. Use a roasting dish with a glass lid. Set a higher temperature.

#### ⚠ WARNING – Risk of injury!

If hot glass cookware is placed on a wet or cold surface, the glass may shatter.

Place hot glass ovenware on a dry mat after cooking.

# 

Very hot steam may escape when the lid is opened after cooking. Steam may not be visible, depending on the temperature.

- ► Lift the lid in such a way that the hot steam can escape away from you.
- Keep children away from the appliance.

# Selection for the main oven

| Food                                    | Accessories/cookware                              | Shelf position |                | Temperature in °C/grill setting                | Cooking<br>time in mins                              |
|---|---|----------------|----------------|--|--|
| Victoria sponge cake                    | 2 pcs<br>Ø 20 cm cake tin                         | 2              | ک              | 150-170 <sup>1</sup>                           | 15-25  |
| Rich fruit cake                         | Deep 23 cm diameter tin                           | 2              | n<br>60        | 140-150  | 180-210  |
| Fruit pie                               | 20 cm diameter plate or pie tin                   | 2              | L              | 170-190  | 60-75  |
| Quiche                                  | Quiche tin (dark-coated)                          | 3              | °0             | 180-200  | 40-55  |
| (White) bread                           | Loaf tin (1 x 900 g or 2 x 450 g)                 | 2              | =              | 190-210 <sup>1</sup>                           | 25-40  |
| Scones                                  | Baking sheet on wire rack                         | 3              | =              | 190-200²                                       | 10-15  |
| Biscuits                                | Baking sheet on wire rack                         | 3              | L              | 140-160 <sup>1</sup>                           | 10-20  |
| Small cakes                             | 12-cup tin  | 3              | =              | 150 <sup>3</sup>                               | 25-35  |
| Pavlova                                 | Baking sheet on wire rack                         | 3              | ک              | 90-1004  | 160-180  |
| Yorkshire pudding                       | 12-cup tin  | 3              | J              | 200-220 5                                      | 18-25  |
| Pizza, home-made                        | Baking tray                                       | 3              | L              | 190-210  | 20-30  |
| Pizza, home-made, thin base             | Round pizza tray                                  | 2              | J              | 220-240 <sup>1</sup>                           | 15-20  |
| Victoria sponge cake, 2 levels          | 4 pcs<br>Ø 20 cm cake tin                         | 3+1            | ٤              | 150-160 <sup>2</sup>                           | 20-30  |
| Biscuits, 2 or 3 levels                 | Baking sheet on wire rack                         | 3+1<br>4+3+1   | L              | 140-160 <sup>2</sup>                           | 15-25  |
| Beef, top side/top rump                 | Cookware without lid                              | 2              | J              | 170  | 40+30  |
| Lamb leg (on the bone)                  | Cookware without lid                              | 2              | J              | 160-170  | 25+15  |
| Pork belly                              | Cookware without lid                              | 2              | 1. =<br>2. *** | <b>1.</b> 170-180 <b>2.</b> 250                | <b>1.</b> 30+30 <sup>6</sup> <b>2.</b> 3-5           |
| Chicken, whole                          | Wire rack   | 2              | J              | 170-180  | 25+15 <sup>7</sup>                                   |
| Turkey, crown                           | Wire rack   | 2              | J              | 140-150  | 20+25  |
| Turkey, whole, 4-8 kg                   | Wire rack   | 1              | S              | 150-160  | 12+12 <sup>8</sup>                                   |
| Fish, braised, whole 300 g, e. g. trout | Cookware with lid                                 | 2              | °°             | 170-190  | 25-35  |
| Diced meat (beef, pork, lamb), 500 g    | Cookware with lid                                 | 2              | 00             | 140  | 120-140  |
| Complete meal with chicken              | Wire rack<br>+<br>Wire rack<br>+<br>Universal pan | 4+1            | \$             | 180, then<br>200 (York-<br>shire pud-<br>ding) | Chicken:<br>(25+25) + 20<br>for Yorkshire<br>pudding |
| Bacon rashers                           | Wire rack   | 3              | ****           | 9  | 1 side 4-5<br>2 side 3-4                             |

<sup>&</sup>lt;sup>1</sup> Preheat the appliance. Do not use the rapid heating function.

Preheat the appliance.
 Preheat the appliance for five minutes. Do not use the rapid heating function.
 Preheat the appliance to 150 °C using HotAir.
 Preheat the appliance for 20 minutes.

<sup>&</sup>lt;sup>6</sup> Do not turn the food.

<sup>&</sup>lt;sup>7</sup> Slide the universal pan underneath the wire rack.

<sup>&</sup>lt;sup>8</sup> Turn the food after approx. one hour.

<sup>&</sup>lt;sup>9</sup> Preheat the appliance for 5 minutes.

| Food                       | Accessories/cookware | Shelf po-<br>sition |      | Temperature in °C/grill setting | Cooking<br>time in mins |
|----------------------------|----------------------|---------------------|------|---------------------------------|-------------------------|
| Sausages, thickness 2-4 cm | Wire rack            | 3                   | **** | ···· 1                          | 10-15 <sup>2</sup>      |
| Pork, gammon joint         | Cookware without lid | 2                   | Ĩ    | 170-180                         | 25+20 <sup>3</sup>      |
| Chicken, whole             | Cookware without lid | 2                   | ž    | 170-180                         | 20+20 4                 |

#### 17.5 Food selection

#### Selection for the top oven

| Food                            | Accessories/cook-<br>ware | Shelf po-<br>sition | Type of heating | Temperature in °C    | Cooking time in mins       |
|---------------------------------|---------------------------|---------------------|-----------------|----------------------|----------------------------|
| Scones                          | Baking sheet              | 1                   | Ξ               | 200-2105             | 10-12                      |
| Small cakes                     | 12-cup-tin                | 1                   | =               | 150-160 <sup>5</sup> | 25-35                      |
| Lamb chops, height 2-3 cm       | Wire rack                 | 3                   | ****            | Grill <sup>5</sup>   | 1. side 7-9<br>2. side 5-8 |
| Pork sausages, thickness 2-4 cm | Wire rack                 | 3                   | ****            | Grill                | 14-18                      |

# 17.6 Yoghurt

You can use your appliance to make your own yoghurt.

# **Preparing yoghurt**

- **1.** Remove the accessories and shelf supports from the cooking compartment.
- 2. Pour the previously prepared yoghurt mixture into small containers, e.g. into cups or small jars.
- 3. Cover the containers with foil, e. g. with cling film.
- **4.** Place the containers on the cooking compartment floor.
- **5.** Set the appliance according to the recommended setting.
- **6.** After making the yoghurt, leave it to cool in the refrigerator.

# **Recommended settings for yoghurt**

#### Selection for the main oven

| Food    | Accessories/cook-<br>ware | Shelf position            | Type of heating | Temperature in °C                      | Cooking<br>time in<br>mins    |
|---------|---------------------------|---------------------------|-----------------|--|-------------------------------|
| Yoghurt | Individual moulds         | Cooking compartment floor | 1. ***<br>2. �  | <b>1.</b> 100 <sup>6</sup> <b>2.</b> - | <b>1.</b> - <b>2.</b> 8–9 hrs |

#### 17.7 Test dishes

These overviews have been produced for test institutes to facilitate appliance testing in accordance with EN 60350-1.

#### Baking

Please take note of the following information if you are baking test dishes.

#### **General information**

- The setting values apply to food that is placed into a cold cooking compartment.
- Observe the notes about preheating in the tables.
   These setting values apply without rapid heat-up.

When baking, use the lower of the listed temperatures to begin with.

#### **Shelf positions**

Shelf positions for baking on two levels:

**Note:** Items that are placed in the oven on baking trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

- Universal pan: Shelf position 3 Baking tray: Shelf position 1
- Baking tins/dishes on the wire rack First wire rack: Shelf position 3 Second wire rack: Shelf position 1

Hot water sponge cake:

When baking on 2 levels, place the springform tins each in the centre of the wire racks.

<sup>&</sup>lt;sup>1</sup> Preheat the appliance for 3 minutes.

<sup>&</sup>lt;sup>2</sup> Turn the food occasionally.

<sup>&</sup>lt;sup>3</sup> Do not turn the food.

<sup>&</sup>lt;sup>4</sup> Slide the universal pan underneath the wire rack.

<sup>&</sup>lt;sup>5</sup> Preheat the appliance.

<sup>&</sup>lt;sup>6</sup> Preheat the appliance for 15 minutes.

# Recommended settings for baking

| Food                          | Accessories/cookware                     | Shelf position | Type of heating | Temperature in °C    | Cooking<br>time in<br>mins |
|-------------------------------|--|----------------|-----------------|----------------------|----------------------------|
| Shortbread                    | Baking tray                              | 3              | =               | 140-150 <sup>1</sup> | 25-35                      |
| Shortbread                    | Baking tray                              | 3              | L               | 140-150 <sup>1</sup> | 20-30                      |
| Shortbread, 2 levels          | Universal pan<br>+<br>Baking tray        | 3+1            | L               | 140-150 <sup>1</sup> | 25-35                      |
| Shortbread, 3 levels          | Universal pan<br>+<br>x 2<br>Baking tray | 4+3+1          | \$              | 130-140 <sup>1</sup> | 35-55                      |
| Small Cakes                   | Baking tray                              | 3              | =               | 150-160 <sup>1</sup> | 20-30                      |
| Small Cakes                   | Baking tray                              | 3              | L               | 150 ¹                | 20-30                      |
| Small Cakes, 2 levels         | Universal pan<br>+<br>Baking tray        | 3+1            | S               | 150 ¹                | 25-35                      |
| Small Cakes, 3 levels         | Universal pan<br>+<br>x 2<br>Baking tray | 4+3+1          | J.              | 140 <sup>1</sup>     | 30-40                      |
| Fatless sponge cake           | Springform cake tin, dia-<br>meter 26 cm | 2              | =               | 160-170 <sup>2</sup> | 25-35                      |
| Fatless sponge cake           | Springform cake tin, dia-<br>meter 26 cm | 2              | n<br>co         | 160-170              | 30-35                      |
| Fatless sponge cake, 2 levels | Springform cake tin, dia-<br>meter 26 cm | 3+1            | ک               | 150-160 <sup>2</sup> | 35-50                      |

# Recommended settings for grilling

### Selection for the main oven

| Food           | Accessories/cookware | Shelf position | Type of heating | Temperature in °C/grill setting | •       |
|----------------|----------------------|----------------|-----------------|---------------------------------|---------|
| Toasting bread | Wire rack            | 4              | ***             | ···· 1                          | 0.5-1.5 |

# **Recommended settings for grilling**

# Selection for the top oven

| Food           | Accessories/cookware | Shelf po-<br>sition | Type of heating | Temperature in °C | Cooking<br>time in<br>mins |
|----------------|----------------------|---------------------|-----------------|-------------------|----------------------------|
| Toasting bread | Wire rack            | 3                   | ****            | Grill             | 4-6                        |

 $<sup>^{\</sup>rm 1}$  Preheat the appliance for five minutes. Do not use the rapid heating function.  $^{\rm 2}$  Preheat the appliance. Do not use the rapid heating function.

# 18 Installation instructions

Observe this information when installing the appliance.






# 18.1 General installation instructions

Follow these instructions before you start installing the appliance.

- The safe operation of this appliance can only be guaranteed if it has been installed to a professional standard in accordance with these installation instructions. The installer shall be liable for damages incurred as a result of incorrect installation.
- Do not use the door handle for the transport or installation.
- The appliance must be transported by two people using the carry handles on the right and left.
- Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.
- Before starting up the appliance, remove any packaging material and adhesive film from the cooking compartment and the door.
- Proceed in accordance with the installation sheets for installing accessories.
- Fitted units must be heat-resistant up to 95 °C, and adjacent unit fronts up to 70 °C.
- Do not install the appliance behind a decorative door or the door of a kitchen unit. There is a risk of overheating.
- Cut-out work on the units should be carried out before installing the appliance. Remove any shavings. Otherwise, the correct operation of electrical components may be adversely affected.
- Position the appliance on a horizontal surface.
- The mains socket for the appliance must either be located in the hatched area a or outside of the area where the appliance is installed.

1 Any unsecured units must be secured to the 2. wall using a standard bracket b.



- Wear protective gloves so that you do not cut yourself. Parts that are accessible during installation may have sharp edges.
- Dimensions of the figures in mm.

### ⚠ WARNING – Risk of electric shock!

Once the appliance has been installed, the openings in the back panel of the appliance must not be accessible to children, not even through the drawers and kitchen cabinets underneath. This must be ensured through the installation. In the case of an island unit, a closed back panel is required.

#### ⚠ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ► Only use adapters and power cords approved by the manufacturer.
- If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.


#### **ATTENTION**

Carrying the appliance by the door handle could break it. The door handle cannot support the weight of the appliance.

▶ Do not carry or hold the appliance by the door handle.


### 18.2 Appliance dimensions

You will find the dimensions of the appliance here




#### 18.3 Installation in a tall unit

Observe the installation dimensions and the installation instructions when installing in a tall unit.




To ventilate the appliance, there must be a gap of 20 mm between all intermediate floors and the wall.



 Only fit the appliance up to a height which allows accessories to be easily removed.

#### 18.4 Corner installation

Observe the installation dimensions and the installation instructions when installing in a corner.



• To ensure that the appliance door can be opened, you must take the minimum dimensions into consideration when installing in a corner. The dimension a is dependent on the thickness of the unit front and the handle.

#### 18.5 Electrical connection

In order to safely connect the appliance to the electrical system, follow these instructions.

- The appliance corresponds to protection class I and must only be operated with a protective earth connec-
- The fuse protection must correspond to the power rating specified on the appliance's rating plate and to the local regulations.
- The appliance must be disconnected from the power supply whenever installation work is being carried
- Contact protection must be guaranteed by the install-

# Electrically connecting an appliance without a protective contact plug

Note: Only licensed specialists may connect the appliance. Damage caused by incorrect connection is not covered under the warranty.

An isolating switch must be integrated into the permanent electrical installation according to the installation regulations.

- 1. Identify the phase and neutral conductors in the socket.
  - The appliance may be damaged if it is not connected correctly.
- 2. Connect the hob in accordance with the connection diagram.


The yellow/green wire for the safety earth terminal must be 10 mm longer on the appliance side than the other wires.

See the rating plate for the voltage.


Connection 3N~ / 2N~ / 1N~: Use a H05VV-F mains power cable or one with a higher rating.

# 18.6 Installing the appliance


1. Remove the transport locks on the right and left and then dispose of them.



2. The appliance must be transported by two people using the carry handles on the right and left, while securing the front of the appliance with one hand.




3. Place the appliance in the unit and fold the carry handles down.




4. Push the appliance in fully. Do not kink or trap the connection cable, or route it over sharp edges.

5. Centre the appliance.




There must be an air gap of at least 5 mm between the appliance and adjacent unit fronts.

- 6. Use a spirit level to adjust the appliance so that it is perfectly level.
- 7. Screw the appliance into place.




# 18.7 For handleless kitchens with vertical bar handle strips:

1. Attach a suitable filling piece on both sides in order to cover any sharp edges and to guarantee safe installation.




2. Secure the filling piece to the unit.

3. Pre-drill the filling piece and the unit to establish a screw connection.




4. Secure the appliance using a suitable screw.



# 18.8 Removing the appliance

- Disconnect the appliance from the power supply.
   Undo the fastening screws.
   Lift the appliance slightly and pull it out completely.





Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom



Register your product online **neff-home.com** 

**BSH Hausgeräte GmbH** Carl-Wery-Straße 34 81739 München, GERMANY



**9001910118** (050626) REG25 en