



1

2

3

4a

4b

5

6

7

8

9

10

11

12

13

14

1

6

7a

8a

9a

10

14

7a

8a

9a

9a

22

23

11

12

14

nicht einklemmen
do not pinch
ne pas coincer
No doblar

verspannen
brace
caler verticalement
Enrasar

min. 70 mm
max. 120 mm

einstellen
adjust
régler
ajustar

c =	d =
650 mm	≥ 30 mm
660 mm	≥ 20 mm
670 mm	≥ 10 mm
680 - 725 mm	≥ 0 mm

Scheibe entfernen
remove disc
enlever le disque
Eliminar disco

Dichtheit nach einem Spülgang prüfen.
Check for leaks after one wash cycle.
Vérifiez l'étanchéité après un lavage.
Verificar la estanqueidad tras un ciclo de lavado

*) Mat-Nr. 00350564

*) Mat-Nr. 12022522