




de Montageanleitung
Einbaugerät Flachscharnier

en Installation instructions
Built-in appliance
Piano Hinge
fr Notice de montage
Appareil encastrable
à charnières à pantographe
it Istruzioni per il montaggio
Apparecchio da incasso
a cerniera piatta
nl Montagehandleiding
Inbouwapparaat
vlakscharnier



Minimum 550 mm Nischentiefe (siehe Bedienungsanleitung)
Cavity depth minimum 550 mm (see Operating instructions)
Profondeur de niche minimum 550 mm (voir Notice d'instructions)
Profondità della nicchia minimo 550 mm (vedi Istruzioni per l'uso)
Nisdiepte minimum 550 mm (zie Gebruiksaanwijzing)
Nischedybde minimum 550 mm (se Betjeningsvejledning)
Nisjedybde minimum 550 mm (se Betjeningsanvisning)
Nischdjup minimum 550 mm (se Bruksanvisning)
Asennustilan syvyys vähintään 550 mm (katso Käyttöohje)
Profundidad del hueco de montaje mínimo 550 mm (véase Instrucciones de uso)
Profundidade do nicho no mínimo 550 mm (ver Instruções de serviço)
Montaj boşluğunun derinliği en az 550 mm (bakınız bölüm Kullanma kılavuzu)
Głębokość wnęki co najmniej 550 mm (patrz Instrukcja obsługi)

