


CLIP RAIL Z11TC16X0



 $\sqrt{}$ One pair pull-out rails and a frame for retrofitting an oven with a standard oven rack. With pull-out rails, baking accessories can be pulled all the way out of the oven without tipping. For comfortably sliding baking accessories into and out of the oven, usable on all shelf levels.

