

N 70, ELECTRIC HOB, 60 CM, BLACK, T16FD56X0





Optional accessories

Z9367X0 Intermediate bottom Z9428FE0 Iron pan Ø 18 / 28 cm Z943SE0 Set of 2 pots and 1 pan

Standalone electric hob with TouchControl

- $\sqrt{}$ Touch Control Control your hob with a simple touch.
- $\sqrt{\mbox{ Power Boost}}$ An extra surge of heat when you need fast results.

Features

Technical Data Product name/family: Cooking zone ceramic Energy input: Electric Required niche size for installation (HxWxD):45 x 560-560 x 490-500 mm Dimensions of the packed product (HxWxD): . $100 \times 750 \times 590$ mm Gross weight: 8.2 kg Residual heat indicator:Separate Location of control panel:Front



N 70, ELECTRIC HOB, 60 CM, BLACK, T16FD56X0

Features

Design

- · Bevelled front edge
- 60 cm: space for 4 pots or pans.

Flexibility of cooking zones

- Ring zone double: use regular or larger cookware on the extendable cooking zone.
- Cooking zone front left: 145 mm, 1.2 KW
- Cooking zone rear left: 180 mm, 2 KW
- Cooking zone rear right: 145 mm, 1.2 KW
- Cooking zone front right: 120 mm, 210 mm, 0.8 KW (max. power

Usage convenience

- Touch control: control the power with imprinted +/- touch buttons.
- Variable 17-stage power settings for each zone: precisely adapt the heat with 17 power levels (9 main levels and 8 intermediate levels).
- Keep warm function: keep dishes warm at preset low power level.
- Timer with automatic shut off for all zones
- : switches off the cooking zone at the end of the time set (e.g. for boiled eggs).
- \bullet LED timer for each zone with switch off function and acoustic signal
- : an alarm sounds at the end of the time set (e.g. for pasta).

Time saving & efficiency

- PowerBoost function in the front right zone: boil water more quickly thanks to 20% more energy than at the highest standard level.
- ReStart function: in case of unintentional switch-off, this feature restores all previous settings by switching on the hob again within 4 seconds
- Quick-Off: quickly switch off a cooking zone with one longer touch.

Safety

- 2 stage residual heat indicators: indicates which cooking zones are still hot or warm.
- \bullet Control panel lock: prevent unintended activation of the hob.
- Control panel suspension: wipe overboiled liquids without unintentionally changing settings (blocking all touch buttons for 30 seconds).
- Main switch: switch off all cooking zones at the touch of a button.
- Power on indicator light: indicates if the hob is heating.
- Safety cut out facility: for safety reasons, heating stops after a preset time if not used (possible to customise).
- Energy consumption display: shows the electricity consumption of the last cooking process.


Installation

- \bullet Dimensions of the product (HxWxD mm): 45 x 592 x 522
- Required niche size for installation (HxWxD mm) : 45 x 560 x (490 500)
- Min. worktop thickness: 16 mm
- Connected load: 7 KW



N 70, ELECTRIC HOB, 60 CM, BLACK, T16FD56X0

Dimensioned drawings



- **A**: Minimum distance from the hob cut-out to the wall.
- **B**: Recessed depth
- C: With fitted oven underneath min. 20, possibly more; see space requirements for the oven.